

SR3090 (D588)

SR3090 (D588)

PARTS CATALOG


This catalog gives the numbers and names of parts on this machine.

CONTENTS

1.Exterior (D588).....	2
2.Transport Section (D588).....	4
3.Paper Exit Section 1 (D588)	6
4.Paper Exit Section 2 (D588)	8
5.Vertical Transport (D588).....	10
6.Staple Section 1 (D588).....	12
7.Staple Section 2 (D588).....	14
8.Staple Section 3 (D588).....	16
9.Shift Tray Drive (D588)	18
10.Drive Section (D588).....	20
11.Electrical Section (D588)	22
12.Decals And Documents (D588)	24
Parts Index.....	27

August 23, 2011

1.Exterior (D588)




1.Exterior (D588)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D588 6142	Cover:Rear	1
2	D588 6151	Cover:Left Upper	1
3	D588 3414	Tray:Slide	1
4	B714 3115	Knob Screw:Document Feeder:Fix	1
5	D588 3411	Tray	1
6	D588 6161	Cover:Left Lower	1
7	B408 1317	Caster:250N	4
8	B408 1429	Ground Plate Bracket	1
9	B408 1390	Flat Screw:Groove Type	2
10	D588 6131	Inner Cover:Left Sideways	1
11	D588 1241	Guard:Side Plate:Front	1
12	B408 6124	Hinge - Door Lower	1
13	D588 7851	Decal:Misfeed Removal	1
14	D588 6121	Cover:Front	1
15	AG07 0512	Magnetic Catch:Ass'y	1
16	B408 6172	Cover:Right Lower	1
17	B408 6122	Hinge - Door Upper	1
18	D588 7871	Decal:Positioning Display:Staple	1
19	D588 6111	Cover:Upper	1
20	B408 2192	Guide Plate - Connecting Upper	1
21	B408 1418	Mylar - Rear Joint Bracket	1
22	B408 1431	Flat Screw:Coupling	4
23	B408 1414	Bracket - Coupling Rear	1
24	B408 1450	Bracket:Coupling:Ground Plate:Front:Ass'y	1
25	B408 2191	Guide Plate - Connecting Lower	1
26	D588 1251	Film:Side Plate:Front	1
27	B408 1441	Bracket:Coupling:Ground Plate:Rear:Ass'y	1
28	D588 3412	Tray:Slide	2
29	B408 1099	Front Cover - Stopper	1
30	D636 7813	Decal:Caution:Proof Tray:	
		Paper Exit Sub-unit	1
31	D588 3412	Tray:Slide	1
32	B408 6145	Absorption Sheet:Cover:Rear	1



Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 3006Q	Tapping Screw:3x6	
102	0451 3008N	Tapping Screw - M3x8	
103	0451 3006N	Tapping Screw - 3x6	
104	0451 4025N	Tapping Screw:M4x25	

2.Transport Section (D588)




2.Transport Section (D588)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B408 2271	Pulley - T24	3
2	AA08 2101	Bushing - 6x10x6	6
3	B408 2532	Lever - Paper Guide Upper	1
4	G020 5626	Push Switch	1
5	B408 2221	Transfer Roller - Upper	1
6	B408 2232	Exit Roller:Proof Tray	1
7	B408 2211	Transfer Roller	1
8	B408 5315	Harness - Connecting	1
9	AW02 0170	Photointerruptor:Overflow:CT	1
10	A859 3425	Spring Plate	2
11	A859 3420	Middle Driven Roller	2
12	D588 2158	Guide Plate:Entrance:Left	1
13	B408 2152	Guide Plate - Entrance	1
14	AW02 0169	Photointerruptor - OS - 580213-703	1
15	A548 1317	Lever Cushion	1
16	B408 2723	Upper Paer Guide	1
17	B408 2722	Spring - Upper Paper Guide	1
18	AG07 0514	Magnet Catch:Ass'y	2
19	B408 2715	Discharge Brush	1
20	B408 2731	Arm - Top Cover	1
21	5447 2681	Snap Ring	1
22	D588 2711	Cover:Proof Tray	1
23	AF04 0558	Driven Roller	4
24	A688 3960	Roller Holder	4
25	D588 2281	Lever:Transport Roller	1
26	D588 7814	Decal:Knob:R2	1
27	B408 1231	Angle - Front Side Plate	1
28	B408 2751	Ground Plate:Exit:Proof Tray	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 3006Q	Tapping Screw:3x6	
102	0805 0089	Retaining Ring - M4	
103	1105 0623	Clamp - LBWS-0206S-V0	
104	1105 0522	Edge Saddle - LES0510	

3.Paper Exit Section 1 (D588)




3.Paper Exit Section 1 (D588)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B408 2314	Arm - Roller Slide	1
2	B408 2313	Pulley - T24	1
3	AA08 2101	Bushing - 6x10x6	1
4	B408 5355	Harness:Connecting:280mm	1
5	AW02 0156	Photointerruptor:EE-SX4235A-P2	1
6	B408 2841	Bracket - Home Position Sensor	1
7	B408 2833	Shaft - Worm Wheel	1
8	B408 2832	Worm Wheel - Z20	1
9	B408 2861	Arm - Guide Plate	1
10	5447 2681	Snap Ring	1
11	B408 2831	Gear - Z53	1
12	B408 2821	Stay - Guide Plate	1
13	D588 5630	Stepper Motor:MM42:0.85A	1
14	A681 2742	Driven Exit Roller	2
15	A666 4210	Shaft - Exit Roller	1
16	B408 2813	Discharge Brush:Exit:Open and Close	1
17	B408 2852	Spring - Guide Plate Exit	2
18	B408 2811	Guide Plate - Exit	1
19	B408 2312	Bushing - Roller Slide	1
20	AW01 0109	Photo Reflection Sensor:PS117ED1	1
21	B408 2311	Slide Roller	1
22	B408 2162	Guide Mylar	2
23	B408 2161	Guide Plate:Shift	1
24	AG07 0514	Magnet Catch:Ass'y	1
25	B408 2175	Bushing - Roller Slide	2
26	A697 2144	Pressure Spring	2
27	B408 2172	Guide Plate - Shift	1
28	B408 2174	Spring	2
29	B408 2173	Slide Roller	1
30	D588 7802	Decal:Shift Tray:R1	1
31	D588 5445	Harness:Connecting:Exit:Open And Close	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 3006Q	Tapping Screw:3x6	
102	0805 0089	Retaining Ring - M4	
103	0720 0040E	Retaining Ring - M4	
104	0451 3006N	Tapping Screw - 3x6	
105	1105 0623	Clamp - LBWS-0206S-V0	
106	0453 3006N	Tapping Screw - M3x6	

4.Paper Exit Section 2 (D588)




4.Paper Exit Section 2 (D588)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B408 2272	Pulley - T30	1
2	AA08 2101	Bushing - 6x10x6	2
3	B352 2407	Reverse Roller - 20z	2
4	B408 2246	Reverse Roller Arm	1
5	B352 2409	Idler Gear - 17z	2
6	B408 2241	Exit Roller	1
7	D588 5425	Harness:Connecting:Paper Senser	1
8	AW02 0156	Photointerruptor:EE-SX4235A-P2	1
9	B408 3613	Lever - Micro Switch	1
10	B408 3611	Stay - Paper Sensor	1
11	B408 3612	Paper Sensor Feeler	1
12	B408 2184	Guide Plate:Exit:Stapler	1
13	A681 2722	Guide Mylar - Lower Exit Guide	4
14	B408 1413	Coupling Stay	1
15	AA14 3790	Screw:Contact Point	2
16	B408 1411	Coupling Lever	1
17	B408 1412	Flat Screw	1



Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 3006Q	Tapping Screw:3x6	
102	0805 0089	Retaining Ring - M4	
103	0452 3020N	Tapping Screw - 3x20	
104	0452 3008N	Tapping Screw - M3x8	
105	1105 0623	Clamp - LBWS-0206S-V0	
106	1204 2540	Micro Switch - AM50650C3	
107	0451 3006N	Tapping Screw - 3x6	

5.Vertical Transport (D588)




5.Vertical Transport (D588)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AA08 2101	Bushing - 6x10x6	4
2	AG07 0514	Magnet Catch:Ass'y	1
3	D588 7822	Decal:Stapler Tray:Lengthwise:R3	1
4	A859 3425	Spring Plate	2
5	A859 3420	Middle Driven Roller	2
6	B408 2142	Guide Plate - Stapler Tray	1
7	A697 2144	Pressure Spring	2
8	AA08 0237	Bushing - 4x5x7	2
9	AF02 2097	Driven Roller	1
10	B408 2541	Gate Pawl:Lower	1
11	A548 1317	Lever Cushion	1
12	B408 2211	Transfer Roller	2
13	B408 2131	Upper Guide Plate	1
14	B408 2271	Pulley - T24	2
15	B408 1212	Cover:Push Switch	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 3006Q	Tapping Screw:3x6	
102	0720 0040E	Retaining Ring - M4	
103	0805 0089	Retaining Ring - M4	
104	1204 2844	Switch:FA1L-CJAH	
105	1105 0623	Clamp - LBWS-0206S-V0	

6.Staple Section 1 (D588)




6.Staple Section 1 (D588)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AA08 2101	Bushing - 6x10x6	5
2	B408 2435	Gathering Roller:Ass'y	1
3	B408 2434	Timing Belt - 124P2M4	1
4	B408 2422	Pulley - T16	1
5	B408 2411	Arm - Positioning Roller	1
6	B408 2421	Bracket - Positioning Roller	1
7	B408 2444	Spring - Positioning Roller	1
8	B408 2451	DC Solenoid - 12.5W	1
9	A498 4625	Arm Cushion	1
10	B408 2441	Shaft - Positioning Roller	1
11	B408 2251	Stapler Exit Roller	1
12	B408 2117	Discharge Brush:Exit:Stapler Tray	1
13	B352 2206	Tension Spring - Lower Guide	2
14	D588 7832	Decal:Stapler Tray:Exit:R4	1
15	B700 2113	Guide:Trailing Edge	4
16	B408 2011	Guide Plate:Lower:Open and Close:Small: Ass'y	1
17	A697 2144	Pressure Spring	2
18	B352 2205	Bushing - Driven Roller	2
19	B352 2204	Driven Roller	1
20	B352 2229	Roller - Paper Guide	2
21	B352 2222	Paper Guide - Trailing Edge	1
22	B352 2232	Torsion Spring	1
23	AW02 0169	Photointerruptor - OS - 580213-703	1
24	B408 5355	Sensor Relay Harness - 280mm	1
25	B408 2122	Guide Plate - Lower	1
26	B408 2271	Pulley - T24	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 3006Q	Tapping Screw:3x6	
102	0805 0089	Retaining Ring - M4	
103	0720 0040E	Retaining Ring - M4	
104	1105 0623	Clamp - LBWS-0206S-V0	
105	1105 0328	Harness Clamp - ES-0505	
106	0353 0040N	Screw - M3x4	
107	0451 3006N	Tapping Screw - 3x6	

7.Staple Section 2 (D588)




7.Staple Section 2 (D588)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D588 5440	Harness:Connecting:Stapler Tray	1
2	AW02 0166	Photointerruptor:Paper Feed Sensor	1
3	B408 4336	Timing Belt - 940P2M4	1
4	A697 4170	Pulley - 32T	1
5	B408 4392	Exit Tension Bracket	1
6	B408 4398	Tension Spring	1
7	B408 4395	Pulley - Exit Belt	1
8	B408 4321	Stay - Stapler Tray	1
9	D588 5630	DC Stepper Motor:1.48W:Ass'y	1
10	B408 4337	Spring	1
11	B408 4332	Bracket - Jogger Motor	1
12	AA14 3790	Screw:Contact Point	1
13	B408 4343	Slider Fence Shaft	1
14	B352 4232	Slider - Training Edge Fence	2
15	B408 4342	Trailing Edge Fence	2
16	B700 4107	Spring:Rerurn:Standard Fence	1
17	A666 3180	Timing Pulley - Z32	2
18	D588 5620	Stepper Motor:MM42:S3M:T15:Ass'y	1
19	B408 4385	Shaft - Exit Belt	1
20	B408 4382	Pulley - T26	1
21	B408 4371	Timing Belt - 246P3M4	1
22	D588 4311	Stapler Tray	1
23	AW02 0156	Photointerruptor:EE-SX4235A-P2	1
24	B408 4347	Guide:Standard Fence:Inner Back	1
25	B408 4383	Shaft - Idler Exit Belt	1
26	B408 4372	Exit Belt Ass'y	1
27	AW01 0109	Photo Reflection Sensor:PS117ED1	1
28	B408 4363	Slider - Jogger Fence	4
29	D588 4362	Jogger Fence:Front	1
30	D588 7842	Decal:Jogger Fence:R5	1
31	B408 4367	Shaft - Jogger Fence	1
32	A681 4515	Bushing - 6mm	2
33	B408 4364	Film - Jogger Fence	2
34	D588 4366	Jogger Fence:Inner Back	1
35	B408 4335	Timing Pulley - Jogger	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	B408 4344	Guide:Standard Fence:Front	1
101	0451 3010N	Tapping Screw:3x10	
102	0451 3006N	Tapping Screw - 3x6	
103	0450 3008N	Tapping Screw - M3x8	
104	0720 0040E	Retaining Ring - M4	
105	1105 0310	Harness Clamp - LWS-1S	
106	1105 0623	Clamp - LBWS-0206S-V0	
107	0453 3006N	Tapping Screw - M3x6	
108	0805 3385	Bushing - 6mm	
109	0451 3008N	Tapping Screw - M3x8	

8.Staple Section 3 (D588)




8.Staple Section 3 (D588)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B408 4211	Stapler Stay	1
2	D588 5415	Harness:Sensor:Stapler Tray	1
3	B408 4212	Stapler Guide Rod	1
4	B408 4223	Belt Tensioner - Stapler	1
5	AA06 2334	Tension Spring:4.9N	1
6	AA14 3790	Screw:Contact Point	1
7	A697 4170	Pulley - 32T	1
8	B408 4231	Timing Belt - 846P2M4	1
9	AW02 0156	Photointerruptor:EE-SX4235A-P2	1
10	B408 4125	Stapler Bushing	2
11	B408 4126	Timing Belt Stay	1
12	B408 4121	Stapler Slider	1
13	B408 4127	Stay Slider	1
14	B408 4128	Spring	1
15	AA14 3823	Tapping Screw	1
16	B408 4114	Stapler Stopper	1
17	D588 7861	Decal:Stapler	1
18	D588 4113	Knob:Turn	1
19	B408 4116	Base:Stapler	1
20	B408 5457	Harness:Stapler	1
21	B408 4112	Stapler Guide	1
22	AJ01 1015	Stapler:Eh-530	1
23	D588 5640	Stepper Motor:Ass'y	1
24	B408 4115	Stapler Upper Mylar	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1105 0334	Edge - 17	
102	0451 3006N	Tapping Screw - 3x6	
103	0720 0040E	Retaining Ring - M4	
104	1105 0328	Harness Clamp - ES-0505	
105	0452 3006N	Binding Self-Tapping Screw:3x6	
106	1105 0623	Clamp - LBWS-0206S-V0	
107	1105 0310	Harness Clamp - LWS-1S	

9.Shift Tray Drive (D588)




9.Shift Tray Drive (D588)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B408 3233	Tray H.P Sensor Feeler	1
2	A666 2331	Rack	2
3	B408 3235	Guide Plate:Rear:Peen	1
4	B408 3212	Base:Tray	1
5	B408 1511	Middle Stay	1
6	B408 3225	Guide Plate:Front:Peen	1
7	B408 3112	End Fence	1
8	A666 2345	Gear - Z20	2
9	AA08 2070	Bushing - 8x16x7	2
10	B408 3311	Tray Shaft	1
11	G838 2347	Gear:Z45	1
12	AW02 0166	Photointerruptor:Paper Feed Sensor	1
13	AX04 0248	DC Motor:Tray:Upper Lower:Drive:4.8W	1
14	D588 5435	Harness:Connecting:Tray:Upper Lower	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 3006Q	Tapping Screw:3x6	
102	0453 3006N	Tapping Screw - M3x6	
103	0450 4020N	Tapping Screw - M4x20	
104	0720 0060E	Retaining Ring - M6	
105	1105 0623	Clamp - LBWS-0206S-V0	
106	1105 0310	Harness Clamp - LWS-1S	
107	0451 3010N	Tapping Screw:3x10	
108	0451 3006N	Tapping Screw - 3x6	

10.Drive Section (D588)




10. Drive Section (D588)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B408 2512	Bracket - DC Solenoid	2
2	B545 5809	DC Solenoid:Polarization Powl	2
3	B408 5610	Stepper Motor:MM42:S3M:T11:Ass'y	2
4	B408 2912	Bracket - Stepper Motor	1
5	B408 2901	Timing Belt - B40S3M720	1
6	B408 2903	Timing Belt - B40S3M525	1
7	B408 2922	Bracket - Stepper Motor	1
8	B408 2902	Timing Belt - B40S3M579	1
9	AA06 2333	Tension Spring:2.16N	1
10	B408 2955	Bracket:Tightener:Ass'y	3
11	A548 2139	Pulley	6
12	AA14 3790	Screw:Contact Point	3
13	AA06 2334	Tension Spring:4.9N	3
14	AB03 0354	Pulley - 20T	1
15	B408 2980	DC Stepper Motor:Transport:Upper:Ass'y	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 3006Q	Tapping Screw:3x6	
102	0451 3006N	Tapping Screw - 3x6	
103	0353 0040N	Screw - M3x4	
104	0720 0040E	Retaining Ring - M4	

11.Electrical Section (D588)











11.Electrical Section (D588)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D588 5550	Harness:Interface:Ass'y	1
2	D588 5400	Harness:Sensor:Main	1
3	D588 5410	Harness:Sensor:Tray:Lower	1
4	B408 5545	Harness Bracket	5
5	D588 5415	Harness:Sensor:Stapler Tray	1
6	D588 5101	PCB:Main Control:King-b:Ass'y	1
7	D588 5405	Harness:Motor:Main	1
8	D588 5532	DC Stepper Motor:0.99W: Drive:Roller:Slide:Ass'y	1
9	B408 2321	Bracket - Motor Slide	1
10	AW02 0156	Photointerruptor:EE-SX4235A-P2	1
11	B408 2331	Link Drive Gear	1
12	B408 1121	Angle - Side Plate Rear	1
13	B408 5540	Main Board Bracket	4

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 3006Q	Tapping Screw:3x6	
102	0805 0089	Retaining Ring - M4	
103	0453 3006N	Tapping Screw - M3x6	
104	1105 0623	Clamp - LBWS-0206S-V0	
105	1105 0310	Harness Clamp - LWS-1S	
106	0451 3006N	Tapping Screw - 3x6	
107	1105 0487	Harness Clamp	

12.Decals And Documents (D588)

1		2		3		4		5		7	
6								8			
  											
								9			
											

12.Decals And Documents (D588)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D588 7802	Decal:Shift Tray:R1	1
2	D588 7814	Decal:Knob:R2	1
3	D588 7822	Decal:Stapler Tray:Lengthwise:R3	1
4	D588 7832	Decal:Stapler Tray:Exit:R4	1
5	D588 7842	Decal:Jogger Fence:R5	1
6	D588 7851	Decal:Misfeed Removal	1
7	D588 7861	Decal:Stapler	1
8	B408 7171	Decal - Staple	1
9	D636 7813	Decal:Caution:Proof Tray: Paper Exit Sub-unit	1

Index No.	Part No.	Description	Q'ty Per Assembly

Parts Index

Parts Index

Part No.	Description	Page and Index No.
D588 1241	Guard:Side Plate:Front	3 - 11
D588 1251	Film:Side Plate:Front	3 - 26
D588 2158	Guide Plate:Entrance:Left	5 - 12
D588 2281	Lever:Transport Roller	5 - 25
D588 2711	Cover:Proof Tray	5 - 22
D588 3411	Tray	3 - 5
D588 3412	Tray:Slide	3 - 31
D588 3412	Tray:Slide	3 - 28
D588 3414	Tray:Slide	3 - 3
D588 4113	Knob:Turn	17 - 18
D588 4311	Stapler Tray	15 - 22
D588 4362	Jogger Fence:Front	15 - 29
D588 4366	Jogger Fence:Inner Back	15 - 34
D588 5101	PCB:Main Control:King-b:Ass'y	23 - 6
D588 5400	Harness:Sensor:Main	23 - 2
D588 5405	Harness:Motor:Main	23 - 7
D588 5410	Harness:Sensor:Tray:Lower	23 - 3
D588 5415	Harness:Sensor:Stapler Tray	23 - 5
D588 5415	Harness:Sensor:Stapler Tray	17 - 2
D588 5425	Harness:Connecting:Paper Senser	9 - 7
D588 5435	Harness:Connecting:Tray:Upper Lower	19 - 14
D588 5440	Harness:Connecting:Stapler Tray	15 - 1
D588 5445	Harness:Connecting:Exit:Open And Close	7 - 31
D588 5532	DC Stepper Motor:0.99W:	
	Drive:Roller:Slide:Ass'y	23 - 8
D588 5550	Harness:Interface:Ass'y	23 - 1
D588 5620	Stepper Motor:MM42:S3M:T15:Ass'y	15 - 18
D588 5630	Stepper Motor:MM42:0.85A	7 - 13
D588 5630	DC Stepper Motor:1.48W:Ass'y	15 - 9
D588 5640	Stepper Motor:Ass'y	17 - 23
D588 6111	Cover:Upper	3 - 19
D588 6121	Cover:Front	3 - 14
D588 6131	Inner Cover:Left Sideways	3 - 10
D588 6142	Cover:Rear	3 - 1
D588 6151	Cover:Left Upper	3 - 2

Part No.	Description	Page and Index No.
D588 6161	Cover:Left Lower	3 - 6
D588 7802	Decal:Shift Tray:R1	7 - 30
D588 7802	Decal:Shift Tray:R1	25 - 1
D588 7814	Decal:Knob:R2	5 - 26
D588 7814	Decal:Knob:R2	25 - 2
D588 7822	Decal:Stapler Tray:Lengthwise:R3	11 - 3
D588 7822	Decal:Stapler Tray:Lengthwise:R3	25 - 3
D588 7832	Decal:Stapler Tray:Exit:R4	13 - 14
D588 7832	Decal:Stapler Tray:Exit:R4	25 - 4
D588 7842	Decal:Jogger Fence:R5	15 - 30
D588 7842	Decal:Jogger Fence:R5	25 - 5
D588 7851	Decal:Misfeed Removal	25 - 6
D588 7851	Decal:Misfeed Removal	3 - 13
D588 7861	Decal:Stapler	25 - 7
D588 7861	Decal:Stapler	17 - 17
D588 7871	Decal:Positioning Display:Staple	3 - 18

Part No.	Description	Page and Index No.
A498 4625	Arm Cushion	13 - 9
A548 1317	Lever Cushion	11 - 11
A548 1317	Lever Cushion	5 - 15
A548 2139	Pulley	21 - 11
A666 2331	Rack	19 - 2
A666 2345	Gear - Z20	19 - 8
A666 3180	Timing Pulley - Z32	15 - 17
A666 4210	Shaft - Exit Roller	7 - 15
A681 2722	Guide Mylar - Lower Exit Guide	9 - 13
A681 2742	Driven Exit Roller	7 - 14
A681 4515	Bushing - 6mm	15 - 32
A688 3960	Roller Holder	5 - 24
A697 2144	Pressure Spring	7 - 26
A697 2144	Pressure Spring	13 - 17
A697 2144	Pressure Spring	11 - 7
A697 4170	Pulley - 32T	15 - 4
A697 4170	Pulley - 32T	17 - 7
A859 3420	Middle Driven Roller	5 - 11
A859 3420	Middle Driven Roller	11 - 5
A859 3425	Spring Plate	11 - 4
A859 3425	Spring Plate	5 - 10
B352 2204	Driven Roller	13 - 19
B352 2205	Bushing - Driven Roller	13 - 18
B352 2206	Tension Spring - Lower Guide	13 - 13
B352 2222	Paper Guide - Trailing Edge	13 - 21
B352 2229	Roller - Paper Guide	13 - 20
B352 2232	Torsion Spring	13 - 22
B352 2407	Reverse Roller - 20z	9 - 3
B352 2409	Idler Gear - 17z	9 - 5
B352 4232	Slider - Training Edge Fence	15 - 14
B408 1099	Front Cover - Stopper	3 - 29
B408 1121	Angle - Side Plate Rear	23 - 12
B408 1212	Cover:Push Switch	11 - 15
B408 1231	Angle - Front Side Plate	5 - 27

Part No.	Description	Page and Index No.
B408 1317	Caster:250N	3 - 7
B408 1390	Flat Screw:Groove Type	3 - 9
B408 1411	Coupling Lever	9 - 16
B408 1412	Flat Screw	9 - 17
B408 1413	Coupling Stay	9 - 14
B408 1414	Bracket - Coupling Rear	3 - 23
B408 1418	Mylar - Rear Joint Bracket	3 - 21
B408 1429	Ground Plate Bracket	3 - 8
B408 1431	Flat Screw:Coupling	3 - 22
B408 1441	Bracket:Coupling:Ground Plate:Rear:Ass'y	3 - 27
B408 1450	Bracket:Coupling:Ground Plate:Front:Ass'y	3 - 24
B408 1511	Middle Stay	19 - 5
B408 2011	Guide Plate:Lower:Open and Close:Small: Ass'y	13 - 16
B408 2117	Discharge Brush:Exit:Stapler Tray	13 - 12
B408 2122	Guide Plate - Lower	13 - 25
B408 2131	Upper Guide Plate	11 - 13
B408 2142	Guide Plate - Stapler Tray	11 - 6
B408 2152	Guide Plate - Entrance	5 - 13
B408 2161	Guide Plate:Shift	7 - 23
B408 2162	Guide Mylar	7 - 22
B408 2172	Guide Plate - Shift	7 - 27
B408 2173	Slide Roller	7 - 29
B408 2174	Spring	7 - 28
B408 2175	Bushing - Roller Slide	7 - 25
B408 2184	Guide Plate:Exit:Stapler	9 - 12
B408 2191	Guide Plate - Connecting Lower	3 - 25
B408 2192	Guide Plate - Connecting Upper	3 - 20
B408 2211	Transfer Roller	5 - 7
B408 2211	Transfer Roller	11 - 12
B408 2221	Transfer Roller - Upper	5 - 5
B408 2232	Exit Roller:Proof Tray	5 - 6
B408 2241	Exit Roller	9 - 6
B408 2246	Reverse Roller Arm	9 - 4
B408 2251	Stapler Exit Roller	13 - 11

Part No.	Description	Page and Index No.
B408 2271	Pulley - T24	5 - 1
B408 2271	Pulley - T24	13 - 26
B408 2271	Pulley - T24	11 - 14
B408 2272	Pulley - T30	9 - 1
B408 2311	Slide Roller	7 - 21
B408 2312	Bushing - Roller Slide	7 - 19
B408 2313	Pulley - T24	7 - 2
B408 2314	Arm - Roller Slide	7 - 1
B408 2321	Bracket - Motor Slide	23 - 9
B408 2331	Link Drive Gear	23 - 11
B408 2411	Arm - Positioning Roller	13 - 5
B408 2421	Bracket - Positioning Roller	13 - 6
B408 2422	Pulley - T16	13 - 4
B408 2434	Timing Belt - 124P2M4	13 - 3
B408 2435	Gathering Roller:Ass'y	13 - 2
B408 2441	Shaft - Positioning Roller	13 - 10
B408 2444	Spring - Positioning Roller	13 - 7
B408 2451	DC Solenoid - 12.5W	13 - 8
B408 2512	Bracket - DC Solenoid	21 - 1
B408 2532	Lever - Paper Guide Upper	5 - 3
B408 2541	Gate Pawl:Lower	11 - 10
B408 2715	Discharge Brush	5 - 19
B408 2722	Spring - Upper Paper Guide	5 - 17
B408 2723	Upper Paer Guide	5 - 16
B408 2731	Arm - Top Cover	5 - 20
B408 2751	Ground Plate:Exit:Proof Tray	5 - 28
B408 2811	Guide Plate - Exit	7 - 18
B408 2813	Discharge Brush:Exit:Open and Close	7 - 16
B408 2821	Stay - Guide Plate	7 - 12
B408 2831	Gear - Z53	7 - 11
B408 2832	Worm Wheel - Z20	7 - 8
B408 2833	Shaft - Worm Wheel	7 - 7
B408 2841	Bracket - Home Position Sensor	7 - 6
B408 2852	Spring - Guide Plate Exit	7 - 17
B408 2861	Arm - Guide Plate	7 - 9

Part No.	Description	Page and Index No.
B408 2901	Timing Belt - B40S3M720	21 - 5
B408 2902	Timing Belt - B40S3M579	21 - 8
B408 2903	Timing Belt - B40S3M525	21 - 6
B408 2912	Bracket - Stepper Motor	21 - 4
B408 2922	Bracket - Stepper Motor	21 - 7
B408 2955	Bracket:Tightener:Ass'y	21 - 10
B408 2980	DC Stepper Motor:Transport:Upper:Ass'y	21 - 15
B408 3112	End Fence	19 - 7
B408 3212	Base:Tray	19 - 4
B408 3225	Guide Plate:Front:Peen	19 - 6
B408 3233	Tray H.P Sensor Feeler	19 - 1
B408 3235	Guide Plate:Rear:Peen	19 - 3
B408 3311	Tray Shaft	19 - 10
B408 3611	Stay - Paper Sensor	9 - 10
B408 3612	Paper Sensor Feeler	9 - 11
B408 3613	Lever - Micro Switch	9 - 9
B408 4112	Stapler Guide	17 - 21
B408 4114	Stapler Stopper	17 - 16
B408 4115	Stapler Upper Mylar	17 - 24
B408 4116	Base:Stapler	17 - 19
B408 4121	Stapler Slider	17 - 12
B408 4125	Stapler Bushing	17 - 10
B408 4126	Timing Belt Stay	17 - 11
B408 4127	Stay Slider	17 - 13
B408 4128	Spring	17 - 14
B408 4211	Stapler Stay	17 - 1
B408 4212	Stapler Guide Rod	17 - 3
B408 4223	Belt Tensioner - Stapler	17 - 4
B408 4231	Timing Belt - 846P2M4	17 - 8
B408 4321	Stay - Stapler Tray	15 - 8
B408 4332	Bracket - Jogger Motor	15 - 11
B408 4335	Timing Pulley - Jogger	15 - 35
B408 4336	Timing Belt - 940P2M4	15 - 3
B408 4337	Spring	15 - 10
B408 4342	Trailing Edge Fence	15 - 15

Part No.	Description	Page and Index No.
B408 4343	Slider Fence Shaft	15 - 13
B408 4344	Guide:Standard Fence:Front	15 - 36
B408 4347	Guide:Standard Fence:Inner Back	15 - 24
B408 4363	Slider - Jogger Fence	15 - 28
B408 4364	Film - Jogger Fence	15 - 33
B408 4367	Shaft - Jogger Fence	15 - 31
B408 4371	Timing Belt - 246P3M4	15 - 21
B408 4372	Exit Belt Ass'y	15 - 26
B408 4382	Pulley - T26	15 - 20
B408 4383	Shaft - Idler Exit Belt	15 - 25
B408 4385	Shaft - Exit Belt	15 - 19
B408 4392	Exit Tension Bracket	15 - 5
B408 4395	Pulley - Exit Belt	15 - 7
B408 4398	Tension Spring	15 - 6
B408 5315	Harness - Connecting	5 - 8
B408 5355	Harness:Connecting:280mm	7 - 4
B408 5355	Sensor Relay Harness - 280mm	13 - 24
B408 5457	Harness:Stapler	17 - 20
B408 5540	Main Board Bracket	23 - 13
B408 5545	Harness Bracket	23 - 4
B408 5610	Stepper Motor:MM42:S3M:T11:Ass'y	21 - 3
B408 6122	Hinge - Door Upper	3 - 17
B408 6124	Hinge - Door Lower	3 - 12
B408 6145	Absorption Sheet:Cover:Rear	3 - 32
B408 6172	Cover:Right Lower	3 - 16
B408 7171	Decal - Staple	25 - 8
B545 5809	DC Solenoid:Polarization Powl	21 - 2
B700 2113	Guide:Trailing Edge	13 - 15
B700 4107	Spring:Rerurn:Standard Fence	15 - 16
B714 3115	Knob Screw:Document Feeder:Fix	3 - 4
D636 7813	Decal:Caution:Proof Tray:	
	Paper Exit Sub-unit	3 - 30
D636 7813	Decal:Caution:Proof Tray:	
	Paper Exit Sub-unit	25 - 9
G020 5626	Push Switch	5 - 4

Part No.	Description	Page and Index No.
G838 2347	Gear:Z45	19 - 11

Part No.	Description	Page and Index No.
AA06 2333	Tension Spring:2.16N	21 - 9
AA06 2334	Tension Spring:4.9N	17 - 5
AA06 2334	Tension Spring:4.9N	21 - 13
AA08 0237	Bushing - 4x5x7	11 - 8
AA08 2070	Bushing - 8x16x7	19 - 9
AA08 2101	Bushing - 6x10x6	11 - 1
AA08 2101	Bushing - 6x10x6	9 - 2
AA08 2101	Bushing - 6x10x6	13 - 1
AA08 2101	Bushing - 6x10x6	7 - 3
AA08 2101	Bushing - 6x10x6	5 - 2
AA14 3790	Screw:Contact Point	17 - 6
AA14 3790	Screw:Contact Point	9 - 15
AA14 3790	Screw:Contact Point	21 - 12
AA14 3790	Screw:Contact Point	15 - 12
AA14 3823	Tapping Screw	17 - 15
AB03 0354	Pulley - 20T	21 - 14
AF02 2097	Driven Roller	11 - 9
AF04 0558	Driven Roller	5 - 23
AG07 0512	Magnetic Catch:Ass'y	3 - 15
AG07 0514	Magnet Catch:Ass'y	7 - 24
AG07 0514	Magnet Catch:Ass'y	5 - 18
AG07 0514	Magnet Catch:Ass'y	11 - 2
AJ01 1015	Stapler:Eh-530	17 - 22
AW01 0109	Photo Reflection Sensor:PS117ED1	15 - 27
AW01 0109	Photo Reflection Sensor:PS117ED1	7 - 20
AW02 0156	Photointerruptor:EE-SX4235A-P2	7 - 5
AW02 0156	Photointerruptor:EE-SX4235A-P2	23 - 10
AW02 0156	Photointerruptor:EE-SX4235A-P2	17 - 9
AW02 0156	Photointerruptor:EE-SX4235A-P2	9 - 8
AW02 0156	Photointerruptor:EE-SX4235A-P2	15 - 23
AW02 0166	Photointerruptor:Paper Feed Sensor	19 - 12
AW02 0166	Photointerruptor:Paper Feed Sensor	15 - 2
AW02 0169	Photointerruptor - OS - 580213-703	13 - 23
AW02 0169	Photointerruptor - OS - 580213-703	5 - 14
AW02 0170	Photointerruptor:Overflow:CT	5 - 9

Part No.	Description	Page and Index No.
AX04 0248	DC Motor:Tray:Upper Lower:Drive:4.8W	19 - 13

Part No.	Description	Page and Index No.
0353 0040N	Screw - M3x4	13 - 106
0353 0040N	Screw - M3x4	21 - 103
0450 3008N	Tapping Screw - M3x8	15 - 103
0450 4020N	Tapping Screw - M4x20	19 - 103
0451 3006N	Tapping Screw - 3x6	19 - 108
0451 3006N	Tapping Screw - 3x6	15 - 102
0451 3006N	Tapping Screw - 3x6	17 - 102
0451 3006N	Tapping Screw - 3x6	9 - 107
0451 3006N	Tapping Screw - 3x6	7 - 104
0451 3006N	Tapping Screw - 3x6	13 - 107
0451 3006N	Tapping Screw - 3x6	21 - 102
0451 3006N	Tapping Screw - 3x6	23 - 106
0451 3006N	Tapping Screw - 3x6	3 - 103
0451 3008N	Tapping Screw - M3x8	15 - 109
0451 3008N	Tapping Screw - M3x8	3 - 102
0451 3010N	Tapping Screw:3x10	15 - 101
0451 3010N	Tapping Screw:3x10	19 - 107
0451 4025N	Tapping Screw:M4x25	3 - 104
0452 3006N	Binding Self-Tapping Screw:3x6	17 - 105
0452 3008N	Tapping Screw - M3x8	9 - 104
0452 3020N	Tapping Screw - 3x20	9 - 103
0453 3006N	Tapping Screw - M3x6	23 - 103
0453 3006N	Tapping Screw - M3x6	19 - 102
0453 3006N	Tapping Screw - M3x6	7 - 106
0453 3006N	Tapping Screw - M3x6	15 - 107
0454 3006Q	Tapping Screw:3x6	21 - 101
0454 3006Q	Tapping Screw:3x6	19 - 101
0454 3006Q	Tapping Screw:3x6	23 - 101
0454 3006Q	Tapping Screw:3x6	3 - 101
0454 3006Q	Tapping Screw:3x6	9 - 101
0454 3006Q	Tapping Screw:3x6	7 - 101
0454 3006Q	Tapping Screw:3x6	13 - 101
0454 3006Q	Tapping Screw:3x6	5 - 101
0454 3006Q	Tapping Screw:3x6	11 - 101
0720 0040E	Retaining Ring - M4	11 - 102

Part No.	Description	Page and Index No.
0720 0040E	Retaining Ring - M4	21 - 104
0720 0040E	Retaining Ring - M4	17 - 103
0720 0040E	Retaining Ring - M4	7 - 103
0720 0040E	Retaining Ring - M4	13 - 103
0720 0040E	Retaining Ring - M4	15 - 104
0720 0060E	Retaining Ring - M6	19 - 104
0805 0089	Retaining Ring - M4	23 - 102
0805 0089	Retaining Ring - M4	7 - 102
0805 0089	Retaining Ring - M4	9 - 102
0805 0089	Retaining Ring - M4	13 - 102
0805 0089	Retaining Ring - M4	5 - 102
0805 0089	Retaining Ring - M4	11 - 103
0805 3385	Bushing - 6mm	15 - 108
1105 0310	Harness Clamp - LWS-1S	23 - 105
1105 0310	Harness Clamp - LWS-1S	17 - 107
1105 0310	Harness Clamp - LWS-1S	15 - 105
1105 0310	Harness Clamp - LWS-1S	19 - 106
1105 0328	Harness Clamp - ES-0505	17 - 104
1105 0328	Harness Clamp - ES-0505	13 - 105
1105 0334	Edge - 17	17 - 101
1105 0487	Harness Clamp	23 - 107
1105 0522	Edge Saddle - LES0510	5 - 104
1105 0623	Clamp - LBWS-0206S-V0	7 - 105
1105 0623	Clamp - LBWS-0206S-V0	19 - 105
1105 0623	Clamp - LBWS-0206S-V0	9 - 105
1105 0623	Clamp - LBWS-0206S-V0	17 - 106
1105 0623	Clamp - LBWS-0206S-V0	5 - 103
1105 0623	Clamp - LBWS-0206S-V0	15 - 106
1105 0623	Clamp - LBWS-0206S-V0	23 - 104
1105 0623	Clamp - LBWS-0206S-V0	11 - 105
1105 0623	Clamp - LBWS-0206S-V0	13 - 104
1204 2540	Micro Switch - AM50650C3	9 - 106
1204 2844	Switch:FA1L-CJAH	11 - 104

