

SR820 (B442)

## **SR820 (B442)**

### **PARTS CATALOG**


This catalog gives the numbers and names of parts on this machine.

### **CONTENTS**

|                                         |           |
|-----------------------------------------|-----------|
| 1.Exterior (B442).....                  | 2         |
| 2.Shift Tray (B442).....                | 4         |
| 3.Drive Section (B442).....             | 6         |
| 4.Paper Exit Section (B442) .....       | 8         |
| 5.Paper Feed Section (B442) .....       | 10        |
| 6.Frame/Electrical Section (B442) ..... | 12        |
| <b>Parts Index</b> .....                | <b>16</b> |

**August ,10 ' 2001**

## 1.Exterior (B442)




## 1.Exterior (B442)

| Index No. | Part No.  | Description                   | Q'ty Per Assembly |
|-----------|-----------|-------------------------------|-------------------|
| 1         | G314 3112 | Guide Plate - Lower           | 1                 |
| 2         | G302 1012 | Photointerruptor              | 2                 |
| 3         | G302 1150 | Spring - Paper Sensor         | 2                 |
| 4         | G314 3231 | Paper Sensor Lever            | 1                 |
| 5         | G302 1106 | Link - Paper Sensor           | 1                 |
| 6         | G302 0410 | Solenoid - Paper Sensor Ass'y | 1                 |
| 7         | G302 1143 | Rubber Cushion - MM6          | 2                 |
| 8         | G302 1526 | Screw - 4X12                  | 2                 |
| 9         | B442 1082 | Front Cover                   | 1                 |
| 10        | B442 0430 | Rear Cover Ass'y              | 1                 |
| 11        | B442 1057 | Cover - Open                  | 1                 |
| 12        | B442 1083 | Rear Cover                    | 1                 |
| 13        | G302 1100 | Cover Rear Link               | 1                 |
| 14        | G302 1090 | Cover Front Link              | 1                 |
| 15        | G314 3111 | Upper Cover                   | 1                 |
| 16        | B442 1153 | Decal - Paper Jam             | 1                 |
| 17        | G302 1045 | Spring Plate - Ground         | 1                 |
| 18        | G302 1042 | Cover - Right                 | 1                 |
| 19        | B442 1064 | Cover - Bracket Install       | 1                 |
| 20        | G302 0470 | Bracket - Joint Ass'y         | 1                 |
| 21        | G302 1113 | Guide Plate - Joint           | 1                 |
| 22        | G314 3113 | Cap - Guide Plate Lower       | 1                 |

| Index No. | Part No.  | Description          | Q'ty Per Assembly |
|-----------|-----------|----------------------|-------------------|
| 101       | G302 1500 | Tapping Screw - 4x12 |                   |
| 102       | G302 1504 | Screw - 4x6          |                   |
| 103       | G302 1501 | Pan Head Screw - 4x7 |                   |
| 104       | G302 1023 | Connector - Solenoid |                   |
| 105       | G302 1529 | Pan Head Screw - M4  |                   |

## 2.Shift Tray (B442)




## 2.Shift Tray (B442)

| Index No. | Part No.  | Description           | Q'ty Per Assembly |
|-----------|-----------|-----------------------|-------------------|
| 1         | G314 3171 | Holder - Tray         | 1                 |
| 2         | G314 3178 | Plate - Tray          | 2                 |
| 3         | G314 3180 | Rear Link Cover       | 1                 |
| 4         | G302 1154 | DC Motor - Tray       | 1                 |
| 5         | G302 1012 | Photointerruptor      | 2                 |
| 6         | G314 3177 | Middle Tray Cover     | 1                 |
| 7         | G314 3181 | Tray Drive Gear       | 1                 |
| 8         | G314 3176 | Front Cover Link      | 1                 |
| 9         | G302 1108 | Gear - Z40            | 1                 |
| 10        | G302 1109 | Tray Right Gear       | 1                 |
| 11        | G314 3170 | Link - Tray Ass'y     | 1                 |
| 12        | G314 3179 | Tray Link Cover       | 1                 |
| 13        | G314 3155 | Tray Base Holder      | 1                 |
| 14        | G314 3150 | Exit Tray Ass'y       | 1                 |
| 15        | G302 1030 | Tray Drawer Connector | 1                 |
| 16        | G302 1104 | Connector Cover       | 1                 |
| 17        | G302 1122 | Rubber Cushion        | 3                 |
| 18        | G314 3151 | Main Tray             | 1                 |
| 19        | G314 3152 | Middle Slide Tray     | 1                 |
| 20        | G314 3153 | End Slide Tray        | 1                 |

| Index No. | Part No.  | Description          | Q'ty Per Assembly |
|-----------|-----------|----------------------|-------------------|
| 101       | G302 1500 | Tapping Screw - 4x12 |                   |
| 102       | G302 1519 | Snap Ring - Tray     |                   |

### 3. Drive Section (B442)




### 3. Drive Section (B442)

| Index No. | Part No.  | Description               | Q'ty Per Assembly |
|-----------|-----------|---------------------------|-------------------|
| 1         | G302 1119 | Spring - Belt Tension     | 1                 |
| 2         | G302 0500 | Tensioner - Drive Ass'y   | 1                 |
| 3         | G302 1101 | Holder - Belt Tensioner   | 1                 |
| 4         | G302 1069 | Pulley - Z18              | 1                 |
| 5         | G302 1068 | Feed Out Pulley           | 1                 |
| 6         | G302 1076 | Link Lever                | 1                 |
| 7         | G302 1024 | Timing Belt - Transport   | 1                 |
| 8         | G302 1081 | Paddle Holder             | 1                 |
| 9         | G302 1071 | Gear - Paddle Z32         | 1                 |
| 10        | G302 1079 | Gear - Z18                | 1                 |
| 11        | G314 2123 | Drive Link                | 1                 |
| 12        | G302 1044 | Drive Bracket             | 1                 |
| 13        | G314 2122 | Gear - Z85 Ass'y          | 1                 |
| 14        | G302 1128 | Link Lever Spring         | 1                 |
| 15        | G302 0340 | DC Solenoid - Exit Ass'y  | 1                 |
| 16        | G302 1144 | Rubber Cushion - Solenoid | 1                 |
| 17        | G302 1155 | Paddle Solenoid           | 1                 |
| 18        | G302 1125 | Paddle Clutch Spring      | 1                 |
| 19        | G302 1120 | Holder Spring             | 1                 |
| 20        | G302 1152 | Rubber Bushing - MM5      | 1                 |
| 21        | G302 1077 | Drive Link Holder         | 1                 |
| 22        | G302 1072 | Left Link Pulley          | 1                 |
| 23        | G302 1121 | Timing Belt - Drive Link  | 1                 |
| 24        | G302 1080 | Right Link Pulley         | 1                 |

| Index No. | Part No.  | Description            | Q'ty Per Assembly |
|-----------|-----------|------------------------|-------------------|
| 101       | G302 1509 | Pan Head Screw - 3x6   |                   |
| 102       | G302 1008 | Washer - MM6           |                   |
| 103       | G302 1505 | Retaining Ring - MM5   |                   |
| 104       | G302 1501 | Pan Head Screw - 4x7   |                   |
| 105       | G302 1506 | Harness Clamp - Type B |                   |
| 106       | G302 1515 | Snap Ring - MM4        |                   |




#### 4. Paper Exit Section (B442)



9

## 5. Paper Feed Section (B442)




## 5. Paper Feed Section (B442)

| Index No. | Part No.  | Description                   | Q'ty Per Assembly |
|-----------|-----------|-------------------------------|-------------------|
| 1         | G302 0200 | Transport Roller Ass'y        | 1                 |
| 2         | G302 1517 | Rubber Bushing - MM8          | 2                 |
| 3         | G302 1514 | Bushing - MM6                 | 2                 |
| 4         | G302 1516 | Bushing - Side Plate - Rear   | 2                 |
| 5         | G302 1016 | Harness - Drawer Connector    | 1                 |
| 6         | G302 1156 | Stapler Unit                  | 1                 |
| 7         | G302 1043 | Bracket - Stapler Unit        | 1                 |
| 8         | G302 1022 | Micro Switch - Cover          | 1                 |
| 9         | G302 0220 | Roller - Paper Feed Ass'y     | 1                 |
| 10        | G302 0230 | Roller - Paper Feed Sub Ass'y | 1                 |
| 11        | G302 1097 | Holder - Cat Roller - Rear    | 1                 |
| 12        | G302 1117 | Caterpillar Belt              | 1                 |
| 13        | G302 1098 | Roller - Cat                  | 1                 |
| 14        | G314 1162 | Holder - Paper Feed Front     | 1                 |
| 15        | G302 1054 | Shaft - Weight - Cat          | 2                 |
| 16        | G302 1099 | Holder - Paper Plate          | 2                 |
| 17        | G302 1095 | Pressure Plate - Rear         | 1                 |
| 18        | G302 1149 | Feed Out Roller               | 1                 |
| 19        | G302 1141 | Front Film - Guide Plate      | 1                 |
| 20        | G302 1138 | Entrance Film - Guide Plate   | 1                 |
| 21        | G302 1059 | Entrance Lower Guide          | 1                 |
| 22        | G302 0210 | Guide Plate - Entrance Ass'y  | 1                 |
| 23        | G302 1094 | Pressure Plate - Paper Feed   | 4                 |
| 24        | G302 1147 | Rubber Cushion - Guide Plate  | 2                 |
| 25        | G302 1036 | Spring Plate - Rack           | 1                 |
| 26        | G314 1181 | Guide Plate - Tray Front      | 1                 |
| 27        | G314 3141 | Front Guide Plate             | 1                 |
| 28        | G302 1019 | Side Fence Rack               | 1                 |
| 29        | G302 1020 | Side Fence                    | 1                 |
| 30        | G302 1029 | Harness - Jogger Fence        | 1                 |
| 31        | G302 1012 | Photointerruptor              | 2                 |
| 32        | G302 1038 | Stepper Motor Bracket         | 1                 |
| 33        | G302 1037 | Ground Plate - Jogger Fence   | 1                 |
| 34        | G302 1032 | Stepper Motor - Jogger Fence  | 1                 |
| 35        | G302 1131 | Exit Spring                   | 1                 |

[illegible]

## 6.Frame/Electrical Section (B442)



## 6.Frame/Electrical Section (B442)

| Index No. | Part No.  | Description                | Q'ty Per Assembly |
|-----------|-----------|----------------------------|-------------------|
| 1         | G302 1011 | Cover Detector Feeler      | 1                 |
| 2         | G302 1012 | Photointerruptor           | 1                 |
| 3         | G302 1010 | Bracket - Cover Detector   | 1                 |
| 4         | G302 1014 | Micro Switch Harness       | 1                 |
| 5         | G302 1015 | Exit Micro Switch          | 1                 |
| 6         | G302 1013 | Exit Lever                 | 1                 |
| 7         | G302 1009 | Rear Frame                 | 1                 |
| 8         | B442 1027 | Interface Harness          | 1                 |
| 9         | G302 1056 | Joint Shaft                | 1                 |
| 10        | G302 1148 | Base Cushion               | 1                 |
| 11        | G302 1028 | Sensor Harness             | 1                 |
| 12        | G302 1021 | Base Fuse                  | 1                 |
| 13        | G302 1016 | Harness - Drawer Connector | 1                 |
| 14        | B442 0410 | Main Control Board         | 1                 |
| 15        | G302 1002 | Ground Spring Plate        | 2                 |
| 16        | G302 1001 | Base Bracket               | 1                 |
| 17        | G302 0490 | Bracket - Frame Base Ass'y | 1                 |
| 18        | G302 1000 | Base                       | 1                 |
| 19        | B442 0120 | Stepper Motor - KH56       | 1                 |
| 20        | G302 0130 | Front Side Plate           | 1                 |
| 21        | G302 1004 | Bracket Stopper Shaft      | 1                 |
| 22        | G302 1003 | Stopper Bracket            | 1                 |

| Index No. | Part No.  | Description            | Q'ty Per Assembly |
|-----------|-----------|------------------------|-------------------|
| 101       | G302 1005 | Washer - MM5           |                   |
| 102       | G302 1511 | Harness Clamp          |                   |
| 103       | G302 1500 | Tapping Screw - 4x12   |                   |
| 104       | G302 1503 | Harness Clamp - Type A |                   |
| 105       | G302 1502 | Locking Support        |                   |
| 106       | G302 1501 | Pan Head Screw - 4x7   |                   |
| 107       | G302 1504 | Screw - 4x6            |                   |
| 108       | G302 1506 | Harness Clamp - Type B |                   |
| 109       | G302 1513 | Snap Ring - MM7        |                   |

# Parts Index

## Parts Index

| Part No.  | Description             | Page and Index No. |
|-----------|-------------------------|--------------------|
| B442 0120 | Stepper Motor - KH56    | 13- 19             |
| B442 0310 | Shaft - Paddle Ass'y    | 9- 21              |
| B442 0410 | Main Control Board      | 13- 14             |
| B442 0430 | Rear Cover Ass'y        | 3- 10              |
| B442 1027 | Interface Harness       | 13- 8              |
| B442 1057 | Cover - Open            | 3- 11              |
| B442 1064 | Cover - Bracket Install | 3- 19              |
| B442 1082 | Front Cover             | 3- 9               |
| B442 1083 | Rear Cover              | 3- 12              |
| B442 1153 | Decal - Paper Jam       | 3- 16              |

| Part No.  | Description                   | Page and Index No. |
|-----------|-------------------------------|--------------------|
| G302 0130 | Front Side Plate              | 13- 20             |
| G302 0200 | Transport Roller Ass'y        | 11- 1              |
| G302 0210 | Guide Plate - Entrance Ass'y  | 11- 22             |
| G302 0220 | Roller - Paper Feed Ass'y     | 11- 9              |
| G302 0230 | Roller - Paper Feed Sub Ass'y | 11- 10             |
| G302 0260 | Feeler - Entrance Guide Ass'y | 9- 36              |
| G302 0270 | Roller - Driven - Rear Ass'y  | 9- 25              |
| G302 0280 | Front Driven Roller           | 9- 38              |
| G302 0340 | DC Solenoid - Exit Ass'y      | 7- 15              |
| G302 0410 | Solenoid - Paper Sensor Ass'y | 3- 6               |
| G302 0470 | Bracket - Joint Ass'y         | 3- 20              |
| G302 0490 | Bracket - Frame Base Ass'y    | 13- 17             |
| G302 0500 | Tensioner - Drive Ass'y       | 7- 2               |
| G302 1000 | Base                          | 13- 18             |
| G302 1001 | Base Bracket                  | 13- 16             |
| G302 1002 | Ground Spring Plate           | 13- 15             |
| G302 1003 | Stopper Bracket               | 13- 22             |
| G302 1004 | Bracket Stopper Shaft         | 13- 21             |
| G302 1005 | Washer - MM5                  | 13-101             |
| G302 1008 | Washer - MM6                  | 7-102              |
| G302 1009 | Rear Frame                    | 13- 7              |
| G302 1010 | Bracket - Cover Detector      | 13- 3              |
| G302 1011 | Cover Detector Feeler         | 13- 1              |
| G302 1012 | Photointerruptor              | 5- 5               |
| G302 1012 | Photointerruptor              | 13- 2              |
| G302 1012 | Photointerruptor              | 9- 35              |
| G302 1012 | Photointerruptor              | 11- 31             |
| G302 1012 | Photointerruptor              | 3- 2               |
| G302 1013 | Exit Lever                    | 13- 6              |
| G302 1014 | Micro Switch Harness          | 13- 4              |
| G302 1015 | Exit Micro Switch             | 13- 5              |
| G302 1016 | Harness - Drawer Connector    | 11- 5              |
| G302 1016 | Harness - Drawer Connector    | 13- 13             |
| G302 1019 | Side Fence Rack               | 11- 28             |
| G302 1020 | Side Fence                    | 11- 29             |



| Part No.  | Description                    | Page and Index No. |
|-----------|--------------------------------|--------------------|
| G302 1021 | Base Fuse                      | 13- 12             |
| G302 1022 | Micro Switch - Cover           | 11- 8              |
| G302 1023 | Connector - Solenoid           | 3-104              |
| G302 1024 | Timing Belt - Transport        | 7- 7               |
| G302 1028 | Sensor Harness                 | 13- 11             |
| G302 1029 | Harness - Jogger Fence         | 11- 30             |
| G302 1030 | Tray Drawer Connector          | 5- 15              |
| G302 1032 | Stepper Motor - Jogger Fence   | 11- 34             |
| G302 1035 | Lever - Micro Switch           | 11- 38             |
| G302 1036 | Spring Plate - Rack            | 11- 25             |
| G302 1037 | Ground Plate - Jogger Fence    | 11- 33             |
| G302 1038 | Stepper Motor Bracket          | 11- 32             |
| G302 1039 | Entrance Bracket - Guide Plate | 11- 37             |
| G302 1041 | Bracket - Paper Exit Unit      | 9- 11              |
| G302 1042 | Cover - Right                  | 3- 18              |
| G302 1043 | Bracket - Stapler Unit         | 11- 7              |
| G302 1044 | Drive Bracket                  | 7- 12              |
| G302 1045 | Spring Plate - Ground          | 3- 17              |
| G302 1046 | Spring Plate - Front Ground    | 9- 12              |
| G302 1047 | Spring Plate - Rear Ground     | 9- 4               |
| G302 1049 | Plate Shaft                    | 9- 7               |
| G302 1050 | Paddle Drive Shaft             | 9- 17              |
| G302 1052 | Timing Belt - Paddle           | 9- 20              |
| G302 1054 | Shaft - Weight - Cat           | 11- 15             |
| G302 1056 | Joint Shaft                    | 13- 9              |
| G302 1058 | Exit Feeler                    | 11- 36             |
| G302 1059 | Entrance Lower Guide           | 11- 21             |
| G302 1060 | Holder - Roller                | 9- 26              |
| G302 1068 | Feed Out Pulley                | 7- 5               |
| G302 1069 | Pulley - Z18                   | 7- 4               |
| G302 1071 | Gear - Paddle Z32              | 7- 9               |
| G302 1072 | Left Link Pulley               | 7- 22              |
| G302 1074 | Guide Plate - Paper Exit Unit  | 9- 9               |
| G302 1075 | Roller - Plate                 | 9- 5               |
| G302 1076 | Link Lever                     | 7- 6               |

| Part No.  | Description                     | Page and Index No. |
|-----------|---------------------------------|--------------------|
| G302 1077 | Drive Link Holder               | 7- 21              |
| G302 1079 | Gear - Z18                      | 7- 10              |
| G302 1080 | Right Link Pulley               | 7- 24              |
| G302 1081 | Paddle Holder                   | 7- 8               |
| G302 1084 | Paddle Shaft                    | 9- 23              |
| G302 1085 | Pulley - Paddle - Z14           | 9- 16              |
| G302 1086 | Guide - Entrance Upper          | 9- 33              |
| G302 1089 | Entrance Guide Feeler           | 9- 37              |
| G302 1090 | Cover Front Link                | 3- 14              |
| G302 1091 | Roller - Pull Back Belt         | 9- 27              |
| G302 1094 | Pressure Plate - Paper Feed     | 11- 23             |
| G302 1095 | Pressure Plate - Rear           | 11- 17             |
| G302 1097 | Holder - Cat Roller - Rear      | 11- 11             |
| G302 1098 | Roller - Cat                    | 11- 13             |
| G302 1099 | Holder - Paper Plate            | 11- 16             |
| G302 1100 | Cover Rear Link                 | 3- 13              |
| G302 1101 | Holder - Belt Tensioner         | 7- 3               |
| G302 1102 | Pressure Roller - Front         | 9- 32              |
| G302 1104 | Connector Cover                 | 5- 16              |
| G302 1106 | Link - Paper Sensor             | 3- 5               |
| G302 1108 | Gear - Z40                      | 5- 9               |
| G302 1109 | Tray Right Gear                 | 5- 10              |
| G302 1113 | Guide Plate - Joint             | 3- 21              |
| G302 1115 | Spring - Paper Exit Unit - Rear | 9- 10              |
| G302 1116 | Spring - Driven Roller          | 9- 28              |
| G302 1117 | Caterpillar Belt                | 11- 12             |
| G302 1119 | Spring - Belt Tension           | 7- 1               |
| G302 1120 | Holder Spring                   | 7- 19              |
| G302 1120 | Holder Spring                   | 9- 18              |
| G302 1121 | Timing Belt - Drive Link        | 7- 23              |
| G302 1122 | Rubber Cushion                  | 5- 17              |
| G302 1123 | Exit Paddle                     | 9- 24              |
| G302 1124 | Large Brush                     | 9- 15              |
| G302 1125 | Paddle Clutch Spring            | 7- 18              |
| G302 1126 | Paddle Film                     | 9- 22              |

| Part No.  | Description                  | Page and Index No. |
|-----------|------------------------------|--------------------|
| G302 1128 | Link Lever Spring            | 7- 14              |
| G302 1129 | Middle Brush                 | 9- 8               |
| G302 1130 | Small Brush                  | 9- 3               |
| G302 1131 | Exit Spring                  | 11- 35             |
| G302 1137 | Entrance Film                | 9- 34              |
| G302 1138 | Entrance Film - Guide Plate  | 11- 20             |
| G302 1141 | Front Film - Guide Plate     | 11- 19             |
| G302 1143 | Rubber Cushion - MM6         | 3- 7               |
| G302 1144 | Rubber Cushion - Solenoid    | 7- 16              |
| G302 1147 | Rubber Cushion - Guide Plate | 11- 24             |
| G302 1148 | Base Cushion                 | 13- 10             |
| G302 1149 | Feed Out Roller              | 11- 18             |
| G302 1150 | Spring - Paper Sensor        | 3- 3               |
| G302 1152 | Rubber Bushing - MM5         | 7- 20              |
| G302 1152 | Rubber Bushing - MM5         | 9- 30              |
| G302 1154 | DC Motor - Tray              | 5- 4               |
| G302 1155 | Paddle Solenoid              | 7- 17              |
| G302 1156 | Stapler Unit                 | 11- 6              |
| G302 1500 | Tapping Screw - 4x12         | 3-101              |
| G302 1500 | Tapping Screw - 4x12         | 5-101              |
| G302 1500 | Tapping Screw - 4x12         | 13-103             |
| G302 1500 | Tapping Screw - 4x12         | 11-102             |
| G302 1500 | Tapping Screw - 4x12         | 9-101              |
| G302 1501 | Pan Head Screw - 4x7         | 13-106             |
| G302 1501 | Pan Head Screw - 4x7         | 7-104              |
| G302 1501 | Pan Head Screw - 4x7         | 11-108             |
| G302 1501 | Pan Head Screw - 4x7         | 3-103              |
| G302 1502 | Locking Support              | 13-105             |
| G302 1503 | Harness Clamp - Type A       | 13-104             |
| G302 1504 | Screw - 4x6                  | 3-102              |
| G302 1504 | Screw - 4x6                  | 11-109             |
| G302 1504 | Screw - 4X6                  | 9-102              |
| G302 1504 | Screw - 4x6                  | 13-107             |
| G302 1505 | Retaining Ring - MM5         | 7-103              |
| G302 1505 | Retaining Ring - MM5         | 11-101             |

| Part No.  | Description                       | Page and Index No. |
|-----------|-----------------------------------|--------------------|
| G302 1506 | Harness Clamp - Type B            | 7-105              |
| G302 1506 | Harness Clamp - Type B            | 13-108             |
| G302 1506 | Harness Clamp - Type B            | 11-106             |
| G302 1507 | Screw - 2.3X12                    | 11-104             |
| G302 1508 | Tapping Screw - 3x6               | 11-107             |
| G302 1509 | Pan Head Screw - 3x6              | 7-101              |
| G302 1509 | Pan Head Screw - 3x6              | 11-105             |
| G302 1510 | Snap Ring - MM5                   | 9-104              |
| G302 1511 | Harness Clamp                     | 13-102             |
| G302 1512 | Harness Clamp - Type C            | 11-103             |
| G302 1513 | Snap Ring - MM7                   | 13-109             |
| G302 1514 | Bushing - MM6                     | 11- 3              |
| G302 1514 | Bushing - MM6                     | 9- 13              |
| G302 1515 | Snap Ring - MM4                   | 9-103              |
| G302 1515 | Snap Ring - MM4                   | 7-106              |
| G302 1516 | Bushing - Side Plate - Rear       | 11- 4              |
| G302 1517 | Rubber Bushing - MM8              | 11- 2              |
| G302 1517 | Rubber Bushing - MM8              | 9- 1               |
| G302 1518 | Bushing - Paper Exit Unit - Point | 9- 39              |
| G302 1519 | Snap Ring - Tray                  | 5-102              |
| G302 1526 | Screw - 4X12                      | 3- 8               |
| G302 1527 | Bushing - Paddle - MM5            | 9- 14              |
| G302 1528 | Bushing - MM5                     | 9- 19              |
| G302 1529 | Pan Head Screw - M4               | 3-105              |
| G314 1111 | Lever - Plate Ass'y               | 9- 29              |
| G314 1112 | Lever Plate - Left Ass'y          | 9- 42              |
| G314 1115 | Plate Lever                       | 9- 31              |
| G314 1116 | Right Film                        | 9- 43              |
| G314 1125 | Protection - Paddle               | 9- 41              |
| G314 1162 | Holder - Paper Feed Front         | 11- 14             |
| G314 1181 | Guide Plate - Tray Front          | 11- 26             |
| G314 2122 | Gear - Z85 Ass'y                  | 7- 13              |
| G314 2123 | Drive Link                        | 7- 11              |
| G314 3101 | Lever - Paper Exit                | 9- 6               |
| G314 3102 | Balancer - Lever Paper Exit       | 9- 40              |

| Part No.  | Description             | Page and Index No. |
|-----------|-------------------------|--------------------|
| G314 3104 | Guide - Paper Exit      | 9- 2               |
| G314 3111 | Upper Cover             | 3- 15              |
| G314 3112 | Guide Plate - Lower     | 3- 1               |
| G314 3113 | Cap - Guide Plate Lower | 3- 22              |
| G314 3141 | Front Guide Plate       | 11- 27             |
| G314 3150 | Exit Tray Ass'y         | 5- 14              |
| G314 3151 | Main Tray               | 5- 18              |
| G314 3152 | Middle Slide Tray       | 5- 19              |
| G314 3153 | End Slide Tray          | 5- 20              |
| G314 3155 | Tray Base Holder        | 5- 13              |
| G314 3170 | Link - Tray Ass'y       | 5- 11              |
| G314 3171 | Holder - Tray           | 5- 1               |
| G314 3176 | Front Cover Link        | 5- 8               |
| G314 3177 | Middle Tray Cover       | 5- 6               |
| G314 3178 | Plate - Tray            | 5- 2               |
| G314 3179 | Tray Link Cover         | 5- 12              |
| G314 3180 | Rear Link Cover         | 5- 3               |
| G314 3181 | Tray Drive Gear         | 5- 7               |
| G314 3231 | Paper Sensor Lever      | 3- 4               |

| Part No. | Description | Page and Index No. |
|----------|-------------|--------------------|
|          |             |                    |