

PRINTER OPTION (B305/G690)

PARTS CATALOG


INTRODUCTION

This chapter instructs you the numbers and names of parts on this machine.

INDEX to PARTS CATALOG

1.PRINTER CONTROLLER TYPE 185 (B305)	2
2.PRINTER HARD DISK TYPE 185 (G690).....	4
PARTS INDEX.....	7

1.PRINTER CONTROLLER TYPE 185 (B305)




1.PRINTER CONTROLLER TYPE 185 (B305)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A845 5875	Panel - Printer Bracket	1
2	A845 5878	Card Cover	1
3	A845 5876	Cover - Printer Option	2
4	A845 5870	Bracket:printer:ass'y	1
5	B305 5171	PCB PRT Sub-Ass'y	1
5	B305 5173	PCB PRT Lanier Sub-Ass'y (LAN)	1
6	A250 5145	PCB - ST-C1-MB	1
7	A250 5251	DC Harness - FFC-MB	1
8	A250 5250	DC Harness - MB Power Source	1
9	A845 5872	Controller Bracket Cover	1
10	A845 5877	Bracket - Mother Board	1
11	A885 1456	Keytop - Right Application	1
12	A885 1457	Keytop - Left Application	1
13	B305 1460	Decal 2/3 Application-14l	1
14	A885 1458	Keytop 3 - Application	1
15	A291 1302	Main Switch Cover	1
16	A891 1453	Sheet - Power Source Cover (115V)	1
16	A891 1473	Sheet - Power Source Cover (230V)	1
17	A891 0051	Switch - Power Source (115V)	1
17	A891 0052	Switch - Power Source (230V)	1
18	A885 1452	Keytop - Power Source	1
19	A845 5879	Spring Plate - Earth	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0353 0080Z	Philips Trass Head Screw - M3x8	
103	1105 0460	Clamp	
104	1407 4730	SRAM STK12C68-W45	

2.PRINTER HARD DISK TYPE 185 (G690)



2.PRINTER HARD DISK TYPE 185 (G690)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G690 5714	PCB HDD - 1.6GB	1
2	A853 7000	HDD MK1608MAT	1
3	G690 5920	Bracket - HDD	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0313 0050B	Philips Pan Head Screw - M3X5	
102	0951 3004Z	Philips Screw With Flat Washer - M3x4	

PARTS INDEX

Part No.	Description	Page and Index No.
B305 1460	Decal 2/3 Application-14I	3- 13
B305 5171	PCB PRT Sub-Ass'y	3- 5
B305 5173	PCB PRT Lanier Sub-Ass'y (LAN)	3- 5

Part No.	Description	Page and Index No
B305 1460	Decal 2/3 Application-14I	3- 13
B305 5171	PCB PRT Sub-Ass'y	3- 5
B305 5173	PCB PRT Lanier Sub-Ass'y (LAN)	3- 5
G690 5714	PCB HDD - 1.6GB	5- 1
G690 5920	Bracket - HDD	5- 3

Part No.	Description	Page and Index No.
A250 5145	PCB - ST-C1-MB	3- 6
A250 5250	DC Harness - MB Power Source	3- 8
A250 5251	DC Harness - FFC-MB	3- 7
A291 1302	Main Switch Cover	3- 15
A845 5870	Bracket:printer:ass'y	3- 4
A845 5872	Controller Bracket Cover	3- 9
A845 5875	Panel - Printer Bracket	3- 1
A845 5876	Cover - Printer Option	3- 3
A845 5877	Bracket - Mother Board	3- 10
A845 5878	Card Cover	3- 2
A845 5879	Spring Plate - Earth	3- 19
A853 7000	HDD MK1608MAT	5- 2
A885 1452	Keytop - Power Source	3- 18
A885 1456	Keytop - Right Application	3- 11
A885 1457	Keytop - Left Application	3- 12
A885 1458	Keytop 3 - Application	3- 14
A891 0051	Switch - Power Source (115V)	3- 17
A891 0052	Switch - Power Source (230V)	3- 17
A891 1453	Sheet - Power Source Cover (115V)	3- 16
A891 1473	Sheet - Power Source Cover (230V)	3- 16

Part No.	Description	Page and Index No
0313 0050B	Philips Pan Head Screw - M3X5	5-101
0353 0080Z	Philips Trass Head Screw - M3x8	3-102
0451 3006B	Tapping Screw - M3x6	3-101
0951 3004Z	Philips Screw With Flat Washer - M3x4	5-102
1105 0460	Clamp	3-103
1407 4730	SRAM STK12C68-W45	3-104