

Paper Feed Unit TK1060 (J516)

Paper Feed Unit TK1060 (J516)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.Paper Feed Unit 1 (J516)	2
2.Paper Feed Unit 2 (J516)	4
3.Paper Feed Unit 3 (J516)	6
Parts Index	10

July ,30 ' 2007

1.Paper Feed Unit 1 (J516)




1.Paper Feed Unit 1 (J516)

Index No.	Part No.	Description	Q'ty Per Assembly
1	J516 1085	Cover:Left Front	1
2	J516 1083	Cover:Left Upper	1
3	J516 1084	Cover:Left Lower	1
4	G102 1042	Rubber Foot:Frame	2
5	J516 3250	Friction Pad Unit	1
6	J516 1081	Cover:Right Upper	1
7	J516 1082	Cover:Right Lower	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 3010N	Tapping Screw - M3x10	

2.Paper Feed Unit 2 (J516)




2.Paper Feed Unit 2 (J516)

Index No.	Part No.	Description	Q'ty Per Assembly
1	J516 3510	Cassette	1
2	J016 3001	Extension Tray	1
3	J012 3003	End Fence:Tos-C1	1
4	J012 3020	Protection:Cassette	2
5	J016 2310	Decal:Protection:Right	1
6	J016 2309	Decal:Protection:Left	1
7	J012 3019	Arm:Cassette	2
8	J006 3006	Tension Spring	2
9	J001 3008	Gear:Side Fence	1
10	J016 3040	Side Fence:Left	1
11	J016 3050	Side Fence:Right	1
12	J516 3070	Base Plate	1
13	J516 3561	Stopper:Lengthwise	1
14	J016 4906	Dust Cover	1
15	J516 4905	Dust Cover:Upper	1

Index No.	Part No.	Description	Q'ty Per Assembly

3. Paper Feed Unit 3 (J516)



3.Paper Feed Unit 3 (J516)

Index No.	Part No.	Description	Q'ty Per Assembly
1	J516 3003	Ground Plate	1
2	AW02 0156	Photointerruptor:EE-SX4235A-P2	3
3	G555 3127	Feeler Spring	1
4	J506 3030	Feeler:Transport Sensor	1
5	J516 3002	Cover:Harness:2	1
6	J516 3006	Transport Roller	1
7	J516 5320	Harness:Motor	1
8	J506 7000	Stepper Motor DC4.29V	1
9	J516 3039	Heat Sink:Front	1
10	J506 3016	Bracket:Motor	1
11	B806 1305	Timing Belt - 40S2M216	1
12	J506 3026	Pulley:48T:Gear:Z21	1
13	J516 3020	Bracket:Drive Unit	1
14	J506 3028	Gear:17Z:29Z	1
15	J502 3118	Gear:Roller Clutch	1
16	J502 3116	Gear:20Z	1
17	J007 3016	Spring Clutch:Feed	1
18	AA08 2116	Bushing - M8	2
19	J502 3115	Gear:Paper Feed:Z21	1
20	J516 3010	Bracket:Drive Sub-Unit:Inner Back:Peen	1
21	J516 3038	Heat Sink	1
22	J516 5300	Harness:I/F	1
23	J516 5310	Harness:Sensor:1	1
24	J516 5330	Harness:Sensor:2	1
25	J516 3007	Sheet:Housing	1
26	J516 5100	PCB:Main	1
27	J001 3001	Paper Feed Roller	1
28	J516 3004	Shaft:Paper Feed Roller	1
29	J001 3014	Pressure Roller	1
30	J015 4907	Roller:Stopper:Paper	1
31	J015 4906	Stopper:Paper	1
32	J516 3001	Cover:Harness:1	1
33	J516 3031	Feeler:Paper End Sensor	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0313 0060N	Screw - M3x6	
103	0450 3008N	Tapping Screw - M3x8	
104	1103 3780	Connector:04RH178-3122	
105	1105 0511	Harness Clamp - LWS-0306ZC	
106	0741 3706	Ball Bearing - 6x10x3	
107	0720 0040E	Retaining Ring - M4	
107	1105 0192	Locking Support	
108	0720 0060E	Retaining Ring - M6	
109	1105 0192	Locking Support	
110	0450 3008N	Tapping Screw - M3x8	

Parts Index

Parts Index

Part No.	Description	Page and Index No.
J516 1081	Cover:Right Upper	3 - 6
J516 1082	Cover:Right Lower	3 - 7
J516 1083	Cover:Left Upper	3 - 2
J516 1084	Cover:Left Lower	3 - 3
J516 1085	Cover:Left Front	3 - 1
J516 3001	Cover:Harness:1	7 - 32
J516 3002	Cover:Harness:2	7 - 5
J516 3003	Ground Plate	7 - 1
J516 3004	Shaft:Paper Feed Roller	7 - 28
J516 3006	Transport Roller	7 - 6
J516 3007	Sheet:Housing	7 - 25
J516 3010	Bracket:Drive Sub-Unit:Inner Back:Peen	7 - 20
J516 3020	Bracket:Drive Unit	7 - 13
J516 3031	Feeler:Paper End Sensor	7 - 33
J516 3038	Heat Sink	7 - 21
J516 3039	Heat Sink:Front	7 - 9
J516 3070	Base Plate	5 - 12
J516 3250	Friction Pad Unit	3 - 5
J516 3510	Cassette	5 - 1
J516 3561	Stopper:Lengthwise	5 - 13
J516 4905	Dust Cover:Upper	5 - 15
J516 5100	PCB:Main	7 - 26
J516 5300	Harness:I/F	7 - 22
J516 5310	Harness:Sensor:1	7 - 23
J516 5320	Harness:Motor	7 - 7
J516 5330	Harness:Sensor:2	7 - 24

Part No.	Description	Page and Index No.
B806 1305	Timing Belt - 40S2M216	7 - 11
G102 1042	Rubber Foot:Frame	3 - 4
G555 3127	Feeler Spring	7 - 3
J001 3001	Paper Feed Roller	7 - 27
J001 3008	Gear:Side Fence	5 - 9
J001 3014	Pressure Roller	7 - 29
J006 3006	Tension Spring	5 - 8
J007 3016	Spring Clutch:Feed	7 - 17
J012 3003	End Fence:Tos-C1	5 - 3
J012 3019	Arm:Cassette	5 - 7
J012 3020	Protection:Cassette	5 - 4
J015 4906	Stopper:Paper	7 - 31
J015 4907	Roller:Stopper:Paper	7 - 30
J016 2309	Decal:Protection:Left	5 - 6
J016 2310	Decal:Protection:Right	5 - 5
J016 3001	Extension Tray	5 - 2
J016 3040	Side Fence:Left	5 - 10
J016 3050	Side Fence:Right	5 - 11
J016 4906	Dust Cover	5 - 14
J502 3115	Gear:Paper Feed:Z21	7 - 19
J502 3116	Gear:20Z	7 - 16
J502 3118	Gear:Roller Clutch	7 - 15
J506 3016	Bracket:Motor	7 - 10
J506 3026	Pulley:48T:Gear:Z21	7 - 12
J506 3028	Gear:17Z:29Z	7 - 14
J506 3030	Feeler:Transport Sensor	7 - 4
J506 7000	Stepper Motor DC4.29V	7 - 8

Part No.	Description	Page and Index No.
AA08 2116	Bushing - M8	7 - 18
AW02 0156	Photointerruptor:EE-SX4235A-P2	7 - 2

Part No.	Description	Page and Index No.
0313 0060N	Screw - M3x6	7 - 102
0450 3008N	Tapping Screw - M3x8	7 - 103
0450 3008N	Tapping Screw - M3x8	7 - 110
0450 3010N	Tapping Screw - M3x10	3 - 101
0451 3006N	Tapping Screw - 3x6	7 - 101
0720 0040E	Retaining Ring - M4	7 - 107
0720 0060E	Retaining Ring - M6	7 - 108
0741 3706	Ball Bearing - 6x10x3	7 - 106
1103 3780	Connector:04RH178-3122	7 - 104
1105 0192	Locking Support	7 - 107
1105 0192	Locking Support	7 - 109
1105 0511	Harness Clamp - LWS-0306ZC	7 - 105