

**Paper Feed Unit TK1230/TK1240**  
**Machine Code: M407/M408**  
**Field Service Manual**  
**Ver 1.0**

**Latest Release: Nov, 2016**  
**Initial Release: Nov, 2016**  
**Copyright (c) 2016 Ricoh Co.,Ltd.**




# Symbols, Abbreviations and Trademarks

## Symbols, Abbreviations

This manual uses several symbols and abbreviations. The meaning of those symbols and abbreviations are as follows:

Symbol	What it means
	Clip ring
	Screw
	Connector
	Clamp
	E-ring
	Flat Flexible Cable
	Timing Belt
SEF	Short Edge Feed
LEF	Long Edge Feed
K	Black
C	Cyan
M	Magenta
Y	Yellow
B/W, BW	Black and White
FC	Full color



c2790086

[A] Short Edge Feed (SEF)

[B] Long Edge Feed (LEF)

---

## Trademarks

---

Adobe, Acrobat, PostScript, and PostScript 3 are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.

Bonjour, Macintosh, Mac OS, OS X, and Safari are trademarks of Apple Inc., registered in the United States and other countries.

Citrix, Citrix Presentation Server and Citrix XenApp are either registered trademarks or trademarks of Citrix Systems, Inc.

Firefox® is a registered trademark of the Mozilla Foundation.

IPS is a trademark or registered trademark of Zoran Corporation and/or its subsidiaries in the United States or other countries.

Java is a registered trademark of Oracle and/or its affiliates.

JAWS® is a registered trademark of Freedom Scientific, Inc., St. Petersburg, Florida and/or other countries.

Microsoft, Windows, Windows Server, Windows Vista, and Internet Explorer are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

Monotype is a registered trademark of Monotype Imaging Inc.

IPX and NDS are either registered trademarks or trademarks of Novell, Inc.

OpenLDAP is a registered trademark of the OpenLDAP Foundation.

PCL® is a registered trademark of Hewlett-Packard Company.

PictBridge is a trademark.

UNIX is a registered trademark of the Open Group.

UPnP™ is a trademark of the UPnP™ Implementers Corporation.

The proper name of Internet Explorer 6 is Microsoft® Internet Explorer® 6.

The proper name of Internet Explorer 8 is Windows® Internet Explorer® 8.

The proper names of the Windows operating systems are as follows:

- The product names of Windows Vista are as follows:

Microsoft® Windows Vista® Ultimate

Microsoft® Windows Vista® Business

Microsoft® Windows Vista® Home Premium

Microsoft® Windows Vista® Home Basic

Microsoft® Windows Vista® Enterprise

- The product names of Windows 7 are as follows:

Microsoft® Windows® 7 Home Premium

Microsoft® Windows® 7 Professional

Microsoft® Windows® 7 Ultimate

Microsoft® Windows® 7 Enterprise

- The product names of Windows 8 are as follows:

Microsoft® Windows® 8

Microsoft® Windows® 8 Pro

Microsoft® Windows® 8 Enterprise

- The product names of Windows 8.1 are as follows:

Microsoft® Windows® 8.1

Microsoft® Windows® 8.1 Pro

Microsoft® Windows® 8.1 Enterprise

- The product names of Windows 10 are as follows:

Microsoft® Windows® 10 Home Premium

Microsoft® Windows® 10 Pro

Microsoft® Windows® 10 Enterprise

Microsoft® Windows® 10 Education

- The product names of Windows Server 2003 are as follows:

Microsoft® Windows Server® 2003 Standard Edition

Microsoft® Windows Server® 2003 Enterprise Edition

- The product names of Windows Server 2003 R2 are as follows:

Microsoft® Windows Server® 2003 R2 Standard Edition

Microsoft® Windows Server® 2003 R2 Enterprise Edition

- The product names of Windows Server 2008 are as follows:

Microsoft® Windows Server® 2008 Standard

Microsoft® Windows Server® 2008 Enterprise

- The product names of Windows Server 2008 R2 are as follows:

Microsoft® Windows Server® 2008 R2 Standard

Microsoft® Windows Server® 2008 R2 Enterprise

- The product names of Windows Server 2012 are as follows:

Microsoft® Windows Server® 2012 Foundation

Microsoft® Windows Server® 2012 Essentials

Microsoft® Windows Server® 2012 Standard

- The product names of Windows Server 2012 R2 are as follows:

Microsoft® Windows Server® 2012 R2 Foundation

Microsoft® Windows Server® 2012 R2 Essentials

Microsoft® Windows Server® 2012 R2 Standard

Other product names used herein are for identification purposes only and might be trademarks of their respective companies. We disclaim any and all rights to those marks.

Microsoft product screen shots reprinted with permission from Microsoft Corporation.



## Table of Contents

1.	Product Information .....	2
	Overview .....	2
	Specifications .....	2
2.	Replacement and Adjustment.....	3
	Paper Feed Tray.....	3
	Left Cover .....	3
	Right Cover .....	3
	Rear Cover .....	4
	Paper Feed Unit.....	4
	Paper Feed Roller .....	5
	Friction Pad .....	6
	Paper Feed Motor .....	6
	Paper Feed Gear .....	7
	Paper Feed Tray Board.....	7
	Paper Size Detection Switch .....	8
	Paper End Sensor .....	8
	Paper Feed Sensor .....	9
	Side Fence Adjustment.....	9
	Mechanism .....	13
	Paper Feed Separation Mechanism .....	13
	Paper Size Detection .....	13
	Paper Size Detect Combination (Switch is pressed: L).....	13

# 1. Product Information


---

## Overview

---

### Specifications

---




1. Grip roller clutch (Left side as viewed from the front of the machine)
2. Paper feed clutch (Right side as viewed from the front of the machine)
3. Grip roller
4. Paper feed roller
5. Friction pad

## 2. Replacement and Adjustment

### Paper Feed Tray

#### Left Cover

1. Remove the left cover [A] ( $\wedge \times 3$ ).




Note

- Two of the red circle is the tapping screws.

#### Right Cover

1. Remove the right cover [A] ( $\wedge \times 3$ ).



Note

- Two of the red circle is the tapping screws.

## 2. Replacement and Adjustment

---

### Rear Cover

---


1. Remove the rear cover [A] ( $\wedge$ ×2, Hook×4).





### Paper Feed Unit

---

1. Remove the left cover (Left Cover).
2. Remove the right cover (Right Cover).
3. Remove the front cover [A] ( $\wedge$ ×5).



4. Remove the paper feed unit [A] (×5, ×1, ×1).




---

### Paper Feed Roller

---

1. Remove the paper feed roller [A].




## 2. Replacement and Adjustment

---


### Friction Pad

---

1. Remove the friction pad unit (×2).




2. Remove the friction pad [A] (×1).




### Paper Feed Motor

---

1. Remove the paper feed unit ([Paper Feed Unit](#)).
2. Remove the paper feed motor [A] (×4, ×1).






---

### Paper Feed Gear

---

1. Remove the paper feed unit ([Paper Feed Unit](#)).
2. Remove the gear cover [A] ( $\varnothing \times 2$ ,  $\text{Screw} \times 1$ ) and the paper feed clutch bracket [B] ( $\varnothing \times 2$ ,  $\text{Screw} \times 1$ ,  $\text{Spring} \times 1$ ), then remove each gear.



---


### Paper Feed Tray Board

---

1. Remove the paper feed unit ([Paper Feed Unit](#)).

## 2. Replacement and Adjustment

2. Remove the paper feed tray board [A] (×4, ×4).




---

### Paper Size Detection Switch

---

1. Remove the paper feed unit ([Paper Feed Unit](#)).  
2. Remove the paper size detection switch [A] (×1, Hook×2).





---

### Paper End Sensor

---



1. Remove the paper feed unit ([Paper Feed Unit](#)).  
2. Remove the remove the feeler [B], then remove the paper end sensor [A] (×1).





### Paper Feed Sensor

1. Remove the paper feed unit ([Paper Feed Unit](#)).
2. Remove the paper feed sensor [A] (☞ ×1).



### Side Fence Adjustment


For the optional paper tray, you can adjust the side-to-side registration within a range of 2 mm, by changing the position of the Pinion on the side fence.

1. Pull out the tray from the optional tray and then turn it over.

## 2. Replacement and Adjustment

### Note

- With the default setting ( $\pm 0$ ), the pinion is positioned so that the triangle marks are fully aligned.



2. Loosen the screws and lift up the pinion. Adjust the side-to-side registration in the desired direction and then tighten the screws.



### Note


- The example image shows that the registration is adjusted by 2 mm to the right.

## End fence and side fences


---

There are five screw holes so that the end fence and side fences can be fixed in place.

This is useful for ensuring that the paper guides will not move when the size of the paper to be used is fixed.

**End fence****Note**

- Fixable paper sizes are shown below.



- [A]: A5 SEF
- [B]: 8.5" (HLT SEF)
- [C]: 11" (LT SEF)
- [D]: A4 SEF
- [E]: 14" (LG SEF)


## 2. Replacement and Adjustment

### Side fences



#### Note

- Fixable paper sizes are shown below.



- [A]: A4 SEF
- [B]: LG SEF/LT SEF

## Mechanism

### Paper Feed Separation Mechanism

Upon receiving the paper feed signal, the Paper Feed Clutch and the Griproller Clutch of the OptionalTray are turned on to rotate the Paper Feed Roller. Only the sheet in the top in the Cassette is fed by the Friction Pad.


### Paper Size Detection

The Paper Size Detection Dial, which is located on the right side of the Optional Tray, uses combination of four detection switches to detect the paper size. The size setting is indicated on the front of the tray.

### Paper Size Detect Combination (Switch is pressed: L)

SW Knob	Knob 4	Knob 3	Knob 2	Knob 1	Paper Size
SW Side	CN1-1	CN1-2	CN1-4	CN1-5	
PCB Side	CN102-5	CN102-4	CN102-2	CN102-1	
SW value	SW3	SW2	SW1	SW0	
0	L	L	L	L	A5 T
1	L	L	L	H	Custom Size
2	L	L	H	L	B5 T
3	L	L	H	H	LG
4	L	H	L	L	LT
5	L	H	L	H	HLT
6	L	H	H	L	A4 T
7	L	H	H	H	No Cassette
8	H	L	L	L	No Cassette
9	H	L	L	H	No Cassette
10	H	L	H	L	No Cassette
11	H	L	H	H	No Cassette
12	H	H	L	L	No Cassette
13	H	H	L	H	No Cassette
14	H	H	H	L	No Cassette
15	H	H	H	H	No Cassette

## 2. Replacement and Adjustment



w\_m112m0017\_en