G767-8517B

Printer Maintenance Kit Type 3800E

(Code: G767)

MAINTENANCE GUIDE

1 **Check the contents of the box for the following items:**

| Description	Q'ty
Waste Toner Bottle	1
Maintenance Guide (This manual)	1

2 **Be sure to check the following points:**

- The power is turned off.
- The power cord is unplugged from the wall outlet.
- The interface cable is unplugged from the printer.

3 **Turn off the power, and then unplug the power cable.**

**4** **Slowly open the front cover by pulling down from the two areas on the left and right.**

ZDJH007J

✐ **Note**

❒ For machine models without waste oil bottles, proceed to step **6**.

1

**E** **Carefully pivot the waste oil bottle outward, in the direction of the arrow.**


ZHXH150J

F **Take the new waste toner bottle out of the bag.**

ZDJH228J

**G** **Slowly remove the used waste toner bottle from inside the printer.**

ZHXH590J

⚠️**Important**

❒ Be sure to remove the waste toner bottle horizontally.

**H** **Remove the lid (①), and then put it in the position shown in the illustration (②).**

ZDJH229J

I **Put the used waste toner bottle into the bag that contained the new waste toner bottle, and then seal the bag.**

⚠️**Important**

❒ Be sure to handle the bottle carefully so waste toner does not spill.

J **Insert the new waste toner bottle as shown.**

ZHXH610J

2

11 **Push it in until it stops.**

ZHXH600J

✳️**Important**

❒ Be sure to firmly insert the waste toner bottle to avoid toner leakage inside the printer.

📝 **Note**

❒ For machine models without waste oil bottles, proceed to step **13**.

12 **Slowly close the waste oil bottle in the direction of the arrow.**

ZHXH160J

13 **Slowly close the front cover by pushing the two areas on the left and right.**

ZDJH041J

14 **Plug in the power cable, and then turn on the power.**

3