

Model PL-P2L (G162)

PARTS CATALOG

First edition, March 2007

Ricoh Company, LTD.

Model PL-P2L (G162)

PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

Model PL-P2L	(G162)
Paper Feed Unit Type 1000	(G389)

Model PL-P2L (G162)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.Exterior 1 (G162).....	2
2.Exterior 2 (G162).....	4
3.PCU Section (G162).....	6
4.Fusing Unit (G162).....	8
5.Paper Exit Section (G162).....	10
6.Electrical Section (G162).....	12
Parts Index	16

March ,8 ' 2007

1.Exterior 1 (G162)




1.Exterior 1 (G162)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G162 7010	Photoconductor Unit	1
2	G162 7020	OPC Charger Roller	1
3	G162 7030	Cleaning Roller	1
4	V128 699	Fusing Unit (110V) FU 2	1
5	V128 664	Cleaning Roller Cover PU	1
6	V128 409	Power Cord (110 V) PU	1
7	G162 3000	Operating Instructions Setup Guide	1
8	G139 2690	Plate - Logo RIC	1

Index No.	Part No.	Description	Q'ty Per Assembly


2.Exterior 2 (G162)





5

3.PCU Section (G162)



3.PCU Section (G162)




Index No.	Part No.	Description	Q'ty Per Assembly
1	G162 7340	Transfer Unit	1
2	V128 464	Paper Guide (A) PU	1
3	V128 465	Paper Guide (B) PU	1
4	G162 7350	Paper Guide Ass'y - C	1
5	G162 7360	Paper Feed Roller	1
6	V128 468	Separator Pad 5 PU	1
7	V128 469	Erase Lamp PU	1
8	V128 470	Paper Guide (D) PU	1
9	V128 471	Toner Density Sensor PU	1
10	V126 168	Belt Sensor	1
11	V126 167	Paper Sensor	1
12	V128 467	Tray Empty Actuator PU	1



Index No.	Part No.	Description	Q'ty Per Assembly

4.Fusing Unit (G162)




4.Fusing Unit (G162)



Index No.	Part No.	Description	Q'ty Per Assembly
*	V128 699	Fusing Unit (110V) FU 2	1
1	G162 7370	Top Fuser Cover	1
2	V128 477	Fuser Connector (110V) FU	1
3	G162 7480	Lock Knob Ass'y	1

Index No.	Part No.	Description	Q'ty Per Assembly

5. Paper Exit Section (G162)




5.Paper Exit Section (G162)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G162 7380	Rear Cover	1
2	V128 710	Transfer Base Ass'y E PU 2	1
3	G162 7410	Transfer Roller	1
4	G162 7420	Exit Guide	1
5	V128 490	Exit Roller Assy PU	1
6	G162 7430	Exit Fan Assy	1
7	V128 494	Exit Drive Assy PU	1
8	G162 7510	Idler Lever	1
9	V128 496	Rear Cover Latch Assy PU	1
10	G162 7390	Upper Duplex Cover	1
11	G162 7400	Lower Duplex Cover	1
12	V128 486	Registration Actuator PU	1
13	G162 7490	Registration Roller Ass'y PU	1
14	V128 490	Exit Roller Assy PU	1
15	V126 167	Paper Sensor	1
16	V128 491	Fuser Exit Actuator PU	1
17	V123 842	Discharge Brush	1
18	G162 7440	Exit Fan - DC 2.2W	1
19	G162 7500	Exit Fan Duct	1

Index No.	Part No.	Description	Q'ty Per Assembly

6.Electrical Section (G162)



6.Electrical Section (G162)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G162 7270	Engine Control Board	1
2	G162 7280	Power Supply - High Voltage	1
3	G162 7290	Power Supply - Low Voltage	1
4	G162 7320	Power Supply Fan - DC 2.2W	1
5	G162 7300	Power Supply Bracket	1
6	V128 436	Interlock Switch PU	1
7	G162 7310	Fan Ass'y - Power Supply	1
8	V128 477	Fuser Connector (110V) FU	1
9	G162 7470	Fan Duct - Powersupply Unit	1
10	V126 169	Toner Sensor Assy	1
11	V128 461	Toner Present Sensor PU	1
12	V126 168	Belt Sensor	1
13	G162 7330	Controller Board	1

Index No.	Part No.	Description	Q'ty Per Assembly

Parts Index

Parts Index

Part No.	Description	Page and Index No.
G162 3000	Operating Instructions Setup Guide	3 - 7
G162 7010	Photoconductor Unit	3 - 1
G162 7020	OPC Charger Roller	3 - 2
G162 7030	Cleaning Roller	3 - 3
G162 7040	Top Cover Ass'y	5 - 1
G162 7050	Top_Cover	5 - 4
G162 7060	Panel Silk	5 - 6
G162 7070	Right Cover	5 - 2
G162 7080	Left Cover	5 - 3
G162 7090	Inner Cover	5 - 7
G162 7100	Front Cover	5 - 9
G162 7110	Main Motor - DC 53W	5 - 8
G162 7120	OPC Drive Gear	5 - 17
G162 7130	Paper Feed Clutch	5 - 10
G162 7140	Registration Clutch	5 - 11
G162 7150	Transfer Roller Clutch	5 - 13
G162 7160	Gear Unit - Main Drive	5 - 15
G162 7170	Waste Toner Feeder	5 - 16
G162 7180	Development Drive Unit	5 - 18
G162 7190	Development Gear	5 - 19
G162 7200	Waste Toner Holder	5 - 21
G162 7210	Laser Unit	5 - 24
G162 7220	Tray Guide Ass'y - Left	5 - 26
G162 7240	Right Toner Guide	5 - 27
G162 7250	Left Toner Guide	5 - 28
G162 7260	Duplex Connector Cover	5 - 30
G162 7270	Engine Control Board	13 - 1
G162 7280	Power Supply - High Voltage	13 - 2
G162 7290	Power Supply - Low Voltage	13 - 3
G162 7300	Power Supply Bracket	13 - 5
G162 7310	Fan Ass'y - Power Supply	13 - 7
G162 7320	Power Supply Fan - DC 2.2W	13 - 4
G162 7330	Controller Board	13 - 13
G162 7340	Transfer Unit	7 - 1
G162 7350	Paper Guide Ass'y - C	7 - 4

Part No.	Description	Page and Index No.
G162 7360	Paper Feed Roller	7 - 5
G162 7370	Top Fuser Cover	9 - 1
G162 7380	Rear Cover	11 - 1
G162 7390	Upper Duplex Cover	11 - 10
G162 7400	Lower Duplex Cover	11 - 11
G162 7410	Transfer Roller	11 - 3
G162 7420	Exit Guide	11 - 4
G162 7430	Exit Fan Assy	11 - 6
G162 7440	Exit Fan - DC 2.2W	11 - 18
G162 7470	Fan Duct - Powersupply Unit	13 - 9
G162 7480	Lock Knob Ass'y	9 - 3
G162 7490	Registration Roller Ass'y PU	11 - 13
G162 7500	Exit Fan Duct	11 - 19
G162 7510	Idler Lever	11 - 8

Part No.	Description	Page and Index No.
G139 2690	Plate - Logo RIC	3 - 8

Part No.	Description	Page and Index No.
V123 842	Discharge Brush	11 - 17
V126 167	Paper Sensor	7 - 11
V126 167	Paper Sensor	11 - 15
V126 168	Belt Sensor	13 - 12
V126 168	Belt Sensor	7 - 10
V126 169	Toner Sensor Assy	13 - 10
V126 169	Toner Sensor Assy	5 - 23
V127 223	Paper Size Sensor 2	5 - 32
V128 409	Power Cord (110 V) PU	3 - 6
V128 423	Main Motor PU	5 - 12
V128 428	Cleaning Roller Clutch PU	5 - 14
V128 436	Interlock Switch PU	13 - 6
V128 436	Interlock Switch PU	5 - 22
V128 438	Right Tray Guide PU	5 - 25
V128 441	Room Temp. Thermistor PU	5 - 33
V128 446	Waste Toner Agitator PU	5 - 31
V128 461	Toner Present Sensor PU	13 - 11
V128 464	Paper Guide (A) PU	7 - 2
V128 465	Paper Guide (B) PU	7 - 3
V128 467	Tray Empty Actuator PU	7 - 12
V128 468	Separator Pad 5 PU	7 - 6
V128 469	Erase Lamp PU	7 - 7
V128 470	Paper Guide (D) PU	7 - 8
V128 471	Toner Density Sensor PU	7 - 9
V128 477	Fuser Connector (110V) FU	9 - 2
V128 477	Fuser Connector (110V) FU	13 - 8
V128 486	Registration Actuator PU	11 - 12
V128 490	Exit Roller Assy PU	11 - 5
V128 490	Exit Roller Assy PU	11 - 14
V128 491	Fuser Exit Actuator PU	11 - 16
V128 494	Exit Drive Assy PU	11 - 7
V128 496	Rear Cover Latch Assy PU	11 - 9
V128 648	Left Tray Guide PU 2	5 - 20
V128 664	Cleaning Roller Cover PU	3 - 5
V128 699	Fusing Unit (110V) FU2	3 - 4

