

Model AR-P2 (G139/G149) PARTS CATALOG

First edition, December 2005

Ricoh Company, LTD.

Model AR-P2 (G139/G149)

Model AR-P2 (G139/G149)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.EXTERIOR (G139/G149).....	2
2.BY-PASS FEED SECTION (G139/G149).....	4
3.PAPER TRAY (G139/G149)	6
4.PAPER FEED UNIT (G139/G149).....	8
5.OPTICAL UNIT (G139/G149)	10
6.TRANSFER BELT UNIT (G139/G149)	12
7.TRANSFER BELT DRIVE (G139/G149)	14
8.PAPER TRANSFER UNIT (G139/G149).....	16
9.FUSING UNIT (G139/G149)	18
10.PAPER EXIT (G139/G149).....	20
11.DRIVE SECTION 1 (G139/G149).....	22
12.DRIVE SECTION 2 (G139/G149)	24
13.ELECTRICAL SECTION 1 (G139/G149).....	26
14.ELECTRICAL SECTION 2 (G139/G149).....	28
PARTS INDEX.....	31

December ,31 ' 2005

1.EXTERIOR (G139/G149)




1.EXTERIOR (G139/G149)

Index No.	Part No.	Description	Q'ty Per Assembly
*	G139 2201	IH Assembly 200V	1
1	G081 1222	Stopper Base	1
2	G139 0101	LCD Panel Cover Ass'y	1
3	G139 0103	Top Cover Ass'y	1
4	G081 5307	Sensor - Toner Cartridge Cover	2
5	G081 1223	Stopper Guide	1
6	G081 1215	Toner Cartridge Cover	1
7	G081 1203	Right Cover	1
8	G139 0104	Left Cover	1
9	G139 2204	Rear Cover - RIC	1
9	G139 2205	Rear Cover	1
9	G139 2207	Rear Cover - NRG	1
10	G081 1217	Cartridge Lever B	1
11	G081 1206	Cover - Option Paper Unit Harness	1
12	G081 1207	Cassette Cover	1
13	G081 1212	Front Support Lever	1
14	G081 1214	Lever Spring	1
15	G081 1211	Left Axis - Front Cover	1
16	G081 1213	Right - Axis - Front Cover	1
17	G081 1219	Right Cover Hook	2
18	G081 1218	Cartridge Lever A	1
19	G081 4536	Screw 3x8	1
20	G081 4537	Screw 3x12	2
21	GA00 3034	Decal - Energystar	1
22	GA00 3038	Decal - Inkjet Paper Caution	1
23	G139 2356	Decal - Power Source/Toner Supply	1
24	G139 2358	Decal - Power Source	1
25	G139 2004	Yellow Toner Bottol Case	1
26	G139 2003	Magenta Toner Bottol Case	1
27	G139 8507	Manual - Admin	1
27	G139 8511	Manual	1
28	A267 8561	Safety Information Sheet	1
28	G139 8509	Safety Information Sheet	1
29	G139 2001	Black Toner Bottol Case	1
30	G139 2002	Cyan Toner Bottol Case	1

Index No.	Part No.	Description	Q'ty Per Assembly
31	G139 2352	Sheet - Color Chart	1
32	G105 7299	Ferrite Core:G-p1	1
33	G131 6110	Operation Panel	1
101	1607 1715	Ferrite Core - RFC-5	
102	1150 0373	Power Supply Code:125V 15A NA	
102	1150 0377	Power Supply Code:250V:10A:EU	

2.BY-PASS FEED SECTION (G139/G149)




2.BY-PASS FEED SECTION (G139/G149)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G081 2452	Pickup Roller Holder	1
2	G081 2453	Pickup Rubber	1
3	G081 2481	One Way Clutch	1
4	G081 2454	Pickup Roller	1
5	G081 2455	Belt - Pickup Roller	1
6	G081 2456	Paper Guide - Upper Cassette	1
7	G081 2457	Separation Pad Holder	1
8	G139 1801	Pickup Roller Shaft	1
9	G081 2460	Right Paper Guide	1
10	G081 2459	Left Paper Guide	1
11	G139 1802	Mpt Paper Holder Spring	1
12	G081 2492	Spring - R	1
13	G081 2463	Pinion Gear	1
14	G081 2464	Cover - Main Cassette	1
15	G081 2494	Paper Tray Assy	1
16	G081 2466	Paper Tray Base	1
17	G081 2467	Left Cam	1
18	G081 2468	Actuator - Paper Empty Sensor	1
19	G139 1803	Cassette Gear Bracket	1
20	G081 2470	Spring	1
21	G081 2472	Bushing	2
22	G081 2473	Roller Gear	1
23	G139 1804	Delay Pad Ass'y	1
24	G081 2475	Separation Pad Spring	1
25	G081 2476	Tray Protector	1
26	G081 2477	Idle Gear	1
27	G081 2478	Gear Spacer	1
28	G081 2479	Gear Cover	1
29	G081 2480	Cam Gear	1
30	G081 2482	Roller Position Arm	1
31	G139 1805	Cam Shaft	1
32	G139 1806	Right Cam	1
33	G139 1807	Paper Chute Spportor Ass'y	1
34	G081 4529	E-ring	1
35	G139 1808	Pin	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	G081 2485	Friction Pad	2
37	G081 2292	Pick Roller	1
38	G139 0505	Screw - M3X8	1
39	G139 0313	Screw - M3X6	1
40	G139 0203	Screw - M3X10	3
41	G139 2357	Decal - Manual Feed	1

3.PAPER TRAY (G139/G149)




3.PAPER TRAY (G139/G149)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G081 2501	Paper Guide - Paper Feed Unit	1
2	G139 1901	Cassette Base Plate	1
3	G139 1902	Lift Large Spring	2
4	G081 2504	Side Pressure Spring	1
5	G081 2505	Left Corner Separator	1
6	G081 2506	Left Paper Side Guide	1
7	G081 2507	Spring	2
8	G081 2508	Slider	2
9	G139 1903	Lift Plate (L)	1
10	G081 2510	Bushing	2
11	G081 2511	Plastic Washer	2
12	G081 2512	Paper Size Selector	1
13	G139 1904	Lift Plate (R)	1
14	G081 2514	Cassette Base	1
15	G081 2515	Right Corner Separator	1
16	G081 2516	Right Paper Side Guide	1
17	G081 2517	Rack	2
18	G081 2518	Pinion Gear	1
19	G081 2519	Paper Size Adjuster	1
20	G081 2520	Paper Size Detector Support	1
21	G139 1905	Screw - M3x8	1

Index No.	Part No.	Description	Q'ty Per Assembly

4.PAPER FEED UNIT (G139/G149)




4.PAPER FEED UNIT (G139/G149)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G139 1411	Paper Feed Unit	1
2	G081 2472	Bushing	2
3	G139 1405	Registration Pinch Roller	1
4	G081 2420	Pin	2
5	G081 2419	Registration Pinch Roller Gear	1
6	G081 2493	Spring - L	2
7	G081 2417	Registration Roller Tension	2
8	G081 2421	Registration Roller Gear	1
9	G139 1406	Registration Roller	1
10	G139 1403	Pickup Solenoid	1
11	G081 2499	Actuator - Paper Empty Sensor	1
12	G139 1404	Paper Empty/Registration Sensor	1
13	G081 2413	Actuator - Paper Resistration	1
14	G081 2414	Spring	1
15	G139 1410	Varistor	1
16	G081 2415	Bushing	2
17	G081 2435	Paper Feed Unit Frame	1
18	G081 2429	Pickup Rubber	2
19	G081 2428	Pickup Rubber Frame	2
20	G081 2430	Pickup Roller Shaft	1
21	G081 2431	Pin	2
22	G139 1409	Paper Feed Roller	1
23	G081 2423	Registration Paper Guide	1
24	G081 2496	Pinch Roller Spring	2
25	G081 2426	Pinch Roller Holder	1
26	G139 1407	Pinch Roller	4
27	G081 2450	Paper Guide Spring	1
28	G139 1408	Pinch Roller Shaft	1
29	G081 2434	Plastic Washer	1
30	G081 2410	Ratchet Arm	1
31	G081 2433	Bushing	1
32	G139 1402	Gear Bracket	1
33	G081 2405	Inner Gear-b	1
34	G081 2403	Inner Gear	2
35	G081 2404	Outer Gear	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	G081 2407	Gear	1
37	G081 2471	Pickup Gear	1
38	G081 2255	Bushing	1
39	G081 2408	Idle Gear	1
40	G081 2409	Feed Gear	1
41	G139 0313	Screw - M3X6	1

5.OPTICAL UNIT (G139/G149)




5.OPTICAL UNIT (G139/G149)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G081 2371	Cassette Stopper Roller	1
2	G139 1301	Earth Plate - Laser Unit	1
3	G081 2389	Cassette Stopper	1
4	G139 1302	Laser Unit	1
5	G139 1313	Lsu Earth Plate	2
6	G081 2387	Fusing Unit Lock Lever	2
7	G081 2388	IH Harness Cover	1
8	G139 1305	OPC Unit Sub-guide	1
9	G139 1304	Ih Shield Cover	1
10	G139 1303	STR Plate Holde	1
11	G139 1306	IH Ass'y(100V)	1
12	G139 1311	Washer	1
13	G139 1315	Regist Stopper (R)	1
14	G139 1314	Regist Stopper (L)	1
15	G081 2489	Snap Ring - D4	1
16	G139 1401	Registration Roller Clutch	1
17	G081 2401	Registration Roller Joint Gear	1
18	G139 1308	Mpt Paper Detection Sensor	1
19	G139 1309	Mpt HP Sensor	1
20	G139 1310	Mpt Sensor Cover	1
21	G139 0313	Screw - M3x6	5
22	G139 1312	Screw - M3x10	3
23	G139 0203	Screw - M3x10	3
24	G139 0413	Screw - M3x12	6

Index No.	Part No.	Description	Q'ty Per Assembly

6.TRANSFER BELT UNIT (G139/G149)




6. TRANSFER BELT UNIT (G139/G149)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G139 1015	Registration Sensor	1
2	G081 2216	Interlock Cover	1
3	G081 2215	IH Harnes Cover	1
4	G139 1014	ACC Unit Detector	1
5	G081 5210	Fan Motor - DC24V-2.88W	1
6	G081 2233	Fusing Fan Connector Sheet	1
7	G081 5307	Sensor - Toner Cartridge Cover	1
8	G139 1003	Acc Fixing Plate	2
9	G139 1013	Spring	1
10	G139 1001	Interlock Switc Bracket	1
11	G139 1012	Color Registration Board Holder	1
12	G139 1008	Interlock Switc	1
13	G139 1002	Interlock Switc	1
14	G081 2231	Interlock Lever Spring	2
15	G081 2214	Interlock Lever	1
16	G139 0505	Screw - M3X8	2
17	G120 2201	PCU Guide	1
18	G081 2213	Left Holer - Wase Toner Cartridge	1
19	G139 1009	OPC Unit Holder Ass'y	1
20	G081 2218	Right Cover Plastic Strap	1
21	G139 1004	Protect Cover	1
22	G139 1006	Blind Plate	1
23	G139 1005	Waste Toner Ful Detection Board	1
24	G139 1007	Waste Toner Bottol Holder - Right	1
25	G139 1011	OPC Unit Guide (Black)	1
26	G139 0413	Screw - M3x12	14
27	G139 0412	Screw - M3x35	2
28	G139 0312	Screw - M3x8	4
29	G081 4513	Screw 2.2x16	1
30	G139 1010	Screw - M3x14	1

Index No.	Part No.	Description	Q'ty Per Assembly

7. TRANSFER BELT DRIVE (G139/G149)




7.TRANSFER BELT DRIVE (G139/G149)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G139 1137	Accumulator Tension Unit	1
2	G139 1102	FTR Cam Slider Slider - Seal	1
3	G139 1106	Changer Lever Spring	1
4	G139 1103	Cam Slider Seal	2
5	G139 1133	Tension Cam Link (R)	1
6	G139 1126	STR Cam Spring	2
7	G139 1136	STR Cam (R)	1
8	G139 1132	STR Release Lever (R)	1
9	G139 1124	Plate	2
10	G139 1131	FTR Lift Lever (R)	1
11	G081 2273	Bushing	2
12	G139 1130	FTR Cam (R)	1
13	G139 1122	FTR Cam Spring	2
14	G139 1120	Damper Cam Link Ass'y	2
15	G139 1129	Center Cam	1
16	G139 1107	Changer Solenoid	1
17	G139 1134	Cam Shaft	1
18	G139 1119	Pin	8
19	G139 1135	Sub Shaft	1
20	G081 2278	Home Tab	1
21	G139 1121	FTR Cam (L)	1
22	G139 1123	FTR Lift Lever	1
23	G139 1125	STR Release Lever (L)	1
24	G139 1127	STR Cam (L)	1
25	G139 1128	Tension Cam Link (L)	1
26	G139 1101	FTR Cam Slider Guide - Damper	1
27	G139 1112	Cam Ratchet Solenoid	1
28	G139 1118	Drive Cam - Waste Toner Bottol	1
29	G139 1117	Outer Gaer - Waste Toner Bottol	1
30	G139 1116	Planetart Gear - Waste Toner Bottol	3
31	G139 1115	Planetary Gear Base (A)	1
32	G081 2255	Bushing	2
33	G139 1114	Tension Unit Base Ass'y	1
34	G139 1104	Accumulator Cam HP Sensor	1
35	G081 2289	Clutch Spring	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	G081 2257	Cam Clutch Slider	1
37	G081 2256	Cam Clutch Core	1
38	G139 1108	Planetary Gear Base (B)	1
39	G081 2259	Planetary Gear	4
40	G081 2260	Outer Gear	1
41	G081 2261	Double Teeth Gear	1
42	G081 2262	Cam Shaft Bushing	1
43	G081 2263	Plastic Washer	1
44	G081 2391	Plastic Washer	1
45	G139 1111	Cam Ratchet Ass'y	1
46	G139 1110	Cam Ratchet Spring	1
47	G139 1109	Cam Ratchet Bracket	1
48	G139 1105	Changer Lever	1
49	G139 0203	Screw - M3X10	2
50	G139 1113	Screw - M3X5	1
51	G081 4529	E-ring	5
52	G081 4528	E-ring	1

8.PAPER TRANSFER UNIT (G139/G149)




8.PAPER TRANSFER UNIT (G139/G149)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G139 0202	Front Emblem	1
2	G139 0201	Front Door Ass'y	1
3	G081 1303	Lock Lever - Front Cover	1
4	G081 1302	Lock Lever Spring	1
5	G081 1305	Plastic Belt	1
6	G139 2206	Str Roller Ass'y	1
7	G139 0204	F-Door Reinforcement Plate	1
8	G139 2690	Plate - Logo RIC	1
8	GA00 1052	Plate:Logo:GES	1
8	GA00 1053	Plate:Logo:NSA	1
8	GA00 1054	Plate:Logo:REX	1
9	G139 0309	Plastic Washer	2
10	G139 0301	STR Frame Base Ass'y	1
11	G081 2263	Plastic Washer	2
12	G139 0304	STR Bushing	2
13	G139 0305	Plastic Washer	2
14	G139 0308	STR Cover Shaft	1
15	G139 0302	STR Spring	2
16	G139 0310	STR Hinge Shaft	1
17	G139 0306	STR Roller Holder (R)	1
18	G139 0311	STR Cover Ass'y	1
19	G139 0303	Terminal Plate	1
20	G139 0307	STR Holder Ass'y	1
21	G139 0203	Screw - M3x10	2
22	G139 0105	Screw - M3x12	4
23	G139 0312	Screw - M3x8	2
24	G139 0313	Screw - M3x6	1
25	G139 2360	Decal - Aficio CL3500N	1
25	G139 2371	Decal - Aficio CL3500CH	1
25	G139 2372	Decal:C7521DN:GES	1
25	G139 2375	Decal:C7521DN:NAS	1
25	G139 2376	Decal:C7521DN:REX	1
25	G139 2377	Decal:C7521N:GES	1
25	G139 2378	Decal:C7521N:NAS	1
25	G139 2379	Decal:C7521N:REX	1

Index No.	Part No.	Description	Q'ty Per Assembly

9.FUSING UNIT (G139/G149)




9.FUSING UNIT (G139/G149)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G139 2101	PR Thermistor	1

Index No.	Part No.	Description	Q'ty Per Assembly

10.PAPER EXIT (G139/G149)




10.PAPER EXIT (G139/G149)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G139 1203	Paper Full Sensor	1
2	G081 2340	Paper Exit Gear Cover	1
3	G081 2375	Paper Exit Roller Joint Gear	1
4	G081 2376	Rotation Switching Gear - A	1
5	G081 2378	Outer Gear	2
6	G081 2403	Inner Gear	4
7	G081 2381	Coupling Gear	2
8	G081 2377	Rotation Switching Gear - B	1
9	G081 2379	Intermediate Gear	1
10	G081 2380	Double Teeth Gear	1
11	G081 2338	Switching Lever Spring	1
12	G081 2339	Switching Lever	1
13	G139 1201	Rotation Switching Solenoid	1
14	G139 1205	Exit Sub-roller	4
15	G081 2352	Exit Roller Rubber	4
16	G081 2351	Paper Exit Roller	1
17	G139 1204	Exit Restraint Lever	2
18	G139 1206	Exit Frame	1
19	G081 2354	Paper Stopper - A	1
20	G081 2342	Holder - Paper Exit Roller	1
21	G139 1207	Discharge Brush	1
22	G081 2343	Pinch Roller - A	6
23	G081 2344	Pinch Roller Spring	8
24	G139 1202	Star Rubber	2
25	G081 2345	Pinch Roller - B	2
26	G081 2348	Exit Paper Guide	1
27	G081 2350	Actuator - Paper Full Sensor	1
28	G081 2349	Spring	1
29	G139 0313	Screw - M3x6	3
30	G139 0203	Screw - M3x10	3
31	G139 0413	Screw - M3x12	2

Index No.	Part No.	Description	Q'ty Per Assembly

11.DRIVE SECTION 1 (G139/G149)




11.DRIVE SECTION 1 (G139/G149)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G139 0504	Exit Fg Board	1
2	G081 2203	Gear - Toner Cartridge Drive	1
3	G139 0501	Toner Bottol Holder Ass'y	1
4	G139 0701	Bias Terminal Ass'y	1
5	G139 0901	Shaft	1
6	G081 2209	Bias Terminal Plate A	8
7	G081 2210	Bias Terminal Plate B	8
8	G081 4533	Charge Harness	2
9	G139 0703	FTR Cable	1
10	G081 4534	Harness - Charge Output Process	1
11	G081 2206	Middle Terminal Spring	4
12	G081 2208	Short Terminal Spring	4
13	G081 2207	Long Terminal Spring	8
14	G139 0503	Fhv Plate	1
15	G139 0902	Toner Bottol Drive Base	1
16	G139 0903	Toner Empty Sensor	1
17	G081 2202	Gear - Toner Cartridge Drive	3
18	G081 2204	Granding Plate	1
19	G139 0904	Washer	1
20	G139 0502	Power Supply Fan Duct	1
21	G081 5210	Fan Motor - DC24V-2.88W	1
22	G139 0702	Screw - M2.3x6	16
23	G139 0505	Screw - M3x8	1
24	G139 0203	Screw - M3x10	1
25	G139 0313	Screw - M3x6	2
26	G139 0412	Screw - M3x35	2
27	G139 0413	Screw - M3x12	12
28	G081 4528	E-ring	2
29	G139 0506	Ferrite Core	1

Index No.	Part No.	Description	Q'ty Per Assembly

12.DRIVE SECTION 2 (G139/G149)




12.DRIVE SECTION 2 (G139/G149)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G139 0808	Main Drive Unit	1
2	G081 2103	Feed Idle Gear	1
3	G139 0801	Drive Motor Drive Motor:DC24V 32WATT	2
5	G081 2123	Feed Belt	1
5	G081 2125	Flange - Feed Pulley Gear	1
6	G139 0803	OPC Unit Cam HP Sensor	1
7	G081 2146	Developer Gear	4
8	G081 2112	Devloper Spring	4
9	G081 2111	Devloper Coupling	4
10	G081 2119	Bushing - Transfer Belt	1
11	G081 2118	PCU Home Lever	1
12	G081 2117	PCU Home Spring	1
13	G081 2116	CMY Home Lever	1
14	G081 2106	Left - PCU Idle Gear	4
15	G081 2107	Right - PCU Idle Gear	1
16	G081 2108	Left - Transfer Belt Idle Gear	2
17	G081 2109	Right - Transfer Belt Idle Gear	1
18	G081 2145	PCU Gear	4
19	G081 2121	Feed Pulley Gear	1
20	G081 2105	Cam Gear	1
21	G081 2104	Fuser Idle Gear	1
22	G139 0804	Drive Unit Bracket (S)	1
23	G081 2115	Granding Plate - Transfer Belt	1
24	G081 2138	Hopper Gear B	2
25	G081 2137	Hopper Gear A	2
26	G081 2139	Hopper Gear C	1
27	G081 2136	Joint Gear	1
28	G081 2135	Hopper Change Gear	1
29	G081 4529	E-ring	2
30	G139 0802	Bk Solenoid	1
31	G139 0806	Screw - M3x8	9
32	G139 0313	Screw - M3x6	8
33	G139 0807	Tension Roller Brecket	1
34	G081 2141	Tension Roller Spring	1
35	G081 2124	Tension Roller	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	G081 2127	CMY Change Gear	2
37	G081 2126	Flange - Transfer Belt Pulley Gear	1
38	G139 0805	Screw - M3X8	8
39	G120 2203	BK Change Gear 2	1
40	G120 2205	Clutch Spacer	1
41	G120 2204	Clutch Bearing 2	1
42	G120 2102	Pulley Gear - Transfer Belt	1

13.ELECTRICAL SECTION 1 (G139/G149)




13.ELECTRICAL SECTION 1 (G139/G149)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G139 0106	Ferrite Core	1
2	G081 5205	Ferrite Core	1
3	G139 0407	Engine Board Bracket - Small	1
4	G139 0401	Fusing Earth Plate	1
5	G139 0402	Inner Cover	1
6	G139 0403	ADU Jam Detection Sensor	1
7	G081 5304	Sensor - Duplex Unit	1
8	G139 0405	IH Fan Duct	1
9	G081 5318	SUB Fusing Fan	1
10	G081 2015	Grounding Plate	1
11	G081 2018	Paper Pickup Gear	1
12	G139 0404	Paper Pickup Motor Bracet	1
13	G139 0406	Temp./Humidity Sensor	1
14	G081 5211	Motor - DC24V-8.16W	1
15	G139 0408	Engine Board Bracket - Large	1
16	G139 0411	Shield Cover - Engine Control Board	1
17	G081 2022	Transfer Terminal	1
18	G139 2020	Duplex Unit Drive Gear	1
19	G139 0602	Harness - CN1	1
20	G139 0620	Harness - CN2	1
21	G139 0601	Harness - CN3	1
22	G139 0604	Harness - CN11	1
23	G139 0606	Harness - CN44	1
24	G139 0605	Harness - CN7	1
25	G081 5407	Harness - CN10	1
26	G139 0607	Harness - CN30	1
27	G139 0608	Harness - CN12	1
28	G139 0609	Harness - CN17	1
29	G139 0610	Harness - CN15	1
30	G139 0611	Harness - CN39	1
31	G139 0618	Harness - CN27	1
32	G139 0617	Harness - CN5	1
33	G081 5422	Harness - CN6	1
34	G081 5420	Harness - CN23	1
35	G081 5419	Harness - CN18	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	G139 0615	Harness - CN14	1
37	G081 5417	Harness - CN13	1
38	G139 0614	Harness - CN8	1
39	G081 5302	Paper Size Detector	1
40	G139 0612	Harness - CN33	1
41	G139 0613	Harness - CN34	1
42	G081 5426	Harness - CN32	1
43	G139 0619	Harness - CN28	1
44	G139 0616	Harness - CN29	1
45	G139 0603	Harness - C45/46	1
46	G139 0410	EEPROM (IC5)	1
47	G139 2202	IH Power Supply Board 200V	1
48	G139 0621	Ferrite Core	1
49	G139 0313	Screw - M3x6	6
50	G139 0413	Screw - M3x12	7
51	G139 0412	Screw - M3x35	2
52	G139 0203	Screw - M3x10	2
53	G139 0414	Screw - M3x6	1

14.ELECTRICAL SECTION 2 (G139/G149)



14.ELECTRICAL SECTION 2 (G139/G149)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G081 4556	Rip Lock Screw A	1
2	G081 4557	Rip Lock Screw B	1
3	G142 5513	PCB:CTL:Ares-P2:DOM:Sub-Ass'y	1
4	G081 2441	Guide Rail - MCB	2
5	G139 1601	Shield Cover Ass'y	1
6	G139 1602	Shield Base Cover Ass'y	1
7	G139 1506	Washer	4
8	G139 1701	Power Supply Shield Cover Ass'y	1
9	G139 1503	Earth Plate	1
10	G139 1702	Power Supply Inner Duct	1
11	G081 5430	Harness	1
12	G139 1705	Input Power Cable	1
13	G139 1704	Power Supply(100V)	1
13	G139 2203	Power Supply 200V	1
14	G139 1703	IH Power Supply Board(100V)	1
14	G139 2202	IH Power Supply Board 200V	1
15	G139 1708	Earth Plate Cover	1
16	G139 1707	Earth Plate	1
17	G139 1706	Power Supply Base Plate	1
18	G139 1501	Complete - High Voltage Board	1
19	G139 1505	HV Earth Plate	1
20	G139 1502	Shield Cover - High Voltage Board	1
21	G081 2491	Recovery Grand Spring	1
22	G139 1504	Cassette Holder	1
23	G139 1507	Rubber Foot	4
24	G139 0313	Screw - M3x6	39
25	G139 0413	Screw - M3x12	14
26	G139 0505	Screw - M3x8	2
27	G142 5854	Control Board Bracket	1
28	G104 5141	Knob Screw:M3	2
29	G142 5859	Option/Device Panel	1
30	G142 5855	Grip - Control Board Plate	1
31	G142 5857	Shielding Plate - Sdcard	1
32	G142 5858	Knob Screw	1
33	G142 5002	SD-Card:AR-P2:EXP	1

Index No.	Part No.	Description	Q'ty Per Assembly
34	G142 5851	Control Board Plate	1
101	0451 3005N	Tapping Screw:M3x5	
102	0450 3008N	Tapping Screw - M3x8	
103	1407 6465	RAM:FM25L256-PG(rev.ag)	
104	0353 0050N	Screw-m3x5	

Parts Index

Parts Index

Part No.	Description	Page and Index No.
G139 0101	LCD Panel Cover Ass'y	3 - 2
G139 0103	Top Cover Ass'y	3 - 3
G139 0104	Left Cover	3 - 8
G139 0105	Screw - M3x12	17 - 22
G139 0106	Ferrite Core	27 - 1
G139 0201	Front Door Ass'y	17 - 2
G139 0202	Front Emblem	17 - 1
G139 0203	Screw - M3X10	5 - 40
G139 0203	Screw - M3x10	11 - 23
G139 0203	Screw - M3x10	21 - 30
G139 0203	Screw - M3x10	23 - 24
G139 0203	Screw - M3x10	17 - 21
G139 0203	Screw - M3X10	15 - 49
G139 0203	Screw - M3x10	27 - 52
G139 0204	F-Door Reinforcement Plate	17 - 7
G139 0301	STR Frame Base Ass'y	17 - 10
G139 0302	STR Spring	17 - 15
G139 0303	Terminal Plate	17 - 19
G139 0304	STR Bushing	17 - 12
G139 0305	Plastic Washer	17 - 13
G139 0306	STR Roller Holder (R)	17 - 17
G139 0307	STR Holder Ass'y	17 - 20
G139 0308	STR Cover Shaft	17 - 14
G139 0309	Plastic Washer	17 - 9
G139 0310	STR Hinge Shaft	17 - 16
G139 0311	STR Cover Ass'y	17 - 18
G139 0312	Screw - M3x8	13 - 28
G139 0312	Screw - M3x8	17 - 23
G139 0313	Screw - M3x6	25 - 32
G139 0313	Screw - M3x6	27 - 49
G139 0313	Screw - M3x6	29 - 24
G139 0313	Screw - M3X6	9 - 41
G139 0313	Screw - M3X6	5 - 39
G139 0313	Screw - M3x6	11 - 21
G139 0313	Screw - M3x6	23 - 25

Part No.	Description	Page and Index No.
G139 0313	Screw - M3x6	21 - 29
G139 0313	Screw - M3x6	17 - 24
G139 0401	Fusing Earth Plate	27 - 4
G139 0402	Inner Cover	27 - 5
G139 0403	ADU Jam Detection Sensor	27 - 6
G139 0404	Paper Pickup Motor Bracet	27 - 12
G139 0405	IH Fan Duct	27 - 8
G139 0406	Temp./Humidity Sensor	27 - 13
G139 0407	Engine Board Bracket - Small	27 - 3
G139 0408	Engine Board Bracket - Large	27 - 15
G139 0410	EEPROM (IC5)	27 - 46
G139 0411	Shield Cover - Engine Control Board	27 - 16
G139 0412	Screw - M3x35	23 - 26
G139 0412	Screw - M3x35	13 - 27
G139 0412	Screw - M3x35	27 - 51
G139 0413	Screw - M3x12	21 - 31
G139 0413	Screw - M3x12	27 - 50
G139 0413	Screw - M3x12	29 - 25
G139 0413	Screw - M3x12	13 - 26
G139 0413	Screw - M3x12	23 - 27
G139 0413	Screw - M3x12	11 - 24
G139 0414	Screw - M3x6	27 - 53
G139 0501	Toner Bottol Holder Ass'y	23 - 3
G139 0502	Power Supply Fan Duct	23 - 20
G139 0503	Fhv Plate	23 - 14
G139 0504	Exit Fg Board	23 - 1
G139 0505	Screw - M3X8	5 - 38
G139 0505	Screw - M3X8	13 - 16
G139 0505	Screw - M3x8	23 - 23
G139 0505	Screw - M3x8	29 - 26
G139 0506	Ferrite Core	23 - 29
G139 0601	Harness - CN3	27 - 21
G139 0602	Harness - CN1	27 - 19
G139 0603	Harness - C45/46	27 - 45
G139 0604	Harness - CN11	27 - 22

Part No.	Description	Page and Index No.
G139 0605	Harness - CN7	27 - 24
G139 0606	Harness - CN44	27 - 23
G139 0607	Harness - CN30	27 - 26
G139 0608	Harness - CN12	27 - 27
G139 0609	Harness - CN17	27 - 28
G139 0610	Harness - CN15	27 - 29
G139 0611	Harness - CN39	27 - 30
G139 0612	Harness - CN33	27 - 40
G139 0613	Harness - CN34	27 - 41
G139 0614	Harness - CN8	27 - 38
G139 0615	Harness - CN14	27 - 36
G139 0616	Harness - CN29	27 - 44
G139 0617	Harness - CN5	27 - 32
G139 0618	Harness - CN27	27 - 31
G139 0619	Harness - CN28	27 - 43
G139 0620	Harness - CN2	27 - 20
G139 0621	Ferrite Core	27 - 48
G139 0701	Bias Terminal Ass'y	23 - 4
G139 0702	Screw - M2.3x6	23 - 22
G139 0703	FTR Cable	23 - 9
G139 0801	Drive Motor Drive Motor:DC24V 32WATT	25 - 3
G139 0802	Bk Solenoid	25 - 30
G139 0803	OPC Unit Cam HP Sensor	25 - 6
G139 0804	Drive Unit Bracket (S)	25 - 22
G139 0805	Screw - M3X8	25 - 38
G139 0806	Screw - M3x8	25 - 31
G139 0807	Tension Roller Brecket	25 - 33
G139 0808	Main Drive Unit	25 - 1
G139 0901	Shaft	23 - 5
G139 0902	Toner Bottol Drive Base	23 - 15
G139 0903	Toner Empty Sensor	23 - 16
G139 0904	Washer	23 - 19
G139 1001	Interlock Switc Bracket	13 - 10
G139 1002	Interlock Switc	13 - 13
G139 1003	Acc Fixing Plate	13 - 8

Part No.	Description	Page and Index No.
G139 1004	Protect Cover	13 - 21
G139 1005	Waste Toner Ful Detection Board	13 - 23
G139 1006	Blind Plate	13 - 22
G139 1007	Waste Toner Bottol Holder - Right	13 - 24
G139 1008	Interlock Switc	13 - 12
G139 1009	OPC Unit Holder Ass'y	13 - 19
G139 1010	Screw - M3x14	13 - 30
G139 1011	OPC Unit Guide (Black)	13 - 25
G139 1012	Color Registration Board Holder	13 - 11
G139 1013	Spring	13 - 9
G139 1014	ACC Unit Detector	13 - 4
G139 1015	Registration Sensor	13 - 1
G139 1101	FTR Cam Slider Guide - Damper	15 - 26
G139 1102	FTR Cam Slider Slider - Seal	15 - 2
G139 1103	Cam Slider Seal	15 - 4
G139 1104	Accumulator Cam HP Sensor	15 - 34
G139 1105	Changer Lever	15 - 48
G139 1106	Changer Lever Spring	15 - 3
G139 1107	Changer Solenoid	15 - 16
G139 1108	Planetary Gear Base (B)	15 - 38
G139 1109	Cam Ratchet Bracket	15 - 47
G139 1110	Cam Ratchet Spring	15 - 46
G139 1111	Cam Ratchet Ass'y	15 - 45
G139 1112	Cam Ratchet Solenoid	15 - 27
G139 1113	Screw - M3X5	15 - 50
G139 1114	Tension Unit Base Ass'y	15 - 33
G139 1115	Planetary Gear Base (A)	15 - 31
G139 1116	Planetart Gear - Waste Toner Bottol	15 - 30
G139 1117	Outer Gaer - Waste Toner Bottol	15 - 29
G139 1118	Drive Cam - Waste Toner Bottol	15 - 28
G139 1119	Pin	15 - 18
G139 1120	Damper Cam Link Ass'y	15 - 14
G139 1121	FTR Cam (L)	15 - 21
G139 1122	FTR Cam Spring	15 - 13
G139 1123	FTR Lift Lever	15 - 22

Part No.	Description	Page and Index No.
G139 1124	Plate	15 - 9
G139 1125	STR Release Lever (L)	15 - 23
G139 1126	STR Cam Spring	15 - 6
G139 1127	STR Cam (L)	15 - 24
G139 1128	Tension Cam Link (L)	15 - 25
G139 1129	Center Cam	15 - 15
G139 1130	FTR Cam (R)	15 - 12
G139 1131	FTR Lift Lever (R)	15 - 10
G139 1132	STR Release Lever (R)	15 - 8
G139 1133	Tension Cam Link (R)	15 - 5
G139 1134	Cam Shaft	15 - 17
G139 1135	Sub Shaft	15 - 19
G139 1136	STR Cam (R)	15 - 7
G139 1137	Accumulator Tension Unit	15 - 1
G139 1201	Rotation Switching Solenoid	21 - 13
G139 1202	Star Rubber	21 - 24
G139 1203	Paper Full Sensor	21 - 1
G139 1204	Exit Restraint Lever	21 - 17
G139 1205	Exit Sub-roller	21 - 14
G139 1206	Exit Frame	21 - 18
G139 1207	Discharge Brush	21 - 21
G139 1301	Earth Plate - Laser Unit	11 - 2
G139 1302	Laser Unit	11 - 4
G139 1303	STR Plate Holde	11 - 10
G139 1304	Ih Shield Cover	11 - 9
G139 1305	OPC Unit Sub-guide	11 - 8
G139 1306	IH Ass'y(100V)	11 - 11
G139 1308	Mpt Paper Detection Sensor	11 - 18
G139 1309	Mpt HP Sensor	11 - 19
G139 1310	Mpt Sensor Cover	11 - 20
G139 1311	Washer	11 - 12
G139 1312	Screw - M3x10	11 - 22
G139 1313	Lsu Earth Plate	11 - 5
G139 1314	Regist Stopper (L)	11 - 14
G139 1315	Regist Stopper (R)	11 - 13

Part No.	Description	Page and Index No.
G139 1401	Registration Roller Clutch	11 - 16
G139 1402	Gear Bracket	9 - 32
G139 1403	Pickup Solenoid	9 - 10
G139 1404	Paper Empty/Registration Sensor	9 - 12
G139 1405	Registration Pinch Roller	9 - 3
G139 1406	Registration Roller	9 - 9
G139 1407	Pinch Roller	9 - 26
G139 1408	Pinch Roller Shaft	9 - 28
G139 1409	Paper Feed Roller	9 - 22
G139 1410	Varistor	9 - 15
G139 1411	Paper Feed Unit	9 - 1
G139 1501	Complete - High Voltage Board	29 - 18
G139 1502	Shield Cover - High Voltage Board	29 - 20
G139 1503	Earth Plate	29 - 9
G139 1504	Cassette Holder	29 - 22
G139 1505	HV Earth Plate	29 - 19
G139 1506	Washer	29 - 7
G139 1507	Rubber Foot	29 - 23
G139 1601	Shield Cover Ass'y	29 - 5
G139 1602	Shield Base Cover Ass'y	29 - 6
G139 1701	Power Supply Shield Cover Ass'y	29 - 8
G139 1702	Power Supply Inner Duct	29 - 10
G139 1703	IH Power Supply Board(100V)	29 - 14
G139 1704	Power Supply(100V)	29 - 13
G139 1705	Input Power Cable	29 - 12
G139 1706	Power Supply Base Plate	29 - 17
G139 1707	Earth Plate	29 - 16
G139 1708	Earth Plate Cover	29 - 15
G139 1801	Pickup Roller Shaft	5 - 8
G139 1802	Mpt Paper Holder Spring	5 - 11
G139 1803	Cassette Gear Bracket	5 - 19
G139 1804	Delay Pad Ass'y	5 - 23
G139 1805	Cam Shaft	5 - 31
G139 1806	Right Cam	5 - 32
G139 1807	Paper Chute Spportor Ass'y	5 - 33

Part No.	Description	Page and Index No.
G139 1808	Pin	5 - 35
G139 1901	Cassette Base Plate	7 - 2
G139 1902	Lift Large Spring	7 - 3
G139 1903	Lift Plate (L)	7 - 9
G139 1904	Lift Plate (R)	7 - 13
G139 1905	Screw - M3x8	7 - 21
G139 2001	Black Toner Bottol Case	3 - 29
G139 2002	Cyan Toner Bottol Case	3 - 30
G139 2003	Magenta Toner Bottol Case	3 - 26
G139 2004	Yellow Toner Bottol Case	3 - 25
G139 2020	Duplex Unit Drive Gear	27 - 18
G139 2101	PR Thermistor	19 - 1
G139 2201	IH Assembly 200V	3 - *
G139 2202	IH Power Supply Board 200V	29 - 14
G139 2202	IH Power Supply Board 200V	27 - 47
G139 2203	Power Supply 200V	29 - 13
G139 2204	Rear Cover - RIC	3 - 9
G139 2205	Rear Cover	3 - 9
G139 2206	Str Roller Ass'y	17 - 6
G139 2207	Rear Cover - NRG	3 - 9
G139 2352	Sheet - Color Chart	3 - 31
G139 2356	Decal - Power Source/Toner Supply	3 - 23
G139 2357	Decal - Manual Feed	5 - 41
G139 2358	Decal - Power Source	3 - 24
G139 2360	Decal - Aficio CL3500N	17 - 25
G139 2371	Decal - Aficio CL3500CH	17 - 25
G139 2372	Decal:C7521DN:GES	17 - 25
G139 2375	Decal:C7521DN:NAS	17 - 25
G139 2376	Decal:C7521DN:REX	17 - 25
G139 2377	Decal:C7521N:GES	17 - 25
G139 2378	Decal:C7521N:NAS	17 - 25
G139 2379	Decal:C7521N:REX	17 - 25
G139 2690	Plate - Logo RIC	17 - 8
G139 8507	Manual - Admin	3 - 27
G139 8509	Safety Information Sheet	3 - 28

Part No.	Description	Page and Index No.
G139 8511	Manual	3 - 27

Part No.	Description	Page and Index No.
A267 8561	Safety Information Sheet	3 - 28
G081 1203	Right Cover	3 - 7
G081 1206	Cover - Option Paper Unit Harness	3 - 11
G081 1207	Cassette Cover	3 - 12
G081 1211	Left Axis - Front Cover	3 - 15
G081 1212	Front Support Lever	3 - 13
G081 1213	Right - Axis - Front Cover	3 - 16
G081 1214	Lever Spring	3 - 14
G081 1215	Toner Cartridge Cover	3 - 6
G081 1217	Cartridge Lever B	3 - 10
G081 1218	Cartridge Lever A	3 - 18
G081 1219	Right Cover Hook	3 - 17
G081 1222	Stopper Base	3 - 1
G081 1223	Stopper Guide	3 - 5
G081 1302	Lock Lever Spring	17 - 4
G081 1303	Lock Lever - Front Cover	17 - 3
G081 1305	Plastic Belt	17 - 5
G081 2015	Grounding Plate	27 - 10
G081 2018	Paper Pickup Gear	27 - 11
G081 2022	Transfer Terminal	27 - 17
G081 2103	Feed Idle Gear	25 - 2
G081 2104	Fuser Idle Gear	25 - 21
G081 2105	Cam Gear	25 - 20
G081 2106	Left - PCU Idle Gear	25 - 14
G081 2107	Right - PCU Idle Gear	25 - 15
G081 2108	Left - Transfer Belt Idle Gear	25 - 16
G081 2109	Right - Transfer Belt Idle Gear	25 - 17
G081 2111	Devloper Coupling	25 - 9
G081 2112	Devloper Spring	25 - 8
G081 2115	Granding Plate - Transfer Belt	25 - 23
G081 2116	CMY Home Lever	25 - 13
G081 2117	PCU Home Spring	25 - 12
G081 2118	PCU Home Lever	25 - 11
G081 2119	Bushing - Transfer Belt	25 - 10
G081 2121	Feed Pulley Gear	25 - 19

Part No.	Description	Page and Index No.
G081 2123	Feed Belt	25 - 5
G081 2124	Tension Roller	25 - 35
G081 2125	Flange - Feed Pulley Gear	25 - 5
G081 2126	Flange - Transfer Belt Pulley Gear	25 - 37
G081 2127	CMY Change Gear	25 - 36
G081 2135	Hopper Change Gear	25 - 28
G081 2136	Joint Gear	25 - 27
G081 2137	Hopper Gear A	25 - 25
G081 2138	Hopper Gear B	25 - 24
G081 2139	Hopper Gear C	25 - 26
G081 2141	Tension Roller Spring	25 - 34
G081 2145	PCU Gear	25 - 18
G081 2146	Developer Gear	25 - 7
G081 2202	Gear - Toner Cartridge Drive	23 - 17
G081 2203	Gear - Toner Cartridge Drive	23 - 2
G081 2204	Granding Plate	23 - 18
G081 2206	Middle Terminal Spring	23 - 11
G081 2207	Long Terminal Spring	23 - 13
G081 2208	Short Terminal Spring	23 - 12
G081 2209	Bias Terminal Plate A	23 - 6
G081 2210	Bias Terminal Plate B	23 - 7
G081 2213	Left Holer - Wase Toner Cartridge	13 - 18
G081 2214	Interlock Lever	13 - 15
G081 2215	IH Harnes Cover	13 - 3
G081 2216	Interlock Cover	13 - 2
G081 2218	Right Cover Plastic Strap	13 - 20
G081 2231	Interlock Lever Spring	13 - 14
G081 2233	Fusing Fan Connector Sheet	13 - 6
G081 2255	Bushing	15 - 32
G081 2255	Bushing	9 - 38
G081 2256	Cam Clutch Core	15 - 37
G081 2257	Cam Clutch Slider	15 - 36
G081 2259	Planetary Gear	15 - 39
G081 2260	Outer Gear	15 - 40
G081 2261	Double Teeth Gear	15 - 41

Part No.	Description	Page and Index No.
G081 2262	Cam Shaft Bushing	15 - 42
G081 2263	Plastic Washer	15 - 43
G081 2263	Plastic Washer	17 - 11
G081 2273	Bushing	15 - 11
G081 2278	Home Tab	15 - 20
G081 2289	Clutch Spring	15 - 35
G081 2292	Pick Roller	5 - 37
G081 2338	Switching Lever Spring	21 - 11
G081 2339	Switching Lever	21 - 12
G081 2340	Paper Exit Gear Cover	21 - 2
G081 2342	Holder - Paper Exit Roller	21 - 20
G081 2343	Pinch Roller - A	21 - 22
G081 2344	Pinch Roller Spring	21 - 23
G081 2345	Pinch Roller - B	21 - 25
G081 2348	Exit Paper Guide	21 - 26
G081 2349	Spring	21 - 28
G081 2350	Actuator - Paper Full Sensor	21 - 27
G081 2351	Paper Exit Roller	21 - 16
G081 2352	Exit Roller Rubber	21 - 15
G081 2354	Paper Stopper - A	21 - 19
G081 2371	Cassette Stopper Roller	11 - 1
G081 2375	Paper Exit Roller Joint Gear	21 - 3
G081 2376	Rotation Switching Gear - A	21 - 4
G081 2377	Rotation Switching Gear - B	21 - 8
G081 2378	Outer Gear	21 - 5
G081 2379	Intermediate Gear	21 - 9
G081 2380	Double Teeth Gear	21 - 10
G081 2381	Coupling Gear	21 - 7
G081 2387	Fusing Unit Lock Lever	11 - 6
G081 2388	IH Harness Cover	11 - 7
G081 2389	Cassette Stopper	11 - 3
G081 2391	Plastic Washer	15 - 44
G081 2401	Registration Roller Joint Gear	11 - 17
G081 2403	Inner Gear	21 - 6
G081 2403	Inner Gear	9 - 34

Part No.	Description	Page and Index No.
G081 2404	Outer Gear	9 - 35
G081 2405	Inner Gear-b	9 - 33
G081 2407	Gear	9 - 36
G081 2408	Idle Gear	9 - 39
G081 2409	Feed Gear	9 - 40
G081 2410	Ratchet Arm	9 - 30
G081 2413	Actuator - Paper Registration	9 - 13
G081 2414	Spring	9 - 14
G081 2415	Bushing	9 - 16
G081 2417	Registration Roller Tension	9 - 7
G081 2419	Registration Pinch Roller Gear	9 - 5
G081 2420	Pin	9 - 4
G081 2421	Registration Roller Gear	9 - 8
G081 2423	Registration Paper Guide	9 - 23
G081 2426	Pinch Roller Holder	9 - 25
G081 2428	Pickup Rubber Frame	9 - 19
G081 2429	Pickup Rubber	9 - 18
G081 2430	Pickup Roller Shaft	9 - 20
G081 2431	Pin	9 - 21
G081 2433	Bushing	9 - 31
G081 2434	Plastic Washer	9 - 29
G081 2435	Paper Feed Unit Frame	9 - 17
G081 2441	Guide Rail - MCB	29 - 4
G081 2450	Paper Guide Spring	9 - 27
G081 2452	Pickup Roller Holder	5 - 1
G081 2453	Pickup Rubber	5 - 2
G081 2454	Pickup Roller	5 - 4
G081 2455	Belt - Pickup Roller	5 - 5
G081 2456	Paper Guide - Upper Cassette	5 - 6
G081 2457	Separation Pad Holder	5 - 7
G081 2459	Left Paper Guide	5 - 10
G081 2460	Right Paper Guide	5 - 9
G081 2463	Pinion Gear	5 - 13
G081 2464	Cover - Main Cassette	5 - 14
G081 2466	Paper Tray Base	5 - 16

Part No.	Description	Page and Index No.
G081 2467	Left Cam	5 - 17
G081 2468	Actuator - Paper Empty Sensor	5 - 18
G081 2470	Spring	5 - 20
G081 2471	Pickup Gear	9 - 37
G081 2472	Bushing	9 - 2
G081 2472	Bushing	5 - 21
G081 2473	Roller Gear	5 - 22
G081 2475	Separation Pad Spring	5 - 24
G081 2476	Tray Protector	5 - 25
G081 2477	Idle Gear	5 - 26
G081 2478	Gear Spacer	5 - 27
G081 2479	Gear Cover	5 - 28
G081 2480	Cam Gear	5 - 29
G081 2481	One Way Clutch	5 - 3
G081 2482	Roller Position Arm	5 - 30
G081 2485	Friction Pad	5 - 36
G081 2489	Snap Ring - D4	11 - 15
G081 2491	Recovery Grand Spring	29 - 21
G081 2492	Spring - R	5 - 12
G081 2493	Spring - L	9 - 6
G081 2494	Paper Tray Assy	5 - 15
G081 2496	Pinch Roller Spring	9 - 24
G081 2499	Actuator - Paper Empty Sensor	9 - 11
G081 2501	Paper Guide - Paper Feed Unit	7 - 1
G081 2504	Side Pressure Spring	7 - 4
G081 2505	Left Corner Separator	7 - 5
G081 2506	Left Paper Side Guide	7 - 6
G081 2507	Spring	7 - 7
G081 2508	Slider	7 - 8
G081 2510	Bushing	7 - 10
G081 2511	Plastic Washer	7 - 11
G081 2512	Paper Size Selector	7 - 12
G081 2514	Cassette Base	7 - 14
G081 2515	Right Coner Sperater	7 - 15
G081 2516	Right Paper Side Guide	7 - 16

Part No.	Description	Page and Index No.
G081 2517	Rack	7 - 17
G081 2518	Pinion Gear	7 - 18
G081 2519	Paper Size Adjuster	7 - 19
G081 2520	Paper Size Detector Support	7 - 20
G081 4513	Screw 2.2x16	13 - 29
G081 4528	E-ring	15 - 52
G081 4528	E-ring	23 - 28
G081 4529	E-ring	5 - 34
G081 4529	E-ring	25 - 29
G081 4529	E-ring	15 - 51
G081 4533	Charge Harness	23 - 8
G081 4534	Harness - Charge Output Process	23 - 10
G081 4536	Screw 3x8	3 - 19
G081 4537	Screw 3x12	3 - 20
G081 4556	Rip Lock Screw A	29 - 1
G081 4557	Rip Lock Screw B	29 - 2
G081 5205	Ferrite Core	27 - 2
G081 5210	Fan Motor - DC24V-2.88W	13 - 5
G081 5210	Fan Motor - DC24V-2.88W	23 - 21
G081 5211	Motor - DC24V-8.16W	27 - 14
G081 5302	Paper Size Detector	27 - 39
G081 5304	Sensor - Duplex Unit	27 - 7
G081 5307	Sensor - Toner Cartridge Cover	13 - 7
G081 5307	Sensor - Toner Cartridge Cover	3 - 4
G081 5318	SUB Fusing Fan	27 - 9
G081 5407	Harness - CN10	27 - 25
G081 5417	Harness - CN13	27 - 37
G081 5419	Harness - CN18	27 - 35
G081 5420	Harness - CN23	27 - 34
G081 5422	Harness - CN6	27 - 33
G081 5426	Harness - CN32	27 - 42
G081 5430	Harness	29 - 11
G104 5141	Knob Screw:M3	29 - 28
G105 7299	Ferrite Core:G-p1	3 - 32
G120 2102	Pulley Gear - Transfer Belt	25 - 42

Part No.	Description	Page and Index No.
G120 2201	PCU Guide	13 - 17
G120 2203	BK Change Gear 2	25 - 39
G120 2204	Clutch Bearing 2	25 - 41
G120 2205	Clutch Spacer	25 - 40
G131 6110	Operation Panel	3 - 33
G142 5002	SD-Card:AR-P2:EXP	29 - 33
G142 5513	PCB:CTL:Ares-P2:DOM:Sub-Ass'y	29 - 3
G142 5851	Control Board Plate	29 - 34
G142 5854	Control Board Bracket	29 - 27
G142 5855	Grip - Control Board Plate	29 - 30
G142 5857	Shielding Plate - Sdcard	29 - 31
G142 5858	Knob Screw	29 - 32
G142 5859	Option/Device Panel	29 - 29

Part No.	Description	Page and Index No.
GA00 1052	Plate:Logo:GES	17 - 8
GA00 1053	Plate:Logo:NSA	17 - 8
GA00 1054	Plate:Logo:REX	17 - 8
GA00 3034	Decal - Energystar	3 - 21
GA00 3038	Decal - Inkjet Paper Caution	3 - 22

Part No.	Description	Page and Index No.
0353 0050N	Screw-m3x5	29 -104
0450 3008N	Tapping Screw - M3x8	29 -102
0451 3005N	Tapping Screw:M3x5	29 -101
1150 0373	Power Supply Code:125V 15A NA	3 - 102
1150 0377	Power Supply Code:250V:10A:EU	3 - 102
1407 6465	RAM:FM25L256-PG(rev.ag)	29 -103
1607 1715	Ferrite Core - RFC-5	3 - 101

Part No.	Description	Page and Index No.