# Mail Bin Type 5000

(Code: G312)

For Machine Code: G071 INSTALLATION GUIDE

# Preparation

For a safe operation, read "Safety Information" in Maintenance Guide 1.

Install the Interchange Unit before installing the 4-bin Mailbox. The 4-bin Mailbox cannot be installed without the Interchange Unit installed in advance.

#### **↑** CAUTION:

- The inside of the machine becomes very hot. Do not touch the parts with a label indicating "▲" (means hot surface). Touching "▲" (means hot surface) could result in a burn.
- When installing the 4-bin Mailbox, be sure to hold the sides of them. If you hold the bottom, your hands may get caught and injured.
- When moving the 4-bin Mailbox, hold the center of both sides, and then lift it slowly. Lifting it carelessly or dropping it may cause an injury.

# **∰**Important

- ☐ Check the printer nameplate to confirm the model code.
- ☐ Since either the Finisher or the 4-bin Mailbox can be installed to the printer, the 4-bin Mailbox cannot be installed if the Finisher is already installed to the printer.

- 1 Turn off the power switch, and then unplug the power cable.
- **2** Remove the adhesive tapes.
- **E** Check the contents.
  - Screw




**❖** Two Screws






Four Output Trays



#### Labels


y P&	, Ag	>PS<
, PR	× PSk	>PS<
N N N N N N N N N N N N N N N N N N N	×PS,	>PS<
N N N N N N N N N N N N N N N N N N N	y d v	>P.Sc
ž Ž	š (	× ×

Remove the top cover of the Interchange Unit. First, pull up the stopper (1), and then lift the cover (2).




#### 

- ☐ The removed cover will not be used.
- Hold the 4-bin Mailbox with both hands, and then slowly insert it vertically to the top of the printer.




**6** Open the Bypass Tray.




#### Note


- ☐ Remove paper on the Bypass Tray to prevent them from falling.
- If the Duplex Unit is installed, open it by pushing the catch upwards.




Open the right cover of the printer by pushing up the handle.



Open the right cover of the Interchange Unit.




Fasten the two places with two different kinds of screws as shown in the illustration.




Use a coin to fasten them tightly.


- **𝚱** Note
- ☐ There are two kinds of screws supplied.
- Close the right cover of the Interchange Unit.




Close the right cover of the printer.



- **𝚱** Note
- ☐ Press "PUSH" to close the cover firmly.
- If the Duplex Unit is installed, close it.




- Close the Bypass Tray.
- Fasten the position shown in the illustration with the remaining screw.



Use a coin to fasten it firmly.

# Set the four output trays from the bottom.



#### Note

- ☐ Use the supplied labels to assign the trays for individuals or business groups.
- ☐ After finishing installation, you can check whether the 4-bin Mailbox is installed properly. Print the configuration page from the "List/Test Print" menu. If it is installed properly, you will see "4-bin Mailbox" under the "Options" list.
- ☐ If the 4-bin Mailbox is not installed properly, reinstall from step ①. If you cannot install it properly even after reinstallation, contact your sales or service representative.

### 

See "Using the Control Panel" in the Administrator Reference for printing the configuration page.