

Notes for Users

These notes provide additional information on using this product, and errata for the descriptions in the operating manual. Read these notes together with the User Guide.

Topic	Error	Correction
Making Printer Settings > Making Printer Settings Using the Control Panel	Incomplete Information	Counter <Menu> <ul style="list-style-type: none"> • Show Counter • Print
Making Printer Settings > Making Printer Settings Using the Control Panel > Counter Menu	Incomplete Information	Counter Menu You can check and print out the machine's counter figures. Counters show the number of prints made by the machine. Print counter numbers do not include test patterns printed using "Maintenance", system configurations printed using "Test Print", and counter printouts made using "Counter". ❖ Show Counter <ul style="list-style-type: none"> • Color: This counter shows the number of color originals printed using the printer driver's [Color] setting. • Black: This counter shows a total that includes the number of black and white originals printed and the number of color originals printed using the printer driver's [Black and White] setting. ❖ Print You can print out the machine's counter figures. *For details about displaying counter, see p.2 "Displaying the Counter".

Topic	Error	Correction
Making Printer Settings > Making Printer Settings Using the Control Panel > List/Test Print Menu > Interpreting the Configuration Page	System Reference Information such as the printer's version, attached options, printer language name, and remaining amount of ink are printed in this area.	System Reference Information such as the printer's version, attached options, printer language name, and remaining amount of ink are printed in this area. Unlike [Counter] displayed on the machine's control panel, the "Total Counter" numbers include test patterns printed using "Maintenance", system configurations printed using "Test Print", and counter print-outs made using "Counter".
Making Printer Settings > Making Printer Settings Using the Control Panel > System Menu	Energy Saver <ul style="list-style-type: none"> • <u>E.Saver ON/OFF</u> 	Deleted
Making Printer Settings > Making Printer Settings Using the Control Panel > System Menu	Energy Saver <ul style="list-style-type: none"> • E.Saver Timer Default: <u>15</u>minutes 	Energy Saver <ul style="list-style-type: none"> • E.Saver Timer Default: <u>5</u>minutes

Displaying the Counter

You can display the counter.

- 1 On the control panel, press the **[Menu]** key.



- 2 Press **[▲]** or **[▼]** to scroll to "Counter" on the display, and then press the **[#Enter]** key.

```
<Menu>
Counter
```

- 3 Press **[▲]** or **[▼]** to scroll to "Show Counter" on the display, and then press the **[#Enter]** key.

```
<Counter>
1. Show Counter
```

- 4 Checks the "Color" and "Black" on the display.

```
Color: 12345678
Black: 12345678
```

- 5 Press the **[Online]** key.
The operating screen appears.

User Guide>Monitoring and Configuring the Printer>Using Web Browser>Notifying the Printer Status by E-mail

❖ Error Notification Group

❖ Group to Notify 1-3

Functions	Selectable value	Default
Group Name	19 characters max. (1-byte alphanumeric) (2-byte characters available)	None
E-mail Language	English Japanese German French Italian Spanish Dutch Swedish Danish Norwegian Portuguese	English
Subject	31 characters max. (1-byte alphanumeric) (2-byte characters available)	None
Text	255 characters max. (1-byte alphanumeric) (2-byte characters available)	None

❖ Recipient Setup

❖ Recipient address 1-10

Functions	Selectable value	Default
Name	19 characters max. (1-byte alphanumeric) (2-byte characters available)	None
E-mail Address	127 characters max. (1-byte alphanumeric)	None

❖ Email Transmission Function Alerts

This section lists the settings for notification by e-mail.

Functions	Selectable value	Default
Error Notification Group 1-3	ON OFF	ON
Notify when error	Occurs Occurs & Fixed	Occurs
Notify within (min.)	0 5 10 15 20 25 30	5

❖ **Counter Notification Group**

❖ **Group to Notify**

Functions	Selectable value	Default
E-mail Language	English Japanese German French Italian Spanish Dutch Swedish Danish Norwegian Portuguese	English
Subject	31 characters max. (1-byte alphanumeric) (2-byte characters available)	None

❖ Destinations

❖ Destinations 1-10

Functions	Selectable value	Default
Name	19 characters max. (1-byte alpha- numerics) (2-byte characters available)	None
E-mail Address	127 characters max. (1-byte alpha- numerics)	None


❖ Machine Total

This section lists the settings for counter notification by e-mail.

Functions	Selectable value	Default
Counter Notification Group	ON OFF	OFF
Notification Method	Number of Pages Number of Pages & Monthly	Number of Pages
Notify Every	100 200 300 400 500 1000 2000 (pages)	100 (pages)
Notification Day	1-28	1

Copyright © 2006,2007

Printed in China

EN  J010-6606A



J0106606A