

Setup Precautions

Follow the precautions below to avoid malfunctions resulting from incorrect setup.

Use the print cartridge that is supplied with the machine

Before powering the machine for the first time, be sure to install the unused print cartridge that is supplied. Installing any other cartridge could result in incomplete ink filling and malfunction.

Do not handle the machine while the cartridge is being filled

Ink filling begins when the machine's power is switched on. Until the "Loading Ink..." message disappears from the control panel.

Copyright © 2006

Printed in China

GB (GB) EN (USA) 8A600883



8A600883