

Model T-P1s (J015)

PARTS CATALOG

First edition, July 2007

Ricoh Company, LTD.

Model T-P1s (J015)

PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

Toscana-P1s	(J015)
Network Interface Board Type GX3a	(J517)

Model T-P1s (J015)

Model T-P1s (J015)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.Exterior 1 (J015).....	2
2.Exterior 2 (J015).....	4
3.Paper Tray ((J015)	6
4.Process Section (J015)	8
5.Paper Exit Section (J015)	10
6.Electrical Section (J015)	12
7.Decal And Document (J015)	14
Parts Index	18

July ,30 ' 2007

1.Exterior 1 (J015)




1.Exterior 1 (J015)

Index No.	Part No.	Description	Q'ty Per Assembly
1	J015 1526	Front Cover - Ink Cartridge NA	1
1	J015 1524	Front Cover - Ink Cartridge EU RIC	1
1	J015 1527	Front Cover - Ink Cartridge NRG	1
2	J007 3018	Friction Pad Unit	1
3	J015 1501	Right Cover - NA	1
3	J015 1551	Right Cover - EU	1
4	J015 1011	Lever:Lock	2
5	J015 1012	Compression Spring	1
6	J015 1503	Cover:Rear:P1s	1
6	J015 1553	Cover:Rear:P1s:EU	1
7	J015 1070	Filter:Fan	1
8	J015 1522	Rear Cover - NA	1
8	J015 1523	Rear Cover - EU	1
9	J015 1542	Cover:Tank	1
10	J015 1548	Cover:NIC:NON	1
11	J015 0152	Cover:Upper	1
12	J015 2307	Decal:Pick-Up Paper Jam:P1s:Exp	1
13	J015 1520	Rear Middle Cover - NA	1
13	J015 1521	Rear Middle Cover - EU	1
14	J001 2314	Decal:WEEE - EU	1
15	J015 5511	Power Supply Cord - NA	1
15	J015 5512	Power Supply Cord - EU	1
16	J015 6651	CD-ROM:Driver:Manual:Tos-P1s:NA	1
17	J015 6620	Installation Procedure:English:P1s/W	1
18	J015 6624	Installation Procedure:Safety:P1s/W:NA	1
18	J015 6622	Installation Procedure:Safety:P1s/W:EU	1
19	J517 0017	Option:NIC:Exp:P1s:Ass'y	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0452 3008N	Tapping Screw - M3x8	
102	0452 3010N	Binding Self-Tapping Screw:3x10	
103	0454 3006Q	Tapping Screw - M3x6	

2.Exterior 2 (J015)




2.Exterior 2 (J015)

Index No.	Part No.	Description	Q'ty Per Assembly
1	J015 1506	Ink Cartridge Cover - NA	1
1	J015 1556	Cover - Ink Cartridge	1
2	J015 0175	Operation Panel - NA	1
2	J015 0173	Operation Panel - EU	1
3	J012 1508	Plate:Logo:RIC	1
3	J012 1515	Logo Plate - NSA	1
3	J012 1516	Logo Plate - REX	1
3	J012 1517	Logo Plate - GES	1
4	J015 5440	Harness:Safety Switch:Front:Tos-P1s	1
5	J015 1544	Cover:Safety Switch	1
6	J015 0154	Cover:Front	1
6	J015 0174	Front Cover - EU RIC	1
6	J015 0177	Front Cover - NRG	1
7	J015 4906	Stopper:Paper	1
8	J015 4908	Roller:Stopper:Paper	1
9	J015 5395	Harness:OPU:AU:Tos-P1s	1
10	G020 5626	Push Switch	1
11	J015 4902	Cover:Exit Roller	1
12	B044 3191	Tapping Screw-M3x8	3
13	J007 5291	PCB:CCB:Tos	1
14	J007 5451	Harness:CCB:Connecting	1
15	J007 4696	Positioning Plate:Cartridge:Tos	1
16	J015 1500	Left Cover - NA	1
16	J015 1560	Left Cover - EU	1
17	J015 1550	Inner Cover:Dial	1
18	J015 1513	Dial Cover - NA	1
18	J015 1563	Dial Cover - EU	1
19	J015 1541	Cover - Power Supply Unit NA	1
19	J015 1561	Cover - Power Supply Unit	1
20	J015 5478	Harness:Jam:Connecting	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0452 3008N	Tapping Screw - M3x8	

3.Paper Tray ((J015)




3.Paper Tray ((J015)



Index No.	Part No.	Description	Q'ty Per Assembly
1	J007 3025	Base Plate:Exp:Ass'y	1
2	J015 2341	Decal:P1s:ES	1
3	J012 3019	Arm:Cassette	2
4	J001 3057	Tension Spring:Base:P1	2
5	J012 3003	End Fence:Tos-C1	1
6	J015 3050	Side Fence:Right	1
7	J015 3040	Side Fence:Left	1
8	J001 3008	Gear:Side Fence	1
9	J015 0031	Cassette Unit	1
10	J015 2301	Decal:Cassette Work	1
11	J015 0496	EIT Tray Unit	1
12	J016 2303	Decal:Paper:Caution:Exp	1
13	J001 3061	Discharge Brush:Base Plate	1


Index No.	Part No.	Description	Q'ty Per Assembly

4.Process Section (J015)





5. Paper Exit Section (J015)




5.Paper Exit Section (J015)

Index No.	Part No.	Description	Q'ty Per Assembly
1	J007 2990	Guide:Reverse	1
2	J001 2989	Guide:Sheet:Reverse	1
3	J015 2303	Decal:Reverse:Right	1
4	J001 2813	Spring:Pawl:Guide	2
5	J001 2811	Pawl:Guide:Reverse	2
6	J007 2806	Feeler:Registration Sensor	1
7	J001 2807	Spring:Feeler:Registration Sensor	1
8	J001 2814	Spring:Roller:No.1	2
9	J001 2991	Pickoff Pawl	8
10	J001 2810	Bushing:Roller:No.1	2
11	J001 2808	Roller:No.1	1
12	J001 2804	Gear:Transport Roller:Pressure	1
13	J015 2302	Decal:Reverse:Left	1
14	J007 3016	Spring Clutch:Feed	1
15	J015 5480	Harness:Inlet	1
15	J015 5481	Harness:Inlet:Tos-P1s:Exp	1
16	J006 2992	Spring:Roller:Leading Edge	4
17	J015 2701	Pressure Plate:Roller:Leading Edge:	
17		Right:Ass'y	1
18	J007 5476	Harness:PDET2:Connecting	1
19	J015 2700	Pressure Plate:Roller:Leading Edge:Ass'y	1
20	J015 5439	Harness:Safety Switch:Rear	1
21	GW02 0020	Photointerruptor:LG248NL1	1
22	J015 5130	PCB:CTL:AU:Tos-P1s:Ass'y	1
23	J015 5479	Harness:Jam	1
24	J015 5442	Harness:Motor:Tos-P1s	1
25	J015 5437	Harness:CCB	1
26	J015 5455	Harness:Sensor:Rear	1
27	J015 5456	Harness:Sensor:Front	1
28	J015 5434	Harness:HVP:Tos-P1s	1
28	J015 5435	Harness:HVP:Tos-P1s:EU	1
29	J015 5489	Harness:Paper Feed Sensor	1
30	J007 5472	Harness:Trailing Edge:Connecting	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0805 0088	Retaining Rings-E:Silencer:DIA6	
103	1403 1384	Photointerruptor:SG1291-RC86	
104	0950 4006N	Screw:Spring Washer:M4x6	

6.Electrical Section (J015)




6.Electrical Section (J015)

Index No.	Part No.	Description	Q'ty Per Assembly
1	J007 5360	Power Pack	1
2	J007 1055	Cover - Power Pack	1
3	J007 5330	Power Supply Unit(100V)	1
3	J007 5331	Power Supply Unit:Tos/Pie:EU	1
4	J015 5411	Harness:Power Supply Unit	1
5	J007 4200	Holder - Left	1
6	J015 1031	Bracket:Fan:2	1
7	J015 1030	Shielding Plate:Bracket:Fan	1
8	J007 5621	Fan:MM60:15mm:37V	1
9	J015 0411	Maintenance Unit	1
10	J015 5465	Harness:Used Developer:Base:Tos-P1s	1
11	J012 1008	Rubber Foot	2
12	J007 4062	Guide Plate:DC Solenoid	1
13	AX11 0125	DC Solenoid:Valve	1
14	J007 4061	Lever:Actuator:Valve	1
15	AW02 0150	Photointerruptor:Flat:7mm	1
16	J001 4604	Tension Spring:Lever	1
17	J016 1059	Cover:Power Supply Cord - EU	1
18	J015 3542	Shadeing Plate:FFC:Carriage:P1s	1
19	J015 3510	Cover:Shadeing Plate:FFC:Carriage:P1s	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3008N	Tapping Screw - M3x8	
102	0451 3006N	Tapping Screw - 3x6	
103	1105 0516	Clamp	
104	0451 4020N	Tapping Screw - M4x20	
105	0353 0040N	Screw:M3x4	
106	0452 3008N	Tapping Screw - M3x8	

7.Decal And Document (J015)



7.Decal And Document (J015)

Index No.	Part No.	Description	Q'ty Per Assembly
1	J015 2341	Decal:P1s:ES	1
2	J015 2301	Decal:Cassette Work	1
3	J015 2304	Decal:Operate:Dial:P1s	1
4	J015 2303	Decal:Reverse:Right	1
5	J015 2302	Decal:Reverse:Left	1
6	J001 2314	Decal:WEEE - EU	1
7	J016 2303	Decal:Paper:Caution:Exp	1
8	J016 3540	Decal:Lever	1

Index No.	Part No.	Description	Q'ty Per Assembly

Parts Index

Parts Index

Part No.	Description	Page and Index No.
J015 0031	Cassette Unit	7 - 9
J015 0152	Cover:Upper	3 - 11
J015 0154	Cover:Front	5 - 6
J015 0173	Operation Panel - EU	5 - 2
J015 0174	Front Cover - EU RIC	5 - 6
J015 0175	Operation Panel - NA	5 - 2
J015 0177	Front Cover - NRG	5 - 6
J015 0411	Maintenance Unit	13 - 9
J015 0496	EIT Tray Unit	7 - 11
J015 1011	Lever:Lock	3 - 4
J015 1012	Compression Spring	3 - 5
J015 1030	Shielding Plate:Bracket:Fan	13 - 7
J015 1031	Bracket:Fan:2	13 - 6
J015 1070	Filter:Fan	3 - 7
J015 1500	Left Cover - NA	5 - 16
J015 1501	Right Cover - NA	3 - 3
J015 1503	Cover:Rear:P1s	3 - 6
J015 1506	Ink Cartridge Cover - NA	5 - 1
J015 1513	Dial Cover - NA	5 - 18
J015 1520	Rear Middle Cover - NA	3 - 13
J015 1521	Rear Middle Cover - EU	3 - 13
J015 1522	Rear Cover - NA	3 - 8
J015 1523	Rear Cover - EU	3 - 8
J015 1524	Front Cover - Ink Cartridge EU RIC	3 - 1
J015 1526	Front Cover - Ink Cartridge NA	3 - 1
J015 1527	Front Cover - Ink Cartridge NRG	3 - 1
J015 1541	Cover - Power Supply Unit NA	5 - 19
J015 1542	Cover:Tank	3 - 9
J015 1544	Cover:Safety Switch	5 - 5
J015 1548	Cover:NIC:NON	3 - 10
J015 1550	Inner Cover:Dial	5 - 17
J015 1551	Right Cover - EU	3 - 3
J015 1553	Cover:Rear:P1s:EU	3 - 6
J015 1556	Cover - Ink Cartridge	5 - 1
J015 1560	Left Cover - EU	5 - 16

Part No.	Description	Page and Index No.
J015 1561	Cover - Power Supply Unit	5 - 19
J015 1563	Dial Cover - EU	5 - 18
J015 2301	Decal:Cassette Work	15 - 2
J015 2301	Decal:Cassette Work	7 - 10
J015 2302	Decal:Reverse:Left	11 - 13
J015 2302	Decal:Reverse:Left	15 - 5
J015 2303	Decal:Reverse:Right	15 - 4
J015 2303	Decal:Reverse:Right	11 - 3
J015 2304	Decal:Operate:Dial:P1s	15 - 3
J015 2304	Decal:Operate:Dial:P1s	9 - 13
J015 2307	Decal:Pick-Up Paper Jam:P1s:Exp	3 - 12
J015 2341	Decal:P1s:ES	7 - 2
J015 2341	Decal:P1s:ES	15 - 1
J015 2700	Pressure Plate:Roller:Leading Edge:Ass'y	11 - 19
J015 2701	Pressure Plate:Roller:Leading Edge:Right:Ass'y	11 - 17
J015 2890	Timing Belt:B30S2M452	9 - 15
J015 2891	Pulley:Dial:Jam	9 - 14
J015 2892	Pulley 75T	9 - 7
J015 3040	Side Fence:Left	7 - 7
J015 3050	Side Fence:Right	7 - 6
J015 3502	DC Motor 37V 29.6W	9 - 24
J015 3510	Cover:Shadeing Plate:FFC:Carriage:P1s	13 - 19
J015 3541	Lever:Guide Rod:Tos-P1s:Ass'y	9 - 33
J015 3542	Shadeing Plate:FFC:Carriage:P1s	13 - 18
J015 4900	Exit Roller:Ass'y	9 - 3
J015 4902	Cover:Exit Roller	5 - 11
J015 4906	Stopper:Paper	5 - 7
J015 4908	Roller:Stopper:Paper	5 - 8
J015 5130	PCB:CTL:AU:Tos-P1s:Ass'y	11 - 22
J015 5205	DC Motor 37V 25.9W	9 - 1
J015 5395	Harness:OPU:AU:Tos-P1s	5 - 9
J015 5411	Harness:Power Supply Unit	13 - 4
J015 5434	Harness:HVP:Tos-P1s	11 - 28
J015 5435	Harness:HVP:Tos-P1s:EU	11 - 28
J015 5437	Harness:CCB	11 - 25

Part No.	Description	Page and Index No.
J015 5439	Harness:Safety Switch:Rear	11 - 20
J015 5440	Harness:Safety Switch:Front:Tos-P1s	5 - 4
J015 5442	Harness:Motor:Tos-P1s	11 - 24
J015 5455	Harness:Sensor:Rear	11 - 26
J015 5456	Harness:Sensor:Front	11 - 27
J015 5465	Harness:Used Develper:Base:Tos-P1s	13 - 10
J015 5478	Harness:Jam:Connecting	5 - 20
J015 5479	Harness:Jam	11 - 23
J015 5480	Harness:Inlet	11 - 15
J015 5481	Harness:Inlet:Tos-P1s:Exp	11 - 15
J015 5489	Harness:Paper Feed Sensor	11 - 29
J015 5511	Power Supply Cord - NA	3 - 15
J015 5512	Power Supply Cord - EU	3 - 15
J015 6620	Installation Procedure:English:P1s/W	3 - 17
J015 6622	Installation Procedure:Safety:P1s/W:EU	3 - 18
J015 6624	Installation Procedure:Safety:P1s/W:NA	3 - 18
J015 6651	CD-ROM:Driver:Manual:Tos-P1s:NA	3 - 16

Part No.	Description	Page and Index No.
B044 3191	Tapping Screw-M3x8	5 - 12
G020 5626	Push Switch	5 - 10
J001 1168	Slider:Transport Roller	9 - 8
J001 2314	Decal:WEEE - EU	3 - 14
J001 2314	Decal:WEEE - EU	15 - 6
J001 2804	Gear:Transport Roller:Pressure	11 - 12
J001 2807	Spring:Feeler:Registration Sensor	11 - 7
J001 2808	Roller:No.1	11 - 11
J001 2810	Bushing:Roller:No.1	11 - 10
J001 2811	Pawl:Guide:Reverse	11 - 5
J001 2813	Spring:Pawl:Guide	11 - 4
J001 2814	Spring:Roller:No.1	11 - 8
J001 2928	Timing Pulley:Exit Roller	9 - 11
J001 2989	Guide:Sheet:Reverse	11 - 2
J001 2991	Pickoff Pawl	11 - 9
J001 3008	Gear:Side Fence	7 - 8
J001 3057	Tension Spring:Base:P1	7 - 4
J001 3061	Discharge Brush:Base Plate	7 - 13
J001 4604	Tension Spring:Lever	13 - 16
J006 1148	Spring:Tightener:Drive	9 - 22
J006 2927	Timing Belt:B30S2M88	9 - 12
J006 2992	Spring:Roller:Leading Edge	11 - 16
J006 3405	Holder:Pressure Roller:P-P2W	9 - 28
J006 3406	Spring Plate:Holder:Pressure Roller	9 - 26
J007 1055	Cover - Power Pack	13 - 2
J007 1118	Bracket:Tightener:Ass'y	9 - 20
J007 1122	Timing Belt:227ST1.5-6.0	9 - 5
J007 1130	Pulley:Tightener:Drive	9 - 21
J007 1161	Timing Pulley - 140T	9 - 6
J007 2806	Feeler:Registration Sensor	11 - 6
J007 2990	Guide:Reverse	11 - 1
J007 3016	Spring Clutch:Feed	11 - 14
J007 3018	Friction Pad Unit	3 - 2
J007 3025	Base Plate:Exp:Ass'y	7 - 1
J007 3410	Cover:Carriage:Tos	9 - 32

Part No.	Description	Page and Index No.
J007 3513	Cam:Guide Rod:Right	9 - 35
J007 3514	Cam:Guide Rod:Left	9 - 17
J007 3517	Spring:Guide Rod:1	9 - 19
J007 3518	Spring:Guide Rod:2	9 - 18
J007 3519	Ground Plate:Guide Rod:Left	9 - 16
J007 3520	Sheet:Encoder:Tos	9 - 40
J007 3524	Cam:Guide Rod:Right Front	9 - 36
J007 3525	Timing Belt:524ST55-6.0	9 - 25
J007 3528	Shaft:Pressure Roller	9 - 30
J007 3533	Spring:Pressure Roller:30n	9 - 29
J007 3534	Spring:Lever:3n	9 - 37
J007 3535	Pressure Roller:Press Fit	9 - 31
J007 3539	Bracket:Holder:Pressure Roller	9 - 27
J007 3540	Plate Spring - Guide Rod	9 - 34
J007 4061	Lever:Actuator:Valve	13 - 14
J007 4062	Guide Plate:DC Solenoid	13 - 12
J007 4200	Holder - Left	13 - 5
J007 4696	Positioning Plate:Cartridge:Tos	5 - 15
J007 5291	PCB:CCB:Tos	5 - 13
J007 5330	Power Supply Unit(100V)	13 - 3
J007 5331	Power Supply Unit:Tos/Pie:EU	13 - 3
J007 5360	Power Pack	13 - 1
J007 5451	Harness:CCB:Connecting	5 - 14
J007 5470	Harness:Main:Seconddary:Motor	9 - 2
J007 5472	Harness:Trailing Edge:Connecting	11 - 30
J007 5476	Harness:PDET2:Connecting	11 - 18
J007 5621	Fan:MM60:15mm:37V	13 - 8
J007 5655	PCB:SENC:Tos/Pie	9 - 23
J012 1008	Rubber Foot	13 - 11
J012 1508	Plate:Logo:RIC	5 - 3
J012 1515	Logo Plate - NSA	5 - 3
J012 1516	Logo Plate - REX	5 - 3
J012 1517	Logo Plate - GES	5 - 3
J012 3003	End Fence:Tos-C1	7 - 5
J012 3019	Arm:Cassette	7 - 3

Part No.	Description	Page and Index No.
J016 1059	Cover:Power Supply Cord - EU	13 - 17
J016 2303	Decal:Paper:Caution:Exp	7 - 12
J016 2303	Decal:Paper:Caution:Exp	15 - 7
J016 3540	Decal:Lever	9 - 41
J016 3540	Decal:Lever	15 - 8
J517 0017	Option:NIC:Exp:P1s:Ass'y	3 - 19

Part No.	Description	Page and Index No.
AA08 2101	Bushing:MM6xMM10x6	9 - 9
AW02 0150	Photointerruptor:Flat:7mm	13 - 15
AW50 0023	Push Switch	9 - 4
AX11 0125	DC Solenoid:Valve	13 - 13
GW01 0008	Photo Refiection Sensor:SG113-RC80	9 - 39
GW02 0020	Photointerruptor:LG248NL1	9 - 38
GW02 0020	Photointerruptor:LG248NL1	11 - 21

Part No.	Description	Page and Index No.
0353 0040N	Screw:M3x4	13 - 105
0451 3006N	Tapping Screw - 3x6	11 - 101
0451 3006N	Tapping Screw - 3x6	5 - 101
0451 3006N	Tapping Screw - 3x6	9 - 101
0451 3006N	Tapping Screw - 3x6	13 - 102
0451 3008N	Tapping Screw - M3x8	13 - 101
0451 4020N	Tapping Screw - M4x20	13 - 104
0452 3008N	Tapping Screw - M3x8	13 - 106
0452 3008N	Tapping Screw - M3x8	3 - 101
0452 3008N	Tapping Screw - M3x8	5 - 102
0452 3010N	Binding Self-Tapping Screw:3x10	3 - 102
0454 3006Q	Tapping Screw - M3x6	3 - 103
0720 0025E	Retaining Ring - M2.5	9 - 103
0805 0088	Retaining Rings-E:Silencer:DIA6	11 - 102
0950 4006N	Screw:Spring Washer:M4x6	11 - 104
0951 3005N	Screw:Polished Round:M3x5	9 - 102
1105 0516	Clamp	13 - 103
1403 1384	Photointerruptor:SG1291-RC86	11 - 103

