


P C600

PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1	Covers		3P
2	Paper Cassette		5P
3	Paper Feed Section 1		7P
4	Paper Feed Section 2		9P
5	Conveying Section 1		11P
6	Conveying Section 2		13P
7	Laser Scanner Section		15P
8	Developer Section		17P
9	Image Formation Section		19P
10	Transfer Section		21P
11	Fuser Section		23P
12	Drive Section		25P
13	Electrical Components 1		27P
14	Electrical Components 2		29P
15	Operation Section		31P
16	Accessories		33P
17	Special Tools		35P
	Parts Index		37P

1. Covers




1. Covers

Index No.	Part No.	Description	Q'ty Per Assembly
1	M0CJ1251	COVER:RIGHT	1
2	M0CJ1252	COVER:RIGHT:UPPER:A	1
3	M0CJ1253	COVER:RIGHT:UPPER:B	1
4	M0CJ1254	COVER:CONNECTOR	1
5	M0CJ1255	COVER:OPTION	1
6	M0CJ1256	COVER:INNER:RIGHT	1
7	M0CJ1257	COVER:FRONT:UPPER:LEFT	1
8	M0CJ1258	COVER:FRONT:UPPER:RIGHT	1
9	M0CJ1259	COVER:FRONT:UPPER:MID	1
10	M0CJ1260	COVER:FRONT:MID:A	1
11	M0CJ1261	COVER:FRONT:MID:B	1
12	M0CJ1262	LID:TOP:PRINTER	1
13	M0CJ1263	COVER:NFC	1
14	M0CJ1265	COVER:LEFT	1
15	M0CJ1266	COVER:WASTE	1
16	M0CJ1267	COVER:INNER:LEFT	1
17	M0CJ1268	DUCT:LID:TOP	1
18	M0CJ1269	STAY:LID:TOP	1
19	M0CJ1270	COVER:TOP	1
20	M0CJ1271	COVER:LEFT:UPPER	1
21	M0CJ1272	COVER:WASTE:LOW	1
22	M0CJ1274	COVER:RIGHT:BOTTOM	1
23	M0CJ1275	COVER:LEFT:BOTTOM	1
24	M0CJ1290	HOLDER:MAIN:SWITCH	1
25	M0CJ1291	STRAP:COVER:REAR	2
26	M0CJ1292	KEY:SW	1
27	M0CJ1293	LUTCH	1
28	M0CJ2760	LABEL:JAM	1
29	M0CJ1667	PLATE:NUT	1
30	D0A45750	PCB:NFC:ASS'Y	1

[illegible]


2. Paper Cassette



2. Paper Cassette

[illegible][illegible]


3. Paper Feed Section 1



3. Paper Feed Section 1

[illegible][illegible]


4. Paper Feed Section 2



4. Paper Feed Section 2

[illegible][illegible]


5. Conveying Section 1



5. Conveying Section 1

[illegible][illegible]


6. Conveying Section 2



6. Conveying Section 2

[illegible][illegible]


7. Laser Scanner Section



7. Laser Scanner Section

[illegible][illegible]


8. Developer Section



8. Developer Section

[illegible][illegible]


9. Image Formation Section



9. Image Formation Section

[illegible][illegible]


10. Transfer Section



10. Transfer Section

[illegible][illegible]


11. Fuser Section



11. Fuser Section

[illegible][illegible]

12. Drive Section




12. Drive Section

Index No.	Part No.	Description	Q'ty Per Assembly
1	M0CJ1749	FAN:MOTOR:SP:(FAN5, FAN6)	2
2	M0CJ1151	BUSH:DRIVE	1
3	M0CJ1152	GEAR:Z23L	1
4	M0CJ1153	HOUSING:MPF:DRIVE:A	1
5	M0CJ1154	SPRING:INPUT:MPF	1
6	M0CJ1155	SOLENOID:TONE:(SOL1)	1
7	M0CJ1156	GEAR:Z14L:MPF	1
8	M0CJ1157	GEAR:Z31R-Z24S	1
9	M0CJ1158	GEAR:INPUT:A:Z36S	1
10	M0CJ1159	GEAR:INPUT:B:Z36S	1
11	M0CJ1160	HOUSING:MPF:DRIVE:B	1
12	M0CJ1161	PIN:DRIVE:MPF:A	1
13	M0CJ1162	CAM:MPF	1
14	M0CJ1163	GEAR:Z24L	1
15	M0CJ1670	PARTS_MOTOR-B:(M5, M6, M8)	3
16	M0CJ1165	GEAR:Z35R	1
17	M0CJ1166	GEAR:Z63R-Z24R	1
18	M0CJ1669	FEED:DRIVE:ASSY:SP	1
19	M0CJ1671	MOTOR-BL:W10:SP:(M4)	1
20	M0CJ1673	CLUTCH:35:Z35R:SP:(CL1, CL2, CL4, CL5)	5
21	M2811055	CLUTCH:50:Z35:(CL3)	1
22	M0CJ1740	MOTOR:EJECT:SP:(M3)	1
23	M0CJ1672	MOTOR-PM:FUSER:SP:(M2)	1
24	M0CJ1173	PLATE:MIDDLE:DRIVE:A	1
25	M0CJ1174	GEAR:Z43R-Z16S	1
26	M0CJ1175	GEAR:Z26S	1
27	M0CJ1668	DRIVE UNIT	1
28	M0CJ1674	DC:MOTOR:ASSY:SP:(M7)	1

[illegible]


13. Electrical Components 1



13. Electrical Components 1

[illegible][illegible]


14. Electrical Components 2



14. Electrical Components 2

[illegible][illegible]


15. Operation Section



15. Operation Section

[illegible][illegible]


16. Accessories



16. Accessories

[illegible][illegible]

17. Special Tools



17. Special Tools

[illegible][illegible]

Parts Index

Parts Index

Part No.	Description	Page and Index No.
B6455030	SD Card 2GB	17-1
B6455040	SD Card 8GB	17-2
B6455060	SD Card 16GB	17-3
D0A45750	PCB:NFC:ASS'Y	1-30
M0CJ1050	LABEL:PUSH	5-3
M0CJ1056	HOLDER:LEFT	15-2
M0CJ1057	BRACKET:FRONT:HV	14-8
M0CJ1105	SW.PUSH:(SW3)	14-6
M0CJ1106	DUCT:LEFT:INNER	13-8
M0CJ1109	GUIDE:CASSETTE:LEFT	13-11
M0CJ1110	SWITCH:SIZE:(SW4)	13-12
M0CJ1111	GEAR:Z33R-Z32R	13-13
M0CJ1112	GEAR:Z28S-Z13S	13-14
M0CJ1113	GEAR:Z41S	13-15
M0CJ1114	HOLDER:GEAR	13-16
M0CJ1116	BELT:S2M:Z350	13-18
M0CJ1117	GUIDE:TOP:LEFT	13-19
M0CJ1118	SLIDER:CLEANER:ID	13-20
M0CJ1120	PIN:COVER	13-24
M0CJ1122	LEVER:INTERLOCK	14-11
M0CJ1123	GUIDE:TOP:RIGHT	14-13
M0CJ1151	BUSH:DRIVE	12-2
M0CJ1152	GEAR:Z23L	12-3
M0CJ1153	HOUSING:MPF:DRIVE:A	12-4
M0CJ1154	SPRING:INPUT:MPF	12-5
M0CJ1155	SOLENOID:TONER:(SOL1)	12-6
M0CJ1156	GEAR:Z14L:MPF	12-7
M0CJ1157	GEAR:Z31R-Z24S	12-8
M0CJ1158	GEAR:INPUT:A:Z36S	12-9
M0CJ1159	GEAR:INPUT:B:Z36S	12-10
M0CJ1160	HOUSING:MPF:DRIVE:B	12-11
M0CJ1161	PIN:DRIVE:MPF:A	12-12
M0CJ1162	CAM:MPF	12-13
M0CJ1163	GEAR:Z24L	12-14
M0CJ1165	GEAR:Z35R	12-16

Part No.	Description	Page and Index No.
M0CJ1166	GEAR:Z63R-Z24R	12-17
M0CJ1173	PLATE:MIDDLE:DRIVE:A	12-24
M0CJ1174	GEAR:Z43R-Z16S	12-25
M0CJ1175	GEAR:Z26S	12-26
M0CJ1251	COVER:RIGHT	1-1
M0CJ1252	COVER:RIGHT:UPPER:A	1-2
M0CJ1253	COVER:RIGHT:UPPER:B	1-3
M0CJ1254	COVER:CONNECTOR	1-4
M0CJ1255	COVER:OPTION	1-5
M0CJ1256	COVER:INNER:RIGHT	1-6
M0CJ1257	COVER:FRONT:UPPER:LEFT	1-7
M0CJ1258	COVER:FRONT:UPPER:RIGHT	1-8
M0CJ1259	COVER:FRONT:UPPER:MID	1-9
M0CJ1260	COVER:FRONT:MID:A	1-10
M0CJ1261	COVER:FRONT:MID:B	1-11
M0CJ1262	LID:TOP:PRINTER	1-12
M0CJ1263	COVER:NFC	1-13
M0CJ1265	COVER:LEFT	1-14
M0CJ1266	COVER:WASTE	1-15
M0CJ1267	COVER:INNER:LEFT	1-16
M0CJ1268	DUCT:LID:TOP	1-17
M0CJ1269	STAY:LID:TOP	1-18
M0CJ1270	COVER:TOP	1-19
M0CJ1271	COVER:LEFT:UPPER	1-20
M0CJ1272	COVER:WASTE:LOW	1-21
M0CJ1274	COVER:RIGHT:BOTTOM	1-22
M0CJ1275	COVER:LEFT:BOTTOM	1-23
M0CJ1290	HOLDER:MAIN:SWITCH	1-24
M0CJ1291	STRAP:COVER:REAR	1-25
M0CJ1292	KEY:SW	1-26
M0CJ1293	LUTCH	1-27
M0CJ1400	OPERATION SUB-UNIT:ASS'Y	15-1
M0CJ1651	PCU	9-1
M0CJ1652	CHARGE UNIT	9-2
M0CJ1653	INTERMEDIATE TRANSFER UNIT	10-1

Part No.	Description	Page and Index No.
M0CJ1654	OPTICAL WRITTING UNIT:KM	7-1
M0CJ1655	OPTICAL WRITTING UNIT:CY	7-2
M0CJ1658	DEVELOPMENT UNIT:BK	8-1
M0CJ1659	DEVELOPMENT UNIT:Y	8-4
M0CJ1660	DEVELOPMENT UNIT:M	8-2
M0CJ1661	DEVELOPMENT UNIT:C	8-3
M0CJ1662	REAR COVER:500 PRT ASSY(NA/AP)	5-1
M0CJ1663	REAR COVER:500 PRT ASSY(EU)	5-1
M0CJ1666	HOOK:DU:RELEASE	5-2
M0CJ1667	PLATE:NUT	1-29
M0CJ1668	DRIVE UNIT	12-27
M0CJ1669	FEED:DRIVE:ASSY:SP	12-18
M0CJ1670	PARTS_MOTOR-B:(M5, M6, M8)	12-15
M0CJ1671	MOTOR-BL:W10:SP:(M4)	12-19
M0CJ1672	MOTOR-PM:FUSER:SP:(M2)	12-23
M0CJ1673	CLUTCH:35:Z35R:SP:(CL1, CL2, CL4, CL5)	12-20
M0CJ1674	DC:MOTOR:ASSY:SP:(M7)	12-28
M0CJ1675	ID SENSOR:SP:(PCB6, PCB7)	13-2
M0CJ1676	PCB:ENGINE CONNECT:(PCB21)	13-1
M0CJ1677	PCB:ENGINE:(PCB1)	14-1
M0CJ1678	PCB:DRUM CONNECT:(PCB22)	13-10
M0CJ1680	PCB:SWITCH:(SW5)	14-7
M0CJ1681	HIGH VOLTAGE UNIT:SP:(PCB19)	14-2
M0CJ1682	PCB:EXIT	5-4
M0CJ1683	SWITCHING:REGULATOR:230V:SP(EU/AP):(PCB9)	14-3
M0CJ1684	SWITCHING:REGULATOR:100V:SP(NA):(PCB9)	14-3
M0CJ1685	PCB:CASSETTE:(PCB25)	3-11
M0CJ1686	HVU2:(PCB20)	14-15
M0CJ1688	TONER:FULL:DETECT:ASSY:SP:(S4)	14-12
M0CJ1729	SW.MICRO:(SW1)	14-4
M0CJ1730	SENSOR:OPT.:SP:(S6, S7)	4-11
M0CJ1730	SENSOR:OPT.:SP:(S3)	14-9
M0CJ1731	CASSETTE ASSY	2-1
M0CJ1732	CONVEYING:500:SI:ASSY:SP	6-3
M0CJ1733	ROLLER:TRANSFER:SP	6-1

Part No.	Description	Page and Index No.
M0CJ1734	ROLLER:TRANSFER:ASSY:SP	6-2
M0CJ1735	DC:MOTOR:ASSY:SP:(M11)	13-4
M0CJ1736	PCB:CONTAINER CONN:(PCB26)	13-6
M0CJ1737	PCB:DRUM HEATER	13-23
M0CJ1738	HOLDER:FEED:ASSY:SP	3-12
M0CJ1739	RETARD:ASSY:SP	3-3
M0CJ1740	MOTOR:EJECT:SP:(M3)	12-22
M0CJ1742	CLEANER:ID:ASSY:SP	13-5
M0CJ1743	COVER:MPF:ASSY:SP	4-12
M0CJ1744	PLATE:BOTTOM:MPF:ASSY:SP	4-13
M0CJ1745	MIDDLE:ROLLER:ASSY:SP	3-15
M0CJ1746	DC:MOTOR:ASSY:SP:(M10)	13-9
M0CJ1747	SEPARATOR:MPF:ASSY:SP	4-14
M0CJ1748	SENSOR:OPT.:SP:(S1)	13-3
M0CJ1749	FAN:MOTOR:SP:(FAN5, FAN6)	12-1
M0CJ1750	DC:MOTOR:ASSY:SP:(M9)	13-17
M0CJ1751	ROLLER:REGIST:RUBBER:SP	6-4
M0CJ1752	PIN:READING:GUIDE	7-3
M0CJ1753	SPRING:LSU:HOLD	7-4
M0CJ1754	SPRING:SEPARATION:MPF	4-15
M0CJ1755	BELT:S2M:Z95	4-16
M0CJ1756	BELT:S2M:Z130	4-17
M0CJ1757	ACTUATOR:PE	3-16
M0CJ1758	COVER:SENSOR	3-17
M0CJ1759	LOCK:CASSETTE	3-18
M0CJ1760	SPRING:LOCK:CASSETTE	3-19
M0CJ1761	HOOK:RETARD:RELEASE:B	3-20
M0CJ1762	SPRING:RELEASE	3-21
M0CJ1763	SPRING:SHUTTER	3-23
M0CJ1764	SPRING:PULLEY:MPF	4-1
M0CJ1765	SPRING:ACT	3-24
M0CJ1766	SPRING:ACTUATOR	3-25
M0CJ1770	SW.PUSH:(SW2)	13-7
M0CJ1771	PAD:REGIST:FEED	3-26
M0CJ1772	GUIDE:CASSETTE	3-27

Part No.	Description	Page and Index No.
M0CJ1773	SPRING:SLIDER:CLEANER	13-21
M0CJ1780	COLLECTION BOTTLE	16-1
M0CJ1783	FUSING UNIT(EU/AP)	11-1
M0CJ1784	FUSING UNIT(NA)	11-1
M0CJ2563	LABEL:CURSOR	2-2
M0CJ2568	CURSOR:LEFT	2-3
M0CJ2569	CURSOR:RIGHT	2-4
M0CJ2571	ARM:CURSOR:END	2-5
M0CJ2572	CURSOR:END	2-6
M0CJ2580	GEAR:Z13S:JOINT	2-7
M0CJ2581	GEAR:Z13	2-8
M0CJ2582	WORKPLATE:LIFT	2-9
M0CJ2583	GEAR:Z48S:LIFT	2-10
M0CJ2662	PIN:FEED	3-1
M0CJ2663	COVER:RETARD	3-2
M0CJ2669	HOLDER:RETARD:A	3-5
M0CJ2681	FRAME:FEED	3-6
M0CJ2682	GUIDE:PICK:HOLDER	3-7
M0CJ2683	SHAFT:FEED	3-8
M0CJ2684	RELEASE:ACTUATOR:PE	3-9
M0CJ2686	ACTUATOR:B	3-10
M0CJ2760	LABEL:JAM	1-28
M0CJ2771	CAP:SPRING_B-11	4-2
M0CJ2772	SHAFT:EXIT	4-3
M0CJ2773	PULLEY:FEED:DU	4-4
M0CJ2774	FRAME:MPF	4-5
M0CJ2777	GUIDE:MPF:FEED:LOW:B	4-6
M0CJ2778	GUIDE:MPF:FEED:LOW:A	4-7
M0CJ2780	GUIDE:MPF:FEED:UP	4-8
M0CJ2782	P.W.BOARD:ASSY:FUSER:ZENER	4-9
M0CJ4451	FAN:MOTOR:(FAN2)	5-6
M0CJ4451	FAN:MOTOR:(FAN4)	14-16
M0CJ5020	PCB:IMAGE PROCESSING UNIT:ASS'Y:(PCB2)	14-18
M0CJ5501	PCB:CTL:SUB-ASS'Y:(PCB3)	14-17
M0CJ7490	Color Calibration Sheet	17-4

Part No.	Description	Page and Index No.
M2811054	ROLLER M/P ASS'Y	4-10
M2811055	CLUTCH:50 Z35:(CL3)	12-21
M2811069	FAN:COOLING ONVEYING SP:(FAN7)	5-5
M2811069	FAN:COOLING ONVEYING SP:(FAN3)	13-22
M2811069	FAN:COOLING ONVEYING SP:(FAN1)	14-5
M2811430	PARTS_PWB_ASS	14-14
M2811503	FOOT	14-10
M2812520	RETARD ROLLER	3-4
M2812821	PULLEY:FEED:ASSY	3-13
M2812824	PULLEY:PICK-UP:ASSY	3-14
M2815567	POWER_CORD(120)(NA)	16-3
M2815568	AC CODE ASS'Y(EU/AP)	16-2
M5441664	LEVER PAPER	3-22
M5441672	SPRING FIX	2-12
M5441673	SIZE FIX	2-13
M5441679	SPRING STOPPER	2-11
VSSG9005	MOLYKOTE EM-50L (Grease)	17-5