

IMPORTANT NOTICE for Field Technicians

Be sure to perform Machine Level Adjustment at

1. Machine installation

2. When the machine is transported to another place

using a level with an accuracy of less than

0.0005 inch per inch (0.5mm/1000mm).

See TECHNICAL SERVICE BULLETIN

No. M0B1/M0B2 - 001 for the detailed procedure.

❖ Proper leveling will prevent the following problems:

- Registration Problems
- Image Skew
- Paper Skew
- Image Magnification Misalignment

