





J0326635A

Notes for Users

The manuals contain additional information.

⚠ WARNING

- The supplied power cord is for use with the supplied AC adapter only. Do not use it with any other adapter.
- If AC power to the machine is cut during operation by, for instance, the power plug being accidentally pulled out or a blackout occurring, the machine automatically switches to battery power. If the AC power is restored before the battery becomes exhausted, the machine automatically switches back to the AC power supply. The machine's power goes off when the battery becomes exhausted. If this happens, turn the power back on once the AC power is restored.
- The LED battery level indicator merely gives a rough indication of the battery level. If the battery level is low, recharge the battery using the AC adapter or replace the battery.
- If the battery has been left unused for a long time, fully recharge it before using it again.
- Before you move the machine, remove the battery and insulate the battery terminals with tape or put the battery in a plastic bag or the box it was delivered in. Moving the machine with the battery installed may cause a short circuit, leading to smoke or fire.
- Do not forget to turn off the light for checking printed documents.
- Optimum Environmental Conditions



- White area:
Permissible Range
- Gray area:
Recommended Range

Power Source

- AC adapter for SG 3120B SFNw: 100 V-240 V 1.5A

Voltage must not fluctuate more than 10%.

Please be sure to connect the power cable to a power source as above.

Confirm that the wall outlet is near the machine and freely accessible, so that in event of an emergency, it can be unplugged easily.

NOTICE TO USERS (NEW ZEALAND)

- The grant of a Telepermit for any item of terminal equipment indicates only that Telecom has accepted that the item complies with minimum conditions for connection to its network. It indicates no endorsement of the product by Telecom, nor does it provide any sort of warranty. Above all, it provides no assurance that any item will work correctly in all respects with another item of Telepermitted equipment of a different make or model, nor does it imply that any product is compatible with all of Telecom's network services.
- This equipment is not capable, under all operating conditions, of correct operation at the higher speeds for which it is designed. Telecom will accept no responsibility should difficulties arise in such circumstances.
- Devices connected to the telephone port may lose their memory if this fax machine is on line for extended periods. To prevent this, such devices should have the facility for battery or similar backup of memory.
- This device may be subject to ringing or bell tinkle when certain other devices are connected to the same line. If this occurs, the problem should not be referred to the Telecom Faults Service.
- This equipment should not be used under any circumstances that may constitute a nuisance to other Telecom customers.
- Telepermitted equipment only may be connected to the auxiliary telephone port. The auxiliary telephone port is not specifically designed for 3-wire connected equipment that may not respond to incoming ringing when attached to this port.

© 2013,2014

Printed in China

EN  EN  EN  J032-6635A