

# Notes for Users

---

This leaflet provides supplementary information about using the machine.

---

## Specifying the Paper Size

---

After loading paper in the Paper Feed Unit, set the paper size in "Tray Paper Size" in the Paper Input menu. This section explains settings to load A3 paper in Tray 2 as an example.

1. Press the [▼/Menu] key.
2. Press the [▲] or [▼/Menu] key to display [Paper Input], and then press the [#Enter] key.
3. Press the [▲] or [▼/Menu] key to display [Tray Paper Size], and then press the [#Enter] key.
4. Press the [▲] or [▼/Menu] key to display the paper tray you want to specify, and then press the [#Enter] key.
5. Press the [▲] or [▼/Menu] key to display appropriate paper size, and then press the [#Enter] key.
6. Press the [Escape] key.

© 2014

Printed in China

EN  EN  J314-6611



J3146611