

## Notes for Users

Thank you for purchasing this machine.

This machine is compliant with the revisions to the International energy Star Program effective July 2009.

To reflect these revisions, the following information contained in the instructions supplied with this machine has been changed.

Formerly (pre-revision)	Currently (post-revision)
Time elapsed before machine enters Energy Saving mode: <u>5 minutes</u>	Time elapsed before machine enters Energy Saving mode: <u>1 minute</u>

The machine waits 1 minute following last usage before entering Energy Saving mode. This is the factory-specified default setting.

Copyright © 2009

Printed in China

EN  M001-8648



M0018648