Notes for Users

Please note the following corrections and added precaution to this manual.

Operating Instructions/User Guide

| Торіс | Error | Correction | |
|---|--|--|--|
| Operating Instructions Setting Up the Printer > Place to Install > Space Required for Installation | "Depth" in the recommended space illustration: 67.7cm (26.7") | "Depth" in the recommended space illustration: 68.4cm (27.0") | |
| Operating Instructions Printing > Loading Paper > Loading Envelopes | "Types of Envelopes" in the table: Side-opening envelopes | "Types of Envelopes" in the table Envelopes | |
| User Guide p.62 | | | |
| Operating Instructions Printing > Convenient Functions > Printing on Both Sides of Sheets User Guide p.58 | Duplex printing precautions The types of paper that can be printed on both sides are as follows: Plain (60 to 81g/m²), Recycled, Special, Special 2, Special 3, Middle Thick (82 to 105g/m²), Thick 1(106 to 160g/m²), Color, Letterhead, Preprinted, Prepunched, Bond | Duplex printing precautions • The types of paper that can be printed on both sides are as follows: Plain (60 to 81g/m²), Recycled, Special 1, Special 2, Special 3, Middle Thick (82 to 105g/m²), Color, Letterhead, Preprinted, Prepunched, Bond | |
| Operating Instructions Printing > Convenient Print Functions > Booklet Printing | Booklet printing precautions The paper types that can be used for booklet printing are as follows: Plain (60 to 81g/m²), Recycled, Special, Special 2, Special 3, Middle Thick (82 to 105g/m²), Thick 1 (106 to 160 g/m²), Color, Letterhead, Preprinted, Prepunched, Bond | Booklet printing precautions The paper types that can be used for booklet printing are as follows: Plain (60 to 81g/m²), Recycled, Special 1, Special 2, Special 3, Middle Thick (82 to 105g/m²), Thick 1 (106 to 160 g/m²), Color, Letterhead, Preprinted, Prepunched, Bond | |
| Operating Instructions Maintenance and Specifications > Specifications > Specifications for the Main Unit | Dimensions (W x D x H): 670 x 677 x 641 mm (26.4 x 26.7 x 25.3 inches) Space for the main unit (W x D) | Dimensions (W x D x H): 670 x 684 x 641 mm (26.4 x 27.0 x 25.3 inches) Space for the main unit (W x D) | |
| | 1,065 x 677 mm (42.0 x 26.7 inches) | 1,065 x <u>684</u> mm (42.0 x <u>27.0</u> inches) | |
| Additional Information | | | |

Precaution for label paper:

When loading label paper, place one sheet at a time.

Security Guide

Topic: p.223 "Edit Home"

Error:

| Settings | User | Mach | N/W | File | Unset | Set |
|--------------|------|------|-----|------|-------|-----|
| Edit Icons | - | R/W | - | - | R/W | - |
| Insert Image | - | R/W | - | - | R/W | - |

Correction:

| Settings | User | Mach | N/W | File | Unset | Set |
|------------------------------|------|------|-----|------|-------|-----|
| Move Icon | R | R/W | R | R | R/W | R |
| Delete Icon | R | R/W | R | R | R/W | R |
| Add Icon | - | R/W | - | - | R/W | - |
| Restore Default Icon Display | - | R/W | - | - | R/W | - |
| Insert Image on Home Screen | - | R/W | - | - | R/W | - |

