

Additional Information for Software Installation Guide for Network Connection

This supplement provides you with additional information for setting up the printer in a Windows network environment.

If your environment is using DHCP, be sure to read this supplement as well as *Software Installation Guide for Network Connection* before installing the printer drivers.

When Installing the Drivers in a DHCP Environment

Note the following before installing the printer drivers in a DHCP environment:

- ☐ Make sure the network cable is properly connected to the printer before you print the test page.
- ☐ Omit the procedure in "3. Specify the Printer's IP Address", *Software Installation Guide for Network Connection*. This procedure is not necessary because the printer is automatically recognized by its IP address when its main power is switched to ON.
- ☐ Using Web Image Monitor, change the automatically specified IP address to the IP address printed on the test page.

Reference

For details about Web Image Monitor, see *Software Guide* on the supplied CD-ROM and *Notes to Administrator* that is provided with the printer.

Copyright © 2007

Printed in China

GB (GB) EN (USA) G165-7509



G1657509