

Easy Operation Guide


Basic Procedure




Loading Paper



Adding Ink




Replacing the Master Roll




Removing the Used Master




Control Panel



- | | | |
|--------------------------------|-------------------------------------|---------------------------|
| 1. [Economy] key | 13. [Clear Modes/Energy Saver] key | 25. [Original Type] key |
| 2. [Memory/Class] key | 14. [Proof] key | 26. [Reduce/Enlarge] key |
| 3. [Erase Border] key | 15. [Master Making] mode select key | 27. [Combine/Repeat] key |
| 4. [User Tools] key | 16. [Auto Cycle] key | 28. [Full Size] key |
| 5. [Master Making Density] key | 17. [Print] mode select key | 29. [▲] and [▼] keys |
| 6. Indicators | 18. [Fine] key | 30. [Image Position] keys |
| 7. Panel Display | 19. [Security] key | 31. Number keys |
| 8. [Escape] key (Cancel key) | 20. [Skip Feed/A3 Paper Feed] key | 32. [#] key |
| 9. Counter | 21. Data In indicator (Green) | 33. [Clear/Stop] key |
| 10. [▲] [▼] keys | 22. Error indicator (Red) | 34. [Start] key |
| 11. [OK] key | 23. [Job Reset] key | 35. Processing indicators |
| 12. [Program] key | 24. [Hold Data-in] key | |



- | | |
|--|-------------------------------------|
| 1. Front cover | 6. Separation pressure lever |
| 2. Control panel | 7. Paper feed side plate lock lever |
| 3. Exposure glass cover (optional) or ADF (optional) | 8. Side tray fine adjusting dial |
| 4. Master tray | 9. Paper feed tray |
| 5. Feed roller pressure lever | 10. Paper feed side plates |
| | 11. Paper feed tray down key |




- | | |
|-------------------------------|-------------------------|
| 1. Exposure glass | 6. Paper delivery tray |
| 2. Master eject unit | 7. Main switch |
| 3. Master eject box | 8. Drum unit |
| 4. Paper delivery side plates | 9. Drum unit lock lever |
| 5. Paper delivery end plate | 10. Ink holder |

When the Open Cover/Unit Indicator Lights



Clearing Misfeeds

Paper Misfeeds in the Paper Feed Section




Paper Wrapped Around the Drum




Paper Misfeeds in the Paper Exit Section



Master Misfeeds in the Master Feed Section



Master Misfeeds in the Master Eject Section



Original Misfeeds in the ADF



For details, see *Operating Instructions*.