

Model PT 4 (C282)

PARTS CATALOG

Ricoh Company, LTD.


Model PT 4 (C282)

PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

Model PT 4	(C282)
DF Type20	(C642)
Color Drum Type20	(C647)
TAPE Dispenser Type20	(C651)
Platen Cover Type 1018	(B406)

Model PT 4 (C282)



Model PT 4 (C282)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

Location Of Unit.....	2	18.Delibary Table (C282).....	42
1.Exterior (C282)	8	19.Master Eject Unit 1 (C282).....	44
2.Operation Panel (C282).....	10	20.Master Eject Unit 2 (C282).....	46
3.Scanner Unit 1 (C282)	12	21.Electrical Section 1 (C282)	48
4.Scanner Unit 2 (C282).....	14	22.Electrical Section 2 (C282)	50
5.Scanner Unit 3 (C282).....	16	23.Drive Section 1 (C282).....	52
6.Paper Table Section (C282)	18	24.Drive Section 2 (C282).....	54
7.Paper Registration 1 (C282)	20	25.Frame Section 1 (C282).....	56
8.Paper Registration 2 (C282)	22	26.Frame Section 2 (C282).....	58
9.Paper Feed Section (C282)	24	27.Decals And Documents (C282)	60
10.Plotter Unit 1 (C282)	26	28.Special Tools (C282)	64
11.Plotter Unit 2 (C282)	28	Parts Index.....	67
12.Plotter Unit 3 (C282)	30		
13.Press Roller Section (C282)	32		
14.Drum Unit 1 (C282).....	34		
15.Drum Unit 2 (C282).....	36		
16.Drum Unit 3 (C282).....	38		
17.Vacuume Fan Unit (C282).....	40		


LOCATIONS OF UNITS

1. Exterior (C282)




See Page 9

2. Operation Panel (C282)




See Page 11

3. Scanner Unit 1 (C282)




See Page 13

4. Scanner Unit 2 (C282)




See Page 15

5. Scanner Unit 3 (C282)



See Page 17


6. Paper Table Section (C282)



See Page 19


LOCATIONS OF UNITS

7. Paper Registration 1 (C282)




See Page 21

8. Paper Registration 2 (C282)




See Page 23

9. Paper Feed Section (C282)




See Page 25

10. Protter Unit 1 (C282)




See Page 27

11. Protter Unit 2 (C282)



See Page 29


12. Protter Unit 3 (C282)



See Page 31


LOCATIONS OF UNITS

13. Press Roller Section (C282)




See Page 33

14. Drum Unit 1 (C282)




See Page 35

15. Drum Unit 2 (C282)




See Page 37

16. Drum Unit 3 (C282)




See Page 39

17. Vacuum Fan Unit (C282)



See Page 41


18. Delivery Table (C282)



See Page 43


LOCATIONS OF UNITS

19. Master Eject Unit 1 (C282)




See Page 45

20. Master Eject Unit 2 (C282)




See Page 47

21. Electrical Section 1 (C282)




See Page 49

22. Electrical Section 2 (C282)




See Page 51

23. Drive Section 1 (C282)





See Page 53

24. Drive Section 2 (C282)




See Page 55

LOCATIONS OF UNITS

25. Frame Section 1 (C282)  See Page 57	26. Frame Section 2 (C282)  See Page 59	

1. Exterior (C282)




1. Exterior (C282)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C282 1301	Cover:Door	1
2	AA00 1566	Plate:Logotype:SVN	1
2	AA00 1565	Plate:Logotype:LAN	1
2	AA00 1564	Plate:Logotype:RIC	1
2	AA00 1567	Plate:Logotype:GES	1
2	AA00 1568	Plate:Logotype:NSA	1
2	AA00 1569	Plate:Logotype:REX	1
3	AG07 0514	Magnet Catch	1
4	C282 1396	Decal:Main Switch:CHN:PS	1
5	C282 1392	Decal:Warning:Paper Feed:EXP:PS	2
6	C267 1311	Hinge:Door:Upper:Ass'y	1
7	C267 1312	Hinge:Door:Lower:Ass'y	1
8	C282 1302	Cover:Front	1
9	C279 1330	Decal:Paper Feed Tray	1
10	C282 1305	Cover:Left	1
11	C282 1307	Cover:Rear Upper	1
12	C282 1303	Cover:Rear	1
13	C279 1341	Decal:Warning:Paper Feed:EXP	1
14	2803 0006	Cord Binder	1
15	C282 1306	Cover:Right	1
16	C282 1391	Decal:Master Set Instructions:ABS	1
17	C279 1351	Decal:Counter	1
18	C282 1308	Cap:FVLT	1
19	C238 2770	Paper Side Pad	2
20	C238 2243	Master Flange - MH	2
20	C238 2244	Flange:Master:50.8/20	2
21	C282 4493	Guide:Paper:Side Fence	2
22	C261 5822	Power Supply Cord	1
22	C261 5821	Power Supply Cord	1
22	C274 5820	Power Supply Cord	1
23	C282 1060	Cover:Spacer:Main	4
24	C282 1067	Spacer:Main	4
25	C282 1069	Sheet:Spacer:Main:MX-48HF	4

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008N	Tapping Screw:4x8	
102	0450 4010N	Tapping Screw:M4x10	
103	0451 3008N	Tapping Screw - M3x8	
104	0353 0040N	Screw - M3x4	
105	0451 3006N	Tapping Screw - 3x6	

2. Operation Panel (C282)




2. Operation Panel (C282)

Index No.	Part No.	Description	Q'ty Per Assembly
*	C282 1451	Operation Panel:EXP:Ass'y	1
1	C282 1486	Bracket:Operation Sub-Unit:Left	1
2	C282 1492	Sheet:Operation Sub-Unit:Left:NA	1
2	C282 1494	Sheet:Operation Sub-Unit:Left:EU	1
2	C282 1496	Sheet:Operation Sub-Unit:Left:CHN	1
3	C282 1460	Case:Operation Sub-Unit	1
4	C282 1491	Sheet:Operation Sub-Unit:Right:NA	1
4	C282 1493	Sheet:Operation Sub-Unit:Right:EU	1
4	C282 1495	Sheet:Operation Sub-Unit:Right:CHN	1
5	C267 1495	Lens:LED:Operation Sub-unit	1
6	C282 1482	Keytop:Memory	1
7	C282 1481	Keytop:Usertool	1
8	C282 1480	Keytop:Magnification	1
9	C282 1479	KEYTOP:Return	1
10	C282 1478	Keytop:Program	1
11	C282 1476	Keytop:Reset	1
12	C282 1474	Keytop:Try Print	1
13	C282 1473	Keytop:Numeric	1
14	C282 1472	Keytop:ClearStop	1
15	C282 1471	Keytop:Start	1
16	C282 1475	Keytop:Continuance	1
17	C267 1497	Bracket:Operation Sub-unit:Right	1
18	C271 5162	PCB:OPE	1
19	B129 1495	LCD	1
20	C282 1382	Decal:Name Plate:STD (NA)	1
20	C282 1383	Decal:Name Plate:DD3334 (NA)	1
20	C282 1384	Decal:Name Plate:DD3344 (EU,AA)	1
20	C282 1385	Decal:Name Plate:DD3324 (EU)	1
20	C282 1386	Decal:Name Plate:CP6303C (CHN)	1
20	C282 1387	Decal:Name Plate:DD3344C (CHN)	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0452 3008N	Tapping Screw - M3x8	

3. Scanner Unit 1 (C282)




3. Scanner Unit 1 (C282)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D144 1085	Stepped Screw:M3	6
2	C282 1800	Cover:Sheet Through:Document Feeder	1
3	D147 1805	Exposure Glass:Document Feeder:Apply	1
4	C282 1799	Scale:Rear:Printing	1
5	D149 1699	Frame:Scanner:Rear	1
6	AW02 0214	Photointerruptor:LG248NL1A	1
7	D149 1801	Bracket:Scale:Left	1
8	A250 1752	Exposure Glass	1
9	D149 1698	Frame:Scanner:Front	1
10	C282 1066	Bracket:Fix:Scanner Unit:Left	1
11	D158 1816	Bracket:Document Feeder:Left	1
12	D149 1816	Document Feeder:Cable:Bracket	1
13	AW02 0207	Photointerruptor:Flat:PICH2MM:M4	1
14	C282 5123	Supporting Plate:Cable:Document Feeder	1
15	D158 1815	Bracket:Document Feeder:Right	1
16	D149 1817	Bracket:SIO	1
17	D159 5138	PCB:SIO	1
18	D149 1780	Inner Cover	1
19	D149 1771	Lens:Holder:Ass'y	1
20	D149 1782	Cover:Lens	1
21	D159 5301	Interface Cable:Scanner:LVDS:Ass'y	1
22	C282 1792	Scale:Left:EU:Ass'y	1
23	G570 1225	Sensor Shielding Plate	1
			

Index No.	Part No.	Description	Q'ty Per Assembly

4. Scanner Unit 2 (C282)




4. Scanner Unit 2 (C282)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D149 1730	Carrige:No.1:Ass'y	1
2	D149 1726	Clamp:Drive Were	2
3	D158 1721	Illumination Unit:LEDB:Ass'y	1
4	AA14 3849	Screw:DIA4:M3	3
5	D149 1728	Guide:Harness:LED-B	1
6	D149 1693	Guide:FFC	1
7	AW01 0155	Original:Sensor:3.3V	2
8	D149 1694	Plate Seal:APS:Harness	1
9	D149 1754	Guide:FFC:Carrige:No.2	1
10	D149 1755	Cover:FFC:Carrige:No.2	1
11	D149 5207	Harness:FFC:LED	1
12	D149 5206	Harness:SIO:Scanner Unit	1
13	AC03 0169	Mirror:No.1	1
14	D149 1731	Reflector:Scanner	1
15	M026 1815	Clamp:Mirror:No.1	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0353 0060N	Bind Screw - M3X6	

5. Scanner Unit 3 (C282)




5. Scanner Unit 3 (C282)

Index No.	Part No.	Description	Q'ty Per Assembly
1	D149 1703	DC Stepper Motor	1
2	D149 1705	Bracket:DC Stepper Motor	1
3	D149 1709	Tension Spring:Tension:11.3N:30MM	3
4	D159 5304	Harness:SIO:STM	1
5	D149 1706	Synchronous Belt:138ST1.5-4.0	1
6	D149 1710	Timing Pulley:62	1
7	D149 1715	Pulley:Drive Were:Front	1
8	D029 1749	Pulley:Protction	1
9	D149 1717	Pulley:Drive Were:Rear	1
10	D149 1711	Shaft:Scanner:Drive	1
11	AA08 2144	Busing - 8X12X7	2
12	D159 1740	Carrige:No.2:Ass'y	1
13	D149 1719	Bracket:Tension:Front	1
14	D149 1718	Bracket:Tension:Rear	1
15	B238 1806	Idler Pulley	4
16	D149 1714	Drive Were:DIA1	2
17	AC03 0210	Mirror:No.2:Concave	1
18	B238 1807	Pulley	2
19	G404 2810	Spring Plate – 2nd Mirror	4
20	D149 1742	Carrige:No.2:Sub-Ass'y	1
21	D149 1749	Mirror:No.3:CONVAX:C3	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0805 0106	Retaining Rings-E:Silencer:DIA6	

6. Paper Table Section (C282)




6. Paper Table Section (C282)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C282 2998	Decal:Size Indication:Paper Feed	1
2	C267 2779	Spring:Auxiliary:Rise:Paper Feed Tray	2
3	C238 2800	Tray Lift Bracket	2
4	C238 2805	Tray Lift Slider	4
5	C231 2965	Core	1
6	C267 2790	Rack:Rise:Paper Feed Tray:Front:Ass'y	1
7	G570 1225	Sensor Shielding Plate	1
8	C267 2793	Stay:Harness:Sensor:Paper	1
9	5606 2310	Roller	4
10	C279 2996	Dacal:Paper Set Direction	1
11	C267 2796	Rack:Rise:Paper Feed Tray:Rear:Ass'y	1
12	C238 2806	Tray Position Feeler	1
13	AW02 0203	Photointerruptor	1
14	C238 2825	Sensor Bracket	1
15	C238 2986	Sensor Bracket - Paper Feed Tray	1
16	AW01 0109	Photo Reflection Sensor:PS117ED1	1
17	C282 5271	Harness:Paper Feed Tray:Ass'y	1
18	C282 2980	Side Fence:Paper Feed Tray	2
19	C238 2770	Paper Side Pad	2
20	C249 2840	Paper Feed Tray Pad	1
21	C2822710	Paper Feed Tray:Ass'y	1
22	C249 2790	Spring Plate:Spacer:Paper Feed Tray	1
23	C267 2758	Plate:Magnet Catch:Paper Feed Tray	1
24	C267 2754	Stay:Paper Feed Tray:Rear	1
25	C279 2964	Adjusting Pin:Front Rear:Paper Feed Tray	1
26	C279 2973	Knob:Lock:Side Fence	1
27	C238 2981	Rear Side Fence Rack	2
28	C267 2983	Spacer:Side Fence	2
29	C238 2987	Side Fence Gear	1
30	C231 2985	Spring	1
31	C267 6168	Washer:Slide:End Fence	1
32	C267 2770	Shaft:Lock:Side Fence	1
33	C267 2753	Stay:Paper Feed Tray:Front	1
34	C267 2756	Base:Paper Feed Tray	1
35	C267 2761	Arm:Rear:Paper Feed Tray:Peen	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	C267 2760	Arm:Front:Paper Feed Tray	1
37	C244 1098	Pan Head Screw:Lock:M4x4	4
38	C231 2976	Washer	3
39	C612 1800	Screw:Lens:Guide	3
40	C282 2967	Decal:Adjustment Scale:Move:Paper Feed	1
41	C231 2971	Lock Cam	1
42	C249 2944	Table Sheet	1
43	C282 2752	Paper Feed Tray	1
101	0701 0040N	Washer:DIA4	
102	0594 0080N	Hexagonal Set Screw - M4x8	
103	0951 3012N	Screw:Polished Round:M3x12	
104	0720 0060E	Retaining Ring - M6	
105	0720 0040E	Retaining Ring - M4	
106	0314 0040N	Pan Head Screw - M4x4	
107	1105 0534	Clamp	
108	0450 4008N	Tapping Screw - M4x8	
109	0450 3008N	Tapping Screw - M3x8	
110	0450 3006N	Tapping Screw - M3x6	

7. Paper Registration 1 (C282)




7. Paper Registration 1 (C282)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C267 2944	Screw:Actuator:Surface Of Paper Sensor	1
2	C257 2869	Feeler Roller	1
3	C267 2941	Actuator:Surface Of Paper Sensor:Peen	1
4	C267 2802	Roller:Paper Feed:Ass'y	2
5	C267 2917	Retainer:Arm:Paper Feed	1
6	5606 2066	Paper Feed Guide Disc	2
7	C252 2810	Grip Rings:Mm8	3
8	C252 1080	Bushing	5
9	C267 2806	Arm:Paper Feed	1
10	C271 2808	Shaft:Paper Feed Roller	1
11	C271 2809	Shaft:Pickup	1
12	C267 2813	Timing Belt:B82MXL6.4	1
13	C267 2812	Pulley:Pickup:Paper Feed	1
14	C267 2811	Pulley:Drive:Roller:Paper Feed	1
15	C201 5051	Pinion - 24T	2
16	C267 2781	Shaft:Rise:Paper Feed Tray	1
17	C267 2827	Adjusting Pin:Separation Sub-unit	1
18	C267 2845	Lever:Separation Change	1
19	C209 5220	Spacer - 4x20x6	1
20	5501 8195	Steel Ball 3/16	1
21	C238 2929	Spring Plate	1
22	C267 2844	Bracket:Separation Change	1
23	C231 2922	Pressure Roller	1
24	C261 2835	Adjusting Pin	1
25	C261 2831	Holder:Spring:Separation	1
26	C261 2832	Compression Spring:Separation Pad	1
27	C267 2819	Separation Pad:Ass'y (EU, AA, NA)	1
27	C267 2820	Separation Pad:CHN:Ass'y (CHN)	1
28	C267 2824	Drum Stay:Paper Feed:Ass'y	1
29	C279 2932	Knob:Lever	1
30	C261 2844	Screw:Separation Unit	2
31	C203 5135	Bushing - 10x14x5.9	2
32	C267 2916	Stay:Paper Feed	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0353 0120N	Screw M3x12	
102	0720 0030E	Retaining Ring - M3	
103	0720 0080E	Retaining Ring - M8	
104	0720 0070E	Retaining Ring - M7	
105	0633 0160G	Parallel Pin - 3x16mm	
106	0574 0040E	Hexagon Headless Set Screw - M4x4	
107	0624 0160E	Spring Pin - 4x16mm	
108	0454 3006Q	Tapping Screw - M3x6	
109	0451 4010N	Tapping Screw:4x10	
110	0720 0040E	Retaining Ring - M4	
111	0314 0040N	Pan Head Screw - M4x4	
112	0450 3006N	Tapping Screw - M3x6	
113	0451 4006N	Tapping Screw - 4x6	
114	0451 4008N	Tapping Screw:4x8	

8. Paper Registration 2 (C282)




8. Paper Registration 2 (C282)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C282 5273	Harness:Connecting:Stay:Plotter:Ass'y	1
2	C282 5272	Harness:Stay Ass'y	1
3	AW02 0141	Photointerruptor	2
4	C267 2946	Bracket:Surface Of Paper Sensor	1
5	C267 2947	Holder:Surface Of Paper Sensor	1
6	C267 2953	Cover:Inner Back:Stay:Paper Feed	2
7	G570 1225	Sensor Shielding Plate	2
8	C209 5220	Spacer - 4x20x6	1
9	C238 2939	Spring	1
10	C267 2924	Lever:Pressure:Paper Feed Roller	1
11	C279 2932	Knob:Lever	1
12	5501 8195	Steel Ball 3/16	1
13	C238 2929	Spring Plate	1
14	C267 2931	Arm:Pressure:Paper Feed:Peen	1
15	C238 2936	Arm Bracket	1
16	C267 2918	Bracket:Stay:Paper Feed	1
17	C267 2951	Bracket:Arm:Surface Of Paper Sensor	1
18	C267 2952	Holder:Surface Of Paper Sensor	1
19	C267 2992	Cover:On Off Detector:Plotter:Lower Middle	1
20	C267 2993	Bracket:On Off Detector:Right Lower: Machine Or Copier:2	1
21	C267 2994	Holder:Lock:Plotter	1
22	C282 2995	Decal:Paper Feed Pressure:English	1
22	C267 2996	Decal:Paper Feed Pressure:CHN	
23	C267 2916	Stay:Paper Feed	1
24	C267 2816	Stopper:Arm	1
25	C267 2956	Cover:Auxiliary:Harness:Stay:Paper Feed	1
26	C267 2954	Cover:Harness:Stay:Paper Feed	1
27	C267 2958	Ground Plate:Cover:Stay:Paper Feed	2
28	C231 2922	Pressure Roller	1
29	G020 5626	Push Switch	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 3006Q	Tapping Screw - M3x6	
102	0451 4010N	Tapping Screw:4x10	
103	0353 0060N	Bind Screw - M3x6	
104	0451 4006N	Tapping Screw - 4x6	
105	0453 3006N	Tapping Screw - M3x6	
106	0454 4006Q	Tapping Screw:4x6	
107	1105 0516	Clamp	
108	1105 0511	Harness Clamp - LWS-0306ZC	
109	0720 0040E	Retaining Ring - M4	
110	1102 8797	Connector:1-292215-4	

9. Paper Feed Section (C282)




9. Paper Feed Section (C282)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C267 1056	Shaft:Stay:Machine Or Copier:DIA12	1
2	C261 2881	Feed Roller:Lower	1
3	C238 2894	Upper Registration Roller	1
4	C252 2878	Spring:Pressure:Feed Roller	1
5	C261 2875	Arm:Pressure:Feed Roller:Ass'y	1
6	C275 2895	Arm:Feed Roller:Upper	2
7	C264 2898	Shaft:Arm:Feed Roller:Upper	1
8	C231 2766	Pressure Pin	1
9	C261 2872	Shaft:Swivel:Feed Roller:Upper	1
10	C272 2855	Lever:Cleanner:Registration Sensor (CHN)	1
11	C238 2921	Registration Sensor Bracket	1
12	C261 1056	Shaft:Stay:Machine Or Copier	1
13	C257 5807	Photo Reflection Sensor:GP2A25	1
14	C261 2844	Screw:Separation Unit (CHN)	1
15	C238 2853	Sensor Cleaning Spring (CHN)	1
16	C238 2856	Sensor Cleaning Brush (CHN)	1
17	C275 2870	Bracket:Guide Plate:Rear	1
18	C267 2896	Guide Plate:Feed Roller:Ass'y	1
19	C275 2869	Bracket:Guide Plate:Front	1
20	C267 2267	Bearing Case:Transmission	2
21	C252 1080	Bushing	2
22	C229 2907	Registration Roller Pulley - 14Z	1
23	C275 2871	Feed Roller:Upper:Ass'y	1
24	C267 2897	Sheet:Guide Plate:Feed Roller:Upper	1
25	C275 2898	Screw:M4x6	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0574 0050E	Hexagon Headless Set Screw - M4x5	
102	0451 4006N	Tapping Screw - 4x6	
103	0451 3006N	Tapping Screw - 3x6	
104	0740 3008	Ball Bearing - 8x22x7	
105	1105 0511	Harness Clamp - LWS-0306ZC	
106	0594 0080N	Hexagonal Set Screw - M4x8	
107	0741 3706	Ball Bearing - 6x10x3	
108	0720 0040E	Retaining Ring - M4	
109	0720 0080E	Retaining Ring - M8	
110	0701 0060N	Washer DIA6	
111	0701 0040N	Washer:DIA4	
112	0453 3006N	Tapping Screw - M3x6	
113	0451 4008N	Tapping Screw:4x8	

10. Plotter Unit 1 (C282)




10. Plotter Unit 1 (C282)

Index No.	Part No.	Description	Q'ty Per Assembly
*	C282 1905	Plotter:Fix:B4:Ass'y	1
*	C282 1911	Plotter:UNI:LG	1
1	C267 2167	Cover:Harness:Left	1
2	C267 2164	Cover:Harness:Exit:Upper:Plotter	1
3	C267 2174	Bracket:Connector:Plotter	1
4	C267 2182	Bracket:Harness:Left Inner Rear:Plotter	1
5	C267 2173	Cover:Upper:Plotter:2	1
6	C267 2165	Cover:Harness:Exit:Lower:Plotter	1
7	C267 2161	Bracket:Harness:Rear:Plotter	1
8	C267 2177	Cover:Rear:Plotter	1
9	C267 1994	Stopper:Rail:Plotter:Middle	2
10	C267 2186	Slide Rail:Plotter:Inner	2
11	C267 2160	Bracket:Slide Rail:Plotter:Rear	1
12	C282 1304	Cover:Plotter	1
13	AG07 0514	Magnet Catch	1
14	C267 2288	Bracket:On Off Detector:Lower:Plotter:2	1
15	C267 2170	Bracket:Slide Rail:Plotter:Front	1
16	C267 2178	Cover:Front:Plotter	1
17	C267 2166	Bracket:On Off Detector Board:Upper:Plotter	1
18	A659 1272	Door Catch	1
19	C282 1331	Decal:Master Set Instructions:Stopper Guide	1
20	C282 5242	Harness:Connecting:Plotter:Ass'y	1
21	C282 5244	Harness:Connecting:Plotter:2:Ass'y	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0454 3006Q	Tapping Screw - M3x6	
103	0353 0040N	Screw - M3x4	
104	0451 4006N	Tapping Screw - 4x6	
105	0353 0060N	Bind Screw - M3x6	
106	0451 4008N	Tapping Screw:4x8	
107	1105 0534	Clamp	
108	1105 0488	Harness Clamp	

11. Plotter Unit 2 (C282)




11. Plotter Unit 2 (C282)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C252 2281	Discharge Brush:Cutter	1
2	C252 1971	Decal:Open And Close:Plotter:Left	1
3	C252 1972	Decal:Open And Close:Plotter:Left	1
4	C261 2045	Cover:Open And Close:Plotter	1
5	C261 2046	Guide Plate	1
6	C261 2114	Roller:Tension:B4 (EU, AA, CHN)	1
6	C261 2115	Roller:Tension:LG (NA)	1
7	H012 1181	Bushing - 6mm	2
8	C261 2030	Rear Plate:Open And Close	1
9	C231 2148	Tension Roller Gear	1
10	C231 2147	Idler Gear	1
11	C231 2146	Platen Roller Gear	1
12	C238 2106	Ball Bearing - 6x13x5mm	2
13	C261 2039	Spring:Lever:Lock:Plotter	2
14	C238 2037	Lever Knob	1
15	C261 2036	Lever:Open And Close:Plotter	1
16	C261 2040	Side Plate:Open And Close:Front:Plotter:Ass'y	1
17	C261 2108	Cover:Open And Close:Lower	1
18	C261 2271	Cutter Unit:B4:Ass'y	1
19	C267 2220	Holder:Master:Front	1
20	C261 1955	Stay:Coupling:Plotter	1
21	C252 1950	Positioning Pin:Coupling:Plotter:Ass'y	1
22	C267 2210	Holder:Master:Rear	1
23	C282 2104	Platen:B4	1
23	C282 2105	Platen:A4/LG	1
24	C238 1962	Front Spring	1
25	C238 2243	Master Flange - MH	2
25	C238 2244	Flange:Master:50.8/20	2
26	C261 1961	Spring:Open And Close:Rear:Plotter	1
27	C217 5102	Spring Washer	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0720 0040E	Retaining Ring - M4	
103	0574 0040E	Hexagon Headless Set Screw - M4x4	
104	0450 3008N	Tapping Screw - M3x8	
105	0451 3008N	Tapping Screw - M3x8	

12. Plotter Unit 3 (C282)




12. Plotter Unit 3 (C282)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C252 2085	Guide Plate:Brake:Upper:Plotter	1
2	C252 2082	Guide Plate:Brake:Lower:Plotter:Sub-ass'y	1
3	C252 2281	Discharge Brush:Cutter	1
4	C261 2077	Roller:Brake:Plotter	1
5	C267 2064	Lever:Roller:Brake	2
6	C267 2078	Bracket Shoe:Roller:Brake:Plotter	1
7	C274 2057	Display Sub-unit:Leading Edge:Master:Printing	1
8	C261 2052	Positioning Plate:Master	1
9	C267 2066	Spring:Roller:Brake:Plotter	2
10	C261 2054	Spring:Positioning Plate:Master	1
11	C261 2151	Thermal Head:B4	1
12	C282 5240	Harness:Imaging Unit:Ass'y	1
13	C252 2157	Spring:Thermal Head:Both Ends	4
14	C261 2156	Spring:Thermal Head:Middle	1
15	C261 2026	Base:Thermal Head	1
16	C267 2020	Side Plate:Fix:Front:Plotter:Ass'y	1
17	C280 5854	Optics Sensor:Master:Duct	1
18	C261 2279	Bracket:Sensor:Master	1
19	C252 2092	Guide Plate:Thermal Head:Ass'y	1
20	C267 2095	Guide Plate:Master	1
21	C267 2290	Base:Fix:Plotter:2:Peen	1
22	C282 5241	Harness:Stepper Motor:Ass'y	1
23	C267 5844	Stepper Motor:DIA42:Plotter:Ass'y	1
24	C267 2010	Side Plate:Fix:Rear:Plotter:Ass'y	1
25	C231 2135	Platen Gear - 2	1
26	C267 2133	Gear:Idler:1:Platen	1
27	C231 2234	Brake Pad	1
28	C261 2273	Bracket:On Off Detector:Plotter	1
29	AW02 0203	Photointerruptor	1
30	C249 2230	Brake Shoe	1
31	G570 1225	Sensor Shielding Plate	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0353 0040N	Screw - M3x4	
103	0454 3006Q	Tapping Screw - M3x6	
104	0720 0030E	Retaining Ring - M3	
105	0720 0040E	Retaining Ring - M4	
106	1105 0488	Harness Clamp	
107	1105 0328	Harness Clamp - ES-0505	
108	0352 0080P	Screw M2x8	
109	1106 0851	Bush:NJ-16	
110	0453 3006N	Tapping Screw - M3x6	
111	1105 0534	Clamp	

13. Press Roller Section (C282)




13. Press Roller Section (C282)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C238 3127	Pressure Spring Nut	2
2	C261 4481	Arm:Drive:Pickoff Pawl	1
3	C252 4365	Pickoff Pawl:Exit	1
4	C267 4480	Shaft:Pickoff Pawl:Ass'y	1
5	C238 4493	Exit Pawl Drive Arm 2	1
6	C261 4485	Bracket:Roller:Pressure Release	1
7	C229 2615	Slide Rail Roller	2
8	C261 2601	Stay:Drum:Machine Or Copier:Ass'y	1
9	AW02 0203	Photointerruptor	1
10	C261 5611	Bracket:Sensor:Paper Feed Control	1
11	C261 3123	Anchor:Spring:Pressure:Right:Ass'y	1
12	C267 3134	DC Solenoid:Pressure Release:Right:Ass'y	1
13	C238 3126	Pressure Spring Screw	2
14	C252 3140	Spring:Pressure:B4	2
14	C261 3141	Spring:Pressure:A4/LG	2
15	C261 3103	Side Plate:Pressure:Right:Ass'y	1
16	C267 3050	Pressure Roller:B4:Ass'y	1
16	C267 3052	Pressure Roller:A4/LG:Ass'y	1
17	C261 3113	Arm:Pressure Roller:Right:Ass'y	1
18	C252 1080	Bushing	4
19	C261 3117	Stopper:Pressure Roller	1
20	C261 3116	Bracket:Stopper:Pressure Roller	1
21	C261 3110	Arm:Pressure Roller:Left:Ass'y	1
22	5506 6111	Stepped Screw - M4	1
23	C261 2605	Positioning Pin:Drum:Ass'y	2
24	C261 3100	Side Plate:Pressure:Left:Ass'y	1
25	C267 3130	DC Solenoid:Pressure Release:Left:Ass'y	1
26	C261 3137	Spring:Pressure Release	2
27	C261 3120	Anchor:Spring:Pressure:Left:Ass'y	1
28	C267 4349	Spring:Arm:Pickoff Pawl	1
29	C261 3165	Arm:Pressure Release:Right:Ass'y	1
30	C267 4479	Bushing	1
31	C261 3135	Bracket:Pressure Release:Right	1
32	C261 3160	Arm:Pressure Release:Left:Ass'y	1
33	G570 1225	Sensor Shielding Plate	1

Index No.	Part No.	Description	Q'ty Per Assembly
34	C261 3131	Bracket:Pressure Release:Left	1
101	0593 0080E	Bolt - M3x8	
102	0584 0121N	Hexagonal Head Bolt:M4x12	
103	0710 0040N	Hexagonal Nut:M4	
104	0701 0030N	Washer DIA3	
105	1105 0508	Harness Clamp - LWS-0711	
106	0593 0040E	Hexagonal Set Screw:M3x4	
107	0354 0040N	Screw-M4x4	
108	0720 0080E	Retaining Ring - M8	
109	0451 4006N	Tapping Screw - 4x6	
110	0720 0060E	Retaining Ring - M6	
111	0720 0040E	Retaining Ring - M4	
112	0451 4008N	Tapping Screw:4x8	
113	0353 0060N	Bind Screw - M3x6	

14. Drum Unit 1 (C282)




14. Drum Unit 1 (C282)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C261 2552	Screw:Slider	2
2	C612 1801	Screw:M4x8	4
3	C267 2642	Guide:Slider:Left:WLD:Ass'y	1
4	C267 2641	Slider:Holder:Ink Cartridge:WLD	1
5	C261 2555	Guide:Slider:Right	1
6	C252 2559	Spring:Pressure:Ink Cartridge	1
7	C261 2553	Rail:Holder:Left	1
8	C261 2554	Rail:Holder:Right	1
9	C267 2571	Shield:Holder:Ink Cartridge	1
10	C261 2531	Arm:Grip:Right	1
11	C261 2556	Lever:Release:Holder:Ass'y	1
12	C261 2560	Spring:Lever:Release	1
13	C261 2535	Shaft:Contact Point:Arm:Drum	1
14	C261 2530	Arm:Grip:Left	1
15	C267 2640	Holder:Ink Cartridge (21, 29, 61, 67, 27)	1
15	C267 2675	Holder:Ink Cartridge:NA:STD:Ass'y (11)	1
16	C252 2534	Grip:Drum:Lower	1
17	C267 2574	Slider:Housing	1
18	C261 2543	Cover:Harness:Drum	1
19	C261 2533	Screw:Arm:Drum	1
20	C238 2489	Rubber Bushing Plate	1
21	C261 2538	Bracket:Housing:Drum	1
22	C282 5257	Harness:Drum:Connecting:B4:Ass'y	1
22	C282 5258	Harness:Drum:Connecting:A4:Ass'y	1
22	C282 5259	Harness:Drum:Connecting:Legal:Ass'y	1
23	C238 2573	Stepped Screw	1
24	C267 3452	Roller:Rail:Drum	2
25	C267 2396	Spring Plate:Stopper	1
26	C238 2585	Screw MM6x1.7	3
27	C261 2567	Stay:Coupling:Grip	1
28	C267 2395	Bracket:Stopper:Drum	1
29	C282 2504	Frame:Upper:Drum:Ass'y	1
30	C267 2525	Stay:Grip:Drum:Right	1
31	C267 2524	Stay:Grip:Drum:Left	1
32	C252 2526	Grip:Drum:Upper	1

Index No.	Part No.	Description	Q'ty Per Assembly
33	C267 2394	Spring Plate:Grip:Drum	1
34	C282 2524	Decal:Pull Out:Drum	1
35	C267 2322	Holder:Ink Cartridge:WLD:Ass'y (21, 29, 61, 67, 27)	1
35	C267 2323	Holder:Ink Cartridge:NA:STD:Ass'y (11)	1
36	C267 2390	Sheet:Sensor:Drum	1
37	C252 2412	Friction Pad:Screen:Large (B4)	1
37	C252 2414	Friction Pad:Screen:LG/A4	1
38	C252 2413	Friction Pad:Screen:Small	1
39	C252 2340	Screen:B4:Ass'y	1
39	C252 2341	Screen:LG:Ass'y	1
39	C267 2342	Screen:A4:Ass'y	1
101	0720 0060E	Retaining Ring - M6	
102	0954 4006Z	Screw - M4x6	
103	0720 0040E	Retaining Ring - M4	
104	0353 0050Z	Philips Truss Head Screw - M3x5	
105	0807 5049	Wave Washer - 8 mm	
106	0594 0060Z	Hexagon Socket Bolt - M4x6	
107	0450 4006N	Tapping Screw:4x6	
108	0353 0080Z	Philips Tress Head Screw - M3x8	
109	0354 0040Z	Screw - M4x4	

15. Drum Unit 2 (C282)




15. Drum Unit 2 (C282)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C261 2401	Clamp:Ass'y	1
2	C231 2417	Master Exit Pawls	1
3	C261 2402	Base:Clamp:Drum:Ass'y	1
4	C261 2520	Side Plate:Drum:Left	1
5	C261 2406	Shaft:Clamp:Drum	1
6	C238 2410	Clamper Rear Spring	1
7	C261 2405	Plate:Clamp	1
8	C267 2360	Flange:Drum:B4/LG:Left:Ass'y	1
8	C267 2364	Flange:Drum:A4:Left:Ass'y	1
9	C252 2370	Spacer:Drum Shaft:Right	1
10	C267 2362	Flange:Drum:B4/LG:Right:Ass'y	1
10	C267 2366	Flange:Drum:A4:Right:Ass'y	1
11	C238 2368	Drum Drive Gear	1
12	C252 2396	Wedge:Plate:Thrust	1
13	C252 2395	Plate:Thrust:Drum	1
14	C261 2521	Side Plate:Drum:Right	1
15	C261 2368	Shielding Plate:Drum	1
16	C267 2424	Filter:Pump:Ink	1
17	C261 2388	Stay:Screen:Front:B4	1
17	C261 2390	Stay:Screen:Front:A4/LG	1
18	C261 2389	Stay:Screen:Rear:B4	1
18	C261 2391	Stay:Screen:Rear:A4/LG	1
19	C267 2416	Friction Pad:Small:Magnetic	2
20	C252 2590	Metal Screen - B4	1
20	C252 2593	Dram Metal Screen:Drum:LG:Ass'y	1
20	C267 2586	Dram Metal Screen:Drum:A4:Ass'y	1
21	C238 2413	Sheet:Sensor:Trailing Edge:Screen	1
22	C238 2572	Stopper Spring	1
23	C267 2572	Stopper:Turn	1
24	C267 2570	Bracket:Stopper:Turn	1
25	C252 2410	Torsion Spring:Pawl:Master Ejection:Master	1
26	C238 2585	Screw MM6x1.7	2
27	C217 4581	Ink Roller Drive Gear	1
28	C231 2565	Ink Cartridge Joint	1
29	C261 2558	Base:Lever:Release	1

Index No.	Part No.	Description	Q'ty Per Assembly
30	C238 2412	Clamper Cam	1
101	0720 0020E	Retaining Ring - M2	
102	1105 0511	Harness Clamp - LWS-0306ZC	
103	0951 3008Z	Philips Screw With Flat Washer - M3	
104	0354 0060Z	Philips Truss Head Screw - M4x6	
105	0450 3008Z	Tapping Screw - M3x8	
106	0452 3006N	Binding Self-tapping Screw:3x6	
107	0593 0100Z	Bolt M3x10	
108	0594 0080Z	Bolt - M4x8	
109	0807 7114	Washer - 16x24x0.3mm	
110	0804 6091	Hexagonal Set Screw - M2x5	
111	0808 0021	Rubber Ring	
112	0951 3006Z	Philips Screw With Flat Washer - M3	
113	0592 0040E	Hexagonal Set Screw:M2x4	
114	0354 0040Z	Screw - M4x4	
115	0593 0060Z	Hexagon Bolt - M3x6	

16. Drum Unit 3 (C282)




16. Drum Unit 3 (C282)

Index No.	Part No.	Description	Q'ty Per Assembly
*	C267 2311	Roller:Ink:A4/LG:Ass'y	1
*	C267 2312	Roller:Ink:B4:Ass'y	1
1	C267 2428	Pump Unit:Ink:B4:Ass'y	1
1	C267 2429	Pump Unit:Ink:A4:Ass'y	1
2	C252 2476	Side Plate:Roller:Ink:Right:Ass'y	1
3	C267 5251	Harness:Connecting:Pump:B4:Ass'y	1
3	C267 5254	Harness:Connecting:Pump:A4/LG:Ass'y	1
4	C267 4665	Bearing Case:Roller:Ink	2
5	C207 4672	Gear - 36Z	1
6	C238 2469	Doctor Roller Drive Gear	1
7	C267 2468	Ground Plate:Oil Supply Roller:Ink	1
8	C267 2481	Drum Shaft:B4:Ass'y	1
8	C267 2487	Drum Shaft:A4/LG:Ass'y	1
9	C261 2471	Ink Sensor:Ass'y	1
10	C252 2470	Stay:Ink Sensor	1
11	C261 2463	Stay:Main:Drum:B4	1
11	C261 2464	Stay:Main:Drum:A4/LG	1
12	C231 2450	Ink Roller - B4	1
12	C231 2456	Ink Roller - A4/LG	1
13	C252 2458	Oil Supply Roller:B4	1
13	C252 2459	Oil Supply Roller:LG/A4	1
14	C261 2465	Stay:Sub:Drum:B4	1
14	C261 2466	Stay:Sub:Drum:A4/LG	1
15	C267 2458	Ring:Front:Roller:Drum	1
16	C252 2492	Tension Spring:Ring:Roller:Drum	2
17	C218 4592	Front Bank Plate	1
18	C267 2459	Ring:Rear:Roller:Drum	1
19	C218 4594	Rear Bank Plate	1
20	C252 2475	Side Plate:Roller:Ink:Left	1
21	C252 2495	Plate:Side Plate:Roller:Ink	2
22	C252 2398	Spacer:Drum Shaft:Left (A4/LG)	1
23	C252 2397	Collar:Drum Shaft:Left	1
24	C261 5253	Harness:Ink Sensor:Ass'y	1
25	C200 4748	Gear - 45T	1
26	C247 2461	Adjusting Plate - Doctor Roller	2

Index No.	Part No.	Description	Q'ty Per Assembly
27	C267 2598	Blade:Front:Drum	1
28	C267 2599	Blade:Rear:Drum	1
29	C237 2460	Ink Drive Gear	1
30	5316 7421	O - Ring	2
31	C252 2485	Joint:Drum Shaft	2
32	C238 2489	Rubber Bushing Plate	2
33	C238 2488	Rubber Bushing	2
34	C267 2427	DC Mtor:Pump Unit	1
101	0353 0050Z	Philips Truss Head Screw - M3x5	
102	0807 7114	Washer - 16x24x0.3mm	
103	0725 0160E	Retaining Ring C - M16	
104	0594 0080Z	Bolt - M4x8	
105	0574 0040E	Hexagon Headless Set Screw - M4x4	
106	0951 4006Z	Philips Screw With Flat Washer - M4	
107	0314 0080Z	Philips Screw - 4x8	
108	0720 0050G	Retaining Ring - M5	
109	0450 3008Z	Tapping Screw - M3x8	
110	1105 0511	Harness Clamp - LWS-0306ZC	
111	0951 3006Z	Philips Screw With Flat Washer - M3	
112	0353 0100Z	Bind Screw - M3x10	
113	0354 0060Z	Philips Truss Head Screw - M4x6	

17. Vacuum Fan Unit (C282)




17. Vacuum Fan Unit (C282)

Index No.	Part No.	Description	Q'ty Per Assembly
*	C282 3804	Hale Unit:Ass'y	1
1	C261 3879	Transport Belt:Hale Unit:17	2
2	C261 3890	Guide:Hale Unit	2
3	C275 3879	Timing Belt:Drive:Hale Unit	1
4	C275 5811	DC Motor:2.5W:DIA34:Z15	1
5	C272 5887	Spacer:DC Fan Motor:Axial:MM119:24V	1
6	C275 3875	Pulley:Drive:Hale Unit	1
7	C261 3861	Duct:Hale Unit	1
8	C238 3890	Drive Roller - Drum Side	2
9	C238 3877	Driven Shaft	1
10	C261 3855	Bracket:Fan:Hale Unit:Ass'y	1
11	AX65 5800	DC Fan Motor:Axial:MM119:24V	1
12	AW01 0109	Photo Reflection Sensor:PS117ED1	1
13	C282 5260	Harness:Hale Unit:Ass'y	1
14	C282 5261	Harness:Connecting:Hale:Unit:Ass'y	1
15	C282 5262	Harness:Connecting:Hale:Fan:Ass'y	1
16	C275 3877	Shaft:Drive:Hale Unit:Sub-Ass'y	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008N	Tapping Screw:4x8	
102	0450 4008N	Tapping Screw - M4x8	
103	0354 0450N	Screw:M4x45	
104	0720 0060E	Retaining Ring - M6	
105	0633 0140G	Parallel Pin - 3x14	
106	0353 0060N	Bind Screw - M3x6	

18. Delibary Table (C282)




18. Delibary Table (C282)

Index No.	Part No.	Description	Q'ty Per Assembly
*	C282 4201	Paper Exit Sub-Unit:Ass'y	1
*	C282 4204	Paper Exit Sub-Unit:CHN:Ass'y	1
1	C282 4416	Case:End Plate:Exit	1
2	C282 4432	End Plate:Exit	1
3	C279 4406	Knob:End Plate:Exit	1
4	C267 4410	Bracket:End Plate:Ass'y	1
5	C282 4407	Case:Side Fence:Paper Exit Sub-Unit	2
6	C282 4398	Guide:Lower Rear:Paper Exit Sub-Unit:CHN:Printing	1
6	C282 4396	Guide:Lower Rear:Paper Exit Sub-Unit:Printing	1
7	C282 4464	Side Fence:Rear:Paper Exit Sub-Unit	1
8	C282 4465	Side Fence:Front:Paper Exit Sub-Unit	1
9	C261 4402	Stay:Rear:Paper Exit Sub-unit	1
10	C282 4390	Base:Paper Exit Sub-Unit:Printing	1
11	C231 4420	Slider Spring Plate	3
12	C279 4456	Cover:Slide:Paper Exit Sub-Unit	2
13	C261 4401	Stay:Front:Paper Exit Sub-unit	1
14	C261 4409	Supporting Plate:Paper Exit	1
15	C231 4413	Delivery Table Spring	3
16	C225 6113	Upper Pressure Spring Pin	1
17	C231 4419	End Plate Pin	1
18	C231 4414	Lower Side Fence Pin	2
19	C231 4415	Upper Side Fence Pin	2
20	C244 4426	Shoulder Screw	2
21	C282 4395	Guide:Lower Front:Paper ExitSub-Unit: Printing	1
21	C282 4397	Guide:Lower Front:Paper Exit Sub-Unit: CHN:Printing	1
22	C231 4425	End Plate Sheet	1
23	C267 4417	Cushion:End Fence	1
24	C279 4421	Cover:Slide:Paper Exit Sub-Unit	1
25	C282 4493	Guide:Paper:Side Fence	2
26	C282 4430	End Fence:Adhesion	1
27	C282 4441	Decal:Caution:Exit	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 3008N	Tapping Screw - M3x8	
102	0450 4008N	Tapping Screw - M4x8	
103	0451 3008N	Tapping Screw - M3x8	
104	0451 4006N	Tapping Screw - 4x6	
105	0450 3012N	Tapping Screw:3x12	

19. Master Eject Unit 1 (C282)




19. Master Eject Unit 1 (C282)

Index No.	Part No.	Description	Q'ty Per Assembly
*	C275 3450	Frame:Master Ejection Unit:Ass'y	1
1	C282 3510	Case:Master Ejection Unit:Ass'y	1
2	C279 3489	Lever:Master Ejection	1
3	C267 3679	Bracket:Auxiliary:Master Ejection	1
4	C261 3577	Plate:Master	1
5	C267 3680	Spring Plate:Guide:Master Ejection	2
6	C267 3530	Shaft:Lock:Master Ejection Unit:Ass'y	1
7	C267 3477	Bracket:Contact Point:Turn	1
8	AW02 0203	Photointerruptor	2
9	C267 3526	Bracket:Harness:Master Ejection Unit	1
10	C261 5050	Photointerrupt:Master Ejection	1
11	C261 3467	Bracket:Sensor:Master Ejection Unit	1
12	C261 3472	Cover:Sensor:Master Ejection Unit	1
13	C261 5150	PCB:Optics Sensor	1
14	C282 5230	Harness:Master Ejection Unit:Ass'y	1
15	C261 3469	Duct:Air Knife	1
16	C261 5825	Fan:Sirocco:DC24V:B054	1
17	C261 3470	Base:Air Knife	1
18	G570 1225	Sensor Shielding Plate	2
19	C267 3682	Sheet:Case:Master Ejection	1
20	C282 3678	Case:Master Ejection	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 3006Q	Tapping Screw - M3x6	
102	0454 3008Q	Tapping Screw:3x8	
103	0450 3008N	Tapping Screw 3x8	
104	0450 3006N	Tapping Screw - M3x6	
105	0354 0350N	Screw M4x35	
106	0353 0040N	Screw - M3x4	
107	0451 3006N	Tapping Screw - 3x6	
108	1105 0328	Harness Clamp - ES-0505	
109	1105 0508	Harness Clamp - LWS-0711	
110	1105 0488	Harness Clamp	
111	0353 0060N	Bind Screw - M3x6	
112	0451 3008N	Tapping Screw - M3x8	

20. Master Eject Unit 2 (C282)




20. Master Eject Unit 2 (C282)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C267 3574	Stay:Master Ejection Unit	1
2	C261 3567	Guide Plate	1
3	C267 3501	Side Plate:Front:Master Ejection:Ass'y	1
4	C261 3554	Shaft:Pressure:Master Ejection Unit	1
5	C261 3553	Arm:Pressure:Master Ejection	2
6	C252 3556	Spring:Pressure:Master Ejection:13.98N	2
7	C261 3656	Pressure Plate:Master Ejection	1
8	C267 3485	Roller:Upper:Master Ejection Unit:Ass'y	1
9	C261 3484	Roller:Lower:Master Ejection Unit:Ass'y	1
10	C261 3466	Base:Master Ejection	1
11	C259 5821	Stepper Motor:DIA42:Plotter:Ass'y	2
12	AW02 0203	Photointerruptor	1
13	C267 3521	Side Plate:Rear:Master Ejection:Ass'y	1
14	C252 3684	Gear:Pressure Plate:Master Ejection	1
15	C252 3487	Spring:Pressure:Roller:Master Ejection	2
16	C252 3486	Bushing:Pressure:MM6	2
17	C252 3525	Gear:Pressure:15/124	1
18	G570 1225	Sensor Shielding Plate	1
19	C237 3505	Pin 3x16	1
20	C231 3494	Gear - Lower Roller	1
21	C252 3492	Gear:Roller:50/84	1
22	C231 3489	Lower Roller Gear	1
23	C267 3473	Guide:Master Ejection	1
24	C267 3452	Roller:Rail:Drum	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0805 3385	Bushing - 6mm	
102	0720 0040E	Retaining Ring - M4	
103	0353 0060N	Bind Screw - M3x6	
104	0954 3008N	Screw - M3x8	
105	0451 3006N	Tapping Screw - 3x6	
106	1105 0508	Harness Clamp - LWS-0711	
107	1105 0534	Clamp	

21. Electrical Section 1 (C282)




21. Electrical Section 1 (C282)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C275 5206	Harness:Ink:Ass'y	1
2	C267 5276	Harness:Paper Feed Tray:Sensor:Ass'y	1
3	C282 5200	Harness:DC Drive:Ass'y	1
4	C282 5201	Harness:Motor:Ass'y	1
5	C282 5101	PCB:MPU:Sub-Ass'y	1
6	C275 5675	Bracket:Control Unit:Fix	1
7	C267 5627	Bracket:Power Supply Unit	1
8	C282 5841	Inlet:Ass'y	1
9	C282 5670	Bracket:Power Supply Cord	1
10	C275 5330	DC Power Supply:Main:NA:Ass'y	1
10	C275 5340	DC Power Supply:Main:200V:Ass'y	1
11	AX64 0188	Fan Motor DC24V 1.68W	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4006N	Tapping Screw - 4x6	
102	0451 3006N	Tapping Screw - 3x6	
103	0954 3006N	Screw - M3x6	
104	1107 1295	Fuse:Glass Cartridge:FSL 250V 6.3A(EM)	
105	1107 1296	Fuse:Glass Cartridge:FSL 250V 8A(EM)	
106	1102 6088	Inlet- AC -P03CS05 (EU, NA)	
107	1407 7520	RAM:FM25V02-PG (REV.AA)	

22. Electrical Section 2 (C282)




22. Electrical Section 2 (C282)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C282 3733	Button:Master Ejection	1
2	C267 3732	Lever:Open And Close:Master Ejection Unit	1
3	C261 2552	Screw:Slider	4
4	C267 1060	Cover:Side Plate:Machine Or Copier:Front	1
5	C282 5101	Bracket:Spring:Master Ejection	1
6	C267 3738	Spring:Lever:Lower	1
7	C267 3731	Lever:Lower	1
8	C267 3730	Lever:Middle	1
9	C282 5202	Harness:Main Switch:Ass'y	1
10	C267 5650	Bracket:Main Switch	1
11	C275 5685	Bracket:On Off Detector:Door	1
12	C267 2172	Lever:Safety Switch	2
13	C267 5635	Spring Plate:Safety Switch	1
14	C267 3706	Bracket:On Off Detector:	
		Master Ejection Unit	1
15	C261 2611	Bracket:Receptacle	1
16	C238 5651	Total Counter Bracket	1
17	C267 1085	Cover:On Off Detector:	
		Machine Or Copier:Upper	1
18	C267 1074	Bracket:On Off Detector:	
		Machine Or Copier:Plotter	1
19	G020 5626	Push Switch	1
20	C238 2785	Tray Motor Bracket	1
21	C267 2782	DC Motor:Paper Feed Tray	1
22	C267 1321	Bracket:Plate:Cover:Front	1
23	C257 5856	Push Switch	1
24	AX31 0049	Total Counter:7Fig:24V	2
25	C267 2176	Spring Plate:Safety Switch	1
26	C267 3737	Spring:Lever:Middle	1
27	C261 5686	Screw:Round Point:Safety Switch	2
28	C282 5333	Rocker Switch	1
29	C267 5252	Harness:Connecting:Drum:Ass'y	1
30	C244 2633	Stepped Screw	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	1204 2497	Micro Switch	
102	0951 3025N	Screw:Polished Round:M3x25	
103	0353 0060N	Bind Screw - M3x6	
104	0454 4006Q	Tapping Screw:4x6	
105	0951 3014N	Screw Polished Round M3x14	
106	0450 4025N	Tapping Screw:4x25	
107	0451 4006N	Tapping Screw - 4x6	
108	0314 0040N	Pan Head Screw - M4x4	
109	1105 0534	Clamp	

23. Drive Section 1 (C282)




23. Drive Section 1 (C282)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C267 5622	Bracket:Base:Fix	1
2	C261 2817	Bracket:Drive:Paper Feed Roller	1
3	G570 1225	Sensor Shielding Plate	2
4	C261 5879	Magnetic Clutch:Paper Feed Roller	1
5	C252 1179	Pulley:Drive:Paper Feed	1
6	C275 1160	Gear:Drive:Drum:Ass'y	1
7	C275 1180	Timing Belt:Drive:Main	1
8	C275 1172	Side Plate:Drum Drive Sub-unit	1
9	C261 1171	Bearing Case	1
10	5053 0447	Bushing - 6mm	1
11	C259 5821	Stepper Motor:DIA42:Plotter:Ass'y	1
12	C274 2948	Timing Belt:Paper Feed:140-XL-050	1
13	AA14 3802	Screw:6x1.7	1
14	C244 4426	Shoulder Screw	1
15	C275 1173	Stopper:Gear:Remover/Install	1
16	C275 1177	Spacer:Power Supply Unit	1
17	C252 2888	Pulley:Stepper Motor:Feed:23Z	1
18	C267 2885	Tension Spring:Bracket:Stepper Motor	1
19	C261 2887	Bracket:Stepper Motor:Feed	1
20	C257 5817	Stepper Motor MM56x64	1
21	AW02 0203	Photointerruptor	2
22	C252 4068	Gear:Drive:Rack	1
23	C252 4069	Gear:Slow Down	1
24	C261 4064	Side Plate:Drive Sub-unit:Clamp	1
25	C275 1174	Tension Spring:Lock:Gear:Remover/Install	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0574 0080E	Hexagon Headless Set Screw - M4x8	
102	0354 0080N	Screw:M4x8	
103	0451 4006N	Tapping Screw - 4x6	
104	0740 3010	Ball Bearing - 10x26x8mm	
105	0807 7046	Washer - 10.5x20x0.2mm	
106	0720 0040E	Retaining Ring - M4	
107	0353 0060N	Bind Screw - M3x6	
108	1105 0508	Harness Clamp - LWS-0711	
109	0454 4006Q	Tapping Screw:4x6	
110	1105 0534	Clamp	
111	0451 3006N	Tapping Screw - 3x6	
112	1105 0489	Harness Clamp - LWS 1316	
113	1105 0511	Harness Clamp - LWS-0306ZC	

24. Drive Section 2 (C282)




24. Drive Section 2 (C282)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C267 5623	Bracket:Base:Guard	1
2	C282 5614	Bracket:SD-Card:Front	1
3	C275 5616	Bracket:UC2:Rear	1
4	C267 5616	Bracket:Fix:Power Supply Unit	5
5	C267 5617	Bracket:Fix:Power Supply Uni:Upper	1
6	C252 1152	Timing Pulley:Drive:Main	1
7	C252 1195	Hexagonal Set Screw:M5x8	2
8	C267 1185	Base:Brushless Motor:Main	1
9	C267 5890	Brushless Motor:Main:DC24V	1
10	C279 5631	Cover:Guard:Tape Mark (AA, NA, CHN)	1
11	C282 5639	Cover:No.1	1
12	C261 5610	Bracket:Home Position Sensor	1
13	C252 1154	Roller:Belt Tensioner:Ass'y	1
14	C275 1156	Shaft:Belt Tensioner:Ass'y	1
15	C252 4063	Guide:Clamp:Master Feed	1
16	C261 4055	Lever:Drive:Master Feed:Peen	1
17	C261 4001	Base:Clamp:Open And Close:Ass'y	1
18	C244 4426	Shoulder Screw	2
19	C261 4059	Lever:Drive:Master Ejection:Peen	1
20	C252 4062	Guide:Positioning:Drum	1
21	C238 4070	Eject Clamp Pusher	1
22	C252 4052	Rack:Drive:Clamp	1
23	C279 5630	Bracket:Connector:Tape Mark (AA, NA, CHN)	1
24	C267 3716	Inner Cover:Open And Close	1
25	AW02 0203	Photointerruptor	1
26	G570 1225	Sensor Shielding Plate	1
27	C275 5619	Bracket:Fix:Power Supply Unit:Upper	1
28	C282 5617	Bracket:Fix:MPU:Upper	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0315 0200N	Pan Head Screw:M5x20	
102	0454 4006Q	Tapping Screw:4x6	
103	0451 3006N	Tapping Screw - 3x6	
104	0451 4006N	Tapping Screw - 4x6	
105	0720 0040E	Retaining Ring - M4	
106	0720 0060E	Retaining Ring - M6	
107	0314 0040N	Pan Head Screw - M4x4	
108	1105 0534	Clamp	
109	1105 0508	Harness Clamp - LWS-0711	
110	1105 0490	Harness Clamp - IWS-2218	
111	1105 0522	Edge Saddle - LES0510	

25.Frame Section 1 (C282)




25. Frame Section 1 (C282)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C267 3714	Bracket:Contact Point:Fix: Master Ejection Unit:Middle	1
2	C267 3704	Bracket:Contact Point:Fix: Master Ejection Unit	1
3	C267 3713	Shaft:Contact Point:Master Ejection:Upper	1
4	C267 5612	Bracket:Sensor:Misfeed Removal	1
5	AW02 0203	Photointerruptor	1
6	G570 1225	Sensor Shielding Plate	1
7	C282 5231	Harness:Master Ejecting:Sensor:Ass'y	1
8	C267 3882	Bracket:Drum Stay:Paper Exit Sub-unit:Rear	1
9	C267 3884	Bracket:Drum Stay:Exit:Lower Rear	1
10	C267 4441	Remover/Install Sub-unit:Exit:Rear:Peen	1
11	C267 4431	Remover/Install Sub-unit:Exit:Front:Peen	1
12	C238 4450	Hinge Screw	2
13	C267 3717	Supporter:Master Ejection Unit	1
14	C267 3881	Bracket:Drum Stay:Paper Exit Sub-unit:Front	1
15	C267 3883	Bracket:Drum Stay:Exit:Lower Front	1
16	C275 3801	Drum Stay:Paper Exit Sub-unit:Ass'y	1
17	C267 3888	Discharge Brush:Drum Stay:Exit:Lower	1
18	C267 5652	Bracket:Key Counter	1
19	C238 1339	Key Counter Plate Nut	1
20	C261 3885	Discharge Brush:Long:Paper Exit	2
21	C261 3886	Discharge Brush:Short:Paper Exit	1
22	C279 1086	Cover:Safety:Base:Upper	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4006N	Tapping Screw - 4x6	
102	1105 0534	Clamp	
103	0451 4008N	Tapping Screw:4x8	
104	1105 0508	Harness Clamp - LWS-0711	
105	0323 0100N	Screw M3x10	
106	0451 3006N	Tapping Screw - 3x6	

26. Frame Section 2 (C282)






26. Frame Section 2 (C282)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C267 1075	Cover:Harness:Operation Panel:Upper Left	1
2	C282 1062	Adjutting Pin:Scanner Unit:Upper Lower	2
3	C282 1058	Stay:Machine Or Copier:Scanner Unit:Left	2
4	C267 2958	Ground Plate:Cover:Stay:Paper Feed	2
5	C282 1053	Stay:Main:Scanner:Right:Ass'y	1
6	C267 1079	Screw:DIA4	3
7	C267 1077	Link:Machine Or Copier:Plotter:Front:Peen	2
8	C267 1082	Slider:Harness:Machine Or Copier:Plotter	2
9	C267 1087	Link:Machine Or Copier:Plotter: Inner Back:Peen	1
10	C267 1076	Bracket:Link:Lower	1
11	5447 2681	Snap Ring	1
12	C267 1081	Cover:Harness:Operation Panel:2	1
13	C282 5245	Harness:Connecting:Cutter Unit:Ass'y	1
14	C282 5242	Harness:Connecting:Plotter:1:Ass'y	1
15	C267 2275	Rail:Plotter:Outer	2
16	C282 2276	Slide Rail:Plotter:Middle	2
17	C267 1070	Guard:Rack:Paper Feed Tray	2
18	C238 1057	Rubber Foot	4
19	C282 5244	Harness:Connecting:Plotter:2:Ass'y	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0314 0040N	Pan Head Screw - M4x4	
102	0454 4006Q	Tapping Screw:4x6	
103	0454 3006Q	Tapping Screw - M3x6	
104	1105 0488	Harness Clamp	
105	0452 3006N	Binding Self-tapping Screw:3x6	
106	0451 4006N	Tapping Screw - 4x6	
107	0951 4020N	Screw - M4x20	
108	1105 0489	Harness Clamp - LWS 1316	
109	0451 4008N	Tapping Screw:4x8	

27. Decals and Documents (C282)

1  For Europe: Imported by Ricoh Europe PLC 20 Triton Street, London, NW1 3BF, U.K. For Asia Pacific: Imported by Ricoh Asia Pacific Subsidiary Or Ricoh Asia Pacific Authorised Partner	2 	3 
4 	5 	6 
7 		

27. Decals and Documents (C282)

8

SD375

DD 3334

DD 3344

DD 3324

CP 6303c

DD 3344c

9

10

11

供纸器

厚纸

标准纸

薄纸

Feeder

Thick paper


Standard

Thin paper

12

61

27. Decals and Documents (C282)


13 •Pull out the drum unit, holding the handle with both hands. •Die Trommereinheit herausziehen und mit beiden Händen festhalten. •Sortez le tambour en tenant les poignées avec les deux mains. •Estrarre il tamburo utilizzando le due impugnature come da figura. •Estire la unidad del tambor, sujetando las asas con ambas manos. •抽出印筒時、请用双手握著手柄 •ドラムは、取っ手を両手でしっかりと持って引き抜いてください。 	16  WARNING ATTENTION WARNUNG AVVISO AVISO 警告 •To avoid injury, do not touch moving parts or insert your fingers in the opening during machine operation. To de-energize moving parts, open the front cover. •Afin d'éviter des blessures, ne pas toucher de pièces en mouvement ou insérer vos doigts dans l'ouverture en cours d'utilisation. Pour arrêter le fonctionnement du magasin, ouvrir le carter frontal. •Verletzungsgefahr! Bei Betrieb nicht in die Öffnung greifen. Um bewegliche Teile stromlos zu schalten, Frontklappe öffnen. •Per evitare incidenti, non toccare le parti in movimento o mettere le dita nell'apertura mentre la macchina è in funzione. Per togliere l'energia elettrica alle parti in movimento, aprire il coperchio frontale del cassetto. •Para evitar dañarse, no toque las partes móviles ni ponga sus dedos en la abertura, mientras la máquina esté en funcionamiento. Para desactivar las partes móviles, abra la cubierta frontal. •为避免受伤，当机器运转时请勿接触运转部件，也不要把手指伸入机器的开口处。打开前盖，运转部将自动停止。	17  WARNING ATTENTION WARNUNG AVVISO AVISO 警告 •To avoid injury, do not touch moving parts or insert your fingers in the opening during machine operation. To de-energize moving parts, open the front cover. •Afin d'éviter des blessures, ne pas toucher de pièces en mouvement ou insérer vos doigts dans l'ouverture en cours d'utilisation. Pour arrêter le fonctionnement du magasin, ouvrir le carter frontal. •Verletzungsgefahr! Bei Betrieb nicht in die Öffnung greifen. Um bewegliche Teile stromlos zu schalten, Frontklappe öffnen. •Per evitare incidenti, non toccare le parti in movimento o mettere le dita nell'apertura mentre la macchina è in funzione. Per togliere l'energia elettrica alle parti in movimento, aprire il coperchio frontale del cassetto. •Para evitar dañarse, no toque las partes móviles ni ponga sus dedos en la abertura, mientras la máquina esté en funcionamiento. Para desactivar las partes móviles, abra la cubierta frontal. •为避免受伤，当机器运转时请勿接触运转部件，也不要把手指伸入机器的开口处。打开前盖，运转部将自动停止。
14 	15 	
18 		
19 RICOH Gestetner		

27. Decals and Documents (C282)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C282 1395	Decal:AA:Safety:ABS	1
2	C282 2967	Decal:Adjustment Scale:Move:Paper Feed	1
3	D074 2541	Decal:Arrow Label	1
4	C282 4441	Decal:Caution:Exit	1
5	C282 1396	Decal Main Switch:CHN:PS	1
6	C282 1331	Decal:Master Set Instructions:Stopper Guide	1
7	C282 1391	Decal:Master Set Instructions:ABS	1
8	C282 1382	Decal:Name Plate:STD	1
8	C282 1383	Decal:Name Plate:DD3334	1
8	C282 1384	Decal Name Plate:DD3344	1
8	C282 1385	Decal:Name Plate:DD3324	1
8	C282 1386	Decal:Name Plate:CP6303C	1
8	C282 1387	Decal:Name Plate:DD3344C	1
9	C252 1971	Decal:Open And Close:Plotter:Left	1
10	C252 1972	Decal:Open And Close:Plotter:Left	1
11	C282 2996	Decal:Paper Feed Pressure	1
11	C282 2995	Decal:Paper Feed Pressure:English	1
12	C279 2996	Decal:Paper Set Direction	1
13	C282 2524	Decal:Pull Out:Drum	1
14	M125 6835	Decal:Warning:2000M	1
15	C279 1330	Decal:Paper Feed Tray	1
16	C279 1314	Decal:Warning:Paper Feed:EXP	1
17	C279 1392	Decal:Warning:Paper Feed:EXP:PS	1
18	C282 2998	Decal:Size Indication:Paper Feed	1
19	D120 1551	Sheet:Logo	1
19	D120 1557	Sheet:Logo:GES	1
19	C279 1523	Sheet:Logo:No Brand	1

Index No.	Part No.	Description	Q'ty Per Assembly

28. Special Tools (C282)



28. Special Tools (C282)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A006 9104	Scanner Positioning Pin (4pcs/set)	1
2	B645 5020	SD-Card:Service:1GB:Ass'y	1
3	A069 9502	Alvania 2 Grease	1

Index No.	Part No.	Description	Q'ty Per Assembly

Parts Index

PM Parts Index

Section Name	Part No.	Description in Service Manual	Description in Parts Catalog	Q'ty Per Assembly	Page and Index No.
Paper Registration 1 (C282)	C267 2802	Roller:Paper Feed:Ass'y	Roller:Paper Feed:Ass'y	2	21 - 4
Paper Registration 1 (C282)	C267 2819	Separation Pad:Ass'y	Separation Pad:Ass'y	1	21 - 27
Paper Registration 1 (C282)	C267 2820	Separation Pad:CHN:Ass'y	Separation Pad:CHN:Ass'y	1	21 - 27
Press Roller Section (C282)	C267 3050	Pressure Roller:B4:Ass'y	Pressure Roller:B4:Ass'y	1	33 - 16
Press Roller Section (C282)	C267 3052	Pressure Roller:A4/LG:Ass'y	Pressure Roller:A4/LG:Ass'y	1	33 - 16
Drum Unit 1 (C282)	C252 2340	Screen:B4:Ass'y	Screen:B4:Ass'y	1	35 - 39
Drum Unit 1 (C282)	C252 2341	Screen:LG:Ass'y	Screen:LG:Ass'y	1	35 - 39
Drum Unit 1 (C282)	C267 2342	Screen:A4:Ass'y	Screen:A4:Ass'y	1	35 - 39
Vacuume Fan Unit (C282)	C261 3879	Transport Belt:Hale Unit:17	Transport Belt:Hale Unit:17	2	41 - 1

Parts Index

Part No.	Description	Page and Index No.
0314 0040N	Pan Head Screw - M4x4	19 - 106
0314 0040N	Pan Head Screw - M4x4	21 - 111
0314 0040N	Pan Head Screw - M4x4	51 - 108
0314 0040N	Pan Head Screw - M4x4	55 - 107
0314 0040N	Pan Head Screw - M4x4	57 - 101
0314 0080Z	Philips Screw - 4x8	39 - 107
0315 0200N	Pan Head Screw:M5x20	55 - 101
0323 0100N	Screw M3x10	57 - 105
0352 0080P	Screw M2x8	31 - 108
0353 0040N	Screw - M3x4	9 - 104
0353 0040N	Screw - M3x4	27 - 103
0353 0040N	Screw - M3x4	31 - 102
0353 0040N	Screw - M3x4	45 - 106
0353 0050Z	Philips Truss Head Screw - M3x5	35 - 104
0353 0050Z	Philips Truss Head Screw - M3x5	39 - 101
0353 0060N	Bind Screw - M3X6	15 - 101
0353 0060N	Bind Screw - M3x6	23 - 103
0353 0060N	Bind Screw - M3x6	27 - 105
0353 0060N	Bind Screw - M3x6	33 - 113
0353 0060N	Bind Screw - M3x6	41 - 106
0353 0060N	Bind Screw - M3x6	45 - 111
0353 0060N	Bind Screw - M3x6	47 - 103
0353 0060N	Bind Screw - M3x6	51 - 103
0353 0060N	Bind Screw - M3x6	53 - 107
0353 0080Z	Philips Tress Head Screw - M3x8	35 - 108
0353 0100Z	Bind Screw - M3x10	39 - 112
0353 0120N	Screw M3x12	21 - 101
0354 0040N	Screw-M4x4	33 - 107
0354 0040Z	Screw - M4x4	35 - 109
0354 0040Z	Screw - M4x4	37 - 114
0354 0060Z	Philips Truss Head Screw - M4x6	37 - 104
0354 0060Z	Philips Truss Head Screw - M4x6	39 - 113
0354 0080N	Screw:M4x8	53 - 102
0354 0350N	Screw M4x35	45 - 105
0354 0450N	Screw:M4x45	41 - 103

Part No.	Description	Page and Index No.
0450 3006N	Tapping Screw - M3x6	19 - 110
0450 3006N	Tapping Screw - M3x6	21 - 112
0450 3006N	Tapping Screw - M3x6	45 - 104
0450 3008N	Tapping Screw - M3x8	19 - 109
0450 3008N	Tapping Screw - M3x8	29 - 104
0450 3008N	Tapping Screw - M3x8	43 - 101
0450 3008N	Tapping Screw 3x8	45 - 103
0450 3008Z	Tapping Screw - M3x8	37 - 105
0450 3008Z	Tapping Screw - M3x8	39 - 109
0450 3012N	Tapping Screw:3x12	43 - 105
0450 4006N	Tapping Screw:4x6	35 - 107
0450 4008N	Tapping Screw - M4x8	19 - 108
0450 4008N	Tapping Screw - M4x8	41 - 102
0450 4008N	Tapping Screw - M4x8	43 - 102
0450 4010N	Tapping Screw:M4x10	9 - 102
0450 4025N	Tapping Screw:4x25	51 - 106
0451 3006N	Tapping Screw - 3x6	9 - 105
0451 3006N	Tapping Screw - 3x6	25 - 103
0451 3006N	Tapping Screw - 3x6	27 - 101
0451 3006N	Tapping Screw - 3x6	29 - 101
0451 3006N	Tapping Screw - 3x6	31 - 101
0451 3006N	Tapping Screw - 3x6	45 - 107
0451 3006N	Tapping Screw - 3x6	47 - 105
0451 3006N	Tapping Screw - 3x6	49 - 102
0451 3006N	Tapping Screw - 3x6	53 - 111
0451 3006N	Tapping Screw - 3x6	55 - 103
0451 3006N	Tapping Screw - 3x6	57 - 106
0451 3008N	Tapping Screw - M3x8	9 - 103
0451 3008N	Tapping Screw - M3x8	29 - 105
0451 3008N	Tapping Screw - M3x8	43 - 103
0451 3008N	Tapping Screw - M3x8	45 - 112
0451 4006N	Tapping Screw - 4x6	21 - 113
0451 4006N	Tapping Screw - 4x6	23 - 104
0451 4006N	Tapping Screw - 4x6	25 - 102
0451 4006N	Tapping Screw - 4x6	27 - 104

Part No.	Description	Page and Index No.
0451 4006N	Tapping Screw - 4x6	33 - 109
0451 4006N	Tapping Screw - 4x6	43 - 104
0451 4006N	Tapping Screw - 4x6	49 - 101
0451 4006N	Tapping Screw - 4x6	51 - 107
0451 4006N	Tapping Screw - 4x6	53 - 103
0451 4006N	Tapping Screw - 4x6	55 - 104
0451 4006N	Tapping Screw - 4x6	57 - 101
0451 4006N	Tapping Screw - 4x6	57 - 106
0451 4008N	Tapping Screw:4x8	9 - 101
0451 4008N	Tapping Screw:4x8	21 - 114
0451 4008N	Tapping Screw:4x8	25 - 113
0451 4008N	Tapping Screw:4x8	27 - 106
0451 4008N	Tapping Screw:4x8	33 - 112
0451 4008N	Tapping Screw:4x8	41 - 101
0451 4008N	Tapping Screw:4x8	57 - 103
0451 4008N	Tapping Screw:4x8	57 - 109
0451 4010N	Tapping Screw:4x10	21 - 109
0451 4010N	Tapping Screw:4x10	23 - 102
0452 3006N	Binding Self-tapping Screw:3x6	37 - 106
0452 3006N	Binding Self-tapping Screw:3x6	57 - 105
0452 3008N	Tapping Screw - M3x8	11 - 101
0453 3006N	Tapping Screw - M3x6	23 - 105
0453 3006N	Tapping Screw - M3x6	25 - 112
0453 3006N	Tapping Screw - M3x6	31 - 110
0454 3006Q	Tapping Screw - M3x6	21 - 108
0454 3006Q	Tapping Screw - M3x6	23 - 101
0454 3006Q	Tapping Screw - M3x6	27 - 102
0454 3006Q	Tapping Screw - M3x6	31 - 103
0454 3006Q	Tapping Screw - M3x6	45 - 101
0454 3006Q	Tapping Screw - M3x6	57 - 103
0454 3008Q	Tapping Screw:3x8	45 - 102
0454 4006Q	Tapping Screw:4x6	23 - 106
0454 4006Q	Tapping Screw:4x6	51 - 104
0454 4006Q	Tapping Screw:4x6	53 - 109
0454 4006Q	Tapping Screw:4x6	55 - 102

Part No.	Description	Page and Index No.
0454 4006Q	Tapping Screw:4x6	57 - 102
0574 0040E	Hexagon Headless Set Screw - M4x4	21 - 106
0574 0040E	Hexagon Headless Set Screw - M4x4	29 - 103
0574 0040E	Hexagon Headless Set Screw - M4x4	39 - 105
0574 0050E	Hexagon Headless Set Screw - M4x5	25 - 101
0574 0080E	Hexagon Headless Set Screw - M4x8	53 - 101
0584 0121N	Hexagonal Head Bolt:M4x12	33 - 102
0592 0040E	Hexagonal Set Screw:M2x4	37 - 113
0593 0040E	Hexagonal Set Screw:M3x4	33 - 106
0593 0060Z	Hexagon Bolt - M3x6	37 - 115
0593 0080E	Bolt - M3x8	33 - 101
0593 0100Z	Bolt M3x10	37 - 107
0594 0060Z	Hexagon Socket Bolt - M4x6	35 - 106
0594 0080N	Hexagonal Set Screw - M4x8	19 - 102
0594 0080N	Hexagonal Set Screw - M4x8	25 - 106
0594 0080Z	Bolt - M4x8	37 - 108
0594 0080Z	Bolt - M4x8	39 - 104
0624 0160E	Spring Pin - 4x16mm	21 - 107
0633 0140G	Parallel Pin - 3x14	41 - 105
0633 0160G	Parallel Pin - 3x16mm	21 - 105
0701 0030N	Washer DIA3	33 - 104
0701 0040N	Washer:DIA4	19 - 101
0701 0040N	Washer:DIA4	25 - 111
0701 0060N	Washer DIA6	25 - 110
0710 0040N	Hexagonal Nut:M4	33 - 103
0720 0020E	Retaining Ring - M2	37 - 101
0720 0030E	Retaining Ring - M3	21 - 102
0720 0030E	Retaining Ring - M3	31 - 104
0720 0040E	Retaining Ring - M4	19 - 105
0720 0040E	Retaining Ring - M4	21 - 110
0720 0040E	Retaining Ring - M4	23 - 109
0720 0040E	Retaining Ring - M4	25 - 108
0720 0040E	Retaining Ring - M4	29 - 102
0720 0040E	Retaining Ring - M4	31 - 105
0720 0040E	Retaining Ring - M4	33 - 111

Part No.	Description	Page and Index No.
0720 0040E	Retaining Ring - M4	35 - 103
0720 0040E	Retaining Ring - M4	47 - 102
0720 0040E	Retaining Ring - M4	53 - 106
0720 0040E	Retaining Ring - M4	55 - 105
0720 0050G	Retaining Ring - M5	39 - 108
0720 0060E	Retaining Ring - M6	19 - 104
0720 0060E	Retaining Ring - M6	33 - 110
0720 0060E	Retaining Ring - M6	35 - 101
0720 0060E	Retaining Ring - M6	41 - 104
0720 0060E	Retaining Ring - M6	55 - 106
0720 0070E	Retaining Ring - M7	21 - 104
0720 0080E	Retaining Ring - M8	21 - 103
0720 0080E	Retaining Ring - M8	25 - 109
0720 0080E	Retaining Ring - M8	33 - 108
0725 0160E	Retaining Ring C - M16	39 - 103
0740 3008	Ball Bearing - 8x22x7	25 - 104
0740 3010	Ball Bearing - 10x26x8mm	53 - 104
0741 3706	Ball Bearing - 6x10x3	25 - 107
0804 6091	Hexagonal Set Screw - M2x5	37 - 110
0805 0106	Retaining Rings-E:Silencer:DIA6	17 - 101
0805 3385	Bushing - 6mm	47 - 101
0807 5049	Wave Washer - 8 mm	35 - 105
0807 7046	Washer - 10.5x20x0.2mm	53 - 105
0807 7114	Washer - 16x24x0.3mm	37 - 109
0807 7114	Washer - 16x24x0.3mm	39 - 102
0808 0021	Rubber Ring	37 - 111
0951 3006Z	Philips Screw With Flat Washer - M3	37 - 112
0951 3006Z	Philips Screw With Flat Washer - M3	39 - 111
0951 3008Z	Philips Screw With Flat Washer - M3	37 - 103
0951 3012N	Screw:Polished Round:M3x12	19 - 103
0951 3014N	Screw Polished Round M3x14	51 - 105
0951 3025N	Screw:Polished Round:M3x25	51 - 102
0951 4006Z	Philips Screw With Flat Washer - M4	39 - 106
0951 4020N	Screw - M4x20	57 - 107
0954 3006N	Screw - M3x6	49 - 103

Part No.	Description	Page and Index No.
0954 3008N	Screw - M3x8	47 - 104
0954 4006Z	Screw - M4x6	35 - 102
1102 6088	Inlet- AC -P03CS05 (EU, NA)	49 - 106
1102 8797	Connector:1-292215-4	23 - 110
1105 0328	Harness Clamp - ES-0505	31 - 107
1105 0328	Harness Clamp - ES-0505	45 - 108
1105 0488	Harness Clamp	27 - 108
1105 0488	Harness Clamp	31 - 106
1105 0488	Harness Clamp	45 - 110
1105 0488	Harness Clamp	57 - 104
1105 0489	Harness Clamp - LWS 1316	57 - 108
1105 0489	Harness Clamp - LWS 1316	53 - 112
1105 0490	Harness Clamp - IWS-2218	55 - 110
1105 0508	Harness Clamp - LWS-0711	33 - 105
1105 0508	Harness Clamp - LWS-0711	45 - 109
1105 0508	Harness Clamp - LWS-0711	47 - 106
1105 0508	Harness Clamp - LWS-0711	53 - 108
1105 0508	Harness Clamp - LWS-0711	55 - 109
1105 0508	Harness Clamp - LWS-0711	57 - 104
1105 0511	Harness Clamp - LWS-0306ZC	23 - 108
1105 0511	Harness Clamp - LWS-0306ZC	25 - 105
1105 0511	Harness Clamp - LWS-0306ZC	37 - 102
1105 0511	Harness Clamp - LWS-0306ZC	39 - 110
1105 0511	Harness Clamp - LWS-0306ZC	53 - 113
1105 0516	Clamp	23 - 107
1105 0522	Edge Saddle - LES0510	55 - 111
1105 0534	Clamp	19 - 107
1105 0534	Clamp	27 - 107
1105 0534	Clamp	51 - 109
1105 0534	Clamp	31 - 111
1105 0534	Clamp	47 - 107
1105 0534	Clamp	53 - 110
1105 0534	Clamp	55 - 108
1105 0534	Clamp	57 - 102
1106 0851	Bush:NJ-16	31 - 109

Part No.	Description	Page and Index No.
1107 1295	Fuse:Glass Cartridge:FSL 250V 6.3A(EM)	49 - 104
1107 1296	Fuse:Glass Cartridge:FSL 250V 8A(EM)	49 - 105
1204 2497	Micro Switch	51 - 101
1407 7520	RAM:FM25V02-PG (REV.AA)	49 - 107
2803 0006	Cord Binder	9 - 14
5053 0447	Bushing - 6mm	53 - 10
5316 7421	O - Ring	39 - 30
5447 2681	Snap Ring	57 - 11
5501 8195	Steel Ball 3/16	21 - 20
5501 8195	Steel Ball 3/16	23 - 12
5506 6111	Stepped Screw - M4	33 - 22
5606 2066	Paper Feed Guide Disc	21 - 6
5606 2310	Roller	19 - 9
A250 1752	Exposure Glass	13 - 8
A659 1272	Door Catch	27 - 18
AA00 1564	Plate:Logotype:RIC	9 - 2
AA00 1565	Plate:Logotype:LAN	9 - 2
AA00 1566	Plate:Logotype:SVN	9 - 2
AA00 1567	Plate:Logotype:GES	9 - 2
AA00 1568	Plate:Logotype:NSA	9 - 2
AA00 1569	Plate:Logotype:REX	9 - 2
AA08 2144	Busing - 8X12X7	17 - 11
AA14 3802	Screw:6x1.7	53 - 13
AA14 3849	Screw:DIA4:M3	15 - 4
AC03 0169	Mirror:No.1	15 - 13
AC03 0210	Mirror:No.2:Concave	17 - 17
AG07 0514	Magnet Catch	9 - 3
AG07 0514	Magnet Catch	27 - 13
AW01 0109	Photo Reflection Sensor:PS117ED1	19 - 16
AW01 0109	Photo Reflection Sensor:PS117ED1	41 - 12
AW01 0155	Original:Sensor:3.3V	15 - 7
AW02 0141	Photointerruptor	23 - 3
AW02 0203	Photointerruptor	19 - 13
AW02 0203	Photointerruptor	55 - 25
AW02 0203	Photointerruptor	31 - 29

Part No.	Description	Page and Index No.
AW02 0203	Photointerruptor	33 - 9
AW02 0203	Photointerruptor	45 - 8
AW02 0203	Photointerruptor	47 - 12
AW02 0203	Photointerruptor	53 - 21
AW02 0203	Photointerruptor	57 - 5
AW02 0207	Photointerruptor:Flat:PICH2MM:M4	13 - 13
AW02 0214	Photointerruptor:LG248NL1A	13 - 6
AX31 0049	Total Counter:7Fig:24V	51 - 24
AX64 0188	Fan Motor DC24V 1.68W	49 - 11
AX65 5800	DC Fan Motor:Axial:MM119:24V	41 - 11
B129 1495	LCD	11 - 19
B238 1806	Idler Pulley	17 - 15
B238 1807	Pulley	17 - 18
C200 4748	Gear - 45T	39 - 25
C201 5051	Pinion - 24T	21 - 15
C203 5135	Bushing - 10x14x5.9	21 - 31
C207 4672	Gear - 36Z	39 - 5
C209 5220	Spacer - 4x20x6	21 - 19
C209 5220	Spacer - 4x20x6	23 - 8
C217 4581	Ink Roller Drive Gear	37 - 27
C217 5102	Spring Washer	29 - 27
C218 4592	Front Bank Plate	39 - 17
C218 4594	Rear Bank Plate	39 - 19
C225 6113	Upper Pressure Spring Pin	43 - 16
C229 2615	Slide Rail Roller	33 - 7
C229 2907	Registration Roller Pulley - 14Z	25 - 22
C231 2135	Platen Gear - 2	31 - 25
C231 2146	Platen Roller Gear	29 - 11
C231 2147	Idler Gear	29 - 10
C231 2148	Tension Roller Gear	29 - 9
C231 2234	Brake Pad	31 - 27
C231 2417	Master Exit Pawls	37 - 2
C231 2450	Ink Roller - B4	39 - 12
C231 2456	Ink Roller - A4/LG	39 - 12
C231 2565	Ink Cartridge Joint	37 - 28

Part No.	Description	Page and Index No.
C231 2766	Pressure Pin	25 - 8
C231 2922	Pressure Roller	21 - 23
C231 2922	Pressure Roller	23 - 28
C231 2965	Core	19 - 5
C231 2971	Lock Cam	19 - 41
C231 2976	Washer	19 - 38
C231 2985	Spring	19 - 30
C231 3489	Lower Roller Gear	47 - 22
C231 3494	Gear - Lower Roller	47 - 20
C231 4413	Delivery Table Spring	43 - 15
C231 4414	Lower Side Fence Pin	43 - 18
C231 4415	Upper Side Fence Pin	43 - 19
C231 4419	End Plate Pin	43 - 17
C231 4420	Slider Spring Plate	43 - 11
C231 4425	End Plate Sheet	43 - 22
C237 2460	Ink Drive Gear	39 - 29
C237 3505	Pin 3x16	47 - 19
C238 1057	Rubber Foot	57 - 18
C238 1339	Key Counter Plate Nut	57 - 19
C238 1962	Front Spring	29 - 24
C238 2037	Lever Knob	29 - 14
C238 2106	Ball Bearing - 6x13x5mm	29 - 12
C238 2243	Master Flange - MH	9 - 20
C238 2243	Master Flange - MH	29 - 25
C238 2244	Flange:Master:50.8/20	9 - 20
C238 2244	Flange:Master:50.8/20	29 - 25
C238 2368	Drum Drive Gear	37 - 11
C238 2410	Clamper Rear Spring	37 - 6
C238 2412	Clamper Cam	37 - 30
C238 2413	Sheet:Sensor:Trailing Edge:Screen	37 - 21
C238 2469	Doctor Roller Drive Gear	39 - 6
C238 2488	Rubber Bushing	39 - 33
C238 2489	Rubber Bushing Plate	35 - 20
C238 2489	Rubber Bushing Plate	39 - 32
C238 2572	Stopper Spring	37 - 22

Part No.	Description	Page and Index No.
C238 2573	Stepped Screw	35 - 23
C238 2585	Screw MM6x1.7	35 - 26
C238 2585	Screw MM6x1.7	37 - 26
C238 2770	Paper Side Pad	9 - 19
C238 2770	Paper Side Pad	19 - 19
C238 2785	Tray Motor Bracket	51 - 20
C238 2800	Tray Lift Bracket	19 - 3
C238 2805	Tray Lift Slider	19 - 4
C238 2806	Tray Position Feeler	19 - 12
C238 2825	Sensor Bracket	19 - 14
C238 2853	Sensor Cleaning Spring (CHN)	25 - 15
C238 2856	Sensor Cleaning Brush (CHN)	25 - 16
C238 2894	Upper Registration Roller	25 - 3
C238 2921	Registration Sensor Bracket	25 - 11
C238 2929	Spring Plate	21 - 21
C238 2929	Spring Plate	23 - 13
C238 2936	Arm Bracket	23 - 15
C238 2939	Spring	23 - 9
C238 2981	Rear Side Fence Rack	19 - 27
C238 2986	Sensor Bracket - Paper Feed Tray	19 - 15
C238 2987	Side Fence Gear	19 - 29
C238 3126	Pressure Spring Screw	33 - 13
C238 3127	Pressure Spring Nut	33 - 1
C238 3877	Driven Shaft	41 - 9
C238 3890	Drive Roller - Drum Side	41 - 8
C238 4070	Eject Clamp Pusher	55 - 21
C238 4450	Hinge Screw	57 - 12
C238 4493	Exit Pawl Drive Arm 2	33 - 5
C238 5651	Total Counter Bracket	51 - 16
C244 1098	Pan Head Screw:Lock:M4x4	19 - 37
C244 2633	Stepped Screw	51 - 30
C244 4426	Shoulder Screw	43 - 20
C244 4426	Shoulder Screw	53 - 14
C244 4426	Shoulder Screw	55 - 18
C247 2461	Adjusting Plate - Doctor Roller	39 - 26

Part No.	Description	Page and Index No.
C249 2230	Brake Shoe	31 - 30
C249 2790	Spring Plate:Spacer:Paper Feed Tray	19 - 22
C249 2840	Paper Feed Tray Pad	19 - 20
C249 2944	Table Sheet	19 - 42
C252 1080	Bushing	21 - 8
C252 1080	Bushing	25 - 21
C252 1080	Bushing	33 - 18
C252 1152	Timing Pulley:Drive:Main	55 - 6
C252 1154	Roller:Belt Tensioner:Ass'y	55 - 13
C252 1179	Pulley:Drive:Paper Feed	53 - 5
C252 1195	Hexagonal Set Screw:M5x8	55 - 7
C252 1950	Positioning Pin:Coupling:Plotter:Ass'y	29 - 21
C252 1971	Decal:Open And Close:Plotter:Left	29 - 2
C252 1972	Decal:Open And Close:Plotter:Left	29 - 3
C252 2082	Guide Plate:Brake:Lower:Plotter:Sub-Ass'y	31 - 2
C252 2085	Guide Plate:Brake:Upper:Plotter	31 - 1
C252 2092	Guide Plate:Thermal Head:Ass'y	31 - 19
C252 2157	Spring:Thermal Head:Both Ends	31 - 13
C252 2281	Discharge Brush:Cutter	29 - 1
C252 2281	Discharge Brush:Cutter	31 - 3
C252 2340	Screen:B4:Ass'y	35 - 39
C252 2341	Screen:LG:Ass'y	35 - 39
C252 2370	Spacer:Drum Shaft:Right	37 - 9
C252 2395	Plate:Thrust:Drum	37 - 13
C252 2396	Wedge:Plate:Thrust	37 - 12
C252 2397	Collar:Drum Shaft:Left	39 - 23
C252 2398	Spacer:Drum Shaft:Left (A4/LG)	39 - 22
C252 2410	Torsion Spring:Pawl:Master Ejection:Master	37 - 25
C252 2412	Friction Pad:Screen:Large (B4)	35 - 37
C252 2413	Friction Pad:Screen:Small	35 - 38
C252 2414	Friction Pad:Screen:LG/A4	35 - 37
C252 2458	Oil Supply Roller:B4	39 - 13
C252 2459	Oil Supply Roller:LG/A4	39 - 13
C252 2470	Stay:Ink Sensor	39 - 10
C252 2475	Side Plate:Roller:Ink:Left	39 - 20

Part No.	Description	Page and Index No.
C252 2476	Side Plate:Roller:Ink:Right:Ass'y	39 - 2
C252 2485	Joint:Drum Shaft	39 - 31
C252 2492	Tension Spring:Ring:Roller:Drum	39 - 16
C252 2495	Plate:Side Plate:Roller:Ink	39 - 21
C252 2526	Grip:Drum:Upper	35 - 32
C252 2534	Grip:Drum:Lower	35 - 16
C252 2559	Spring:Pressure:Ink Cartridge	35 - 6
C252 2590	Metal Screen - B4	37 - 20
C252 2593	Dram Metal Screen:Drum:LG:Ass'y	37 - 20
C252 2810	Grip Rings:Mm8	21 - 7
C252 2878	Spring:Pressure:Feed Roller	25 - 4
C252 2888	Pulley:Stepper Motor:Feed:23Z	53 - 17
C252 3140	Spring:Pressure:B4	33 - 14
C252 3486	Bushing:Pressure:MM6	47 - 16
C252 3487	Spring:Pressure:Roller:Master Ejection	47 - 15
C252 3492	Gear:Roller:50/84	47 - 21
C252 3525	Gear:Pressure:15/124	47 - 17
C252 3556	Spring:Pressure:Master Ejection:13.98N	47 - 6
C252 3684	Gear:Pressure Plate:Master Ejection	47 - 14
C252 4052	Rack:Drive:Clamp	55 - 22
C252 4062	Guide:Positioning:Drum	55 - 20
C252 4063	Guide:Clamp:Master Feed	55 - 15
C252 4068	Gear:Drive:Rack	53 - 22
C252 4069	Gear:Slow Down	53 - 23
C252 4365	Pickoff Pawl:Exit	33 - 3
C257 2869	Feeler Roller	21 - 2
C257 5807	Photo Reflection Sensor:GP2A25	25 - 13
C257 5817	Stepper Motor MM56x64	53 - 20
C257 5856	Push Switch	51 - 23
C259 5821	Stepper Motor:DIA42:Plotter:Ass'y	47 - 11
C259 5821	Stepper Motor:DIA42:Plotter:Ass'y	53 - 11
C261 1056	Shaft:Stay:Machine Or Copier	25 - 12
C261 1171	Bearing Case	53 - 9
C261 1955	Stay:Coupling:Plotter	29 - 20
C261 1961	Spring:Open And Close:Rear:Plotter	29 - 26

Part No.	Description	Page and Index No.
C261 2026	Base:Thermal Head	31 - 15
C261 2030	Rear Plate:Open And Close	29 - 8
C261 2036	Lever:Open And Close:Plotter	29 - 15
C261 2039	Spring:Lever:Lock:Plotter	29 - 13
C261 2040	Side Plate:Open And Close:Front:Plotter:Ass'y	29 - 16
C261 2045	Cover:Open And Close:Plotter	29 - 4
C261 2046	Guide Plate	29 - 5
C261 2052	Positioning Plate:Master	31 - 8
C261 2054	Spring:Positioning Plate:Master	31 - 10
C261 2077	Roller:Brake:Plotter	31 - 4
C261 2108	Cover:Open And Close:Lower	29 - 17
C261 2114	Roller:Tension:B4 (EU, AA, CHN)	29 - 6
C261 2115	Roller:Tension:LG (NA)	29 - 6
C261 2151	Thermal Head:B4	31 - 11
C261 2156	Spring:Thermal Head:Middle	31 - 14
C261 2271	Cutter Unit:B4:Ass'y	29 - 18
C261 2273	Bracket:On Off Detector:Plotter	31 - 28
C261 2279	Bracket:Sensor:Master	31 - 18
C261 2368	Shielding Plate:Drum	37 - 15
C261 2388	Stay:Screen:Front:B4	37 - 17
C261 2389	Stay:Screen:Rear:B4	37 - 18
C261 2390	Stay:Screen:Front:A4/LG	37 - 17
C261 2391	Stay:Screen:Rear:A4/LG	37 - 18
C261 2401	Clamp:Ass'y	37 - 1
C261 2402	Base:Clamp:Drum:Ass'y	37 - 3
C261 2405	Plate:Clamp	37 - 7
C261 2406	Shaft:Clamp:Drum	37 - 5
C261 2463	Stay:Main:Drum:B4	39 - 11
C261 2464	Stay:Main:Drum:A4/LG	39 - 11
C261 2465	Stay:Sub:Drum:B4	39 - 14
C261 2466	Stay:Sub:Drum:A4/LG	39 - 14
C261 2471	Ink Sensor:Ass'y	39 - 9
C261 2520	Side Plate:Drum:Left	37 - 4
C261 2521	Side Plate:Drum:Right	37 - 14
C261 2530	Arm:Grip:Left	35 - 14

Part No.	Description	Page and Index No.
C261 2531	Arm:Grip:Right	35 - 10
C261 2533	Screw:Arm:Drum	35 - 19
C261 2535	Shaft:Contact Point:Arm:Drum	35 - 13
C261 2538	Bracket:Housing:Drum	35 - 21
C261 2543	Cover:Harness:Drum	35 - 18
C261 2552	Screw:Slider	35 - 1
C261 2552	Screw:Slider	51 - 3
C261 2553	Rail:Holder:Left	35 - 7
C261 2554	Rail:Holder:Right	35 - 8
C261 2555	Guide:Slider:Right	35 - 5
C261 2556	Lever:Release:Holder:Ass'y	35 - 11
C261 2558	Base:Lever:Release	37 - 29
C261 2560	Spring:Lever:Release	35 - 12
C261 2567	Stay:Coupling:Grip	35 - 27
C261 2601	Stay:Drum:Machine Or Copier:Ass'y	33 - 8
C261 2605	Positioning Pin:Drum:Ass'y	33 - 23
C261 2611	Bracket:Receptacle	51 - 15
C261 2817	Bracket:Drive:Paper Feed Roller	53 - 2
C261 2831	Holder:Spring:Separation	21 - 25
C261 2832	Compression Spring:Separation Pad	21 - 26
C261 2835	Adjusting Pin	21 - 24
C261 2844	Screw:Separation Unit	21 - 30
C261 2844	Screw:Separation Unit (CHN)	25 - 14
C261 2872	Shaft:Swivel:Feed Roller:Upper	25 - 9
C261 2875	Arm:Pressure:Feed Roller:Ass'y	25 - 5
C261 2881	Feed Roller:Lower	25 - 2
C261 2887	Bracket:Stepper Motor:Feed	53 - 19
C261 3100	Side Plate:Pressure:Left:Ass'y	33 - 24
C261 3103	Side Plate:Pressure:Right:Ass'y	33 - 15
C261 3110	Arm:Pressure Roller:Left:Ass'y	33 - 21
C261 3113	Arm:Pressure Roller:Right:Ass'y	33 - 17
C261 3116	Bracket:Stopper:Pressure Roller	33 - 20
C261 3117	Stopper:Pressure Roller	33 - 19
C261 3120	Anchor:Spring:Pressure:Left:Ass'y	33 - 27
C261 3123	Anchor:Spring:Pressure:Right:Ass'y	33 - 11

Part No.	Description	Page and Index No.
C261 3131	Bracket:Pressure Release:Left	33 - 34
C261 3135	Bracket:Pressure Release:Right	33 - 31
C261 3137	Spring:Pressure Release	33 - 26
C261 3141	Spring:Pressure:A4/LG	33 - 14
C261 3160	Arm:Pressure Release:Left:Ass'y	33 - 32
C261 3165	Arm:Pressure Release:Right:Ass'y	33 - 29
C261 3466	Base:Master Ejection	47 - 10
C261 3467	Bracket:Sensor:Master Ejection Unit	45 - 11
C261 3469	Duct:Air Knife	45 - 15
C261 3470	Base:Air Knife	45 - 17
C261 3472	Cover:Sensor:Master Ejection Unit	45 - 12
C261 3484	Roller:Lower:Master Ejection Unit:Ass'y	47 - 9
C261 3553	Arm:Pressure:Master Ejection	47 - 5
C261 3554	Shaft:Pressure:Master Ejection Unit	47 - 4
C261 3567	Guide Plate	47 - 2
C261 3577	Plate:Master	45 - 4
C261 3656	Pressure Plate:Master Ejection	47 - 7
C261 3855	Bracket:Fan:Hale Unit:Ass'y	41 - 10
C261 3861	Duct:Hale Unit	41 - 7
C261 3879	Transport Belt:Hale Unit:17	41 - 1
C261 3885	Discharge Brush:Long:Paper Exit	57 - 20
C261 3886	Discharge Brush:Short:Paper Exit	57 - 21
C261 3890	Guide:Hale Unit	41 - 2
C261 4001	Base:Clamp:Open And Close:Ass'y	55 - 17
C261 4055	Lever:Drive:Master Feed:Peen	55 - 16
C261 4059	Lever:Drive:Master Ejection:Peen	55 - 19
C261 4064	Side Plate:Drive Sub-unit:Clamp	53 - 24
C261 4401	Stay:Front:Paper Exit Sub-unit	43 - 13
C261 4402	Stay:Rear:Paper Exit Sub-unit	43 - 9
C261 4409	Supporting Plate:Paper Exit	43 - 14
C261 4481	Arm:Drive:Pickoff Pawl	33 - 2
C261 4485	Bracket:Roller:Pressure Release	33 - 6
C261 5050	Photointerrupt:Master Ejection	45 - 10
C261 5150	PCB:Optics Sensor	45 - 13
C261 5253	Harness:Ink Sensor:Ass'y	39 - 24

Part No.	Description	Page and Index No.
C261 5610	Bracket:Home Position Sensor	55 - 12
C261 5611	Bracket:Sensor:Paper Feed Control	33 - 10
C261 5686	Screw:Round Point:Safety Switch	51 - 27
C261 5821	Power Supply Cord	9 - 22
C261 5822	Power Supply Cord	9 - 22
C261 5825	Fan:Sirocco:DC24V:B054	45 - 16
C261 5879	Magnetic Clutch:Paper Feed Roller	53 - 4
C264 2898	Shaft:Arm:Feed Roller:Upper	25 - 7
C267 1056	Shaft:Stay:Machine Or Copier:DIA12	25 - 1
C267 1060	Cover:Side Plate:Machine Or Copier:Front	51 - 4
C267 1070	Guard:Rack:Paper Feed Tray	57 - 17
C267 1074	Bracket:On Off Detector:Machine Or Copier:Plotter	51 - 18
C267 1075	Cover:Harness:Operation Panel:Upper Left	57 - 1
C267 1076	Bracket:Link:Lower	57 - 10
C267 1077	Link:Machine Or Copier:Plotter:Front:Peen	57 - 7
C267 1079	Screw:DIA4	57 - 6
C267 1081	Cover:Harness:Operation Panel:2	57 - 12
C267 1082	Slider:Harness:Machine Or Copier:Plotter	57 - 8
C267 1085	Cover:On Off Detector:Machine Or Copier:Upper	51 - 17
C267 1087	Link:Machine Or Copier:Plotter:Inner Back:Peen	57 - 9
C267 1185	Base:Brushless Motor:Main	55 - 8
C267 1311	Hinge:Door:Upper:Ass'y	9 - 6
C267 1312	Hinge:Door:Lower:Ass'y	9 - 7
C267 1321	Bracket:Plate:Cover:Front	51 - 22
C267 1495	Lens:LED:Operation Sub-unit	11 - 5
C267 1497	Bracket:Operation Sub-unit:Right	11 - 17
C267 1994	Stopper:Rail:Plotter:Middle	27 - 9
C267 2010	Side Plate:Fix:Rear:Plotter:Ass'y	31 - 24
C267 2020	Side Plate:Fix:Front:Plotter:Ass'y	31 - 16
C267 2064	Lever:Roller:Brake	31 - 5
C267 2066	Spring:Roller:Brake:Plotter	31 - 9
C267 2078	Bracket Shoe:Roller:Brake:Plotter	31 - 6
C267 2095	Guide Plate:Master	31 - 20
C267 2133	Gear:Idler:1:Platen	31 - 26
C267 2160	Bracket:Slide Rail:Plotter:Rear	27 - 11

Part No.	Description	Page and Index No.
C267 2161	Bracket:Harness:Rear:Plotter	27 - 7
C267 2164	Cover:Harness:Exit:Upper:Plotter	27 - 2
C267 2165	Cover:Harness:Exit:Lower:Plotter	27 - 6
C267 2166	Bracket:On Off Detector Board:Upper:Plotter	27 - 17
C267 2167	Cover:Harness:Left	27 - 1
C267 2170	Bracket:Slide Rail:Plotter:Front	27 - 15
C267 2172	Lever:Safety Switch	51 - 12
C267 2173	Cover:Upper:Plotter:2	27 - 5
C267 2174	Bracket:Connector:Plotter	27 - 3
C267 2176	Spring Plate:Safety Switch	51 - 25
C267 2177	Cover:Rear:Plotter	27 - 8
C267 2178	Cover:Front:Plotter	27 - 16
C267 2182	Bracket:Harness:Left Inner Rear:Plotter	27 - 4
C267 2186	Slide Rail:Plotter:Inner	27 - 10
C267 2210	Holder:Master:Rear	29 - 22
C267 2220	Holder:Master:Front	29 - 19
C267 2267	Bearing Case:Transmission	25 - 20
C267 2275	Rail:Plotter:Outer	57 - 15
C267 2288	Bracket:On Off Detector:Lower:Plotter:2	27 - 14
C267 2290	Base:Fix:Plotter:2:Peen	31 - 21
C267 2311	Roller:Ink:A4/LG:Ass'y	39 - *
C267 2312	Roller:Ink:B4:Ass'y	39 - *
C267 2322	Holder:Ink Cartridge:WLD:Ass'y (21, 29, 61, 67, 27)	35 - 35
C267 2323	Holder:Ink Cartridge:NA:STD:Ass'y (11)	35 - 35
C267 2342	Screen:A4:Ass'y	35 - 39
C267 2360	Flange:Drum:B4/LG:Left:Ass'y	37 - 8
C267 2362	Flange:Drum:B4/LG:Right:Ass'y	37 - 10
C267 2364	Flange:Drum:A4:Left:Ass'y	37 - 8
C267 2366	Flange:Drum:A4:Right:Ass'y	37 - 10
C267 2390	Sheet:Sensor:Drum	35 - 36
C267 2394	Spring Plate:Grip:Drum	35 - 33
C267 2395	Bracket:Stopper:Drum	35 - 28
C267 2396	Spring Plate:Stopper	35 - 25
C267 2416	Friction Pad:Small:Magnetic	37 - 19
C267 2424	Filter:Pump:Ink	37 - 16

Part No.	Description	Page and Index No.
C267 2427	DC Mtor:Pump Unit	39 - 34
C267 2428	Pump Unit:Ink:B4:Ass'y	39 - 1
C267 2429	Pump Unit:Ink:A4:Ass'y	39 - 1
C267 2458	Ring:Front:Roller:Drum	39 - 15
C267 2459	Ring:Rear:Roller:Drum	39 - 18
C267 2468	Ground Plate:Oil Supply Roller:Ink	39 - 7
C267 2481	Drum Shaft:B4:Ass'y	39 - 8
C267 2487	Drum Shaft:A4/LG:Ass'y	39 - 8
C267 2524	Stay:Grip:Drum:Left	35 - 31
C267 2525	Stay:Grip:Drum:Right	35 - 30
C267 2570	Bracket:Stopper:Turn	37 - 24
C267 2571	Shield:Holder:Ink Cartridge	35 - 9
C267 2572	Stopper:Turn	37 - 23
C267 2574	Slider:Housing	35 - 17
C267 2586	Dram Metal Screen:Drum:A4:Ass'y	37 - 20
C267 2598	Blade:Front:Drum	39 - 27
C267 2599	Blade:Rear:Drum	39 - 28
C267 2640	Holder:Ink Cartridge (21, 29, 61, 67, 27)	35 - 15
C267 2641	Slider:Holder:Ink Cartridge:WLD	35 - 4
C267 2642	Guide:Slider:Left:WLD:Ass'y	35 - 3
C267 2675	Holder:Ink Cartridge:NA:STD:Ass'y (11)	35 - 15
C267 2753	Stay:Paper Feed Tray:Front	19 - 33
C267 2754	Stay:Paper Feed Tray:Rear	19 - 24
C267 2756	Base:Paper Feed Tray	19 - 34
C267 2758	Plate:Magnet Catch:Paper Feed Tray	19 - 23
C267 2760	Arm:Front:Paper Feed Tray	19 - 36
C267 2761	Arm:Rear:Paper Feed Tray:Peen	19 - 35
C267 2770	Shaft:Lock:Side Fence	19 - 32
C267 2779	Spring:Auxiliary:Rise:Paper Feed Tray	19 - 2
C267 2781	Shaft:Rise:Paper Feed Tray	21 - 16
C267 2782	DC Motor:Paper Feed Tray	51 - 21
C267 2790	Rack:Rise:Paper Feed Tray:Front:Ass'y	19 - 6
C267 2793	Stay:Harness:Sensor:Paper	19 - 8
C267 2796	Rack:Rise:Paper Feed Tray:Rear:Ass'y	19 - 11
C267 2802	Roller:Paper Feed:Ass'y	21 - 4

Part No.	Description	Page and Index No.
C267 2806	Arm:Paper Feed	21 - 9
C267 2811	Pulley:Drive:Roller:Paper Feed	21 - 14
C267 2812	Pulley:Pickup:Paper Feed	21 - 13
C267 2813	Timing Belt:B82MXL6.4	21 - 12
C267 2816	Stopper:Arm	23 - 24
C267 2819	Separation Pad:Ass'y (EU, AA, NA)	21 - 27
C267 2820	Separation Pad:CHN:Ass'y (CHN)	21 - 27
C267 2824	Drum Stay:Paper Feed:Ass'y	21 - 28
C267 2827	Adjusting Pin:Separation Sub-unit	21 - 17
C267 2844	Bracket:Separation Change	21 - 22
C267 2845	Lever:Separation Change	21 - 18
C267 2885	Tension Spring:Bracket:Stepper Motor	53 - 18
C267 2896	Guide Plate:Feed Roller:Ass'y	25 - 18
C267 2897	Sheet:Guide Plate:Feed Roller:Upper	25 - 24
C267 2916	Stay:Paper Feed	21 - 32
C267 2916	Stay:Paper Feed	23 - 23
C267 2917	Retainer:Arm:Paper Feed	21 - 5
C267 2918	Bracket:Stay:Paper Feed	23 - 16
C267 2924	Lever:Pressure:Paper Feed Roller	23 - 10
C267 2931	Arm:Pressure:Paper Feed:Peen	23 - 14
C267 2941	Actuator:Surface Of Paper Sensor:Peen	21 - 3
C267 2944	Screw:Actuator:Surface Of Paper Sensor	21 - 1
C267 2946	Bracket:Surface Of Paper Sensor	23 - 4
C267 2947	Holder:Surface Of Paper Sensor	23 - 5
C267 2951	Bracket:Arm:Surface Of Paper Sensor	23 - 17
C267 2952	Holder:Surface Of Paper Sensor	23 - 18
C267 2953	Cover:Inner Back:Stay:Paper Feed	23 - 6
C267 2954	Cover:Harness:Stay:Paper Feed	23 - 26
C267 2956	Cover:Auxiliary:Harness:Stay:Paper Feed	23 - 25
C267 2958	Ground Plate:Cover:Stay:Paper Feed	23 - 27
C267 2958	Ground Plate:Cover:Stay:Paper Feed	57 - 4
C267 2983	Spacer:Side Fence	19 - 28
C267 2992	Cover:On Off Detector:Plotter:Lower Middle	23 - 19
C267 2993	Bracket:On Off Detector:Right Lower:Machine Or Copier:2	23 - 20

Part No.	Description	Page and Index No.
C267 2994	Holder:Lock:Plotter	23 - 21
C267 2996	Decal:Paper Feed Pressure:CHN	23 - 22
C267 3050	Pressure Roller:B4:Ass'y	33 - 16
C267 3052	Pressure Roller:A4/LG:Ass'y	33 - 16
C267 3130	DC Solenoid:Pressure Release:Left:Ass'y	33 - 25
C267 3134	DC Solenoid:Pressure Release:Right:Ass'y	33 - 12
C267 3452	Roller:Rail:Drum	35 - 24
C267 3452	Roller:Rail:Drum	47 - 24
C267 3473	Guide:Master Ejection	47 - 23
C267 3477	Bracket:Contact Point:Turn	45 - 7
C267 3485	Roller:Upper:Master Ejection Unit:Ass'y	47 - 8
C267 3501	Side Plate:Front:Master Ejection:Ass'y	47 - 3
C267 3521	Side Plate:Rear:Master Ejection:Ass'y	47 - 13
C267 3526	Bracket:Harness:Master Ejection Unit	45 - 9
C267 3530	Shaft:Lock:Master Ejection Unit:Ass'y	45 - 6
C267 3574	Stay:Master Ejection Unit	47 - 1
C267 3679	Bracket:Auxiliary:Master Ejection	45 - 3
C267 3680	Spring Plate:Guide:Master Ejection	45 - 5
C267 3682	Sheet:Case:Master Ejection	45 - 19
C267 3704	Bracket:Contact Point:Fix:Master Ejection Unit	57 - 2
C267 3706	Bracket:On Off Detector:Master Ejection Unit	51 - 14
C267 3713	Shaft:Contact Point:Master Ejection:Upper	57 - 3
C267 3714	Bracket:Contact Point:Fix:Master Ejection Unit:Middle	57 - 1
C267 3716	Inner Cover:Open And Close	55 - 24
C267 3717	Supporter:Master Ejection Unit	57 - 13
C267 3730	Lever:Middle	51 - 8
C267 3731	Lever:Lower	51 - 7
C267 3732	Lever:Open And Close:Master Ejection Unit	51 - 2
C267 3737	Spring:Lever:Middle	51 - 26
C267 3738	Spring:Lever:Lower	51 - 6
C267 3881	Bracket:Drum Stay:Paper Exit Sub-unit:Front	57 - 14
C267 3882	Bracket:Drum Stay:Paper Exit Sub-unit:Rear	57 - 8
C267 3883	Bracket:Drum Stay:Exit:Lower Front	57 - 15

Part No.	Description	Page and Index No.
C267 3884	Bracket:Drum Stay:Exit:Lower Rear	57 - 9
C267 3888	Discharge Brush:Drum Stay:Exit:Lower	57 - 17
C267 4349	Spring:Arm:Pickoff Pawl	33 - 28
C267 4410	Bracket:End Plate:Ass'y	43 - 4
C267 4417	Cushion:End Fence	43 - 23
C267 4431	Remover/Install Sub-unit:Exit:Front:Peen	57 - 11
C267 4441	Remover/Install Sub-unit:Exit:Rear:Peen	57 - 10
C267 4479	Bushing	33 - 30
C267 4480	Shaft:Pickoff Pawl:Ass'y	33 - 4
C267 4665	Bearing Case:Roller:Ink	39 - 4
C267 5251	Harness:Connecting:Pump:B4:Ass'y	39 - 3
C267 5252	Harness:Connecting:Drum:Ass'y	51 - 29
C267 5254	Harness:Connecting:Pump:A4/LG:Ass'y	39 - 3
C267 5276	Harness:Paper Feed Tray:Sensor:Ass'y	49 - 2
C267 5612	Bracket:Sensor:Misfeed Removal	57 - 4
C267 5616	Bracket:Fix:Power Supply Unit	55 - 4
C267 5617	Bracket:Fix:Power Supply Unit:Upper	55 - 5
C267 5622	Bracket:Base:Fix	53 - 1
C267 5623	Bracket:Base:Guard	55 - 1
C267 5627	Bracket:Power Supply Unit	49 - 7
C267 5635	Spring Plate:Safety Switch	51 - 13
C267 5650	Bracket:Main Switch	51 - 10
C267 5652	Bracket:Key Counter	57 - 18
C267 5844	Stepper Motor:DIA42:Plotter:Ass'y	31 - 23
C267 5890	Brushless Motor:Main:DC24V	55 - 9
C267 6168	Washer:Slide:End Fence	19 - 31
C271 2808	Shaft:Paper Feed Roller	21 - 10
C271 2809	Shaft:Pickup	21 - 11
C271 5162	PCB:OPE	11 - 18
C272 2855	Lever:Cleaner:Registration Sensor (CHN)	25 - 10
C272 5887	Spacer:DC Fan Motor:Axial:MM119:24V	41 - 5
C274 2057	Display Sub-unit:Leading Edge:Master:Printing	31 - 7
C274 2948	Timing Belt:Paper Feed:140-XL-050	53 - 12
C274 5820	Power Supply Cord	9 - 22
C275 1156	Shaft:Belt Tensioner:Ass'y	55 - 14

Part No.	Description	Page and Index No.
C275 1160	Gear:Drive:Drum:Ass'y	53 - 6
C275 1172	Side Plate:Drum Drive Sub-unit	53 - 8
C275 1173	Stopper:Gear:Remover/Install	53 - 15
C275 1174	Tension Spring:Lock:Gear:Remover/Install	53 - 25
C275 1177	Spacer:Power Supply Unit	53 - 16
C275 1180	Timing Belt:Drive:Main	53 - 7
C275 2869	Bracket:Guide Plate:Front	25 - 19
C275 2870	Bracket:Guide Plate:Rear	25 - 17
C275 2871	Feed Roller:Upper:Ass'y	25 - 23
C275 2895	Arm:Feed Roller:Upper	25 - 6
C275 2898	Screw:M4x6	25 - 25
C275 3450	Frame:Master Ejection Unit:Ass'y	45 - *
C275 3801	Drum Stay:Paper Exit Sub-unit:Ass'y	57 - 16
C275 3875	Pulley:Drive:Hale Unit	41 - 6
C275 3877	Shaft:Drive:Hale Unit:Sub-Ass'y	41 - 16
C275 3879	Timing Belt:Drive:Hale Unit	41 - 3
C275 5206	Harness:Ink:Ass'y	49 - 1
C275 5330	DC Power Supply:Main:NA:Ass'y	49 - 10
C275 5340	DC Power Supply:Main:200V:Ass'y	49 - 10
C275 5616	Bracket:UC2:Rear	55 - 3
C275 5619	Bracket:Fix:Power Supply Unit:Upper	55 - 27
C275 5675	Bracket:Control Unit:Fix	49 - 6
C275 5685	Bracket:On Off Detector:Door	51 - 11
C275 5811	DC Motor:2.5W:DIA34:Z15	41 - 4
C279 1086	Cover:Safety:Base:Upper	57 - 22
C279 1330	Decal:Paper Feed Tray	9 - 9
C279 1341	Decal:Warning:Paper Feed:EXP	9 - 13
C279 1351	Decal:Counter	9 - 17
C279 2932	Knob:Lever	21 - 29
C279 2932	Knob:Lever	23 - 11
C279 2964	Adjusting Pin:Front Rear:Paper Feed Tray	19 - 25
C279 2973	Knob:Lock:Side Fence	19 - 26
C279 2996	Dacal:Paper Set Direction	19 - 10
C279 3489	Lever:Master Ejection	45 - 2
C279 4406	Knob:End Plate:Exit	43 - 3

Part No.	Description	Page and Index No.
C279 4421	Cover:Slide:Paper Exit Sub-Unit	43 - 24
C279 4456	Cover:Slide:Paper Exit Sub-Unit	43 - 12
C279 5630	Bracket:Connector:Tape Mark (AA, NA, CHN)	55 - 23
C279 5631	Cover:Guard:Tape Mark (AA, NA, CHN)	55 - 10
C280 5854	Optics Sensor:Master:Duct	31 - 17
C282 1053	Stay:Main:Scanner:Right:Ass'y	57 - 5
C282 1058	Stay:Machine Or Copier:Scanner Unit:Left	57 - 3
C282 1060	Cover:Spacer:Main	9 - 23
C282 1062	Adjusting Pin:Scanner Unit:Upper Lower	57 - 2
C282 1066	Bracket:Fix:Scanner Unit:Left	13 - 10
C282 1067	Spacer:Main	9 - 24
C282 1069	Sheet:Spacer:Main:MX-48HF	9 - 25
C282 1301	Cover:Door	9 - 1
C282 1302	Cover:Front	9 - 8
C282 1303	Cover:Rear	9 - 12
C282 1304	Cover:Plotter	27 - 12
C282 1305	Cover:Left	9 - 10
C282 1306	Cover:Right	9 - 15
C282 1307	Cover:Rear Upper	9 - 11
C282 1308	Cap:FVLT	9 - 18
C282 1331	Decal:Master Set Instructions:Stopper Guide	27 - 19
C282 1382	Decal:Name Plate:STD (NA)	11 - 20
C282 1383	Decal:Name Plate:DD3334 (NA)	11 - 20
C282 1384	Decal:Name Plate:DD3344 (EU,AA)	11 - 20
C282 1385	Decal:Name Plate:DD3324 (EU)	11 - 20
C282 1386	Decal:Name Plate:CP6303C (CHN)	11 - 20
C282 1387	Decal:Name Plate:DD3344C (CHN)	11 - 20
C282 1391	Decal:Master Set Instructions:ABS	9 - 16
C282 1392	Decal:Warning:Paper Feed:EXP:PS	9 - 5
C282 1396	Decal:Main Switch:CHN:PS	9 - 4
C282 1451	Operation Panel:EXP:Ass'y	11 - *
C282 1460	Case:Operation Sub-Unit	11 - 3
C282 1471	Keytop:Start	11 - 15
C282 1472	Keytop:ClearStop	11 - 14
C282 1473	Keytop:Numeric	11 - 13

Part No.	Description	Page and Index No.
C282 1474	Keytop:Try Print	11 - 12
C282 1475	Keytop:Continuance	11 - 16
C282 1476	Keytop:Reset	11 - 11
C282 1478	Keytop:Program	11 - 10
C282 1479	KEYTOP:Return	11 - 9
C282 1480	Keytop:Magnification	11 - 8
C282 1481	Keytop:Usertool	11 - 7
C282 1482	Keytop:Memory	11 - 6
C282 1486	Bracket:Operation Sub-Unit:Left	11 - 1
C282 1491	Sheet:Operation Sub-Unit:Right	11 - 4
C282 1492	Sheet:Operation Sub-Unit:Left:NA	11 - 2
C282 1493	Sheet:Operation Sub-Unit:Right	11 - 4
C282 1494	Sheet:Operation Sub-Unit:Left:EU	11 - 2
C282 1495	Sheet:Operation Sub-Unit:Right	11 - 4
C282 1496	Sheet:Operation Sub-Unit:Left:CHN	11 - 2
C282 1792	Scale:Left:EU:Ass'y	13 - 22
C282 1799	Scale:Rear:Printing	13 - 4
C282 1800	Cover:Sheet Through:Document Feeder	13 - 2
C282 1905	Plotter:Fix:B4:Ass'y	27 - *
C282 1911	Plotter:UNI:LG	27 - *
C282 2104	Platen:B4	29 - 23
C282 2105	Platen:A4/LG	29 - 23
C282 2276	Slide Rail:Plotter:Middle	57 - 16
C282 2504	Frame:Upper:Drum:Ass'y	35 - 29
C282 2524	Decal:Pull Out:Drum	35 - 34
C282 2710	Paper Feed Tray:Ass'y	19 - 21
C282 2752	Paper Feed Tray	19 - 43
C282 2967	Decal:Adjustment Scale:Move:Paper Feed	19 - 40
C282 2980	Side Fence:Paper Feed Tray	19 - 18
C282 2995	Decal:Paper Feed Pressure:English	23 - 22
C282 2998	Decal:Size Indication:Paper Feed	19 - 1
C282 3510	Case:Master Ejection Unit:Ass'y	45 - 1
C282 3678	Case:Master Ejection	45 - 20
C282 3733	Button:Master Ejection	51 - 1
C282 3804	Hale Unit:Ass'y	41 - *

Part No.	Description	Page and Index No.
C282 4201	Paper Exit Sub-Unit:Ass'y	43 - *
C282 4204	Paper Exit Sub-Unit:CHN:Ass'y	43 - *
C282 4390	Base:Paper Exit Sub-Unit:Printing	43 - 10
C282 4395	Guide:Lower Front:Paper ExitSub-Unit: Printing	43 - 21
C282 4396	Guide:Lower Rear:Paper Exit Sub-Unit:Printing	43 - 6
C282 4397	Guide:Lower Front:Paper Exit Sub-Unit: CHN:Printing	43 - 21
C282 4398	Guide:Lower Rear:Paper Exit Sub-Unit: CHN:Printing	43 - 6
C282 4407	Case:Side Fence:Paper Exit Sub-Unit	43 - 5
C282 4416	Case:End Plate:Exit	43 - 1
C282 4430	End Fence:Adhesion	43 - 26
C282 4432	End Plate:Exit	43 - 2
C282 4441	Decal:Caution:Exit	43 - 27
C282 4464	Side Fence:Rear:Paper Exit Sub-Unit	43 - 7
C282 4465	Side Fence:Front:Paper Exit Sub-Unit	43 - 8
C282 4493	Guide:Paper:Side Fence	9 - 21
C282 4493	Guide:Paper:Side Fence	43 - 25
C282 5101	PCB:MPU:Sub-Ass'y	49 - 5
C282 5101	Bracket:Spring:Master Ejection	51 - 5
C282 5123	Supporting Plate:Cable:Document Feeder	13 - 14
C282 5200	Harness:DC Drive:Ass'y	49 - 3
C282 5201	Harness:Motor:Ass'y	49 - 4
C282 5202	Harness:Main Switch:Ass'y	51 - 9
C282 5230	Harness:Master Ejection Unit:Ass'y	45 - 14
C282 5231	Harness:Master Ejecting:Sensor:Ass'y	57 - 7
C282 5240	Harness:Imaging Unit:Ass'y	31 - 12
C282 5241	Harness:Stepper Motor:Ass'y	31 - 22
C282 5242	Harness:Connecting:Plotter:1:Ass'y	57 - 14
C282 5242	Harness:Connecting:Plotter:Ass'y	27 - 20
C282 5244	Harness:Connecting:Plotter:2:Ass'y	27 - 21
C282 5244	Harness:Connecting:Plotter:2:Ass'y	57 - 19
C282 5245	Harness:Connecting:Cutter Unit:Ass'y	57 - 13
C282 5257	Harness:Drum:Connecting:B4:Ass'y	35 - 22
C282 5258	Harness:Drum:Connecting:A4:Ass'y	35 - 22

Part No.	Description	Page and Index No.
C282 5259	Harness:Drum:Connecting:Legal:Ass'y	35 - 22
C282 5260	Harness:Hale Unit:Ass'y	41 - 13
C282 5261	Harness:Connecting:Hale:Unit:Ass'y	41 - 14
C282 5262	Harness:Connecting:Hale:Fan:Ass'y	41 - 15
C282 5271	Harness:Paper Feed Tray:Ass'y	19 - 17
C282 5272	Harness:Stay Ass'y	23 - 2
C282 5273	Harness:Connecting:Stay:Plotter:Ass'y	23 - 1
C282 5333	Rocker Switch	51 - 28
C282 5614	Bracket:SD-Card:Front	55 - 2
C282 5617	Bracket:Fix:MPU:Upper	55 - 28
C282 5639	Cover:No.1	55 - 11
C282 5670	Bracket:Power Supply Cord	49 - 9
C282 5841	Inlet:Ass'y	49 - 8
C612 1800	Screw:Lens:Guide	19 - 39
C612 1801	Screw:M4x8	35 - 2
D029 1749	Pulley:Protction	17 - 8
D144 1085	Stepped Screw:M3	13 - 1
D147 1805	Exposure Glass:Document Feeder:Apply	13 - 3
D149 1693	Guide:FFC	15 - 6
D149 1694	Plate Seal:APS:Harness	15 - 8
D149 1698	Frame:Scanner:Front	13 - 9
D149 1699	Frame:Scanner:Rear	13 - 5
D149 1703	DC Stepper Motor	17 - 1
D149 1705	Bracket:DC Stepper Motor	17 - 2
D149 1706	Synchronous Belt:138ST1.5-4.0	17 - 5
D149 1709	Tension Spring:Tension:11.3N:30MM	17 - 3
D149 1710	Timing Pulley:62	17 - 6
D149 1711	Shaft:Scanner:Drive	17 - 10
D149 1714	Drive Were:DIA1	17 - 16
D149 1715	Pulley:Drive Were:Front	17 - 7
D149 1717	Pulley:Drive Were:Rear	17 - 9
D149 1718	Bracket:Tension:Rear	17 - 14
D149 1719	Bracket:Tension:Front	17 - 13
D149 1726	Clamp:Drive Were	15 - 2
D149 1728	Guide:Harness:LED-B	15 - 5

Part No.	Description	Page and Index No.
D149 1730	Carrige:No.1:Ass'y	15 - 1
D149 1731	Reflector:Scanner	15 - 14
D149 1742	Carrige:No.2:Sub-Ass'y	17 - 20
D149 1749	Mirror:No.3:CONVAX:C3	17 - 21
D149 1754	Guide:FFC:Carrige:No.2	15 - 9
D149 1755	Cover:FFC:Carrige:No.2	15 - 10
D149 1771	Lens:Holder:Ass'y	13 - 19
D149 1780	Inner Cover	13 - 18
D149 1782	Cover:Lens	13 - 20
D149 1801	Bracket:Scale:Left	13 - 7
D149 1816	Document Feeder:Cable:Bracket	13 - 12
D149 1817	Bracket:SIO	13 - 16
D149 5206	Harness:SIO:Scanner Unit	15 - 12
D149 5207	Harness:FFC:LED	15 - 11
D158 1721	Illumination Unit:LEDB:Ass'y	15 - 3
D158 1815	Bracket:Document Feeder:Right	13 - 15
D158 1816	Bracket:Document Feeder:Left	13 - 11
D159 1740	Carrige:No.2:Ass'y	17 - 12
D159 5138	PCB:SIO	13 - 17
D159 5301	Interface Cable:Scanner:LVDS:Ass'y	13 - 21
D159 5304	Harness:SIO:STM	17 - 4
G020 5626	Push Switch	23 - 29
G020 5626	Push Switch	51 - 19
G404 2810	Spring Plate – 2nd Mirror	17 - 19
G570 1225	Sensor Shielding Plate	13 - 23
G570 1225	Sensor Shielding Plate	33 - 33
G570 1225	Sensor Shielding Plate	45 - 18
G570 1225	Sensor Shielding Plate	53 - 3
G570 1225	Sensor Shielding Plate	19 - 7
G570 1225	Sensor Shielding Plate	23 - 7
G570 1225	Sensor Shielding Plate	31 - 31
G570 1225	Sensor Shielding Plate	47 - 18
G570 1225	Sensor Shielding Plate	55 - 26
G570 1225	Sensor Shielding Plate	57 - 6
H012 1181	Bushing - 6mm	29 - 7

Part No.	Description	Page and Index No.
M026 1815	Clamp:Mirror:No.1	15 - 15