


Easy Operation Guide

Basic Procedure




Loading Paper




Adding Ink




Replacing the Master Roll




Removing the Used Master




Control Panel



- | | | |
|------------------------------------|-------------------------------------|-------------------------------|
| 1. [Fine] key | 13. [Auto Cycle] key | 25. [Reduce/Enlarge] key |
| 2. [User Tools] key | 14. [Print] mode select key | 26. [Type of Original] key |
| 3. [Image Density] key | 15. [Master Making] mode select key | 27. [Job Reset] key |
| 4. [Online] key | 16. [Start] key | 28. Data In indicator (Green) |
| 5. [Auto Online] key | 17. [Clear/Stop] key | 29. Error indicator (Red) |
| 6. Indicators | 18. [#] key | 30. [Economy Mode] key |
| 7. [Escape] key | 19. Number keys | 31. [Tint] key |
| 8. [◀] and [▶] keys | 20. [Image Position] keys | 32. [Edge Erase] key |
| 9. [OK] key | 21. Speed keys | 33. Zoom keys |
| 10. [Program] key | 22. [Memory/Class] key | 34. [Skip Feed] key |
| 11. [Clear Modes/Energy Saver] key | 23. [Combine/Repeat] key | 35. [Security] key |
| 12. [Proof] key | 24. [Full Size] key | 36. [Quality Start] key |




- | | |
|----------------------------------|-------------------------------------|
| 1. Front cover | 7. Side tray fine adjusting dial |
| 2. Control panel | 8. Paper feed side plate lock lever |
| 3. Auto Document Feeder (option) | 9. Paper feed side plates |
| 4. Feed roller pressure lever | 10. Paper feed tray |
| 5. Master tray | 11. Paper feed tray down key |
| 6. Lower master tray | |



- | | |
|----------------------------|--------------------------------|
| 1. Main switch | 7. Chocks |
| 2. Exposure glass | 8. Paper delivery tray |
| 3. Drum position indicator | 9. Paper delivery end plate |
| 4. Ink holder | 10. Master eject box |
| 5. Drum unit lock lever | 11. Paper delivery side plates |
| 6. Drum unit | 12. Paper alignment wings |


When the Open Cover/Unit Indicator Lights







Clearing Misfeeds

Paper Misfeeds in the Paper Feed Section

"%r + A"







"%r + A + B"






Paper Wrapped Around the Drum

"%r + B"



Paper Misfeeds in the Paper Exit Section

"%r + C"





Master Misfeeds in the Master Feed Section

"%r + D"




Master Misfeeds in the Master Eject Section

"%r + B + E"



Original Misfeeds in the ADF

"%r + P"



For details, see *Operating Instructions*.