

RICOH DD 5450 RICOH DD 5440c


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1. Outer Cover 1 (Front Cover).....	1 P	16A.Master Feed Section 2 (Roller/Cutter)	39 P
2. Outer Cover 2 (Rear Cover).....	3 P	16B.Master Feed Section 2 (Roller/Cutter)	41 P
3. Outer Cover 3 (Document Cover).....	5 P	16-1. Unit/Assy.....	43 P
4. Outer Cover 4 (Scanner Cover).....	7 P	17. Master Feed Section 3 (Platen Roller).....	45 P
4-1. Unit/Assy.....	9 P	18. Master Feed Section 4 (Thermal Head)...	47 P
5. Control Panel Section 1 (Cover).....	11 P	19. Master Feed Section 5 (Drive)	49 P
6A. Control Panel Section 2.....	13 P	19-1. Unit/Assy.....	51 P
6B. Control Panel Section 2.....	15 P	20. Master Feed Section 6 (Master Set)	53 P
7. Scanner Section 1 (Lock)	17 P	21. Master Feed Section 7 (Thermal head UP/Down)	55 P
8. Scanner Section 2 (Frame)	19 P	22. Master Ejection Section 1 (Frame1).....	57 P
9. Scanner Section 3 (Rail).....	21 P	23. Master Ejection Section 2 (Frame2).....	59 P
10. Scanner Section 4 (Connector Bracket)...	23 P	24. Master Ejection Section 3 (Upper Cover). 61 P	
11. Scanner Section 5 (Slider A)	25 P	25. Master Ejection Section 4 (Drive).....	63 P
12. Scanner Section 6 (Slider B)	27 P	26. Master Ejection Section 5 (Detection Lever)65 P	
13. Scanner Section 7 (Drive)	29 P	27. Paper Feed Section 1 (Feed Tray 1).....	67 P
14A. Scanner Section 8 (CCD).....	31 P	27-1. Unit/Assy.....	69 P
14B. Scanner Section 8 (CCD).....	33 P	28. Paper Feed Section 2 (Feed Tray 2).....	71 P
14C. Scanner Section 8 (CCD).....	35 P	28-1. Unit/Assy.....	73 P
15. Master Feed Section 1 (Frame).....	37 P		

29. Paper Feed Section 3 (Elavator)	75 P	48-1. Unit/Assy.....	127 P
30. Paper Feed Section 4 (Drive 1)	77 P	49. Drum Section 3 (Pump).....	129 P
31. Paper Feed Section 5 (Drive 2)	79 P	49-1. Unit/Assy.....	131 P
32. Paper Feed Section 6 (Paper Separator). 81 P		50. Drum Section 4 (Inner Frame).....	133 P
33. Secondary Feed Section 1 (Timing Roller)83 P		51. Drum Section 5 (Up/Down Drive).....	135 P
34. Secondary Feed Section 2 (Drive)	85 P	52. Drum Section 6 (Outer Frame F).....	137 P
35. Secondary Feed Section 3 (Printing Position Adjust)	87 P	53. Drum Section 7 (Ink Holder).....	139 P
36. Secondary Feed Section 4 (Double Feed Detect)	89 P	54. Drum Section 8 (Outer Frame R)	141 P
37. Master Clamp Section	91 P	55. Frame Section 1 (Frame)	143 P
37-1. Unit/Assy	93 P	56. Frame Section 2 (Main PCB 1)	145 P
38. Driving Section 1 (Main Motor)	95 P	57. Frame Section 3 (Main PCB 2)	147 P
39. Driving Section 2 (Drum Gear)	97 P	58. Frame Section 4 (Rail, Drum).....	149 P
39-1. Unit/Assy	99 P	58-1. Unit/Assy.....	151 P
40. Paper Stripping Section 1 (Pipe)	101 P	59. Safety Labels.....	153 P
40-1. Unit/Assy	103 P	60. Labels 1	155 P
41. Paper Stripping Section 2 (Fan)	105 P	61. Labels 2	157 P
42. Paper Ejection Section	107 P	62. Labels 3 (A/B, INCH size)	159 P
43. Paper Tray Section	109 P	63. Electrical Parts 1 (Switch)	161 P
44. Press Section 1 (Press Roller)	111 P	64. Electrical Parts 2 (Sensor).....	163 P
45. Press Section 2 (Press Lever).....	113 P	65. Electrical Parts 3 (Motor/Fan).....	165 P
45-1. Unit/Assy	115 P	66. Electrical Parts 4 (etc)	167 P
46. Press Adjustment Section	117 P	67. Wiring 1 (Power Supply).....	169 P
46-1. Unit/Assy	119 P	68. Wiring 2 (Main PCB).....	171 P
47. Drum Section 1 (Drum).....	121 P	69. Wiring 3 (Drive PCB).....	173 P
47-1. Unit/Assy	123 P	70. Wiring 4 (Inner).....	175 P
48. Drum Section 2 (Roller).....	125 P	71. Accessories	177 P
		72. Parts Index	179 P

1. Outer Cover 1 (Front Cover)




1. Outer Cover 1 (Front Cover)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C2841277	DP:COVER:B	1
2	C2841275	DP:SPONGE	1
3	C2841255	DP:BRACKET	1
4	C2841121	DP:SENSOR PHOTO MICRO	1
5	C2841276	DP:COVER:A	1
6	C2841254	DP:SENSOR:BRACKET	1
7	C2841271	DP:HINGE:UPPER:ASSY	1
8	C2841272	DP:HINGE:LOWER:ASSY	1
9	C2841273	DP:SCREW:PLATE	2
10	C2841256	DP:COVER	1
11	C2841274	DP:ANGLE	1
12	C2841268	DP:PICK-UP:SWITCH:CABLE UNIT	1
13	C2841253	DP:MAGNET CATCH	1
14	C2841278	DP:WARNING:LABEL	2
	C2841093	DP:WARNING:LABEL:SHEET:EU	2
	C2841286	DP:WARNING:LABEL:CHN	1
	C2841287	DP:WARNING:NAME PLATE:CHN	1
15	C2841257	DP:COVER:ANGLE	1
16			
17	C2841283	DP:PAPER FEED PRESSURE:NAME PLATE:EU:NA:AA	1
	C2841284	DP:PAPER FEED PRESSURE:NAME PLATE:MANY LANGUAGES:EU	1
	C2841285	DP:PAPER FEED PRESSURE:NAME PLATE:CHN	1
18			
19			
20	C2841267	DP:LOGO:RIC:EU:NA:CHN	1
	C2841306	DP:LOGO:GES:AA:CHN	1
21	C2841459	DP:WHITE:LABEL	1
22	C2844325	DP:LOCK:SHAFT	1
23	C2844326	DP:LEVER:ASSY	1


[illegible]

2. Outer Cover 2 (Rear Cover)



[illegible][illegible]


3. Outer Cover 3 (Document Cover)



3. Outer Cover 3 (Document Cover)

[illegible][illegible]


4. Outer Cover 4 (Scanner Cover)



4. Outer Cover 4 (Scanner Cover)

[illegible][illegible]


4-1. Unit/Assy



4-1. Unit/Assy

[illegible][illegible]


5. Control Panel Section 1 (Cover)



5. Control Panel Section 1 (Cover)

[illegible][illegible]

6A. Control Panel Section 2



6A. Control Panel Section 2


Index No.	Part No.	Description	Q'ty Per Assembly
1	C2841485	DP:OPERATION PANEL:COVER:UNIT/EU:AA	1
	C2841484	DP:OPERATION PANEL:COVER:UNIT/NA	1
	C2841486	DPOPERATION PANEL:COVER:UNIT/CHN	1
2	C2841462	DP:PLATE MAKING KEY:UNIT:I284	1
3	C2841463	DP:PRINT KEY:UNIT:I	1
4	C2841468	DP:STOP KEY:UNIT:I	1
5	C2841450	DP:TEST PRINT KEY:UNIT	1
6	C2841476	DP:NOTICE:LED:BASE	1
7	C2841465	DP:RESET KEY:UNIT	1
8	C2841456	DP:HOME KEY:UNIT	1
9	C2841455	DP:10KEY:PAD:UNIT	1
10	C2841474	DP:KEY TOP:PAD	1
11	C2841471	DP:LED:COVER	1
12	C2841489	DP:NAME PLATE:EU:AA	1
	C2841488	DP:PANEL:NAME PLATE:NA	1
	C2841490	DP:PANEL:NAME PLATE:CHN	1
13			
14			
15	C2841472	DP:SPRING PLATE	1
16	C2841473	DP:SHEET	1
17	C2841478	DP:PANEL:LED:CABLE	1
18	C2841477	DP:LIQUID CRYSTAL:FFC:CABLE	1
19	C2841479	DP:CORD CLAMP	2
20	C2841480	DP:CORD CLAMP	1
21	C2841154	DP:CORD CLAMP	1
22	C2841482	DP:PANEL:UNIT	1
23	C2841460	DP:DD5450:NAME PLATE:EU:NA:AA	1
	C2841495	DP:DD5450C:NAME PLATE:CHN	1
	C2841496	DP:CP7450C:NAME PLATE:CHN	1
	C2831495	DP:DD5440C:NAME PLATE:CHN	1
	C2831496	DP:CP7400C:NAME PLATE:CHN	1

[illegible]

6B. Control Panel Section 2

[illegible][illegible]


7. Scanner Section 1 (Lock)



7. Scanner Section 1 (Lock)

[illegible][illegible]


8. Scanner Section 2 (Frame)



8. Scanner Section 2 (Frame)

[illegible][illegible]

9. Scanner Section 3 (Rail)



9. Scanner Section 3 (Rail)

[illegible][illegible]

10. Scanner Section 4 (Connector Bracket)





Fig.55-8

10. Scanner Section 4 (Connector Bracket)

[illegible][illegible]


11. Scanner Section 5 (Slider A)



11. Scanner Section 5 (Slider A)

[illegible][illegible]


12. Scanner Section 6 (Slider B)



12. Scanner Section 6 (Slider B)

[illegible][illegible]


13. Scanner Section 7 (Drive)



13. Scanner Section 7 (Drive)

[illegible][illegible]

14A. Scanner Section 8 (CCD)



14A. Scanner Section 8 (CCD)

[illegible][illegible]

14B. Scanner Section 8 (CCD)





Fig. 11-8

14B. Scanner Section 8 (CCD)

[illegible][illegible]


14C. Scanner Section 8 (CCD)



14C. Scanner Section 8 (CCD)

[illegible][illegible]


15. Master Feed Section 1 (Frame)



15. Master Feed Section 1 (Frame)

[illegible][illegible]


16A. Master Feed Section 2 (Roller/Cutter)



16A. Master Feed Section 2 (Roller/Cutter)

[illegible][illegible]


16B. Master Feed Section 2 (Roller/Cutter)



16B. Master Feed Section 2 (Roller/Cutter)

[illegible][illegible]


16-1. Unit/Assy



16-1. Unit/Assy

[illegible][illegible]

17. Master Feed Section 3 (Platen Roller)




17. Master Feed Section 3 (Platen Roller)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C2841948	DP:COUNTER PLATE	1
2	C2841949	DP:R:GUIDE	1
3	C2841955	DP:BASE:BRACKET	1
4	C2841956	DP:CABLE:BRACKET	1
5	C2841950	DP:PLATENROLLER:14	1
6	C2841959	DP:SHAFT	1
7	C2841951	DP:FRAME:F	1
8	C2841952	DP:FRAME:R	1
9	C2841953	DP:GRIP	1
10	C2841954	DP:CLOSE:NAME PLATE	2
	C2841965	DP:CLOSE:NAME PLATE:CHN	2
11	C2841964	DP:HARNESS CLAMP	1
12	C2841961	DP:LEVER:R	1
13	C2841960	DP:LEVER:L	1
14	C2841957	DP:END MARK:BASE:UNIT	1
15	C2841907	DP:DISCHARGE BRUSH:A	1
16	C2841946	DP:TORSION SPRING	1
17	C2841966	DP:BEARING	2
18	C2841937	DP:BEARING	2
19	C2841940	DP:RADIAL BALL BEARING	2
20	C2841942	DP:ROLLER	2
21	C2841945	DP:SHAFT	3
22	C2841944	DP:PULLEY	1
23	C2841943	DP:PULLEY	2
24	C2841963	DP:BUSHING	1
25	C2841941	DP:SYNCHRONOUS BELT	1
26	C2841918	DP:CAUTION:LABEL:EU:NA:AA	1
	C2841091	DP:CAUTION:LABEL:SHEET:EU	1
	C2841915	DP:CAUTION:LABEL:CHN	1
27	C2841958	DP:DISCHARGE:BRACKET	1
28	C2841962	DP:DISCHARGE BRUSH	1
29	C2841074	DP:CORD CLAMP	1

[illegible]


18. Master Feed Section 4 (Thermal Head)



18. Master Feed Section 4 (Thermal Head)

[illegible][illegible]


19. Master Feed Section 5 (Drive)



19. Master Feed Section 5 (Drive)

[illegible][illegible]


19-1. Unit/Assy



19-1. Unit/Assy

[illegible][illegible]


20. Master Feed Section 6 (Master Set)



20. Master Feed Section 6 (Master Set)

[illegible][illegible]


21. Master Feed Section 7 (Thermal head UP/Down)



21. Master Feed Section 7 (Thermal head UP/Down)

[illegible][illegible]


22. Master Ejection Section 1 (Frame1)



22. Master Ejection Section 1 (Frame1)

[illegible][illegible]

23. Master Ejection Section 2 (Frame2)




23. Master Ejection Section 2 (Frame2)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C2843563	DP:BRACKET	1
2	C2843579	DP:SWITCH:ANGLE	1
3	C2843566	DP:BRACKET	1
4	C2843567	DP:HINGE:STAND	1
5	C2843568	DP:SHAFT	1
6	C2843569	DP:MASTER EJECTION:COVER	1
7	C2843570	DP:BRACKET	1
8	C2843571	DP:LEVER	1
9	C2843572	DP:KNOB	1
10	C2843573	DP:SHAFT	1
11	C2843574	DP:TORSION SPRING	1
12	C2843575	DP:LIGHT SHIELDING PLATE	1
13	C2843576	DP:SENSOR:ANGLE	1
14	C2843577	DP:TORSION SPRING	1
15	C2843580	DP:MASTER EJECTION:ON OFF SW:CABLE UNIT	1
16	C2843552	DP:ROLLER	1
17	C2843553	DP:LOCK:PAWL:UNIT	1
18	C2843554	DP:BRACKET	1
19	C2841680	DP:COIL SPRING:T	1
20	C2843556	DP:SHAFT:UNIT	1
21	C2843558	DP:MICRO SWITCH	1
22	C2841074	DP:CORD CLAMP	1
23	C2841121	DP:SENSOR PHOTO MICRO	1
24	C2841688	DP:Z	1
25	C2843585	DP:Y	2
26	C2843587	DP:SCREW:PLATE	1
27	C2845072	DP:COVER	1
28	C2844320	DP:PLATE	1

[illegible]


24. Master Ejection Section 3 (Upper Cover)



24. Master Ejection Section 3 (Upper Cover)

[illegible][illegible]


25. Master Ejection Section 4 (Drive)



25. Master Ejection Section 4 (Drive)

[illegible][illegible]


26. Master Ejection Section 5 (Detection Lever)



26. Master Ejection Section 5 (Detection Lever)

[illegible][illegible]


27. Paper Feed Section 1 (Feed Tray 1)



27. Paper Feed Section 1 (Feed Tray 1)

[illegible][illegible]


27-1. Unit/Assy



27-1. Unit/Assy

[illegible][illegible]


28. Paper Feed Section 2 (Feed Tray 2)



28. Paper Feed Section 2 (Feed Tray 2)

[illegible][illegible]


28-1. Unit/Assy



28-1. Unit/Assy

[illegible][illegible]


29. Paper Feed Section 3 (Elavator)



29. Paper Feed Section 3 (Elavator)

[illegible][illegible]


30. Paper Feed Section 4 (Drive 1)



30. Paper Feed Section 4 (Drive 1)

[illegible][illegible]


31. Paper Feed Section 5 (Drive 2)



31. Paper Feed Section 5 (Drive 2)

[illegible][illegible]


32. Paper Feed Section 6 (Paper Separator)



32. Paper Feed Section 6 (Paper Separator)

[illegible][illegible]


33. Secondary Feed Section 1 (Timing Roller)



33. Secondary Feed Section 1 (Timing Roller)

[illegible][illegible]


34. Secondary Feed Section 2 (Drive)



34. Secondary Feed Section 2 (Drive)

[illegible][illegible]


35. Secondary Feed Section 3 (Printing Position Adjust)



35. Secondary Feed Section 3 (Printing Position Adjust)

[illegible][illegible]


36. Secondary Feed Section 4 (Double Feed Detect)



36. Secondary Feed Section 4 (Double Feed Detect)


[illegible][illegible]

37. Master Clamp Section




37. Master Clamp Section

37-1. Unit/Assy




37-1. Unit/Assy

38. Driving Section 1 (Main Motor)




38. Driving Section 1 (Main Motor)

39. Driving Section 2 (Drum Gear)




39. Driving Section 2 (Drum Gear)

39-1. Unit/Assy




39-1. Unit/Assy

40. Paper Stripping Section 1 (Pipe)




40-1. Unit/Assy




40-1. Unit/Assy

41. Paper Stripping Section 2 (Fan)



41. Paper Stripping Section 2 (Fan)

42. Paper Ejection Section




42. Paper Ejection Section

Index No.	Part No.	Description	Q'ty Per Assembly
1	C2844120	DP:RADIAL BALL BEARING	4
2	C2844121	DP:SYNCHRONOUS BELT	1
3	C2844122	DP:REFLECTION:SENSOR	1
4	C2844150	DP:DISCHARGE BRUSH	1
5	C2844137	DP:DISCHARGE BRUSH	1
6	C2844124	DP:DC FAN MOTOR	1
7	C2844123	DP:EXIT:BELT	3
8	C2844125	DP:DRIVEN ROLLER:UNIT	1
9	C2844126	DP:DRIVE ROLLER:UNIT	1
10	C2844127	DP:PULLEY	1
11	C2844128	DP:BASE:PLATE	1
12	C2844138	DP:EXIT:MOTOR:BASE	1
13	C2844129	DP:SENSOR:ANGLE	1
14	C2844130	DP:DISCHARGE:BRACKET	1
15	C2844136	DP:GUIDE PLATE	1
16	C2844131	DP:PLATE	1
⑪	C2844139	DP:JUMP PLATE:F:ASSY	1
⑫	C2844140	DP:JUMP PLATE:R:ASSY	1
19	C2844132	DP:EXIT:BASE	1
20	C2844133	DP:EXIT:CABLE UNIT	1
21	C2844134	DP:DC STEPPER MOTOR	1
22	C2844153	DP:EXIT:GUIDE	1
23	C2844154	DP:EXIT:COVER	1
24	C2844155	DP:SHEET	3
25	C2844151	DP:DC MOTOR:ASSY	1
26	C2841074	DP:CORD CLAMP	1
27	C2844135	DP:COLLAR	2
28	C2844141	DP:ANGLE	1
29	C2844142	DP:ANGLE	1
30	C2844156	DP:JUMP PLATE:SCALE BOARD:F:EU:AA	1
	C2844158	DP:JUMP PLATE:SCALE BOARD:F:NA	1
31	C2844157	DP:JUMP PLATE:SCALE BOARD:R:EU:AA	1
	C2844159	DP:JUMP PLATE:SCALE BOARD:R:NA	1
32	C2842777	DP:Z	2

[illegible]

43. Paper Tray Section




43. Paper Tray Section

Index No.	Part No.	Description	Q'ty Per Assembly
①	C2844250	DP:PAPER TRAY:ASSY	1
2			
3	C2844300	DP:TEFLON TAPE	1
4	C2844265	DP:TEFLON TAPE	2
5	C2844301	DP:TEFLON TAPE	1
6	C2844266	DP:TEFLON TAPE	2
7	C2844302	DP:STOPPER:PIN	1
8	C2844267	DP:GUIDE PIN	2
9	C2844303	DP:SPONGE	4
10	C2844268	DP:KNOB	3
11	C2844269	DP:SHEET	2
12	C2844252	DP:SET LINE:NAME PLATE:B:EU:NA:AA	1
	C2844262	DP:SET LINE:NAME PLATE:B/CHN	1
13	C2844253	DP:PAPER TRAY:BASE	1
14	C2844254	DP:PROTECT:ANGLE:F	1
15	C2844255	DP:PROTECT:ANGLE:R	1
16	C2844256	DP:SHAFT	2
17	C2844270	DP:SIDE FENCE:F	1
18	C2844271	DP:SUPPORTER	2
19	C2844272	DP:SLIDE:BRACKET	2
20	C2844273	DP:SPRING PLATE	2
21	C2844274	DP:PROTECT:PLATE	2
22	C2844275	DP:TAPE	2
23	C2844290	DP:SIDE FENCE:R	1
24	C2844305	DP:BASE:STOPPER	1
25	C2844306	DP:MOVEABLE:STOPPER	1
26	C2844307	DP:SUPPORTER	1
27	C2844308	DP:PLATE	1
28	C2844309	DP:SLIDE:BRACKET:ASSY	1
29	C2844310	DP:SPRING PLATE	1
30	C2844311	DP:SPONGE	1
31	C2844263	DP:GUIDE:SCALE BOARD:F/INCH:NA	1
32	C2844264	DP:GUIDE:SCALE BOARD:R/INCH:NA	1
33	C2844277	DP:PAPER TRAY:STOPPER:SCALE BOARD:NA	1


[illegible]

44. Press Section 1 (Press Roller)




44. Press Section 1 (Press Roller)

45. Press Section 2 (Press Lever)



45. Press Section 2 (Press Lever)


45-1. Unit/Assy



45-1. Unit/Assy


[illegible][illegible]

46. Press Adjustment Section




46. Press Adjustment Section

46-1. Unit/Assy




46-1. Unit/Assy

47. Drum Section 1 (Drum)






47-1. Unit/Assy



47-1. Unit/Assy

[illegible][illegible]


48. Drum Section 2 (Roller)



48. Drum Section 2 (Roller)

[illegible][illegible]


48-1. Unit/Assy



48-1. Unit/Assy

[illegible][illegible]



49. Drum Section 3 (Pump)



49. Drum Section 3 (Pump)

[illegible][illegible]


49-1. Unit/Assy



49-1. Unit/Assy

[illegible][illegible]

50. Drum Section 4 (Inner Frame)



50. Drum Section 4 (Inner Frame)

[illegible][illegible]

51. Drum Section 5 (Up/Down Drive)





Fig.50-2

Fig.50-4

51. Drum Section 5 (Up/Down Drive)

[illegible][illegible]


52. Drum Section 6 (Outer Frame F)



52. Drum Section 6 (Outer Frame F)

[illegible][illegible]


53. Drum Section 7 (Ink Holder)



53. Drum Section 7 (Ink Holder)

[illegible][illegible]


54. Drum Section 8 (Outer Frame R)



54. Drum Section 8 (Outer Frame R)

[illegible][illegible]

55. Frame Section 1 (Frame)




55. Frame Section 1 (Frame)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C2841052	DP:EARTH:NAME PLATE	2
2	C2841080	DP:WARNING:LABEL:EU:NA:AA	1
	C2841090	DP:WARNING:LABEL:EU	1
	C2841083	DP:WARNING:LABEL:CHN	1
3	C2841081	DP:WARNING:LABEL:EXP:EU:NA:AA	1
	C2841092	DP:CAUTION:LABEL:SHEET:EU	1
	C2841084	DP:WARNING:LABEL:DC:CHN	1
4	C2841068	DP:FRAME:F:UNIT	1
5	C2841069	DP:MAIN:FRAME:R	1
6	C2841054	DP:SUPPORTING PLATE:BASE	2
7	C2841070	DP:SUPPORTING PLATE:PAPER FEED:UPPER	1
8	C2841055	DP:SUPPORTING PLATE:UPPER:R	1
9	C2841056	DP:GRIP:UNIT	4
10	C2841057	DP:BASE:COVER	1
11	C2841058	DP:SIDE:COVER:L	1
12	C2841067	DP:FEED INLET:COVER	1
13	C2841065	DP:MASTER FEED:INSTALL:BRACKET	4
14	C2841059	DP:SUB FRAME:A	1
15	C2841060	DP:SUB FRAME:B	1
16	C2841061	DP:CABLE:COVER	1
17	C2841062	DP:PROTECT:PLATE	1
18	C2841074	DP:CORD CLAMP	3
19	C2841076	DP:CORD CLAMP	5
20	C2841077	DP:CLAMP	32
21	C2841050	DP:STOPPER	4
22	C2841051	DP:RUBBER FOOT	4
23	C2841078	DP:CLAMP	13
24	C2841075	DP:CLAMP	20
25	C2841066	DP:COVER:PLATE	1

[illegible]

56. Frame Section 2 (Main PCB 1)




56. Frame Section 2 (Main PCB 1)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C2845050	DP:ANGLE	3
2	C2845070	DP:MAIN CONTROL BOARD:INSTALL:BRACKET	1
3	C2845071	DP:SWITCH:BRACKET	1
4	C2845051	DP:HEAT SINKER:DRIVE	1
5	C2845061	DP:HEAT SINKER:MAIN:MOTOR	1
6	C2845062	DP:PLATE:BRACKET	1
7	C2845052	DP:INLET:BRACKET	1
8	C2845053	DP:OP:CONNECTOR:BRACKET	1
9	C2845073	DP:INTERFACE:COVER	1
10	C2845054	DP:USB:INSTALL:BRACKET	1
11	C2845058	DP:USB:COVER	1
12	C2845069	DP:POWER SOURCE:INSTALL:BRACKET	1
13	C2845075	DP:DRIVE:BASE:BRACKET	1
14	C2845055	DP:MOTOR:BASE:COVER	1
15	C2845056	DP:MASTER:DETECTION PCB:BRACKET	1
16	C2845057	DP:FRAME BRACE	1
17	C2845074	DP:RELAY:BASE:BRACKET	1
18	C2841072	DP:BUSHING	1
19	C2841074	DP:CORD CLAMP	1
20	C2841077	DP:CLAMP	9
21	C2841078	DP:CLAMP	5
22	C2845095	DP:CLAMP	8
23	C2841071	DP:BUSHING	2
24	C2841073	DP:CORD CLAMP	2
25	C2841075	DP:CLAMP	4
26	C2845076	DP:COVER	1
27	C2845077	DP:CONNECTOR:COVER	1
28	C2845082	DP:FIRST:CABLE UNIT	1

[illegible]


57. Frame Section 3 (Main PCB 2)



57. Frame Section 3 (Main PCB 2)

[illegible][illegible]


58. Frame Section 4 (Rail, Drum)



58. Frame Section 4 (Rail, Drum)

[illegible][illegible]


58-1. Unit/Assy



58-1. Unit/Assy

[illegible][illegible]

59. Safety Labels



59. Safety Labels

[illegible][illegible]

60. Labels 1

1

--	--	--	--	--	--

2

--	--	--	--

3

↓	↓
---	---

4

--

5

--

6

		○	×	
--	--	---	---	--

7

8

--

60. Labels 1


[illegible][illegible]

61. Labels 2


2



5




6



7




8



61. Labels 2

[illegible][illegible]


62. Labels 3 (A/B,INCH size)



62. Labels 3 (A/B,INCH size)

[illegible][illegible]


63. Electrical Parts 1 (Switch)



63. Electrical Parts 1 (Switch)

[illegible][illegible]


64. Electrical Parts 2 (Sensor)



64. Electrical Parts 2 (Sensor)

[illegible][illegible]


65. Electrical Parts 3 (Motor/Fan)



65. Electrical Parts 3 (Motor/Fan)

[illegible][illegible]


66. Electrical Parts 4 (etc)



66. Electrical Parts 4 (etc)

[illegible][illegible]


67. Wiring 1 (Power Supply)



67. Wiring 1 (Power Supply)

[illegible][illegible]


68. Wiring 2 (Main PCB)



68. Wiring 2 (Main PCB)

[illegible][illegible]


69. Wiring 3 (Drive PCB)



69. Wiring 3 (Drive PCB)

[illegible][illegible]


70. Wiring 4 (Inner)



70. Wiring 4 (Inner)

[illegible][illegible]

71. Accessories



71. Accessories

[illegible][illegible]

72. Parts Index

Part No.	Description	Page and Index No.
C2831150	DP:DRUM:GEAR:B4	98 - 7
C2831495	DP:DD5440C:NAME PLATE:CHN	14 - 23
C2831495	DP:DD5440C:NAME PLATE:CHN	16 - 23
C2831495	DP:DD5440C:NAME PLATE:CHN	158 - 8
C2831496	DP:CP7400C:NAME PLATE:CHN	14 - 23
C2831496	DP:CP7400C:NAME PLATE:CHN	16 - 23
C2831496	DP:CP7400C:NAME PLATE:CHN	158 - 8
C2831970	DP:BRACKET:B4	48 - 6
C2831980	DP:THERMAL HEAD:B4	48 - 7
C2831980	DP:THERMAL HEAD:B4	168 - 9
C2832017	DP:HOLDER:UNIT/B4:CHN	54 - 1
C2832251	DP:DRUM:ASSY/B4:SCREEN	122 - ①
C2832252	DP:ASSY/B4	122 - ⑭
C2832261	DP:SCREEN:B4	122 - 6
C2832262	DP:BAR:F/B4:ASSY	122 - 7
C2832263	DP:BAR:R/B4:ASSY	122 - 8
C2832270	DP:INNER FRAM:UNIT/B4:EXP	122 - ⑩ -2
C2832271	DP:GUIDE	122 - 16
C2832273	DP:COWRING:PLATE:B4	122 - 11
C2832275	DP:ANGLE:B4	134 - 9
C2832295	DP:INK ROLLER:B4	126 - 16
C2832296	DP:BEARING:B4	126 - 17
C2832299	DP:SIDE PLATE:R:UNIT/B4	126 - 20
C2832300	DP:SIDE PLATE:L:UNIT/B4	126 - 21
C2832301	DP:SQUEEGEE:ASSY/B4	126 - ⑫
C2832301	DP:SQUEEGEE:ASSY/B4	128 - ⑫
C2832303	DP:SQUEEGEE:B4	128 - ⑫ -2
C2832312	DP:DISTRIBUTER:B4	130 - 6
C2833053	DP:SHAFT:B4	112 - 8
C2833058	DP:P:ROLLER:UNIT/B4	112 - 6
C2841050	DP:STOPPER	144 - 21
C2841051	DP:RUBBER FOOT	144 - 22
C2841052	DP:EARTH:NAME PLATE	144 - 1
C2841054	DP:SUPPORTING PLATE:BASE	144 - 6

Part No.	Description	Page and Index No.
C2841055	DP:SUPPORTING PLATE:UPPER:R	144 - 8
C2841056	DP:GRIP:UNIT	144 - 9
C2841057	DP:BASE:COVER	144 - 10
C2841058	DP:SIDE:COVER:L	144 - 11
C2841059	DP:SUB FRAME:A	144 - 14
C2841060	DP:SUB FRAME:B	144 - 15
C2841061	DP:CABLE:COVER	144 - 16
C2841062	DP:PROTECT:PLATE	144 - 17
C2841063	DP:PROTECT:PLATE:F2	150 - 13
C2841065	DP:MASTER FEED:INSTALL:BRACKET	144 - 13
C2841066	DP:COVER:PLATE	138 - 21
C2841066	DP:COVER:PLATE	144 - 25
C2841067	DP:FEED INLET:COVER	144 - 12
C2841068	DP:FRAME:F:UNIT	144 - 4
C2841069	DP:MAIN:FRAME:R	144 - 5
C2841070	DP:SUPPORTING PLATE:PAPER FEED:UPPER	144 - 7
C2841071	DP:BUSHING	146 - 23
C2841072	DP:BUSHING	146 - 18
C2841073	DP:CORD CLAMP	146 - 24
C2841074	DP:CORD CLAMP	6 - 12
C2841074	DP:CORD CLAMP	46 - 29
C2841074	DP:CORD CLAMP	60 - 22
C2841074	DP:CORD CLAMP	108 - 26
C2841074	DP:CORD CLAMP	144 - 18
C2841074	DP:CORD CLAMP	146 - 19
C2841075	DP:CLAMP	144 - 24
C2841075	DP:CLAMP	146 - 25
C2841076	DP:CORD CLAMP	24 - 10
C2841076	DP:CORD CLAMP	144 - 19
C2841077	DP:CLAMP	20 - 16
C2841077	DP:CLAMP	144 - 20
C2841077	DP:CLAMP	146 - 20
C2841078	DP:CLAMP	144 - 23
C2841078	DP:CLAMP	146 - 21

Part No.	Description	Page and Index No.
C2841080	DP:WARNING:LABEL:EU:NA:AA	144 - 2
C2841080	DP:WARNING:LABEL:EU:NA:AA	154 - 1
C2841081	DP:WARNING:LABEL:EXP:EU:NA:AA	144 - 3
C2841081	DP:WARNING:LABEL:EXP:EU:NA:AA	154 - 4
C2841083	DP:WARNING:LABEL:CHN	144 - 2
C2841084	DP:WARNING:LABEL:DC:CHN	144 - 3
C2841090	DP:WARNING:LABEL:EU	144 - 2
C2841090	DP:WARNING:LABEL:EU	154 - 1
C2841091	DP:CAUTION:LABEL:SHEET:EU	46 - 26
C2841091	DP:CAUTION:LABEL:SHEET:EU	154 - 2
C2841092	DP:CAUTION:LABEL:SHEET:EU	144 - 3
C2841092	DP:CAUTION:LABEL:SHEET:EU	154 - 4
C2841093	DP:WARNING:LABEL:SHEET:EU	2 - 14
C2841093	DP:WARNING:LABEL:SHEET:EU	154 - 3
C2841094	DP:WARNING:LABEL:SHEET:EU	62 - 10
C2841094	DP:WARNING:LABEL:SHEET:EU	154 - 5
C2841095	DP:WARNING:NAME PLATE:MANY LANGUAGES:EU	40 - 16
C2841095	DP:WARNING:NAME PLATE:MANY LANGUAGES:EU	42 - 3
C2841095	DP:WARNING:NAME PLATE:MANY LANGUAGES:EU	154 - 6
C2841120	DP:SYNCHRONOUS BELT	96 - 1
C2841121	DP:SENSOR PHOTO MICRO	2 - 4
C2841121	DP:SENSOR PHOTO MICRO	6 - 1
C2841121	DP:SENSOR PHOTO MICRO	20 - 8
C2841121	DP:SENSOR PHOTO MICRO	56 - 4
C2841121	DP:SENSOR PHOTO MICRO	60 - 23
C2841121	DP:SENSOR PHOTO MICRO	66 - 7
C2841121	DP:SENSOR PHOTO MICRO	78 - 25
C2841121	DP:SENSOR PHOTO MICRO	80 - 3
C2841121	DP:SENSOR PHOTO MICRO	88 - 2
C2841121	DP:SENSOR PHOTO MICRO	92 - 2
C2841121	DP:SENSOR PHOTO MICRO	96 - 2

Part No.	Description	Page and Index No.
C2841121	DP:SENSOR PHOTO MICRO	98 - 1
C2841121	DP:SENSOR PHOTO MICRO	114 - 1
C2841121	DP:SENSOR PHOTO MICRO	118 - 1
C2841121	DP:SENSOR PHOTO MICRO	136 - 2
C2841121	DP:SENSOR PHOTO MICRO	164 - 2
C2841121	DP:SENSOR PHOTO MICRO	164 - 3
C2841121	DP:SENSOR PHOTO MICRO	164 - 4
C2841121	DP:SENSOR PHOTO MICRO	164 - 5
C2841121	DP:SENSOR PHOTO MICRO	164 - 6
C2841121	DP:SENSOR PHOTO MICRO	164 - 7
C2841121	DP:SENSOR PHOTO MICRO	164 - 8
C2841121	DP:SENSOR PHOTO MICRO	164 - 9
C2841121	DP:SENSOR PHOTO MICRO	164 - 10
C2841121	DP:SENSOR PHOTO MICRO	164 - 11
C2841121	DP:SENSOR PHOTO MICRO	164 - 12
C2841121	DP:SENSOR PHOTO MICRO	164 - 13
C2841121	DP:SENSOR PHOTO MICRO	164 - 14
C2841121	DP:SENSOR PHOTO MICRO	164 - 15
C2841121	DP:SENSOR PHOTO MICRO	164 - 16
C2841122	DP:MOTOR:BASE	96 - 3
C2841123	DP:ENCODER:UNIT	96 - 4
C2841124	DP:MIDDLE:PULLEY:ASSY	96 - 6
C2841125	DP:COLLAR	96 - 7
C2841126	DP:SHAFT	96 - 9
C2841127	DP:COLLAR	96 - 10
C2841128	DP:SENSOR:ANGLE	96 - 11
C2841129	DP:TENSION:ANGLE:UNIT	96 - 12
C2841130	DP:MOTOR:PULLEY	96 - 13
C2841131	DP:TENSION:WHEEL:UNIT	96 - 5
C2841132	DP:MAIN:MOTOR	96 - 8
C2841132	DP:MAIN:MOTOR	166 - 11
C2841141	DP:DRIVE:SHAFT:ASSY	98 - ②
C2841141	DP:DRIVE:SHAFT:ASSY	100 - ②
C2841142	DP:DRIVE:PLATE:UNIT	100 - ②-1

Part No.	Description	Page and Index No.
C2841143	DP:BRACKET	100 - ② -2
C2841144	DP:DRIVE:SHAFT	100 - ② -3
C2841145	DP:HOLDER:UNIT	98 - ③
C2841145	DP:HOLDER:UNIT	100 - ③
C2841146	DP:HOLDER	100 - ③ -2
C2841147	DP:SENSOR:BRACKET:A	98 - 4
C2841148	DP:SENSOR:BRACKET:B	98 - 5
C2841149	DP:ESCAPE CAM	98 - 6
C2841150	DP:DRUM:GEAR:A3	98 - 7
C2841152	DP:RADIAL BALL BEARING	100 - ③ -1
C2841154	DP:CORD CLAMP	14 - 21
C2841154	DP:CORD CLAMP	16 - 21
C2841154	DP:CORD CLAMP	88 - 21
C2841154	DP:CORD CLAMP	90 - 2
C2841154	DP:CORD CLAMP	92 - 16
C2841154	DP:CORD CLAMP	98 - 8
C2841154	DP:CORD CLAMP	136 - 16
C2841250	DP:SUPPORTER:R:ASSY	150 - ①
C2841250	DP:SUPPORTER:R:ASSY	152 - ①
C2841251	DP:SUPPORTER:L:ASSY	150 - ②
C2841251	DP:SUPPORTER:L:ASSY	152 - ②
C2841253	DP:MAGNET CATCH	2 - 13
C2841254	DP:SENSOR:BRACKET	2 - 6
C2841255	DP:BRACKET	2 - 3
C2841256	DP:COVER	2 - 10
C2841257	DP:COVER:ANGLE	2 - 15
C2841260	DP:Y1-T1260:INK PACK:SET:NAME PLATE	156 - 6
C2841261	DP:Y1-T1270:DRUM:INDICATION:NAME PLATE	156 - 7
C2841267	DP:LOGO:RIC:EU:NA:CHN	2 - 20
C2841268	DP:PICK-UP:SWITCH:CABLE UNIT	2 - 12
C2841268	DP:PICK-UP:SWITCH:CABLE UNIT	172 - 2
C2841271	DP:HINGE:UPPER:ASSY	2 - 7
C2841272	DP:HINGE:LOWER:ASSY	2 - 8
C2841273	DP:SCREW:PLATE	2 - 9

Part No.	Description	Page and Index No.
C2841274	DP:ANGLE	2 - 11
C2841275	DP:SPONGE	2 - 2
C2841276	DP:COVER:A	2 - 5
C2841277	DP:COVER:B	2 - 1
C2841278	DP:WARNING:LABEL	2 - 14
C2841278	DP:WARNING:LABEL:EXP:EU:NA:AA	154 - 3
C2841280	DP:REAR:COVER	4 - 1
C2841281	DP:COVER:BRACKET	4 - 2
C2841283	DP:PAPER FEED PRESSURE:NAME PLATE:EU:NA:AA	2 - 17
C2841283	DP:PAPER FEED PRESSURE:NAME PLATE:EU:NA:AA	156 - 5
C2841284	DP:PAPER FEED PRESSURE:NAME PLATE:MANY LANGUAGES:EU	2 - 17
C2841284	DP:PAPER FEED PRESSURE:NAME PLATE:MANY LANGUAGES:EU	156 - 5
C2841285	DP:PAPER FEED PRESSURE:NAME PLATE:CHN	2 - 17
C2841285	DP:PAPER FEED PRESSURE:NAME PLATE:CHN	156 - 5
C2841286	DP:WARNING:LABEL:CHN	2 - 14
C2841287	DP:WARNING:NAME PLATE:CHN	2 - 14
C2841290	DP:ROLLER	152 - ① -1
C2841290	DP:ROLLER	152 - ② -1
C2841291	DP:MICRO SWITCH	76 - 4
C2841291	DP:MICRO SWITCH	150 - 7
C2841291	DP:MICRO SWITCH	162 - 3
C2841291	DP:MICRO SWITCH	162 - 4
C2841292	DP:SCREW:PLATE	40 - 8
C2841292	DP:SCREW:PLATE	42 - 8
C2841292	DP:SCREW:PLATE	150 - 8
C2841293	DP:PIN	6 - 2
C2841293	DP:PIN	24 - 2
C2841293	DP:PIN	112 - 14
C2841293	DP:PIN	138 - 5
C2841294	DP:LOCK:BRACKET	150 - 9

Part No.	Description	Page and Index No.
C2841295	DP:BRACKET	150 - 10
C2841296	DP:SPRING PLATE	150 - 12
C2841297	DP:COIL SPRING:C	138 - 18
C2841298	DP:SUPPORTER:R:ASSY	152 - ①-2
C2841299	DP:SUPPORTER:L:ASSY	152 - ②-2
C2841300	DP:PILLAR:RR	150 - 3
C2841301	DP:PILLAR:FR	150 - 4
C2841302	DP:PILLAR:RL	150 - 5
C2841303	DP:PILLAR:FL	150 - 6
C2841304	DP:Z	80 - 5
C2841304	DP:Z	150 - 11
C2841306	DP:LOGO:GES:AA:CHN	2 - 20
C2841450	DP:TEST PRINT KEY:UNIT	14 - 5
C2841450	DP:TEST PRINT KEY:UNIT	16 - 5
C2841451	DP:COVER	12 - 1
C2841455	DP:10KEY:PAD:UNIT	14 - 9
C2841455	DP:10KEY:PAD:UNIT	16 - 9
C2841456	DP:HOME KEY:UNIT	14 - 8
C2841456	DP:HOME KEY:UNIT	16 - 8
C2841459	DP:WHITE:LABEL	2 - 21
C2841460	DP:DD5450:NAME PLATE:EU:NA:AA	14 - 23
C2841460	DP:DD5450:NAME PLATE:EU:NA:AA	16 - 23
C2841460	DP:DD5450:NAME PLATE:EU:NA:AA	158 - 8
C2841462	DP:PLATE MAKING KEY:UNIT:I284	14 - 2
C2841462	DP:PLATE MAKING KEY:UNIT:I284	16 - 2
C2841463	DP:PRINT KEY:UNIT:I	14 - 3
C2841463	DP:PRINT KEY:UNIT:I	16 - 3
C2841465	DP:RESET KEY:UNIT	14 - 7
C2841465	DP:RESET KEY:UNIT	16 - 7
C2841468	DP:STOP KEY:UNIT:I	14 - 4
C2841468	DP:STOP KEY:UNIT:I	16 - 4
C2841469	DP:BRACKET	12 - 2
C2841470	DP:LCD:BRACKET	12 - 3
C2841471	DP:LED:COVER	14 - 11

Part No.	Description	Page and Index No.
C2841471	DP:LED:COVER	16 - 11
C2841472	DP:SPRING PLATE	14 - 15
C2841472	DP:SPRING PLATE	16 - 15
C2841473	DP:SHEET	14 - 16
C2841473	DP:SHEET	16 - 16
C2841474	DP:KEY TOP:PAD	14 - 10
C2841474	DP:KEY TOP:PAD	16 - 10
C2841475	DP:PANEL:BASE:UNIT	12 - 4
C2841475	DP:PANEL:BASE:UNIT	168 - 7
C2841476	DP:NOTICE:LED:BASE	14 - 6
C2841476	DP:NOTICE:LED:BASE	16 - 6
C2841476	DP:NOTICE:LED:BASE	168 - 8
C2841477	DP:LIQUID CRYSTAL:FFC:CABLE	14 - 18
C2841477	DP:LIQUID CRYSTAL:FFC:CABLE	16 - 18
C2841477	DP:LIQUID CRYSTAL:FFC:CABLE	176 - 10
C2841478	DP:PANEL:LED:CABLE	14 - 17
C2841478	DP:PANEL:LED:CABLE	16 - 17
C2841478	DP:PANEL:LED:CABLE	176 - 11
C2841479	DP:CORD CLAMP	14 - 19
C2841479	DP:CORD CLAMP	16 - 19
C2841479	DP:CORD CLAMP	38 - 11
C2841479	DP:CORD CLAMP	88 - 1
C2841479	DP:CORD CLAMP	90 - 1
C2841479	DP:CORD CLAMP	114 - 2
C2841480	DP:CORD CLAMP	12 - 5
C2841480	DP:CORD CLAMP	14 - 20
C2841480	DP:CORD CLAMP	16 - 20
C2841482	DP:PANEL:UNIT	14 - 22
C2841482	DP:PANEL:UNIT	16 - 22
C2841484	DP:OPERATION PANEL:COVER:UNIT/NA	14 - 1
C2841484	DP:OPERATION PANEL:COVER:UNIT/NA	16 - 1
C2841485	DP:OPERATION PANEL:COVER:UNIT/EU:AA	14 - 1
C2841485	DP:OPERATION PANEL:COVER:UNIT/EU:AA	16 - 1
C2841486	DPOPERATION PANEL:COVER:UNIT/CHN	14 - 1

Part No.	Description	Page and Index No.
C2841488	DP:PANEL:NAME PLATE:NA	14 - 12
C2841489	DP:NAME PLATE:EU:AA	14 - 12
C2841489	DP:NAME PLATE:EU:AA	16 - 12
C2841490	DP:PANEL:NAME PLATE:CHN	14 - 12
C2841495	DP:DD5450C:NAME PLATE:CHN	14 - 23
C2841495	DP:DD5450C:NAME PLATE:CHN	16 - 23
C2841495	DP:DD5450C:NAME PLATE:CHN	158 - 8
C2841496	DP:CP7450C:NAME PLATE:CHN	14 - 23
C2841496	DP:CP7450C:NAME PLATE:CHN	16 - 23
C2841496	DP:CP7450C:NAME PLATE:CHN	158 - 8
C2841650	DP:SHEET	8 - 9
C2841651	DP:GLASS	8 - 6
C2841652	DP:FRONT:COVER	8 - 1
C2841653	DP:GUIDE:COVER:L	8 - 2
C2841654	DP:SIDE:COVER:R	8 - 3
C2841655	DP:REAR:COVER:UNIT	8 - 4
C2841656	DP:HORAIZONTAL:SCALE BOARD	8 - 8
C2841656	DP:HORAIZONTAL:SCALE BOARD	160 - 1
C2841657	DP:SCALE BOARD:ASSY	8 - ⑤
C2841657	DP:SCALE BOARD:ASSY	10 - ⑤
C2841658	DP:SHADING:SHEET	10 - ⑤-1
C2841659	DP:SIZE:COVER	10 - ⑤-2
C2841660	DP:VERTICAL:SCALE BOARD:A/B	10 - ⑤-3
C2841660	DP:VERTICAL:SCALE BOARD:A/B	160 - 2
C2841670	DP:COVER	8 - 7
C2841680	DP:COIL SPRING:T	18 - 7
C2841680	DP:COIL SPRING:T	60 - 19
C2841681	DP:MICRO SWITCH	18 - 8
C2841681	DP:MICRO SWITCH	162 - 2
C2841682	DP:LOCK:PAWL:ASSY	18 - 1
C2841683	DP:BRACKET	18 - 2
C2841684	DP:PUSH LEVER	18 - 3
C2841685	DP:KNOB	18 - 4
C2841686	DP:SWITCH:BRACKET	18 - 5

Part No.	Description	Page and Index No.
C2841687	DP:SCANNER:ON OFF SW:CABLE UNIT	18 - 9
C2841687	DP:SCANNER:ON OFF SW:CABLE UNIT	172 - 14
C2841688	DP:Z	18 - 6
C2841688	DP:Z	60 - 24
C2841688	DP:Z	62 - 6
C2841688	DP:Z	102 - 1
C2841691	DP:SLIDER	22 - 5
C2841693	DP:COLLAR	6 - 3
C2841694	DP:CABLE:GUIDE:B	20 - 12
C2841695	DP:ACTUATOR	6 - 4
C2841696	DP:COIL SPRING:TO	6 - 5
C2841697	DP:BOSS	6 - 15
C2841698	DP:HINGE:BRACKET	6 - 6
C2841699	DP:FRAME UNIT	20 - 1
C2841700	DP:FRONT:FRAME	20 - 2
C2841701	DP:REAR:FRAME	20 - 3
C2841702	DP:SLIDER:RAIL:F	20 - 5
C2841703	DP:SLIDER:RAIL:R	20 - 6
C2841704	DP:LOCK PIN:ASSY	20 - 7
C2841705	DP:GUARD	20 - 9
C2841706	DP:CENTER:BRACKET	20 - 10
C2841707	DP:SPONGE:SHEET	20 - 11
C2841708	DP:SLIDE:STOPPER	22 - 1
C2841709	DP:STOPPER:ANGLE	22 - 2
C2841710	DP:SLIDER:BRACKET	22 - 4
C2841711	DP:SLIDE RAIL	22 - 3
C2841712	DP:CENTER:FRAME	20 - 4
C2841713	DP:FFC:PLATE	20 - 13
C2841714	DP:LED:LAMP:CABLE	26 - 8
C2841714	DP:LED:LAMP:CABLE	176 - 1
C2841716	DP:CORD CLAMP	20 - 14
C2841716	DP:CORD CLAMP	72 - 10
C2841716	DP:CORD CLAMP	138 - 23
C2841717	DP:CLAMP	20 - 15

Part No.	Description	Page and Index No.
C2841717	DP:CLAMP	26 - 7
C2841719	DP:CORD CLAMP	20 - 17
C2841725	DP:COIL SPRING:C	24 - 1
C2841727	DP:PILLAR	24 - 5
C2841728	DP:COIL SPRING:C	24 - 6
C2841729	DP:SPONGE:BRACKET	24 - 11
C2841730	DP:SPONGE	24 - 12
C2841731	DP:CONNECTOR:BRACKET:1	24 - 3
C2841732	DP:CONNECTOR:BRACKET:2	24 - 4
C2841733	DP:ADF:CABLE UNIT:1	24 - 9
C2841733	DP:ADF:CABLE UNIT:1	176 - 5
C2841734	DP:SCANNER:CABLE UNIT:300DPI	24 - 8
C2841734	DP:SCANNER:CABLE UNIT:300DPI	176 - 4
C2841735	DP:CCD:CABLE UNIT	24 - 7
C2841735	DP:CCD:CABLE UNIT	176 - 3
C2841740	DP:SLIDER	26 - 1
C2841740	DP:SLIDER	28 - 1
C2841740	DP:SLIDER	54 - 5
C2841741	DP:WIRE:STOPPER	26 - 2
C2841742	DP:MIRROR:STOPPER	26 - 3
C2841743	DP:MIRROR	26 - 4
C2841744	DP:SLIDER:UNIT	26 - 5
C2841745	DP:LED:LAMP:UNIT	26 - 6
C2841745	DP:LED:LAMP:UNIT	168 - 1
C2841751	DP:SLIDER:B:UNIT	28 - 2
C2841752	DP:PULLEY:UNIT	28 - 3
C2841753	DP:MIRROR:STOPPER:A	28 - 4
C2841754	DP:MIRROR:STOPPER:B	28 - 5
C2841755	DP:PULLEY:F:UNIT	28 - 6
C2841756	DP:PULLEY:R:UNIT	28 - 7
C2841757	DP:SLIDE:BRACKET:F	28 - 8
C2841758	DP:SLIDE:BRACKET:R	28 - 9
C2841759	DP:CABLE:GUIDE:A	28 - 10
C2841760	DP:MIRROR	28 - 11

Part No.	Description	Page and Index No.
C2841770	DP:RADIAL BALL BEARING	30 - 9
C2841771	DP:SYNCHRONOUS BELT	30 - 11
C2841772	DP:TIMING PULLEY	30 - 12
C2841773	DP:MOTOR:BRACKET	30 - 8
C2841774	DP:MIDDLE:PULLEY:UNIT	30 - 15
C2841775	DP:IDLER:PIN:UNIT	30 - 16
C2841776	DP:COIL SPRING:T	30 - 13
C2841777	DP:CORNER GUIDE	30 - 14
C2841778	DP:PULLEY:ASSY	30 - 1
C2841779	DP:DRIVE:SHAFT	30 - 2
C2841780	DP:WIRE	30 - 5
C2841781	DP:WIRE:PULLEY	30 - 6
C2841782	DP:COIL SPRING:ANGLE	30 - 7
C2841783	DP:BRACKET:R	30 - 3
C2841784	DP:BRACKET:F	30 - 4
C2841785	DP:DC STEPPER MOTOR	30 - 10
C2841785	DP:DC STEPPER MOTOR	166 - 15
C2841790	DP:COIL SPRING:C	32 - 6
C2841790	DP:COIL SPRING:C	34 - 11
C2841790	DP:COIL SPRING:C	36 - 5
C2841791	DP:COVER	32 - 5
C2841791	DP:COVER	34 - 10
C2841791	DP:COVER	36 - 4
C2841900	DP:DAMPER:ASSY	50 - ⑨
C2841900	DP:DAMPER:ASSY	52 - ⑨
C2841901	DP:DISCHARGE BRUSH	38 - 8
C2841902	DP:FRAME:F	38 - 1
C2841903	DP:FRAME:R	38 - 2
C2841904	DP:SUPPORTING PLATE:C	38 - 3
C2841905	DP:SUPPORTING PLATE:D	38 - 4
C2841906	DP:GUIDE	38 - 6
C2841907	DP:DISCHARGE BRUSH:A	38 - 7
C2841907	DP:DISCHARGE BRUSH:A	46 - 15
C2841908	DP:MASTER FEED:CABLE UNIT	40 - 17

Part No.	Description	Page and Index No.
C2841908	DP:MASTER FEED:CABLE UNIT	42 - 16
C2841908	DP:MASTER FEED:CABLE UNIT	176 - 6
C2841909	DP:SUPPORTING PLATE:B	38 - 5
C2841910	DP:PILLAR:L:UNIT	38 - 9
C2841911	DP:PILLAR:R:UNIT	38 - 10
C2841915	DP:CAUTION:LABEL:CHN	46 - 26
C2841915	DP:CAUTION:LABEL:CHN	154 - 2
C2841916	DP:COVER:R	38 - 12
C2841917	DP:COVER:F	38 - 13
C2841918	DP:CAUTION:LABEL:EU:NA:AA	46 - 26
C2841918	DP:CAUTION:LABEL:EU:NA:AA	154 - 2
C2841920	DP:RADIAL BALL BEARING	40 - 10
C2841920	DP:RADIAL BALL BEARING	42 - 10
C2841921	DP:DU:BUSHING	40 - 13
C2841921	DP:DU:BUSHING	42 - 13
C2841922	DP:PHOTOINTERRUPTOR	40 - 9
C2841922	DP:PHOTOINTERRUPTOR	42 - 9
C2841922	DP:PHOTOINTERRUPTOR	68 - 1
C2841922	DP:PHOTOINTERRUPTOR	164 - 17
C2841922	DP:PHOTOINTERRUPTOR	164 - 18
C2841922	DP:PHOTOINTERRUPTOR	164 - 19
C2841923	DP:MICRO SWITCH	40 - 7
C2841923	DP:MICRO SWITCH	42 - 7
C2841923	DP:MICRO SWITCH	162 - 1
C2841925	DP:TORSION SPRING	40 - 11
C2841925	DP:TORSION SPRING	42 - 11
C2841926	DP:SWITCH:BRACKET	40 - 6
C2841926	DP:SWITCH:BRACKET	42 - 6
C2841927	DP:SPONGE:ROLLER:A	40 - 1
C2841927	DP:SPONGE:ROLLER:A	42 - 1
C2841928	DP:GUIDE PLATE:A	40 - 2
C2841928	DP:GUIDE PLATE:A	42 - 2
C2841929	DP:GUIDE PLATE:B:ASSY	40 - ④
C2841929	DP:GUIDE PLATE:B:ASSY	42 - ④

Part No.	Description	Page and Index No.
C2841929	DP:GUIDE PLATE:B:ASSY	44 - ④
C2841930	DP:SHEET:UNIT	44 - ④-1
C2841931	DP:GUIDE PLATE:B:UNIT	44 - ④-2
C2841932	DP:SPONGE:ROLLER:B	40 - 5
C2841932	DP:SPONGE:ROLLER:B	42 - 5
C2841933	DP:GUIDE:A:300/600	40 - 3
C2841935	DP:WARNING:NAME PLATE:CHN	40 - 16
C2841935	DP:WARNING:NAME PLATE:CHN	154 - 6
C2841936	DP:A3:CUTTER UNIT	40 - 14
C2841936	DP:A3:CUTTER UNIT	42 - 14
C2841936	DP:A3:CUTTER UNIT	166 - 10
C2841937	DP:BEARING	40 - 12
C2841937	DP:BEARING	42 - 12
C2841937	DP:BEARING	46 - 18
C2841937	DP:BEARING	48 - 12
C2841937	DP:BEARING	64 - 10
C2841937	DP:BEARING	78 - 21
C2841937	DP:BEARING	136 - 1
C2841938	DP:MASTER SET:NAME PLATE:EU:NA:AA	40 - 15
C2841938	DP:MASTER SET:NAME PLATE:EU:NA:AA	42 - 15
C2841939	DP:MASTER SET:NAME PLATE:CHN	40 - 15
C2841939	DP:MASTER SET:NAME PLATE:CHN	158 - 2
C2841940	DP:RADIAL BALL BEARING	46 - 19
C2841941	DP:SYNCHRONOUS BELT	46 - 25
C2841942	DP:ROLLER	46 - 20
C2841942	DP:ROLLER	64 - 18
C2841942	DP:ROLLER	78 - 19
C2841943	DP:PULLEY	46 - 23
C2841944	DP:PULLEY	46 - 22
C2841945	DP:SHAFT	46 - 21
C2841946	DP:TORSION SPRING	46 - 16
C2841947	DP:MASTER SET:NAME PLATE:MANY LANGUAGES:EU	40 - 15

Part No.	Description	Page and Index No.
C2841947	DP:MASTER SET:NAME PLATE:MANY LANGUAGES:EU	42 - 15
C2841948	DP:COUNTER PLATE	46 - 1
C2841949	DP:R:GUIDE	46 - 2
C2841950	DP:PLATENROLLER:14	46 - 5
C2841951	DP:FRAME:F	46 - 7
C2841952	DP:FRAME:R	46 - 8
C2841953	DP:GRIP	46 - 9
C2841954	DP:CLOSE:NAME PLATE	46 - 10
C2841954	DP:CLOSE:NAME PLATE	62 - 8
C2841954	DP:CLOSE:NAME PLATE:EU:NA:AA	156 - 3
C2841955	DP:BASE:BRACKET	46 - 3
C2841956	DP:CABLE:BRACKET	46 - 4
C2841957	DP:END MARK:BASE:UNIT	46 - 14
C2841957	DP:END MARK:BASE:UNIT	168 - 6
C2841958	DP:DISCHARGE:BRACKET	46 - 27
C2841959	DP:SHAFT	46 - 6
C2841960	DP:LEVER:L	46 - 13
C2841961	DP:LEVER:R	46 - 12
C2841962	DP:DISCHARGE BRUSH	46 - 28
C2841963	DP:BUSHING	46 - 24
C2841964	DP:HARNESS CLAMP	46 - 11
C2841965	DP:CLOSE:NAME PLATE:CHN	46 - 10
C2841965	DP:CLOSE:NAME PLATE:CHN	156 - 3
C2841966	DP:BEARING	46 - 17
C2841968	DP:WARNING:NAME PLATE:EU:NA:AA	40 - 16
C2841968	DP:WARNING:NAME PLATE:EU:NA:AA	42 - 3
C2841968	DP:WARNING:NAME PLATE:EU:NA:AA	154 - 6
C2841970	DP:BRACKET:430:A3	48 - 6
C2841971	DP:LEVER	48 - 8
C2841972	DP:SPRING PLATE	48 - 15
C2841973	DP:LEVER:F	48 - 10
C2841974	DP:LEVER:R	48 - 11
C2841975	DP:SHAFT	48 - 2

Part No.	Description	Page and Index No.
C2841976	DP:COIL SPRING:T	48 - 3
C2841977	DP:COLLAR	48 - 4
C2841978	DP:ANGLE	48 - 5
C2841979	DP:COVER:300/600	48 - 1
C2841980	DP:THERMAL HEAD:A3-300	48 - 7
C2841980	DP:THERMAL HEAD:A3-300	168 - 9
C2841981	DP:DISCHARGE BRUSH	48 - 16
C2841982	DP:RATING NAME PLATE:GREEN	48 - 14
C2841982	DP:RATING NAME PLATE:GREEN	158 - 7
C2841983	DP:THERMAL HEAD:CABLE UNIT:300	48 - 13
C2841983	DP:THERMAL HEAD:CABLE UNIT:300	176 - 7
C2841984	DP:Z	48 - 9
C2841984	DP:Z	134 - 18
C2841990	DP:SYNCHRONOUS BELT	50 - 2
C2841991	DP:SYNCHRONOUS BELT	50 - 3
C2841992	DP:SYNCHRONOUS BELT	50 - 4
C2841993	DP:ROTARY:DAMPER	50 - 5
C2841994	DP:DAMPER	52 - ⑨-1
C2841994	DP:DAMPER	78 - 16
C2841995	DP:PULLEY	50 - 7
C2841996	DP:GEAR	50 - 8
C2841997	DP:MOTOR:BRACKET	52 - ⑨-2
C2841998	DP:TIMING PULLEY:S3M38	50 - 10
C2841999	DP:ANGLE	50 - 12
C2842000	DP:SHAFT	50 - 13
C2842001	DP:CLUTCH	50 - 14
C2842001	DP:CLUTCH	162 - 6
C2842002	DP:ANGLE	50 - 1
C2842003	DP:PULLEY	50 - 11
C2842004	DP:MASTER FEED:DC STEPPER MOTOR	50 - 6
C2842004	DP:MASTER FEED:DC STEPPER MOTOR	166 - 13
C2842011	DP:COLLAR	54 - 4
C2842012	DP:COIL SPRING:T	54 - 2
C2842013	DP:SHAFT	54 - 3

Part No.	Description	Page and Index No.
C2842015	DP:COVER:PLATE	38 - 14
C2842017	DP:HOLDER:UNI/A3	54 - 1
C2842021	DP:DC MOTOR	56 - 3
C2842021	DP:DC MOTOR	166 - 3
C2842022	DP:MOTOR:BRACKET	56 - 1
C2842023	DP:CAM:UNIT	56 - 2
C2842024	DP:BUSHING	56 - 5
C2842024	DP:BUSHING	58 - 9
C2842251	DP:DRUM:ASSY/A3:SCREEN	122 - ①
C2842252	DP:ASSY/A3	122 - ⑭
C2842253	DP:CLAMP PLATE:ASSY	122 - ⑮
C2842253	DP:CLAMP PLATE:ASSY	124 - ⑮
C2842254	DP:LINK:ASSY	132 - ① -12
C2842255	DP:CLAMP PLATE	124 - ⑮ -1
C2842256	DP:LEVER	124 - ⑮ -2
C2842257	DP:COIL SPRING:TO/F	122 - 2
C2842258	DP:COIL SPRING:TO/R	122 - 3
C2842259	DP:BEARING PLATE:R	122 - 4
C2842260	DP:BEARING PLATE:F	122 - 5
C2842261	DP:SCREEN:A3	122 - 6
C2842262	DP:BAR:F/A3:ASSY	122 - 7
C2842263	DP:BAR:R/A3:ASSY	122 - 8
C2842264	DP:BASE:UNI:A3	122 - ⑨
C2842264	DP:BASE:UNI:A3	124 - ⑨
C2842265	DP:BASE	124 - ⑨ -1
C2842266	DP:RUBBER MAGNET:A3	124 - ⑨ -2
C2842267	DP:LEVER	124 - ⑮ -3
C2842268	DP:COVER	122 - 10
C2842269	DP:SPONGE	122 - 12
C2842270	DP:ANGLE	122 - 13
C2842271	DP:GUIDE	122 - 16
C2842273	DP:INNER FRAM:UNIT/A3:EXP	122 - ⑩ -2
C2842280	DP:STEEL BALL	126 - 1
C2842281	DP:RADIAL BALL BEARING	126 - 2

Part No.	Description	Page and Index No.
C2842282	DP:ADJUSTING SCREW	126 - 3
C2842283	DP:INK:ADJUSTING SCREW	126 - 4
C2842284	DP:COIL SPRING:C	126 - 5
C2842285	DP:COLLAR	126 - 6
C2842286	DP:INK SCRAPER:R	126 - 7
C2842287	DP:INK SCRAPER:L	126 - 8
C2842288	DP:COIL SPRING:C1	126 - 9
C2842289	DP:COLLAR	126 - 10
C2842290	DP:COIL SPRING:C2	126 - 11
C2842291	DP:GEAR:UNI	126 - 22
C2842292	DP:BASE:R	126 - 13
C2842293	DP:BASE:L	126 - 14
C2842294	DP:COIL SPRING:C	126 - 15
C2842295	DP:INK ROLLER:A3	126 - 16
C2842296	DP:BEARING:A3	126 - 17
C2842297	DP:INK ROLLER:GEAR:R	126 - 18
C2842298	DP:COIL SPRING:C3	126 - 19
C2842299	DP:SIDE PLATE:R:UNIT/A3	126 - 20
C2842300	DP:SIDE PLATE:L:UNIT/A3	126 - 21
C2842301	DP:SQUEEGEE:ASSY/A3	126 - ⑫
C2842301	DP:SQUEEGEE:ASSY/A3	128 - ⑫
C2842302	DP:RADIAL BALL BEARING	128 - ⑫ -1
C2842302	DP:RADIAL BALL BEARING	128 - ⑫ -1
C2842303	DP:SQUEEGEE:A3	128 - ⑫ -2
C2842304	DP:SHAFT:A3	128 - ⑫ -3
C2842310	DP:COLLAR	130 - 2
C2842311	DP:PUMP:BASE	130 - 3
C2842312	DP:DISTRIBUTER:A3	130 - 6
C2842313	DP:DETECTION PCB:BRACKET	130 - 7
C2842314	DP:HOSE	130 - 8
C2842316	DP:STEEL BALL	132 - ① -1
C2842317	DP:O-RING	132 - ① -2
C2842318	DP:OIL SHIELD	132 - ① -3
C2842319	DP:COIL SPRING:C	132 - ① -4

Part No.	Description	Page and Index No.
C2842320	DP:VALVE	132 - ①-5
C2842321	DP:PLUNGER	132 - ①-6
C2842322	DP:COVER	132 - ①-7
C2842323	DP:PLUG	132 - ①-8
C2842324	DP:PACKING	132 - ①-9
C2842325	DP:PACKING	132 - ①-10
C2842326	DP:PACKING	132 - ①-11
C2842327	DP:NUT	132 - ①-13
C2842328	DP:PIPE	132 - ①-14
C2842330	DP:CAP	132 - ①-16
C2842331	DP:MOTOR	130 - 4
C2842331	DP:MOTOR	136 - 15
C2842331	DP:MOTOR	166 - 8
C2842331	DP:MOTOR	166 - 9
C2842332	DP:INK SENSOR:ASSY	130 - 5
C2842332	DP:INK SENSOR:ASSY	168 - 2
C2842333	DP:WIRE BAND	130 - 10
C2842334	DP:Z	130 - 9
C2842335	DP:INK SUPPLY PUMP:R/ASSY	130 - ①
C2842335	DP:INK SUPPLY PUMP:R/ASSY	132 - ①
C2842336	DP:CYLINDER:A	132 - ①-15
C2842340	DP:COLLAR	134 - 1
C2842341	DP:STAY	134 - 2
C2842342	DP:STAY	134 - 3
C2842343	DP:SUB FRAME:F	134 - 4
C2842344	DP:SUB FRAME:R:UNIT	134 - 5
C2842345	DP:SHAFT	134 - 6
C2842346	DP:COLLAR	134 - 8
C2842347	DP:INNER FRAM:F	134 - 10
C2842348	DP:INNER FRAM:R	134 - 11
C2842349	DP:HOLDER:UNIT	134 - ⑩
C2842350	DP:ROLLER:UNIT:A	134 - 13
C2842351	DP:ROLLER:UNIT:B	134 - 14
C2842352	DP:GUIDE PLATE	134 - 15

Part No.	Description	Page and Index No.
C2842353	DP:COVER:F	134 - 16
C2842354	DP:BRACKET	134 - 17
C2842355	DP:CONNECTOR:BRACKET	134 - 7
C2842356	DP:WIRE BINDER	58 - 11
C2842361	DP:GEAR	136 - 3
C2842362	DP:COLLAR	136 - 4
C2842363	DP:COLLAR	136 - 5
C2842364	DP:PLATE	136 - 6
C2842365	DP:MOTOR:BASE	136 - 7
C2842366	DP:UPPER LOWER:DRIVE:SHAFT	136 - 8
C2842367	DP:DRIVE:GEAR	136 - 9
C2842368	DP:CAM	136 - 10
C2842369	DP:LIGHT SHIELDING PLATE	136 - 11
C2842370	DP:UPPER LOWER:STAY	136 - 12
C2842371	DP:UPPER LOWER:COLLAR	136 - 13
C2842372	DP:COIL SPRING:T	136 - 14
C2842380	DP:SHAFT	138 - 1
C2842381	DP:COIL SPRING:T0	138 - 2
C2842382	DP:MAGNET CATCH	140 - 1
C2842383	DP:HEXAGONALPOST	138 - 3
C2842384	DP:PILLAR	138 - 4
C2842385	DP:COVER	138 - 6
C2842386	DP:STOPPER	140 - 2
C2842387	DP:BRACKET:R	138 - 7
C2842388	DP:BRACKET:L	138 - 8
C2842389	DP:LEVER	138 - 9
C2842390	DP:COVER	138 - 10
C2842391	DP:SHAFT	138 - 11
C2842392	DP:ARM:UNIT	138 - 12
C2842393	DP:COIL SPRING:TO/R	138 - 13
C2842394	DP:COIL SPRING:TO/L	138 - 14
C2842395	DP:BRACKET	138 - 15
C2842396	DP:STOPPER:UNIT	138 - 16
C2842397	DP:COVER	138 - 17

Part No.	Description	Page and Index No.
C2842398	DP:PLATE	140 - 3
C2842399	DP:PLATE	140 - 4
C2842400	DP:DRUM:STOPPER:RATING NAME PLATE	138 - 19
C2842400	DP:DRUM:STOPPER:RATING NAME PLATE	156 - 8
C2842401	DP:DRUM:INNER:CABLE UNIT	130 - 11
C2842401	DP:DRUM:INNER:CABLE UNIT	176 - 2
C2842402	DP:OUTER FRAME:F	138 - 20
C2842404	DP:INK:HOLDER:UNIT	140 - 5
C2842406	DP:DRUM:CONNECTING:CABLE UNIT	138 - 22
C2842406	DP:DRUM:CONNECTING:CABLE UNIT	176 - 9
C2842410	DP:PLATE	142 - 1
C2842411	DP:DRUM:RAIL:UNIT	142 - ②
C2842412	DP:SHAFT	142 - 3
C2842413	DP:GRIP	142 - 4
C2842414	DP:OUTER FRAME:R:ASSY	142 - ⑤
C2842650	DP:PAPER FEED:PLATE:ASSY	68 - ②
C2842650	DP:PAPER FEED:PLATE:ASSY	70 - ②
C2842651	DP:DIAL:ASSY	72 - ⑪
C2842651	DP:DIAL:ASSY	74 - ⑪
C2842652	DP:JOINT:ASSY	78 - ⑦
C2842653	DP::SEPARATOR:ASSY	82 - ③
C2842655	DP:PINION	68 - 12
C2842656	DP:SEPARATOR PLATE	70 - ②-1
C2842657	DP:COLLAR	68 - 13
C2842658	DP:COLLAR	72 - 9
C2842659	DP:PAWL	68 - 15
C2842660	DP:COIL SPRING:T	68 - 14
C2842661	DP:SCALE BOARD	70 - ②-2
C2842662	DP:RACK	68 - 5
C2842663	DP:LOCK:LEVER	68 - 6
C2842664	DP:UNDER TRAY	72 - 1
C2842665	DP:SHAFT	72 - 2
C2842666	DP:COLLAR	72 - 3
C2842667	DP:SHAFT	72 - 4

Part No.	Description	Page and Index No.
C2842668	DP:SHAFT	72 - 5
C2842669	DP:SHAFT	72 - 6
C2842670	DP:PLATE	72 - 7
C2842671	DP:SHAFT	68 - 18
C2842672	DP:KNOB	68 - 7
C2842673	DP:PLATE	68 - 9
C2842674	DP:SENSOR:ANGLE	68 - 10
C2842675	DP:COLLAR	74 - ⑪-1
C2842676	DP:DIAL	74 - ⑪-2
C2842677	DP:MOTOR:BRACKET	72 - 8
C2842678	DP:ANGLE	72 - 13
C2842679	DP:DUAL FACES TAPE	70 - ②-3
C2842680	DP:PAPER FEED:SCALE BOARD:A/B	68 - 16
C2842680	DP:PAPER FEED:SCALE BOARD:A/B	160 - 3
C2842681	DP:PAPER FEED:CABLE UNIT	68 - 17
C2842681	DP:PAPER FEED:CABLE UNIT	172 - 8
C2842682	DP:PAPER FEED:TRAY:UNIT	70 - ②-4
C2842683	DP:PLATE:UNIT	68 - 19
C2842684	DP:PLATE	68 - 8
C2842685	DP:PAPER FEED:AUXILIARY:PLATE	68 - 11
C2842686	DP:PAPER FEED:GUIDE:F	68 - 4
C2842687	DP:PAPER FEED:GUIDE:F	68 - 3
C2842688	DP:SIDE:ADJUSTMENT SCALE:ANGLE	72 - 14
C2842689	DP:SIDE:SCALE BOARD	72 - 12
C2842700	DP:RADIAL BALL BEARING	76 - 1
C2842701	DP:JOINT	76 - 17
C2842702	DP:ROLLER:CHAIN	76 - 15
C2842703	DP:ROLLER:CHAIN	76 - 16
C2842704	DP:GEAR	76 - 2
C2842706	DP:SPROCKET	76 - 5
C2842707	DP:GEAR	76 - 6
C2842708	DP:BRACKET	76 - 7
C2842709	DP:SPROCKET:SHAFT	76 - 8
C2842710	DP:RADIAL BALL BEARING:PLATE:F	76 - 9

Part No.	Description	Page and Index No.
C2842711	DP:RADIAL BALL BEARING:PLATE:R	76 - 10
C2842712	DP:GUIDE	76 - 11
C2842713	DP:COIL SPRING:T	76 - 12
C2842714	DP:SWITCH:BRACKET	76 - 13
C2842715	DP:BRACKET	76 - 14
C2842716	DP:MOTOR	76 - 3
C2842716	DP:MOTOR	92 - 3
C2842716	DP:MOTOR	166 - 1
C2842716	DP:MOTOR	166 - 2
C2842720	DP:STEEL BALL	78 - 13
C2842721	DP:SLEEVE:RADIAL BALL BEARING	78 - 18
C2842722	DP:SYNCHRONOUS BELT	78 - 20
C2842725	DP:COIL SPRING:T	78 - 24
C2842727	DP:PILLAR	78 - 23
C2842728	DP:BRACKET:UNIT	78 - 12
C2842729	DP:PAPER FEED:SHAFT	78 - 1
C2842730	DP:PAPER FEED:RING:UNIT	78 - 2
C2842731	DP:PLATE	78 - 3
C2842732	DP:STOPPER:RING	78 - 7
C2842733	DP:PULLEY:ASSY	78 - 8
C2842734	DP:SHAFT:UNIT	78 - 9
C2842735	DP:KNOB	78 - 10
C2842736	DP:STOPPER	78 - 11
C2842737	DP:FALL:SWITCH:CABLE UNIT	172 - 3
C2842738	DP:PAPER FEED:DC STEPPER MOTOR:UNIT	78 - 15
C2842738	DP:PAPER FEED:DC STEPPER MOTOR:UNIT	166 - 12
C2842739	DP:PAPER FEED PRESSURE:BRACKET	78 - 5
C2842740	DP:SENSOR:BRACKET	78 - 6
C2842741	DP:SENSOR:PLATE	78 - 4
C2842742	DP:SPRING PLATE	78 - 14
C2842743	DP:BEARING	64 - 9
C2842743	DP:BEARING	78 - 22
C2842743	DP:BEARING	84 - 11
C2842743	DP:BEARING	118 - 2

Part No.	Description	Page and Index No.
C2842750	DP:SEPARATOR BASE:UNIT	82 - 1
C2842751	DP:COIL SPRING:T	80 - 1
C2842751	DP:COIL SPRING:T	82 - 4
C2842752	DP:AUXILIARY:SEPARATOR	82 - 5
C2842753	DP:STOPPER	82 - 6
C2842754	DP:STOPPER	82 - 7
C2842755	DP:LEVER	82 - 8
C2842756	DP:SHAFT	82 - 9
C2842757	DP:KNOB	82 - 10
C2842758	DP:TURN:PLATE	82 - 12
C2842759	DP:BRACKET	82 - 13
C2842760	DP:SEPARATOR:BRACKET	82 - 14
C2842761	DP:SHAFT	82 - 15
C2842762	DP:BRACKET	82 - 16
C2842763	DP:TURN:PLATE	82 - 17
C2842764	DP:BRACKET	82 - 18
C2842765	DP:STOPPER	82 - 19
C2842767	DP:SEPARATOR:LEVER	82 - 11
C2842768	DP:Z	82 - 21
C2842768	DP:Z	116 - ⑧-2
C2842770	DP:RADIAL BALL BEARING	84 - 1
C2842771	DP:RADIAL BALL BEARING	84 - 2
C2842772	DP:PINION	84 - 4
C2842773	DP:CLUTCH SPRING	84 - 5
C2842774	DP:CLUTCH SPRING	84 - 6
C2842775	DP:T:ROLL	84 - 7
C2842776	DP:RADIAL BALL BEARING:HOLDER	84 - 8
C2842777	DP:Z	84 - 9
C2842777	DP:Z	108 - 32
C2842778	DP:WASHER	84 - 3
C2842780	DP:SLEEVE:RADIAL BALL BEARING	84 - 10
C2842781	DP:G:ROLL	84 - 12
C2842782	DP:BRACKET:F:UNIT	84 - 13
C2842783	DP:BRACKET:R:UNIT	84 - 14

Part No.	Description	Page and Index No.
C2842784	DP:SHAFT:UNIT	84 - 15
C2842785	DP:SHAFT	84 - 16
C2842786	DP:LEVER	84 - 18
C2842788	DP:CLUTCH SPRING	84 - 17
C2842790	DP:SEGMENT:ASSY	86 - 2
C2842791	DP:PILLAR	86 - 3
C2842792	DP:SHAFT	86 - 4
C2842793	DP:BRACKET	86 - 5
C2842794	DP:LEVER:UNIT:ASSY	86 - 6
C2842795	DP:COIL SPRING:T	86 - 7
C2842796	DP:HOOK	86 - 1
C2842797	DP:SEPARATOR PRESSURE:NAME PLATE:NA	82 - 20
C2842798	DP:SEPARATOR PRESSURE:NAME PLATE:CHN	82 - 20
C2842801	DP:BRACKET	88 - 4
C2842802	DP:STAY	88 - 5
C2842803	DP:GEAR	88 - 6
C2842804	DP:WASHER	88 - 7
C2842805	DP:SHAFT	88 - 8
C2842806	DP:2:GEAR	88 - 9
C2842807	DP:SHAFT	88 - 10
C2842808	DP:SEGMENT:UNIT	88 - 11
C2842809	DP:PINION:SHAFT	88 - 12
C2842810	DP:SENSOR:ANGLE	88 - 13
C2842811	DP:ENCODER:UNIT	88 - 15
C2842812	DP:PLATE	88 - 16
C2842813	DP:STAY	88 - 17
C2842814	DP:Z:COLLAR	88 - 18
C2842815	DP:BRACKET	88 - 19
C2842816	DP:COIL SPRING:T	88 - 20
C2842817	DP:SENSOR:ANGLE	88 - 14
C2842818	DP:MOTOR	88 - 3
C2842818	DP:MOTOR	166 - 4
C2842825	DP:COIL SPRING:T	84 - 20
C2842826	DP:ESCAPE LEVER:UNIT	84 - 21

Part No.	Description	Page and Index No.
C2842827	DP:CAM SHAFT	84 - 19
C2842830	DP:SENSOR PHOTO MICRO	90 - 7
C2842830	DP:SENSOR PHOTO MICRO	164 - 21
C2842831	DP:SENSOR PHOTO MICRO	90 - 9
C2842831	DP:SENSOR PHOTO MICRO	164 - 23
C2842832	DP:DUSTPROOF SHEET	90 - 3
C2842833	DP:BRACKET	90 - 4
C2842834	DP:STEPPED SCREW	90 - 5
C2842835	DP:BRACKET	90 - 6
C2842836	DP:GUIDE:A:UNIT	90 - 11
C2842837	DP:ANGLE	90 - 13
C2842838	DP:LEADING EDGE OF PAPER SENSOR :CABLE UNIT	90 - 18
C2842838	DP:LEADING EDGE OF PAPER SENSOR :CABLE UNIT	172 - 12
C2842839	DP:PHOTO:CABLE UNIT	90 - 16
C2842839	DP:PHOTO:CABLE UNIT	172 - 10
C2842840	DP:PAPER:LEADING EDGE:CABLE UNIT	90 - 17
C2842840	DP:PAPER:LEADING EDGE:CABLE UNIT	172 - 11
C2842841	DP:ANGLE	90 - 15
C2842842	DP:FEED INLET:UNIT	82 - 2
C2842842	DP:FEED INLET:UNIT	90 - 12
C2842843	DP:EXTENSION GUIDE	90 - 19
C2843050	DP:SOLENOID:ASSY	114 - ⑧
C2843050	DP:SOLENOID:ASSY	116 - ⑧
C2843051	DP:PRESS:MOTOR:UNIT	118 - ⑩
C2843053	DP:SHAFT:A3	112 - 8
C2843054	DP:LEVER:L	112 - 3
C2843055	DP:LEVER:R	112 - 4
C2843056	DP:COLLAR	112 - 5
C2843058	DP:P:ROLLER:UNIT/A3	112 - 6
C2843059	DP:BRACKET:SHAFT:UNIT	112 - ⑦
C2843060	DP:BRACKET:R:UNIT	112 - 9
C2843061	DP:BRACKET:L:UNIT	112 - 10

Part No.	Description	Page and Index No.
C2843062	DP:COIL SPRING:TO:RIGHT	112 - 11
C2843063	DP:COIL SPRING:TO:LEFT	112 - 12
C2843064	DP:SHAFT	112 - 2
C2843065	DP:ADJUSTMEN ANGLE:ASSY	112 - 15
C2843066	DP:BEARING	112 - 13
C2843071	DP:CAM SHAFT	114 - 3
C2843072	DP:ANGLE	114 - 4
C2843073	DP:PRESS:LEVER:UNIT	114 - 7
C2843074	DP:COIL SPRING:T	114 - 5
C2843075	DP:SENSOR:BRACKET	114 - 6
C2843080	DP:LEVER	116 - ⑧-3
C2843081	DP:LEVER:B	116 - ⑧-4
C2843082	DP:LEVER:C:UNIT	116 - ⑧-5
C2843083	DP:COIL SPRING:T	116 - ⑧-7
C2843084	DP:DC SOLENOID	116 - ⑧-6
C2843084	DP:DC SOLENOID	166 - 20
C2843085	DP:COIL SPRING:T	116 - ⑧-8
C2843086	DP:STOPPER:A	116 - ⑧-9
C2843087	DP:STOPPER:B	116 - ⑧-10
C2843088	DP:CANCEL LEVER:1:UNIT	116 - ⑧-11
C2843089	DP:CANCEL LEVER:2:UNIT	116 - ⑧-12
C2843090	DP:BASE:UNIT	116 - ⑧-13
C2843092	DP:SOLENOID	116 - ⑧-1
C2843092	DP:SOLENOID	166 - 21
C2843101	DP:JOINT	118 - 3
C2843102	DP:SHAFT	118 - 4
C2843103	DP:SENSOR:BRACKET	118 - 5
C2843104	DP:ENCODER	118 - 6
C2843105	DP:BASE	118 - 8
C2843106	DP:SHAFT	118 - 9
C2843107	DP:TRAPEZOIDAL SCREW:ASSY	118 - ⑩
C2843107	DP:TRAPEZOIDAL SCREW:ASSY	120 - ⑩
C2843108	DP:HOLDER	120 - ⑩-1
C2843109	DP:TRAPEZOIDAL SCREW	120 - ⑩-2

Part No.	Description	Page and Index No.
C2843110	DP:COVER	118 - 11
C2843111	DP:COIL SPRING:T	118 - 12
C2843112	DP:COIL SPRING:T	118 - 13
C2843113	DP:LIGHT SHIELDING PLATE	118 - 14
C2843114	DP:MOTOR:PLATE	118 - 15
C2843115	DP:SENSOR:BRACKET	118 - 16
C2843116	DP:PRESS:CONNECTING:CABLE UNIT	118 - 17
C2843116	DP:PRESS:CONNECTING:CABLE UNIT	172 - 13
C2843117	DP:MOTOR	118 - 7
C2843117	DP:MOTOR	166 - 18
C2843551	DP:ACTUATOR:SENSOR PHOTO MICRO	58 - 7
C2843551	DP:ACTUATOR:SENSOR PHOTO MICRO	164 - 25
C2843552	DP:ROLLER	60 - 16
C2843553	DP:LOCK:PAWL:UNIT	60 - 17
C2843554	DP:BRACKET	60 - 18
C2843556	DP:SHAFT:UNIT	60 - 20
C2843558	DP:MICRO SWITCH	60 - 21
C2843558	DP:MICRO SWITCH	162 - 5
C2843559	DP:PROTECT:STAY	58 - 8
C2843560	DP:FRAME:F	58 - 1
C2843561	DP:FRAME:R	58 - 2
C2843562	DP:FRONT:COVER	58 - 3
C2843563	DP:BRACKET	60 - 1
C2843564	DP:GUIDE PLATE	58 - 4
C2843564	DP:GUIDE PLATE	58 - 4
C2843565	DP:BRACKET	58 - 5
C2843566	DP:BRACKET	60 - 3
C2843567	DP:HINGE:STAND	60 - 4
C2843568	DP:SHAFT	60 - 5
C2843569	DP:MASTER EJECTION:COVER	60 - 6
C2843570	DP:BRACKET	60 - 7
C2843571	DP:LEVER	60 - 8
C2843572	DP:KNOB	60 - 9
C2843573	DP:SHAFT	60 - 10

Part No.	Description	Page and Index No.
C2843574	DP:TORSION SPRING	60 - 11
C2843575	DP:LIGHT SHIELDING PLATE	60 - 12
C2843576	DP:SENSOR:ANGLE	60 - 13
C2843577	DP:TORSION SPRING	60 - 14
C2843578	DP:SENSOR COVER	58 - 6
C2843579	DP:SWITCH:ANGLE	60 - 2
C2843580	DP:MASTER EJECTION:ON OFF SW:CABLE UNIT	60 - 15
C2843582	DP:BUSHING	58 - 10
C2843585	DP:Y	60 - 25
C2843587	DP:SCREW:PLATE	60 - 26
C2843590	DP:RUBBER FOOT:CK	62 - 11
C2843591	DP:SHAFT	62 - 4
C2843592	DP:TORSION SPRING	62 - 5
C2843593	DP:UPPER:COVER	62 - 1
C2843594	DP:LOCK:LEVER	62 - 2
C2843595	DP:TORSION SPRING	62 - 3
C2843596	DP:MASTER EJECTION:NAME PLATE	62 - 7
C2843596	DP:MASTER EJECTION:NAME PLATE	156 - 1
C2843598	DP:PUSH:NAME PLATE:EU:NA:AA	156 - 4
C2843600	DP:PUSH:NAME PLATE:CHN	62 - 9
C2843600	DP:PUSH:NAME PLATE:CHN	156 - 4
C2843602	DP:CAUTION:LABEL:EU:NA:AA	62 - 10
C2843602	DP:CAUTION:LABEL:EU:NA:AA	154 - 5
C2843603	DP:CAUTION:LABEL:CHN	62 - 10
C2843603	DP:CAUTION:LABEL:CHN	154 - 5
C2843610	DP:SYNCHRONOUS BELT	64 - 8
C2843611	DP:FEATHER WHEEL	64 - 16
C2843612	DP:COIL SPRING:T	64 - 13
C2843613	DP:BEARING	64 - 14
C2843614	DP:COIL SPRING:T	64 - 15
C2843615	DP:PAWL:A	64 - 17
C2843617	DP:MOTOR:PULLEY	64 - 23
C2843618	DP:RUBBER:ROLLER	64 - 6
C2843619	DP:DRIVE ROLLER	64 - 19

Part No.	Description	Page and Index No.
C2843620	DP:DRIVEN ROLLER:UNIT	64 - 21
C2843621	DP:DRAWING ROLLER	64 - 22
C2843622	DP:TENSION:ANGLE:UNIT	64 - 1
C2843623	DP:GEAR:PULLEY	64 - 2
C2843624	DP:PULLEY	64 - 3
C2843625	DP:GEAR	64 - 4
C2843626	DP:COIL SPRING:T	64 - 5
C2843627	DP:DRIVE ROLLER:UNIT	64 - 20
C2843628	DP:LIFT MOTOR	64 - 7
C2843628	DP:LIFT MOTOR	166 - 16
C2843631	DP:COIL SPRING:T	64 - 11
C2843632	DP:TENSION:RING	64 - 12
C2843636	DP:BRACKET	66 - 1
C2843637	DP:DETECTION:LEVER	66 - 2
C2843638	DP:SENSOR:ANGLE	66 - 3
C2843639	DP:MASTER EJECTION:CABLE UNIT	66 - 4
C2843639	DP:MASTER EJECTION:CABLE UNIT	176 - 8
C2843640	DP:SHEET	66 - 8
C2843641	DP:Z	66 - 5
C2843642	DP:COIL SPRING:T	66 - 6
C2843850	DP:PAPER STRIPPER:PAWL:UNI	102 - ④
C2843850	DP:PAPER STRIPPER:PAWL:UNI	104 - ④
C2843851	DP:AIR PUMP:ASSY	102 - ⑱
C2843851	DP:AIR PUMP:ASSY	104 - ⑱
C2843852	DP:PULLEY:UNIT	104 - ④-1
C2843853	DP:BEARING	102 - 2
C2843854	DP:PAPER STRIPPER:AUXILIARY:PAWL	102 - 3
C2843855	DP:PAPER STRIPPER:PAWL	104 - ④-2
C2843856	DP:LEVER	102 - 17
C2843857	DP:COIL SPRING:T	102 - 5
C2843858	DP:COIL SPRING:T	102 - 6
C2843859	DP:PIPE:B	102 - 7
C2843860	DP:PIPE:C	102 - 8
C2843861	DP:PIPE:D	102 - 9

Part No.	Description	Page and Index No.
C2843862	DP:PIPE:E	102 - 10
C2843863	DP:MANIFOLD	102 - 11
C2843864	DP:STOPPER:ASSY	102 - 12
C2843865	DP:ANGLE	102 - 15
C2843866	DP:PAPER STRIPPER:SHAFT	102 - 13
C2843867	DP:LEVER:UNIT	102 - 14
C2843868	DP:CLIP	104 - ④-3
C2843869	DP:WASHER	102 - 16
C2843870	DP:BUSHING	102 - 24
C2843880	DP:O:RING	104 - ⑱-1
C2843881	DP:CYLINDER	104 - ⑱-2
C2843882	DP:PISTON	104 - ⑱-3
C2843883	DP:CRANK	102 - 20
C2843884	DP:SHAFT	102 - 21
C2843885	DP:WASHER	102 - 22
C2843886	DP:VALVE:UNIT	104 - ⑱-4
C2843887	DP:BRACKET	104 - ⑱-5
C2843888	DP:STAY	102 - 19
C2843889	DP:LINK:UNIT	104 - ⑱-6
C2843890	DP:WASHER	102 - 23
C2843895	DP:DC:DC FAN MOTOR	106 - 2
C2843895	DP:DC:DC FAN MOTOR	166 - 5
C2843896	DP:FAN:COVER	106 - 1
C2843897	DP:TOPFAN:CONNECTING:CABLE	106 - 4
C2843898	DP:COVER	106 - 3
C2844050	DP:SYNCHRONOUS BELT	92 - 1
C2844051	DP:CLAMP:OPEN AND CLOSE:UNIT	92 - ⑰
C2844052	DP:IDLER	92 - 4
C2844053	DP:GEAR	92 - 6
C2844054	DP:TIMING PULLEY:ASSY	92 - ⑦
C2844054	DP:TIMING PULLEY:ASSY	94 - ⑦
C2844057	DP:LEVER	92 - 9
C2844058	DP:SHAFT	92 - 10
C2844059	DP:LEVER	92 - 11

Part No.	Description	Page and Index No.
C2844060	DP:CAM	92 - 12
C2844061	DP:BRACKET	92 - 13
C2844062	DP:BRACKET	92 - 14
C2844063	DP:TIMING PULLEY	92 - 15
C2844064	DP:TENSION:ANGLE:UNIT	92 - 8
C2844065	DP:SENSOR:BRACKET	92 - 5
C2844120	DP:RADIAL BALL BEARING	108 - 1
C2844120	DP:RADIAL BALL BEARING	112 - 1
C2844121	DP:SYNCHRONOUS BELT	50 - 4
C2844121	DP:SYNCHRONOUS BELT	108 - 2
C2844122	DP:REFLECTION:SENSOR	108 - 3
C2844122	DP:REFLECTION:SENSOR	164 - 20
C2844123	DP:EXIT:BELT	108 - 7
C2844124	DP:DC FAN MOTOR	108 - 6
C2844124	DP:DC FAN MOTOR	166 - 7
C2844125	DP:DRIVEN ROLLER:UNIT	108 - 8
C2844126	DP:DRIVE ROLLER:UNIT	108 - 9
C2844127	DP:PULLEY	108 - 10
C2844128	DP:BASE:PLATE	108 - 11
C2844129	DP:SENSOR:ANGLE	108 - 13
C2844130	DP:DISCHARGE:BRACKET	108 - 14
C2844131	DP:PLATE	108 - 16
C2844132	DP:EXIT:BASE	108 - 19
C2844133	DP:EXIT:CABLE UNIT	108 - 20
C2844133	DP:EXIT:CABLE UNIT	172 - 15
C2844134	DP:DC STEPPER MOTOR	108 - 21
C2844134	DP:DC STEPPER MOTOR	166 - 14
C2844135	DP:COLLAR	108 - 27
C2844136	DP:GUIDE PLATE	108 - 15
C2844137	DP:DISCHARGE BRUSH	108 - 5
C2844138	DP:EXIT:MOTOR:BASE	108 - 12
C2844139	DP:JUMP PLATE:F:ASSY	108 - ⑰
C2844140	DP:JUMP PLATE:R:ASSY	108 - ⑱
C2844141	DP:ANGLE	108 - 28

Part No.	Description	Page and Index No.
C2844142	DP:ANGLE	108 - 29
C2844150	DP:DISCHARGE BRUSH	108 - 4
C2844151	DP:DC MOTOR:ASSY	108 - 25
C2844151	DP:DC MOTOR:ASSY	166 - 6
C2844153	DP:EXIT:GUIDE	108 - 22
C2844154	DP:EXIT:COVER	108 - 23
C2844155	DP:SHEET	108 - 24
C2844156	DP:JUMP PLATE:SCALE BOARD:F:EU:AA	108 - 30
C2844157	DP:JUMP PLATE:SCALE BOARD:R:EU:AA	108 - 31
C2844158	DP:JUMP PLATE:SCALE BOARD:F:NA	108 - 30
C2844158	DP:JUMP PLATE:SCALE BOARD:F:NA	160 - 7
C2844159	DP:JUMP PLATE:SCALE BOARD:R:NA	108 - 31
C2844159	DP:JUMP PLATE:SCALE BOARD:R:NA	160 - 8
C2844250	DP:PAPER TRAY:ASSY	110 - ①
C2844252	DP:SET LINE:NAME PLATE:B:EU:NA:AA	110 - 12
C2844253	DP:PAPER TRAY:BASE	110 - 13
C2844254	DP:PROTECT:ANGLE:F	110 - 14
C2844255	DP:PROTECT:ANGLE:R	110 - 15
C2844256	DP:SHAFT	110 - 16
C2844257	DP:GUIDE:SCALE BOARD:F:EU:AA:CHA	160 - 4
C2844258	DP:GUIDE:SCALE BOARD:R:EU:AA:CHA	160 - 5
C2844259	DP:PAPER TRAY:STOPPER:SCALE BOARD:EU:AA:CHA	160 - 6
C2844260	DP:SET LINE:NAME PLATE:A:EU:NA:AA	158 - 5
C2844261	DP:SET LINE:NAME PLATE:A/CHN	110 - 34
C2844261	DP:SET LINE:NAME PLATE:A/CHN	158 - 5
C2844262	DP:SET LINE:NAME PLATE:B/CHN	110 - 12
C2844263	DP:GUIDE:SCALE BOARD:F/INCH:NA	110 - 31
C2844263	DP:GUIDE:SCALE BOARD:F/INCH:NA	160 - 4
C2844264	DP:GUIDE:SCALE BOARD:R/INCH:NA	110 - 32
C2844264	DP:GUIDE:SCALE BOARD:R/INCH:NA	160 - 5
C2844265	DP:TEFLON TAPE	110 - 4
C2844266	DP:TEFLON TAPE	110 - 6
C2844267	DP:GUIDE PIN	110 - 8

Part No.	Description	Page and Index No.
C2844268	DP:KNOB	110 - 10
C2844269	DP:SHEET	110 - 11
C2844270	DP:SIDE FENCE:F	110 - 17
C2844271	DP:SUPPORTER	110 - 18
C2844272	DP:SLIDE:BRACKET	110 - 19
C2844273	DP:SPRING PLATE	110 - 20
C2844274	DP:PROTECT:PLATE	110 - 21
C2844275	DP:TAPE	110 - 22
C2844277	DP:PAPER TRAY:STOPPER:SCALE BOARD:NA	110 - 33
C2844277	DP:PAPER TRAY:STOPPER:SCALE BOARD:NA	160 - 6
C2844290	DP:SIDE FENCE:R	110 - 23
C2844300	DP:TEFLON TAPE	110 - 3
C2844301	DP:TEFLON TAPE	110 - 5
C2844302	DP:STOPPER:PIN	110 - 7
C2844303	DP:SPONGE	110 - 9
C2844305	DP:BASE:STOPPER	110 - 24
C2844306	DP:MOVEABLE:STOPPER	110 - 25
C2844307	DP:SUPPORTER	110 - 26
C2844308	DP:PLATE	110 - 27
C2844309	DP:SLIDE:BRACKET:ASSY	110 - 28
C2844310	DP:SPRING PLATE	110 - 29
C2844311	DP:SPONGE	110 - 30
C2844320	DP:PLATE	60 - 28
C2844321	DP:STOPPER	110 - 35
C2844322	DP:BRACKET:F	110 - 36
C2844323	DP:BRACKET:R	110 - 37
C2844325	DP:LOCK:SHAFT	2 - 22
C2844326	DP:LEVER:ASSY	2 - 23
C2845050	DP:ANGLE	146 - 1
C2845051	DP:HEAT SINKER:DRIVE	146 - 4
C2845052	DP:INLET:BRACKET	146 - 7
C2845053	DP:OP:CONNECTOR:BRACKET	146 - 8
C2845054	DP:USB:INSTALL:BRACKET	146 - 10
C2845055	DP:MOTOR:BASE:COVER	146 - 14

