

Titanium-3.5 / Titanium-D3.6 (C274)

PARTS CATALOG


This catalog gives the numbers and names of parts on this machine.

CONTENTS

Location of Unit	2
1. Exterior (C274).....	6
2. Operation Panel(C274).....	8
3. Scanner Section (C274).....	10
4. Paper Table (C274).....	12
5. Paper Registration (C274).....	14
6. Paper Feed Section (C274)	16
7. Plotter Unit 1 (C274).....	18
8. Plotter Unit 2 (C274).....	20
9. Press Roller Section (C274).....	22
10. Drum Unit 1 (C274)	24
11. Drum Unit 2 (C274)	26
12. Drum Unit 3 (C274)	28
13. Vacuum Fan Unit (C274)	30
14. Delivery Table (C274)	32
15. Master Eject Unit (C274)	34
16. Electrical And Drive Section (C274)	36
17. Drive And Frame Section (C274).....	38
18. Frame Section (C274)	40
Parts Index	42


LOCATIONS OF UNITS

1. Exterior (C274)




See Page 6

2. Operation Panel (C274)




See Page 8

3. Scanner Section (C274)




See Page 10

4. Paper Table (C274)




See Page 12

5. Paper Registration (C274)



See Page 14


6. Paper Feed Section (C274)



See Page 16


LOCATIONS OF UNITS

7. Plotter Unit 1 (C274)




See Page 18

8. Plotter Unit 2 (C274)




See Page 20

9. Press Roller Section (C274)




See Page 22

10. Drum Unit 1 (C274)




See Page 24

11. Drum Unit 2 (C274)



See Page 26


12. Drum Unit 3 (C274)



See Page 28


LOCATIONS OF UNITS

13. Vacuum Fan Unit (C274)




See Page 30

14. Delivery Table (C274)




See Page 32

15. Master Eject Unit (C274)




See Page 34

16. Electrical And Drive Section (C274)




See Page 36

17. Drive And Frame Section (C274)




See Page 38

18. Frame Section (C274)



See Page 40

1.Exterior (C274)




1.Exterior (C274)

Index No.	Part No.	Description	Q'ty Per Assembly
1	H545 4315	Document Tray Extension	1
2	H535 4201	Document Tray	1
3	H545 4311	Document Table - 1	1
4	2803 0006	Cord Binder	1
5	C252 1734	Side Fence:Original	2
6	C261 1737	Decal:Original Insert:ABS	1
7	C261 1364	Decal:Paper Feed Pressure:ABS (CHN)	1
8	C274 1731	Cover:Fix:Image Reading Unit	1
9	C252 1732	Rack:Original:Guide	2
10	C252 1735	Gear:Original:Guide	1
11	C274 1306	Cover:Rear	1
12	C279 1342	Decal:Passing Certificate	1
13	C252 1325	Spring Washer:6.4x11x1.5	1
14	C612 1800	Screw:Lens:Guide	1
15	C274 1304	Cover:Plotter	1
16	AG07 0504	Magnet Catch:44.1N	1
17	C261 1322	Guide:Rear:Cover:Plotter	1
18	AA13 2169	Spacer - 5.7x16x1.5	1
19	C274 1302	Cover:Front	1
20	C261 1362	Decal:Separation Change:ABS	1
21	C274 1345	Sheet:Emblem:RIC:CHN (for DX2432C)	1
21	C274 1341	Sheet:Emblem:RIC:AA (for DX2430 NA/AA/KOR)	1
21	C274 1355	Sheet:Emblem:GES:CHN (for CP6202C)	1
21	C274 1350	Sheet:Emblem:GES:AA (for DX2430 NA/AA/KOR)	1
21	C274 1342	Sheet:Emblem:RIC:LA (for 100V/LG)	1
21	C274 1346	Sheet:Emblem:RIC (for DD2433c)	1
21	C274 1357	Sheet:Emblem:GES (for CP6203c)	1
22	C274 1313	Hinge:Door:Upper:Peen	1
23	C261 1361	Decal:Caution:ABS	1
24	C274 1311	Hinge:Door:Lower:Peen	1
25	C274 1300	Cover:Door	1
26	AG07 0514	Magnet Catch	1
27	C261 1365	Decal:Main Switch:ABS (CHN)	1
28	B132 1531	Panel:Logo	1
29	C261 1366	Decal:WEEE:TRF:ABS (EU)	1

Index No.	Part No.	Description	Q'ty Per Assembly
30	C274 8610	Wall Chart:A3:AA (for DX2430 NA/AA/KOR)	1
30	C274 8677	Wall Chart:A3:LA (for 100V/LG)	1
30	C274 8678	Wall Chart:A3 (CHN)	1
31	C274 8615	Operating Instructions:CHN:RIC (DX2432C)	1
31	C274 8616	Operating Instructions:CHN:GES (CP6202C)	1
31	C274 8617	Operating Instructions:AA (for DX2430 NA/AA/KOR)	1
31	C274 8628	Operating Instructions:LA (for DX2330 NA/LDD745)	1
32	C252 8616	Installation Roller And Pad-ENG (for DX2330 NA/LDD745, DX2430 NA/AA/KOR)	1
32	C252 8618	Installation Roller And Pad (CHN)	1
101	0451 4008N	Tapping Screw:4x8	
102	0450 3006N	Tapping Screw - M3x6	
103	0450 3008N	Tapping Screw - M3x8	
104	0452 3008N	Tapping Screw - M3x8	
105	0450 4010N	Tapping Screw:M4x10	
106	0353 0060N	Bind Screw - M3x6	

2.Operation Panel (C274)




2.Operation Panel (C274)

Index No.	Part No.	Description	Q'ty Per Assembly
*	C274 1455	Operation Panel:English:MM:Ass'y (for DX2430 NA/AA/KOR)	1
*	C274 1456	Operation Panel:English:Inch:Ass'y (for 100V/LG)	1
*	C274 1457	Operation Panel:Chinese:Ass'y (for DX2432C/CP6202C)	1
*	C274 1458	Operation Panel:EU:Ass'y (for DX2330 EU/DX2430 EU)	1
*	C274 1459	Operation Panel:Chinese:Ass'y (for DD2433c/CP6203c)	1
1	C274 1481	Seal:Paper Jam:English:MM (for 100V/LG)	1
1	C274 1480	Seal:Paper Jam:English:Inch (for DX2430 NA/AA/KOR)	1
1	C274 1482	Seal:Paper Jam:Chinese (for DX2432C / CP6202C)	1
1	C274 1483	Seal:Paper Jam:EU:RI (for DX2330 EU/DX2430 EU)	1
1	C274 1484	Seal:Paper Jam:Chinese (for DD2433c/CP6203c)	1
2	C252 1486	Shield:Start:English (for 100V, 200V/LG)	1
2	C252 1487	Shield:Start: (CHN)	1
2	C252 1495	Shield:Start:EU:R1 (EU)	1
3	C252 1484	Shield:On Line:English (for DX2330 NA/LDD745, DX2430 NA/AA/KOR)	1
3	C252 1485	Shield:On Line: (CHN)	1
3	C252 1494	Shield:On Line:EU:R1 (EU)	1
4	C274 1460	Case:Operation Panel	1
5	C252 1477	Keytop:Contenance	1
6	C274 1472	Keytop:Try Print	1
7	C274 1473	Keytop:Start	1
8	C274 1474	Keytop:Start	1
9	C274 1471	Keytop:Clear	1
10	C274 1470	Keytop:10key	1
11	C252 1475	Keytop:On Line	1
12	C252 1476	Keytop:Clear Modes	1
13	C252 1491	Bracket:Operation Sub-unit	2
14	C252 1492	Lens:LED	1
15	C274 5160	PCB:Operation Sub-unit:Ass'y	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0452 3008N	Tapping Screw - M3x8	

3.Scanner Section (C274)




3.Operation Panel (C274)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C274 1733	Cover:Open And Close	1
2	C261 1738	Decal:Scale:ABS	1
3	C252 1721	Guide Plate:Fix:Ass'y	1
4	C274 1739	Contact Image Sensor:Image Reading Unit:Ass'y	1
5	C261 1706	Exit Roller:Fix:Image Reading Unit	1
6	C261 1702	Transport Roller:Fix:Image Reading Unit	1
7	C261 5280	Harness:CIS:Ass'y	1
8	C261 1696	Stay:Fix:Image Reading Unit	1
9	C261 1670	Side Plate:Fix:Front:Ass'y	1
10	C261 1804	Bracket:Grip:Open And Close	1
11	C252 2783	Knob:Lever:Pressure:Paper Feed Tray	1
12	C252 1785	Spring Plate:Pressure:Paper Feed Roller	4
13	C261 1806	Tension Spring:Grip:Open And Close	1
14	C261 1803	Hook:Open And Close:Rear	1
15	C261 1757	Pressure Plate:Shading:Ass'y	1
16	C261 1660	Frame:Open And Close	1
17	C252 1784	Spacer:Roller:Open And Close	4
18	C261 1792	Exit Roller:Open And Close	1
19	C261 1766	Guide Plate:Open And Close:Image Reading Unit:Right	1
20	C261 1767	Guide Plate:Open And Close:Image Reading Unit:Left	1
21	AW01 0107	Paper Feed Sensor	1
22	C261 5281	Harness:Original Sensor:Ass'y	1
23	C261 1802	Hook:Open And Close:Front	1
24	C252 1712	Gear:Transport Roller:Image Reading Unit	2
25	C252 1711	Gear:Idler:2:Image Reading Unit	1
26	C252 2133	Gear:Idler:1:Platen	1
27	C252 2134	Gear:Idler:Stepper Motor	1
28	C261 1680	Side Plate:Fix:Rear:Ass'y	1
29	C259 5821	Stepper Motor:DIA42:Plotter:Ass'y	1
30	C261 1801	Shaft:Grip:Open And Close	1
31	C252 1753	Screw:M3x8	1
32	C261 1762	Compression Spring:Pressure Plate	2
33	C261 1782	Paper Feed Roller:Open And Close	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0353 0060N	Bind Screw - M3x6	
103	0720 0030E	Retaining Ring - M3	
104	0720 0040E	Retaining Ring - M4	
105	0720 0030E	Retaining Ring - 3M	
106	0451 3008N	Tapping Screw M3x8	
107	0805 3480	Bushing - 6mm	
108	0353 0060N	Bind Screw - M3x6	
109	1105 0522	Edge Saddle - LES0510	
110	1105 0511	Harness Clamp - LWS-0306ZC	
111	1105 0516	Clamp	
112	1105 0488	Harness Clamp	
113	0622 0100E	Spring Pin - 2x10mm	

4.Paper Table (C274)




4.Paper Table (C274)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C261 2786	Lever:Paper Feed Pressure:Peen	1
2	C252 2778	Collar:Start:Pressure:Paper Feed Tray	2
3	C261 1062	Shaft:Arm:Paper Feed:Ass'y	3
4	C261 1551	Bracket:Plate:Panel	1
5	C267 2934	Knob:Lever	1
6	C261 2790	Arm:Change:Paper Feed Pressure	1
7	C261 2791	Spring:Pressure:Paper Feed Tray	1
8	C261 2779	Lever:Pressure:Paper Feed Tray:Peen	1
9	C261 2775	Arm:Pressure:Paper Feed Tray	1
10	C261 2782	Lever:Pressure:Paper Feed Tray	1
11	C252 2783	Knob:Lever:Pressure:Paper Feed Tray	1
12	C261 2767	Pad:Plate:Paper:Ass'y	2
13	C261 2760	Side Fence:Paper Feed:Ass'y	2
14	C252 2765	Lever:Lock:Side Fence	2
15	C261 2757	Base:Paper Feed Tray:Ass'y	1
16	C261 2766	Guide:Side Fence	2
17	C261 2750	Paper Feed Tray:Ass'y	1
18	C252 2752	Paper Feed Tray	1
19	C261 5220	Ground Wire:Paper Feed Tray:Ass'y	1
20	C261 4350	Stepped Screw - M6	2
21	C261 2753	Bracket:Paper Feed Tray:Right	1
22	C261 2754	Bracket:Paper Feed Tray:Left	1
23	C261 2771	Shaft:Pressure:Paper Feed Tray	1
24	C261 2773	Bracket:Pressure:Paper Feed Tray	1
25	C267 3452	Roller:Rail:Drum	2
26	C261 2774	Shaft:Bracket:Pressure:Paper Feed Tray	1
27	C252 1080	Bushing	2
28	C229 2840	Pad	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0040E	Retaining Ring - M4	
102	0720 0060E	Retaining Ring - M6	
103	0720 0080E	Retaining Ring - M8	
104	0720 0030E	Retaining Ring - M3	
105	0451 4006N	Tapping Screw - 4x6	
106	0450 4008N	Tapping Screw 4x8	
107	0354 0080N	Screw:M4x8	
108	0450 4010N	Tapping Screw:M4x10	

5.Paper Registration (C274)




5.Paper Registration (C274)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C261 2900	Stay:Harness:Sensor:Ass'y	1
2	C261 1055	Stay:Machine	1
3	C252 1080	Bushing	2
4	C252 2810	Grip Rings:MM8	2
5	5606 2066	Paper Feed Guide Disc	2
6	C252 2802	Roller:Paper Feed:Ass'y	1
7	C261 2808	Shaft:Paper Feed Roller	1
8	C261 2844	Stepped Screw	2
9	C252 2806	Shaft:Drive:Paper Feed Roller:Ass'y	1
10	C252 2820	Separation Pad:Ass'y	1
11	C261 2832	Compression Spring:Separation Pad	1
12	C261 2831	Holder:Spring:Separation	1
13	C261 2827	Adjusting Pin:Separation Sub-unit	1
14	C261 2835	Adjusting Pin	1
15	C261 2824	Drum Stay:Paper Feed:Ass'y	1
16	C261 2838	Washer:Adjusting Pin	1
17	C267 3452	Roller:Rail:Drum	1
18	AA14 3791	Screw:Safety	2
19	C252 2839	Slider:Separation Sub-unit	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1105 0522	Edge Saddle - LES0510	
102	1105 0511	Harness Clamp - LWS-0306ZC	
103	0720 0070E	Retaining Ring - M7	
104	0720 0050E	Retaining Ring - M5	
105	0720 0080E	Retaining Ring - M8	
106	0451 3006N	Tapping Screw - 3x6	
107	0451 4008N	Tapping Screw:4x8	
108	0450 3006N	Tapping Screw - M3x6	
109	0720 0040E	Retaining Ring - M4	
110	0314 0080N	Philips Pan Head Screw - M4x8	

6. Paper Feed Section (C274)




6.Paper Feed Section (C274)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C261 1056	Shaft:Stay:Machine Or Copier	1
2	C261 2881	Feed Roller:Lower	1
3	C252 2873	Feed Roller:Upper:Sub-ass'y	1
4	C252 2878	Spring:Pressure:Feed Roller	1
5	C261 2875	Arm:Pressure:Feed Roller:Ass'y	1
6	C275 2895	Arm:Feed Roller:Upper	2
7	C264 2898	Upper Registration Shaft1	1
8	C231 2766	Slider:Housing	1
9	C261 2872	Shaft:Swivel:Feed Roller:Upper	1
10	C272 2855	Sensor Cleaning Lever (CHN)	1
11	C238 2921	Registration Sensor Bracket	1
12	C261 5270	Harness:Connecting:Sensor:Ass'y	1
13	C257 5807	Photo Refiection Sensor:GP2A25	1
14	C261 2844	Screw:Separation Unit (CHN)	1
15	C238 2853	Sensor Cleaning Spring (CHN)	1
16	C238 2856	Sensor Cleaning Brush (CHN)	1
17	C261 2870	Bracket:Guide Plate:Rear	1
18	C261 2891	Guide Plate:Feed Roller:Ass'y	1
19	C261 2869	Bracket:Guide Plate:Front	1
20	C261 5252	Harness:Connecting:Drum:Ass'y	1
21	C244 2633	Stepped Screw	2
22	C261 2611	Bracket:Receptacle	1
23	C267 2267	Bearing Case:Transmission	2
24	C274 2948	Timing Belt - 140-XL-050	1
25	C229 2907	Registration Roller Pulley - 14Z	1
26	C252 1080	Bushing	2
27	C261 1996	Stay:Front:Main Ass'y:Plotter	1
28	C261 1995	Stay:Inner Back:Main Ass'y:Plotter	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0451 4006N	Tapping Screw - 4x6	
103	0451 4008N	Tapping Screw:4x8	
104	0740 3008	Ball Bearing - 8x22x7	
105	0454 4008Q	Tapping Screw - M4x8	
106	0594 0080E	Bolt - M4x8	
107	0453 3006N	Tapping Screw - M3x6	
108	0720 0040E	Retaining Ring - M4	
109	0720 0080E	Retaining Ring - M8	
110	0701 0060N	Washer DIA6	
111	0701 0040N	Washer:DIA4	
112	1105 0487	Harness Clamp	
113	1105 0511	Harness Clamp - LWS-0306ZC	
114	0741 3706	Ball Bearing - 6x10x3	
115	0574 0050E	Hexagon Headless Set Screw - M4x5	
116	1105 0518	Edge Saddle - LES-1010	

7.Plotter Unit 1 (C274)




7. Plotter Unit 1 (C274)

Index No.	Part No.	Description	Q'ty Per Assembly
*	C274 1910	Plotter:Uni:B4 (for 200V/B4)	1
*	C274 1911	Plotter:Uni:Legal (for 100V, 200V/LG)	1
1	C252 2281	Discharge Brush:Cutter	1
2	C252 1972	Decal:Open And Close:Plotter:Left	1
3	C252 1971	Decal:Open And Close:Plotter:Left	1
4	C261 2045	Cover:Open And Close:Plotter	1
5	C261 2046	Guide Plate	1
6	C261 2114	Roller:Tension:B4 (for 200V/B4)	1
6	C261 2115	Roller:Tension:LG (for 100V, 200V/LG)	1
7	H012 1181	Bushing- 6mm	2
8	C261 2030	Rear Plate:Open And Close	1
9	C231 2148	Tension Roller Gear	1
10	C231 2147	Idler Gear	1
11	C252 2142	Gear:Platen	1
12	C238 2106	Ball Bearing - 6x13x5mm	2
13	C261 2039	Spring:Lever:Lock:Plotter	2
14	C238 2037	Lever Knob	1
15	C261 2036	Lever:Open And Close:Plotter	1
16	C261 2040	Front Plate:Open And Close	1
17	C261 2108	Cover:Open And Close:Lower	1
18	C261 2271	Cutter Unit:B4:Ass'y	1
19	C261 2220	Holder:Master:Front	1
20	C261 1955	Stay:Coupling:Plotter	1
21	C252 1950	Positioning Pin:Coupling:Plotter:Ass'y	1
22	C261 2210	Holder:Master:Rear	1
23	C274 1305	Cover:Right	1
24	C274 1330	Decal:Master Set Instructions:ABS	1
25	C274 2248	Flange:Master:35.5/20	2
26	C261 1961	Spring:Open And Close:Rear:Plotter	1
27	C217 5102	Spring Washer	1
28	C261 2104	Platen:B4 (for 200V/B4)	1
28	C261 2105	Platen:A4 (for 100V, 200V/LG)	1
29	C238 1962	Front Spring	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0720 0040E	Retaining Ring - M4	
103	0574 0040E	Hexagon Headless Set Screw - M4x4	
104	0451 3006N	Tapping Screw - M3x6	
105	0451 3008N	Tapping Screw M3x8	
106	0450 3008N	Philips Tapping Screw - M3x8	
107	0451 4008N	Tapping Screw:4x8	

8. Plotter Unit 2 (C274)




8.Plotter Unit 2 (C274)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C252 2085	Guide Plate:Brake:Upper:Plotter	1
2	C252 2082	Guide Plate:Brake:Lower:Plotter:Sub-ass'y	1
3	C252 2281	Discharge Brush:Cutter	1
4	C261 2077	Roller:Brake:Plotter	1
5	C261 2063	Lever:Roller:Brake	2
6	C267 2078	Bracket Shoe:Roller:Brake:Plotter	1
7	C274 2057	Display Sub-unit:Leading Edge:Master:Printing	1
8	C261 2052	Positioning Plate:Master	1
9	C261 2065	Spring:Roller:Brake:Plotter	2
10	C261 2054	Spring:Positioning Plate:Master	1
11	C261 2151	Thermal Head:B4	1
12	C261 5240	Harness:Imaging Unit:Ass'y	1
13	C252 2157	Spring:Thermal Head:Both Ends	4
14	C261 2156	Spring:Thermal Head:Middle	1
15	C261 2026	Base:Thermal Head	1
16	C274 2020	Side Plate:Fix:Front:Plotter:Ass'y	1
17	C257 5854	Master Duct Sensor	1
18	C261 2279	Bracket:Sensor:Master	1
19	C252 2092	Guide Plate:Thermal Head:Ass'y	1
20	C261 2095	Guide Plate:Master	1
21	C261 2025	Base:Fix:Plotter	1
22	C261 5241	Harness:Stepper Motor:Ass'y	1
23	C259 5821	Stepper Motor:DIA42:Plotter:Ass'y	1
24	C261 2010	Side Plate:Fix:Rear:Plotter:Ass'y	1
25	C231 2135	Platen Gear - 2	1
26	C252 2133	Gear:Idler:1:Platen	1
27	C252 2134	Gear:Idler:Stepper Motor	1
28	C261 2273	Bracket:On Off Detector:Plotter	1
29	AW02 0224	Photointerruptor	1
30	C249 2230	Brake Shoe	2
31	C231 2234	Brake Pad	1
32	C282 1331	Decal:Master Set Instructions:Stopper Guide	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0353 0060N	Bind Screw - M3x6	
103	0454 3006Q	Tapping Screw - M3x6	
104	0720 0030E	Retaining Ring - M3	
105	0720 0040E	Retaining Ring - M4	
106	1105 0488	Harness Clamp	
107	1105 0511	Harness Clamp - LWS-0306ZC	
108	0352 0080P	Screw M2x8	
109	1106 0851	Bush:NJ-16	

9.Press Roller Section (C274)




9.Press Roller Section (C274)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C261 1551	Bracket:Plate:Panel	1
2	C261 4481	Arm:Drive:Pickoff Pawl	1
3	C252 4365	Pickoff Pawl:Exit	1
4	C261 4482	Shaft:Pickoff Pawl	1
5	C238 4493	Exit Pawl Drive Arm 2	1
6	C261 4485	Bracket:Roller:Pressure Release	1
7	C229 2615	Slide Rail Roller	2
8	C261 2601	Stay:Drum:Machine Or Copier:Ass'y	1
9	AW02 0224	Photointerruptor	1
10	C261 5611	Bracket:Sensor:Paper Feed Control	1
11	C261 3123	Anchor:Spring:Pressure:Right:Ass'y	1
12	C261 3134	DC Solenoid:Right:Ass'y	1
13	C238 3126	Pressure Spring Screw	2
14	C252 3140	Spring:Pressure:B4 (for 200V/B4)	2
14	C261 3141	Spring:Pressure:A4 (for 100V, 200V/LG)	2
15	C261 3103	Side Plate:Pressure:Right:Ass'y	1
16	C261 3050	Pressure Roller:B4:Ass'y (for 200V/B4)	1
16	C261 3052	Pressure Roller:Legal:Ass'y (for 100V, 200V/LG)	1
17	C261 3113	Arm:Pressure Roller:Right:Ass'y	1
18	C252 1080	Bushing	4
19	C261 3117	Stopper:Pressure Roller	1
20	C261 3116	Bracket:Stopper:Pressure Roller	1
21	C261 3110	Arm:Pressure Roller:Left:Ass'y	1
22	5506 6111	Stepped Screw - M4	1
23	C261 2605	Positioning Pin:Drum:Ass'y	2
24	C261 3100	Side Plate:Pressure:Left:Ass'y	1
25	C261 3130	DC Solenoid:Left:Ass'y	1
26	C261 3137	Spring:Pressure Release	2
27	C261 3120	Anchor:Spring:Pressure:Left:Ass'y	1
28	C261 4349	Spring:Arm:Pickoff Pawl	1
29	C275 5685	Bracket:On Off Detector:Door	1
30	C267 4479	Bushing:Pickoff Pawl	1
31	C267 2172	Lever:Safety Switch	1
32	C261 5686	Screw:Round Point:Safety Switch	1
33	C267 2176	Spring Plate:Safety Switch	1

Index No.	Part No.	Description	Q'ty Per Assembly
34	C261 3165	Arm:Pressure Release:Right:Ass'y	1
35	AX31 0049	Total Counter:7Fig:24V	2
36	C238 3127	Pressure Spring Nut	2
37	C261 3131	Bracket:Pressure Release:Left	1
38	C261 3160	Arm:Pressure Release:Left:Ass'y	1
39	C261 3135	Bracket:Pressure Release:Right	1
101	0593 0080E	Bolt - M3x8	
102	0584 0121N	Hexagonal Head Bolt:M4x12	
103	0710 0040N	Hexagonal Nut:M4	
104	0701 0030N	Washer DIA3	
105	0454 4008Q	Tapping Screw - M4x8	
106	0951 3014N	Screw Polished Round M3x14	
107	0353 0060N	Bind Screw - M3x6	
108	0451 3006N	Tapping Screw - 3x6	
109	0451 4006N	Tapping Screw - 4x6	
110	0720 0060E	Retaining Ring - M6	
111	0720 0040E	Retaining Ring - M4	
112	0720 0080E	Retaining Ring - M8	
113	1105 0522	Edge Saddle - LES0510	
114	1204 2497	Micro Switch	
115	0354 0040N	Screw-M4x4	
116	0593 0040E	Hexagonal Set Screw:M3x4	
117	1105 0487	Harness Clamp	
118	0622 0140E	Spring Hole Pin - 2x14mm	
119	0451 4008N	Tapping Screw:4x8	

10.Drum Unit 1 (C274)




10.Drum Unit 1 (C274)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C261 2552	Screw:Slider	2
2	C267 2537	Housing:Ass'y (for 200V/B4)	1
2	C267 2538	Housing:Legal:Ass'y (for 100V, 200V/LG)	1
3	C261 2561	Guide:Slider:Left	1
4	C267 2641	Slider:Holder:Ink Cartridge:WLD	1
5	C261 2629	Guide:Slider:Right:Option	1
6	C252 2559	Spring:Pressure:Ink Cartridge	1
7	C261 2553	Rail:Holder:Left	1
8	C261 2554	Rail:Holder:Right	1
9	C267 2571	Shield:Holder:Ink Cartridge	1
10	C261 2531	Arm:Grip:Right	1
11	C261 2556	Lever:Release:Holder:Ass'y	1
12	C261 2560	Spring:Lever:Release	1
13	C261 2535	Shaft:Contact Point:Arm:Drum	1
14	C261 2530	Arm:Grip:Left	1
15	C271 2321	Holder:Ink Cartridge:CHN:Ass'y	1
16	C252 2534	Grip:Drum:Lower	1
17	C267 2574	Slider:Housing	1
18	C261 2543	Cover:Harness:Drum	1
19	C261 2533	Screw:Arm:Drum	1
20	C238 2489	Rubber Bushing Plate	3
21	C261 2538	Bracket:Housing:Drum	1
22	C271 2550	Holder:Ink Cartridge:CHN	1
23	C238 2573	Stepped Screw	1
24	C267 3452	Roller:Rail:Drum	2
25	C267 2396	Spring Plate:Stopper	1
26	C238 2585	Screw MM6x1.7	3
27	C261 2567	Stay:Coupling:Grip	1
28	C267 2395	Bracket:Stopper:Drum	1
29	C282 2504	Frame:Upper:Drum:Ass'y (for 200V/LG/B4)	1
30	C267 2525	Stay:Grip:Drum:Right	1
31	C267 2524	Stay:Grip:Drum:Left	1
32	C252 2526	Grip:Drum:Upper	1
33	C267 2394	Spring Plate:Grip:Drum	1
34	C612 1801	Screw:M4x8	4

Index No.	Part No.	Description	Q'ty Per Assembly
35	C282 5257	Harness:Drum:Connecting:B4:Ass'y (for 200V/B4)	1
35	C282 5259	Harness:Drum:Connecting:Legal:Ass'y (for 100V, 200V/LG)	1
36	C282 2524	Decal:Pull Out:Drum	1
37	C229 5826	Plug Housing 22	1
101	0720 0060E	Retaining Ring - M6	
102	0354 0040Z	Screw - M4x4	
103	0720 0040E	Retaining Ring - M4	
104	0353 0050Z	Philips Truss Head Screw - M3x5	
105	0807 5049	Wave Washer - 8 mm	
106	0594 0060Z	Hexagon Socket Bolt - M4x6	
107	0450 4006N	Tapping Screw:4x6	
108	0954 4006Z	Screw - M4x6	
109	0353 0080Z	Philips Truss Head Screw - M3x8	

11.Drum Unit 2 (C274)




11.Drum Unit 2 (C274)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C261 2401	Clamp:Ass'y	1
2	C231 2417	Master Exit Pawls	1
3	C261 2402	Base:Clamp:Drum:Ass'y	1
4	C261 2520	Side Plate:Drum:Left	1
5	C261 2406	Shaft:Clamp:Drum	1
6	C238 2410	Clamper Rear Spring	1
7	C261 2405	Plate:Clamp	1
8	C267 2360	Flange:Drum:B4:Left:Ass'y	1
9	C252 2370	Spacer:Drum Shaft:Right (for 100V, 200V/LG)	1
10	C267 2362	Flange:Drum:B4:Right:Ass'y	1
11	C238 2368	Drum Drive Gear	1
12	C252 2396	Wedge:Plate:Thrust	1
13	C252 2395	Plate:Thrust:Drum	1
14	C261 2521	Side Plate:Drum:Right	1
15	C261 2368	Shielding Plate:Drum	1
16	C252 2340	Screen:B4:Ass'y (for 200V/B4)	1
16	C252 2341	Screen:Legal:Ass'y (for 100V, 200V/LG)	1
17	C261 2388	Stay:Screen:Front:B4 (for 200V/B4)	1
17	C261 2390	Stay:Screen:Front:A4 (for 100V, 200V/LG)	1
18	C261 2389	Stay:Screen:Rear:B4 (for 200V/B4)	1
18	C261 2391	Stay:Screen:Rear:A4 (for 100V, 200V/LG)	1
19	C267 2390	Sheet:Sensor:Drum	1
20	C252 2590	Metal Screen - B4 (for 200V/B4)	1
20	C252 2593	Metal Screen - Legal (for 100V, 200V/LG)	1
21	C238 2413	Sheet:Sensor:Trailing Edge:Screen	1
22	C238 2572	Stopper Spring	1
23	C267 2572	Stopper:Turn	1
24	C267 2570	Bracket:Stopper:Turn	1
25	C252 2410	Torsion Spring:Pawl:Master Ejection:Master	1
26	C238 2585	Screw MM6x1.7	2
27	C217 4581	Ink Roller Drive Gear	1
28	C231 2565	Ink Cartridge Joint	1
29	C261 2558	Base:Lever:Release	1
30	C238 2412	Clamper Cam	1
31	C252 2413	Friction Pad:Screen:Small (for 200V/B4)	1

Index No.	Part No.	Description	Q'ty Per Assembly
32	C252 2412	Friction Pad:Screen:B4 (for 200V/B4)	1
32	C252 2414	Friction Pad:Screen:LG (for 100V, 200V/LG)	1
33	C267 2424	Filter:Pump:Ink	1
101	0720 0020E	Retaining Ring - M2	
102	1105 0511	Harness Clamp - LWS-0306ZC	
103	0592 0040E	Hexagonal Set Screw:M2x4	
104	0354 0040Z	Screw - M4x4	
105	0450 3008Z	Tapping Screw - M3x8	
106	0452 3006N	Binding Self-Tapping Screw:3x6	
107	0593 0100Z	Bolt M3x10	
108	0593 0060Z	Hexagon Bolt - M3x6	
109	0807 7114	Washer - 16x24x0.3mm	
110	0804 6091	Hexagonal Set Screw - M2x5	
111	0808 0021	Rubber Ring	
112	0354 0060Z	Philips Truss Head Screw - M4x6	
113	1105 0522	Edge Saddle - LES0510	
114	0951 3006Z	Philips Screw With Flat Washer - M3	
115	0951 3008Z	Philips Screw With Flat Washer - M3	
116	0594 0080Z	Bolt - M4x8	

12.Drum Unit 3 (C274)




12.Drum Unit 3 (C274)

Index No.	Part No.	Description	Q'ty Per Assembly
*	C267 2312	Roller:Ink:B4:Ass'y (for 200V/B4)	1
1	C267 2428	Pump Unit:Ink:Ass'y (for 200VB4)	1
1	C267 2429	Pump Unit:Ink:A4:Ass'y (for 100V, 200V/LG)	1
2	C252 2476	Side Plate:Roller:Ink:Right:Ass'y	1
3	C267 5251	Harness:Connecting:Pump:B4:Ass'y (for 200V/B4)	1
3	C267 5254	Harness:Connecting:Pump:A4:Ass'y (for 100V, 200V/LG)	1
4	C267 4665	Bearing Case:Roller:Ink	2
5	C207 4672	Gear - 36Z	1
6	C238 2469	Doctor Roller Drive Gear	1
7	C267 2468	Ground Plate:Oil Supply Roller:Ink	1
8	C267 2481	Drum Shaft:B4:Ass'y (for 200V/B4)	1
8	C267 2487	Drum Shaft:LG:Ass'y (for 100V, 200V/LG)	1
9	C261 2471	Ink Sensor:Ass'y	1
10	C252 2470	Stay:Ink Sensor	1
11	C261 2463	Stay:Main:Drum:B4 (for 200V/B4)	1
11	C261 2464	Stay:Main:Drum:A4 (for 100V, 200V/LG)	1
12	C231 2450	Ink Roller - B4 (for 200V/B4)	1
12	C231 2456	Ink Roller - LG (for 100V, 200V/LG)	1
13	C252 2458	Oil Supply Roller:B4 (for 200V/B4)	1
13	C252 2459	Oil Supply Roller:LG (for 100V, 200V/LG)	1
14	C261 2465	Stay:Sub:Drum:B4 (for 200V/B4)	1
14	C261 2466	Stay:Sub:Drum:LG (for 100V, 200V/LG)	1
15	C267 2458	Ring:Front:Roller:Drum	1
16	C252 2492	Tension Spring:Ring:Roller:Drum	2
17	C218 4592	Front Bank Plate	1
18	C267 2459	Ring:Rear:Roller:Drum	1
19	C218 4594	Rear Bank Plate	1
20	C252 2475	Side Plate:Roller:Ink:Left	1
21	C252 2495	Plate:Side Plate:Roller:Ink	2
22	C252 2398	Spacer:Drum Shaft:Left (for 100V, 200V/LG)	1
23	C252 2397	Collar:Drum Shaft:Left	1
24	C261 5253	Harness:Ink Sensor:Ass'y	1
25	C200 4748	Gear - 45T	1
26	C247 2461	Adjusting Plate - Doctor Roller	2

Index No.	Part No.	Description	Q'ty Per Assembly
27	C267 2598	Blade:Front:Drum	1
28	C267 2599	Blade:Rear:Drum	1
29	C237 2460	Gear:Drive:Roller:Ink	1
30	5316 7421	O - Ring	2
31	C252 2485	Joint:Drum Shaft	2
32	C238 2489	Rubber Bushing Plate	2
33	C238 2488	Rubber Bushing	2
34	C267 2427	DC MOTOR:PUMP UNIT	1
101	0951 3006Z	Philips Screw With Flat Washer - M3	
102	0807 7114	Washer - 16x24x0.3mm	
103	0725 0160E	Retaining Ring C - M16	
104	0594 0080Z	Bolt - M4x8	
105	0574 0040E	Hexagon Headless Set Screw - M4x4	
106	0951 4006Z	Philips Screw With Flat Washer - M4	
107	0314 0080Z	Philips Screw - 4x8	
108	0720 0050G	Retaining Ring - M5	
109	0450 3008Z	Tapping Screw - M3x8	
110	1105 0511	Harness Clamp - LWS-0306ZC	
111	0354 0060Z	Philips Truss Head Screw - M4x6	
112	0353 0050Z	Philips Truss Head Screw - M3x5	
113	0353 0100Z	Bind Screw - M3x10	

13.Vacuum Fan Unit (C274)




13.Vacuum Fan Unit (C274)

Index No.	Part No.	Description	Q'ty Per Assembly
*	C274 3803	Hale Unit:Ass'y	1
1	C261 3879	Transport Belt:Hale Unit:17	2
2	C238 3889	Drive Roller	2
3	C261 3895	Shaft:Drive:Hale Unit	1
4	C252 3876	Bushing:Hale Unit:EAK-3	3
5	5215 2621	Snap Ring - M6	1
6	C252 3875	Timing Pulley:Drive:Hale Unit	1
7	C261 3861	Duct:Hale Unit	1
8	C238 3890	Drive Roller - Drum Side	2
9	C238 3877	Driven Shaft	1
10	C261 3855	Bracket:Fan:Hale Unit:Ass'y	1
11	AX65 5800	DC Fan Motor:Axial:MM119:24V	1
12	AW01 0109	Photo Refiection Sensor:PS117ED1	1
13	C267 5260	Harness:Hale Unit:Ass'y	1
14	C272 5887	Spacer:DC Fan Motor:Axial:MM119:24V	2
15	C261 3890	Guide:Hale Unit	2
16	C261 3873	Shaft:Drive:Hale Unit:Ass'y	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4008N	Tapping Screw:4x8	
102	0450 4008N	Tapping Screw - M4x8	
103	0354 0450N	Screw:M4x45	
104	0720 0060E	Retaining Ring - M6	
105	0633 0140G	Parallel Pin - 3x14	

14.Delivery Table (C274)




14.Delrvery Table (C274)

Index No.	Part No.	Description	Q'ty Per Assembly
*	C274 4201	Paper Exit Sub-unit:Ass'y	1
1	C252 4425	Side Fence:Paper Exit Sub-unit	2
2	C261 4426	Stay:Side Fence:Paper Exit Sub-unit	2
3	C252 4408	Knob:Side Fence:Paper Exit Sub-unit	2
4	C248 4390	Bottom Plate	1
5	C274 4407	End Plate:Paper Exit Sub-unit	1
6	C231 4420	Slider Spring Plate	3
7	C238 4421	Slider Cover	1
8	C238 4456	Slider Cover	2
9	C261 4412	Bracket:End Plate:Ass'y	1
10	C252 4415	Sheet:End Plate	1
11	C261 4409	Supporting Plate:Paper Exit	1
12	C261 4401	Stay:Front:Paper Exit Sub-unit	1
13	C261 4402	Stay:Rear:Paper Exit Sub-unit	1
14	C261 4404	Guide Plate:Stay:Front:Paper Exit	1
15	C261 4403	Guide Plate:Stay:Rear:Paper Exit	1
16	C261 4441	Bracket:Paper Exit:Rear	1
17	C261 4350	Stepped Screw - M6	2
18	C259 7052	Knob Screw:M4x10	3

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0450 3012N	Tapping Screw:3x12	
103	0451 3008N	Tapping Screw - M3x8	
104	0450 4010N	Tapping Screw:M4x10	
105	0451 4008N	Tapping Screw:4x8	

15.Master Eject Unit (C274)




15.Master Eject Unit (C274)

Index No.	Part No.	Description	Q'ty Per Assembly
*	C274 3401	Master Ejection Unit:Ass'y	1
1	C274 3520	Case:Master Ejection Unit:Ass'y	1
2	C261 3577	Plate:Master	1
3	C261 3567	Guide Plate	1
4	AW02 0224	Photointerruptor	3
5	C261 3524	Bracket:Sensor:Pressure Plate	1
6	C261 3521	Side Plate:Rear	1
7	C252 3684	Gear:Pressure Plate:Master Ejection	1
8	C252 3487	Spring:Pressure:Roller:Master Ejection	2
9	C252 3486	Bushing:Pressure:MM6	2
10	C252 3525	Gear:Pressure:15/124	1
11	C259 5821	Stepper Motor:DIA42:Plotter:Ass'y	2
12	C261 3466	Base:Master Ejection	1
13	C261 3484	Roller:Lower:Master Ejection Unit:Ass'y	1
14	C261 3485	Roller:Upper:Master Ejection Unit	1
15	C252 3556	Spring:Pressure:Master Ejection:13.98N	2
16	C261 3553	Arm:Pressure:Master Ejection	2
17	C261 3656	Pressure Plate:Master Ejection	1
18	C261 3554	Shaft:Pressure:Master Ejection Unit	1
19	C261 3501	Side Plate:Front	1
20	C252 3492	Gear:Roller:50/84	1
21	C231 3489	Lower Roller Gear	1
22	C231 3494	Gear - Lower Roller	1
23	C261 3469	Duct:Air Knife	1
24	C261 3470	Base:Air Knife	1
25	C261 5150	PCB:Optics Sensor	1
26	C261 5230	Harness:Master Ejection Unit:Ass'y	1
27	C261 5050	Photointerrupt:Master Ejection	1
28	C261 3467	Bracket:Sensor:Master Ejection Unit	1
29	C237 3505	Pin 3x16	1
30	C261 5825	Fan:Sirocco:DC24V:B054	1
31	C261 3472	Cover:Sensor:Master Ejection Unit	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 3006N	Tapping Screw - M3x6	
102	0451 3006N	Tapping Screw - 3x6	
103	0805 3385	Bushing - 6mm	
104	0720 0040E	Retaining Ring - M4	
105	0353 0060N	Bind Screw - M3x6	
106	0353 0060N	Bind Screw - M3x6	
107	0954 3008N	Screw - M3x8	
108	0353 0040N	Screw - M3x4	
109	0354 0350N	Screw M4x35	
110	1105 0516	Clamp	
111	1105 0534	Clamp	
112	1105 0328	Harness Clamp - ES-0505	

16.Electrical And Drive Section (C274)




16.Electrcal And Drive Section (C274)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C261 2817	Bracket:Drive:Paper Feed Roller	1
2	C261 1172	Side Plate:Drum Drive Sub-unit	1
3	C261 5200	Harness:DC Drive:Ass'y	1
4	C274 5123	PCB:MPU:Ass'y	1
5			1
6	C274 5201	Harness:Motor:Ass'y	1
7	C274 5321	DC Power Supply:Main:200V:Ass'y (for 200V/LG, 200V/B4)	1
7	C274 5301	DC Power Supply:Main:Ass'y (for 100V/LG)	1
8	C252 1181	Timing Belt:Hale:60S3M423	1
9	C252 1175	Timing Pulley:Large:Drive:Hale	1
10	C252 1173	Timing Pulley:Drive:Hale:Ass'y	1
11	C261 1171	Bearing Case	1
12	C261 5019	Power Supply Cord:NA:Ass'y (for 100V/LG)	1
12	C261 5017	Power Supply Cord:EU:Ass'y (for DX2330 EU/DX2430)	1
12	C274 5016	Power Supply Cord:Ass'y (CHN)	1
13	C261 5876	Stepper Motor:MM56x54	1
14	C261 2887	Bracket:Stepper Motor:Feed	1
15	C252 2888	Pulley:Stepper Motor:Feed:23Z	1
16	C261 2885	Tension Spring	1
17	5053 0447	Bushing - 6mm	1
18	C261 5879	Magnetic Clutch:Paper Feed Roller	1
19	C261 5610	Bracket:Home Position Sensor	1
20	AW02 0224	Photointerruptor	3
21	C259 5821	Stepper Motor:DIA42:Plotter:Ass'y	1
22	C261 4064	Side Plate:Drive Sub-unit:Clamp	1
24	C252 4069	Gear:Slow Down	1
25	C252 4068	Gear:Drive:Rack	1
26	C261 5686	Screw:Round Point:Safety Switch	1
27	C261 2071	Stopper:Safety Switch:Scanner	1
28	C261 5606	Lever:Safety Switch	1
29	C274 5607	Bracket:On Off Detector:Plotter	1
30	C267 2176	Spring Plate:Safety Switch	1
31	C261 5290	Harness:Brushless Motor:Ass'y	1

Index No.	Part No.	Description	Q'ty Per Assembly
32	C261 1176	Bracket:Hale:Drive:Ass'y	1
33	C264 5830	Fan:MM50:24W	1
34	C282 5333	Rocker Switch:AJ8R9013F	1
35	C274 5202	Harness:Main Switch:Ass'y	1
36	C274 5608	Guide:Cover:Plotter	1
37	C274 5613	Bracket:Main Switch	1
101	0451 4006N	Tapping Screw - 4x6	
102	0451 3006N	Tapping Screw - 3x6	
103	0454 4008Q	Tapping Screw - M4x8	
104	0951 3014N	Screw Polished Round M3x14	
105	0353 0060N	Bind Screw - M3x6	
106	0954 4008N	Screw - M4x8	
107	0354 0080N	Screw:M4x8	
108	0574 0080E	Hexagon Headless Set Screw - M4x8	
109	1204 2497	Micro Switch	
110	1107 1295	Fuse:Glass Cartridge:FSL 250V 6.3A(EM)	
111	1107 1295	Fuse:Glass Cartridge:FSL 250V 6.3A(EM)	
112	1105 0521	Clamp - LES-1017	
113	1105 0522	Edge Saddle - LES0510	
114	1105 0511	Harness Clamp - LWS-0306ZC	
115	1105 0487	Harness Clamp	
116	1105 0488	Harness Clamp	

17. Drive And Frame Section (C274)




17. Drive And Frame Section (C274)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C261 5615	Bracket:Base:Fix	6
2	C261 1160	Gear:Drive:Drum:Ass'y	1
3	C252 1179	Pulley:Drive:Paper Feed	1
4	C252 1180	Timing Belt:Drive:Main	1
5	C252 4063	Guide:Clamp:Master Feed	1
6	C261 4055	Lever:Drive:Master Feed:Peen	1
7	C261 4001	Base:Clamp:Open And Close:Ass'y	1
8	C261 4059	Lever:Drive:Master Ejection:Peen	1
9	C244 4426	Shoulder Screw	2
10	C238 4070	Eject Clamp Pusher	1
11	C252 4062	Guide:Positioning:Drum	1
12	C252 4052	Rack:Drive:Clamp	1
13	C261 5613	Bracket:Fix:Power Supply Unit	3
14	C261 5614	Bracket:Earth:Power Supply Unit	1
15	C252 1154	Roller:Belt Tensioner:Ass'y	1
16	C261 1156	Shaft:Belt Tensioner:Ass'y	1
17	C261 5619	Bracket:Cover:Fix	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 4006N	Tapping Screw - 4x6	
102	0454 4008Q	Tapping Screw - M4x8	
103	0451 3006N	Tapping Screw - 3x6	
104	0454 3006Q	Tapping Screw - M3x6	
105	0740 3010	Ball Bearing - 10x26x8mm	
106	0720 0040E	Retaining Ring - M4	
107	0720 0060E	Retaining Ring - M6	
108	1105 0488	Harness Clamp	

18.Frame Section (C274)



18.Frame Section (C274)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C261 1691	Base:Image Reading Unit	1
2	C261 1055	Stay:Machine	3
3	C261 3801	Drum Stay:Paper Exit Sub-unit:Ass'y	1
4	C261 3881	Bracket:Paper Exit	2
5	C261 3885	Discharge Brush:Long:Paper Exit	2
6	C261 3886	Discharge Brush:Short:Paper Exit	1
7	C267 2934	Knob:Lever	1
8	5607 3927	Stepped Screw - M3x8	2
9	C261 2842	Lever:Separation Change	1
10	C261 5290	Harness:Brushless Motor:Ass'y	1
11	C261 1151	Cover:Brushless Motor	1
12	C261 5800	Brushless Motor:DC24V:64.7W	1
13	C261 1324	Stopper:Rear:Cover:Plotter	1
14	C238 1057	Rubber Foot	4
15	C252 1152	Timing Pulley:Drive:Main	1
16	C252 1195	Hexagonal Set Screw:M5x8	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0451 3008N	Tapping Screw - M3x8	
103	0451 4008N	Tapping Screw:4x8	
104	0951 5010N	Screw:M5x10	
105	0951 4020N	Screw - M4x20	
106	0807 7046	Washer - 10.5x20x0.2mm	
107	0740 3010	Ball Bearing - 10x26x8mm	
108	1106 0851	Bush:NJ-16	
109	1105 0488	Harness Clamp	
110	1105 0511	Harness Clamp - LWS-0306Z	

Parts Index

PM Parts Index

Section Name	Part No.	Description in Service Manual	Description in Parts Catalog	Q'ty Per Assembly	Page and Index No.		
Scanner Section (C274)	C261 1757	Shading Plate	Pressure Plate:Shading:Ass'y	1	11	-	15
Paper Registration (C274)	C252 2802	Paper Feed Roller	Roller:Paper Feed:Ass'y	1	15	-	6
Paper Registration (C274)	C252 2820	Friction Pad	Separation Pad:Ass'y	1	15	-	10
Press Roller Section (C274)	C261 3050	Press Roller B4	Pressure Roller:B4:Ass'y (for 200V/B4)	1	23	-	16
Press Roller Section (C274)	C261 3052	Press Roller LG	Pressure Roller:Legal:Ass'y (for 100V, 200V/LG)	1	23	-	16
Drum Unit 2 (C274)	C252 2340	Cloth Screen B4	Screen:B4:Ass'y (for 200V/B4)	1	27	-	16
Drum Unit 2 (C274)	C252 2341	Cloth Screen LG	Screen:Legal:Ass'y (for 100V, 200V/LG)	1	27	-	16

Parts Index

Part No.	Description	Page and Index No.
0314 0080N	Philips Pan Head Screw - M4x8	15 - 110
0314 0080Z	Philips Screw - 4x8	29 - 107
0352 0080P	Screw M2x8	21 - 108
0353 0040N	Screw - M3x4	35 - 108
0353 0050Z	Philips Truss Head Screw - M3x5	25 - 104
0353 0050Z	Philips Truss Head Screw - M3x5	29 - 112
0353 0060N	Bind Screw - M3x6	7 - 106
0353 0060N	Bind Screw - M3x6	11 - 102
0353 0060N	Bind Screw - M3x6	11 - 108
0353 0060N	Bind Screw - M3x6	21 - 102
0353 0060N	Bind Screw - M3x6	23 - 107
0353 0060N	Bind Screw - M3x6	35 - 105
0353 0060N	Bind Screw - M3x6	35 - 106
0353 0060N	Bind Screw - M3x6	37 - 105
0353 0080Z	Philips Truss Head Screw - M3x8	25 - 109
0353 0100Z	Bind Screw - M3x10	29 - 113
0354 0040N	Screw - M4x4	23 - 115
0354 0040Z	Screw - M4x4	25 - 102
0354 0040Z	Screw - M4x4	27 - 104
0354 0060Z	Philips Truss Head Screw - M4x6	27 - 112
0354 0060Z	Philips Truss Head Screw - M4x6	29 - 111
0354 0080N	Screw:M4x8	13 - 107
0354 0080N	Screw:M4x8	37 - 107
0354 0350N	Screw M4x35	35 - 109
0354 0450N	Screw:M4x45	31 - 103
0450 3006N	Tapping Screw - M3x6	7 - 102
0450 3006N	Tapping Screw - M3x6	15 - 108
0450 3006N	Tapping Screw - M3x6	35 - 101
0450 3008N	Tapping Screw - M3x8	7 - 103
0450 3008N	Philips Tapping Screw - M3x8	19 - 106
0450 3008Z	Tapping Screw - M3x8	27 - 105
0450 3008Z	Tapping Screw - M3x8	29 - 109
0450 3012N	Tapping Screw:3x12	33 - 102

Part No.	Description	Page and Index No.
0450 4006N	Tapping Screw:4x6	25 - 107
0450 4008N	Tapping Screw 4x8	13 - 106
0450 4008N	Tapping Screw - M4x8	31 - 102
0450 4010N	Tapping Screw - M4x10	7 - 105
0450 4010N	Tapping Screw - M4x10	13 - 108
0450 4010N	Tapping Screw - M4x10	33 - 104
0451 3006N	Tapping Screw - 3x6	11 - 101
0451 3006N	Tapping Screw - 3x6	15 - 106
0451 3006N	Tapping Screw - 3x6	17 - 101
0451 3006N	Tapping Screw - 3x6	19 - 101
0451 3006N	Tapping Screw - 3x6	19 - 104
0451 3006N	Tapping Screw - 3x6	21 - 101
0451 3006N	Tapping Screw - 3x6	23 - 108
0451 3006N	Tapping Screw - 3x6	33 - 101
0451 3006N	Tapping Screw - 3x6	35 - 102
0451 3006N	Tapping Screw - 3x6	37 - 102
0451 3006N	Tapping Screw - 3x6	39 - 103
0451 3006N	Tapping Screw - 3x6	41 - 101
0451 3008N	Tapping Screw - M3x8	11 - 106
0451 3008N	Tapping Screw - M3x8	19 - 105
0451 3008N	Tapping Screw - M3x8	33 - 103
0451 3008N	Tapping Screw - M3x8	41 - 102
0451 4006N	Tapping Screw - 4x6	13 - 105
0451 4006N	Tapping Screw - 4x6	17 - 102
0451 4006N	Tapping Screw - 4x6	23 - 109
0451 4006N	Tapping Screw - 4x6	37 - 101
0451 4006N	Tapping Screw - 4x6	39 - 101
0451 4008N	Tapping Screw:4x8	7 - 101
0451 4008N	Tapping Screw:4x8	15 - 107
0451 4008N	Tapping Screw:4x8	17 - 103
0451 4008N	Tapping Screw:4x8	19 - 107
0451 4008N	Tapping Screw:4x8	23 - 119
0451 4008N	Tapping Screw:4x8	31 - 101

Part No.	Description	Page and Index No.
0451 4008N	Tapping Screw:4x8	33 - 105
0451 4008N	Tapping Screw:4x8	41 - 103
0452 3006N	Binding Self-Tapping Screw:3x6	27 - 106
0452 3008N	Tapping Screw - M3x8	7 - 104
0452 3008N	Tapping Screw - M3x8	9 - 101
0453 3006N	Tapping Screw - M3x6	17 - 107
0454 3006Q	Tapping Screw - M3x6	21 - 103
0454 3006Q	Tapping Screw - M3x6	39 - 104
0454 4008Q	Tapping Screw - M4x8	17 - 105
0454 4008Q	Tapping Screw - M4x8	23 - 105
0454 4008Q	Tapping Screw - M4x8	37 - 103
0454 4008Q	Tapping Screw - M4x8	39 - 102
0574 0040E	Hexagon Headless Set Screw - M4x4	19 - 103
0574 0040E	Hexagon Headless Set Screw - M4x4	29 - 105
0574 0050E	Hexagon Headless Set Screw - M4x5	17 - 115
0574 0080E	Hexagon Headless Set Screw - M4x8	37 - 108
0584 0121N	Hexagonal Head Bolt:M4x12	23 - 102
0592 0040E	Hexagonal Set Screw:M2x4	27 - 103
0593 0040E	Hexagonal Set Screw:M3x4	23 - 116
0593 0060Z	Hexagon Bolt - M3x6	27 - 108
0593 0080E	Bolt - M3x8	23 - 101
0593 0100Z	Bolt M3x10	27 - 107
0594 0060Z	Hexagon Socket Bolt - M4x6	25 - 106
0594 0080E	Bolt - M4x8	17 - 106
0594 0080Z	Bolt - M4x8	27 - 116
0594 0080Z	Bolt - M4x8	29 - 104
0622 0100E	Spring Pin - 2x10mm	11 - 113
0622 0140E	Spring Hole Pin - 2x14mm	23 - 118
0633 0140G	Parallel Pin - 3x14	31 - 105
0701 0030N	Washer DIA3	23 - 104
0701 0040N	Washer:DIA4	17 - 111
0701 0060N	Washer DIA6	17 - 110
0710 0040N	Hexagonal Nut:M4	23 - 103

Part No.	Description	Page and Index No.
0720 0020E	Retaining Ring - M2	27 - 101
0720 0030E	Retaining Ring - M3	11 - 103
0720 0030E	Retaining Ring - 3M	11 - 105
0720 0030E	Retaining Ring - M3	13 - 104
0720 0030E	Retaining Ring - M3	21 - 104
0720 0040E	Retaining Ring - M4	11 - 104
0720 0040E	Retaining Ring - M4	13 - 101
0720 0040E	Retaining Ring - M4	15 - 109
0720 0040E	Retaining Ring - M4	17 - 108
0720 0040E	Retaining Ring - M4	19 - 102
0720 0040E	Retaining Ring - M4	21 - 105
0720 0040E	Retaining Ring - M4	23 - 111
0720 0040E	Retaining Ring - M4	25 - 103
0720 0040E	Retaining Ring - M4	35 - 104
0720 0040E	Retaining Ring - M4	39 - 106
0720 0050E	Retaining Ring - M5	15 - 104
0720 0050G	Retaining Ring - M5	29 - 108
0720 0060E	Retaining Ring - M6	13 - 102
0720 0060E	Retaining Ring - M6	23 - 110
0720 0060E	Retaining Ring - M6	25 - 101
0720 0060E	Retaining Ring - M6	31 - 104
0720 0060E	Retaining Ring - M6	39 - 107
0720 0070E	Retaining Ring - M7	15 - 103
0720 0080E	Retaining Ring - M8	13 - 103
0720 0080E	Retaining Ring - M8	15 - 105
0720 0080E	Retaining Ring - M8	17 - 109
0720 0080E	Retaining Ring - M8	23 - 112
0725 0160E	Retaining Ring C - M16	29 - 103
0740 3008	Ball Bearing - 8x22x7	17 - 104
0740 3010	Ball Bearing - 10x26x8mm	39 - 105
0740 3010	Ball Bearing - 10x26x8mm	41 - 107
0741 3706	Ball Bearing - 6x10x3	17 - 114
0804 6091	Hexagonal Set Screw - M2x5	27 - 110

Part No.	Description	Page and Index No.
0805 3385	Bushing - 6mm	35 - 103
0805 3480	Bushing - 6mm	11 - 107
0807 5049	Wave Washer - 8 mm	25 - 105
0807 7046	Washer - 10.5x20x0.2mm	41 - 106
0807 7114	Washer - 16x24x0.3mm	27 - 109
0807 7114	Washer - 16x24x0.3mm	29 - 102
0808 0021	Rubber Ring	27 - 111
0951 3006Z	Philips Screw With Flat Washer - M3	27 - 114
0951 3006Z	Philips Screw With Flat Washer - M3	29 - 101
0951 3008Z	Philips Screw With Flat Washer - M3	27 - 115
0951 3014N	Screw Polished Round M3x14	23 - 106
0951 3014N	Screw Polished Round M3x14	37 - 104
0951 4006Z	Philips Screw With Flat Washer - M4	29 - 106
0951 4020N	Screw - M4x20	41 - 105
0951 5010N	Screw:M5x10	41 - 104
0954 3008N	Screw - M3x8	35 - 107
0954 4006Z	Screw - M4x6	25 - 108
0954 4008N	Screw - M4x8	37 - 106
1105 0328	Harness Clamp - ES-0505	35 - 112
1105 0487	Harness Clamp	17 - 112
1105 0487	Harness Clamp	23 - 117
1105 0487	Harness Clamp	37 - 115
1105 0488	Harness Clamp	11 - 112
1105 0488	Harness Clamp	21 - 106
1105 0488	Harness Clamp	37 - 116
1105 0488	Harness Clamp	39 - 108
1105 0488	Harness Clamp	41 - 109
1105 0511	Harness Clamp - LWS-0306ZC	11 - 110
1105 0511	Harness Clamp - LWS-0306ZC	15 - 102
1105 0511	Harness Clamp - LWS-0306ZC	17 - 113
1105 0511	Harness Clamp - LWS-0306ZC	21 - 107
1105 0511	Harness Clamp - LWS-0306ZC	27 - 102
1105 0511	Harness Clamp - LWS-0306ZC	29 - 110

Part No.	Description	Page and Index No.
1105 0511	Harness Clamp - LWS-0306ZC	37 - 114
1105 0511	Harness Clamp - LWS-0306Z	41 - 110
1105 0516	Clamp	11 - 111
1105 0516	Clamp	35 - 110
1105 0518	Edge Saddle - LES-1010	17 - 116
1105 0521	Clamp - LES-1017	37 - 112
1105 0522	Edge Saddle - LES0510	11 - 109
1105 0522	Edge Saddle - LES0510	15 - 101
1105 0522	Edge Saddle - LES0510	23 - 113
1105 0522	Edge Saddle - LES0510	27 - 113
1105 0522	Edge Saddle - LES0510	37 - 113
1105 0534	Clamp	35 - 111
1106 0851	Bush:NJ-16	21 - 109
1106 0851	Bush:NJ-16	41 - 108
1107 1295	Fuse:Glass Cartridge:FSL 250V 6.3A(EM)	37 - 110
1107 1295	Fuse:Glass Cartridge:FSL 250V 6.3A(EM)	37 - 111
1204 2497	Micro Switch	37 - 109
1204 2497	Micro Switch	23 - 114
2803 0006	Cord Binder	7 - 4
5053 0447	Bushing - 6mm	37 - 17
5215 2621	Snap Ring - M6	31 - 5
5316 7421	O - Ring	29 - 30
5506 6111	Stepped Screw - M4	23 - 22
5606 2066	Paper Feed Guide Disc	15 - 5
5607 3927	Stepped Screw - M3x8	41 - 8
AA13 2169	Spacer - 5.7x16x1.5	7 - 18
AA14 3791	Screw:Safety	15 - 18
AG07 0504	Magnet Catch:44.1N	7 - 16
AG07 0514	Magnet Catch	7 - 26
AW01 0107	Paper Feed Sensor	11 - 21
AW01 0109	Photo Refiection Sensor:PS117ED1	31 - 12
AW02 0224	Photointerruptor	21 - 29
AW02 0224	Photointerruptor	23 - 9

Part No.	Description	Page and Index No.
AW02 0224	Photointerruptor	35 - 4
AW02 0224	Photointerruptor	37 - 20
AX31 0049	Total Counter:7Fig:24V	23 - 35
AX65 5800	DC Fan Motor:Axial:MM119:24V	31 - 11
B132 1531	Panel:Logo	7 - 28
C200 4748	Gear - 45T	29 - 25
C207 4672	Gear - 36Z	29 - 5
C217 4581	Ink Roller Drive Gear	27 - 27
C217 5102	Spring Washer	19 - 27
C218 4592	Front Bank Plate	29 - 17
C218 4594	Rear Bank Plate	29 - 19
C229 2615	Slide Rail Roller	23 - 7
C229 2840	Pad	13 - 28
C229 2907	Registration Roller Pulley - 14Z	17 - 25
C229 5826	Plug Housing 22	25 - 37
C231 2135	Platen Gear - 2	21 - 25
C231 2147	Idler Gear	19 - 10
C231 2148	Tension Roller Gear	19 - 9
C231 2234	Brake Pad	21 - 31
C231 2417	Master Exit Pawls	27 - 2
C231 2450	Ink Roller - B4 (for 200V/B4)	29 - 12
C231 2456	Ink Roller - LG (for 100V, 200V/LG)	29 - 12
C231 2565	Ink Cartridge Joint	27 - 28
C231 2766	Slider:Housing	17 - 8
C231 3489	Lower Roller Gear	35 - 21
C231 3494	Gear - Lower Roller	35 - 22
C231 4420	Slider Spring Plate	33 - 6
C237 2460	Gear:Drive:Roller:Ink	29 - 29
C237 3505	Pin 3x16	35 - 29
C238 1057	Rubber Foot	41 - 14
C238 1962	Front Spring	19 - 29
C238 2037	Lever Knob	19 - 14
C238 2106	Ball Bearing - 6x13x5mm	19 - 12

Part No.	Description	Page and Index No.
C238 2368	Drum Drive Gear	27 - 11
C238 2410	Clamper Rear Spring	27 - 6
C238 2412	Clamper Cam	27 - 30
C238 2413	Sheet:Sensor:Trailing Edge:Screen	27 - 21
C238 2469	Doctor Roller Drive Gear	29 - 6
C238 2488	Rubber Bushing	29 - 33
C238 2489	Rubber Bushing Plate	25 - 20
C238 2489	Rubber Bushing Plate	29 - 32
C238 2572	Stopper Spring	27 - 22
C238 2573	Stepped Screw	25 - 23
C238 2585	Screw MM6x1.7	25 - 26
C238 2585	Screw MM6x1.7	27 - 26
C238 2853	Sensor Cleaning Spring (CHN)	17 - 15
C238 2856	Sensor Cleaning Brush (CHN)	17 - 16
C238 2921	Registration Sensor Bracket	17 - 11
C238 3126	Pressure Spring Screw	23 - 13
C238 3127	Pressure Spring Nut	23 - 36
C238 3877	Driven Shaft	31 - 9
C238 3889	Drive Roller	31 - 2
C238 3890	Drive Roller - Drum Side	31 - 8
C238 4070	Eject Clamp Pusher	39 - 10
C238 4421	Slider Cover	33 - 7
C238 4456	Slider Cover	33 - 8
C238 4493	Exit Pawl Drive Arm 2	23 - 5
C244 2633	Stepped Screw	17 - 21
C244 4426	Shoulder Screw	39 - 9
C247 2461	Adjusting Plate - Doctor Roller	29 - 26
C248 4390	Bottom Plate	33 - 4
C249 2230	Brake Shoe	21 - 30
C252 1080	Bushing	13 - 27
C252 1080	Bushing	15 - 3
C252 1080	Bushing	17 - 26
C252 1080	Bushing	23 - 18

Part No.	Description	Page and Index No.
C252 1152	Timing Pulley:Drive:Main	41 - 15
C252 1154	Roller:Belt Tensioner:Ass'y	39 - 15
C252 1173	Timing Pulley:Drive:Hale:Ass'y	37 - 10
C252 1175	Timing Pulley:Large:Drive:Hale	37 - 9
C252 1179	Pulley:Drive:Paper Feed	39 - 3
C252 1180	Timing Belt:Drive:Main	39 - 4
C252 1181	Timing Belt:Hale:60S3M423	37 - 8
C252 1195	Hexagonal Set Screw:M5x8	41 - 16
C252 1325	Spring Washer:6.4x11x1.5	7 - 13
C252 1475	Keytop:On Line	9 - 11
C252 1476	Keytop:Clear Modes	9 - 12
C252 1477	Keytop:Contenance	9 - 5
C252 1484	Shield:On Line:English (for DX2330 NA/LDD745, DX2430 NA/AA/KOR)	9 - 3
C252 1485	Shield:On Line: (CHN)	9 - 3
C252 1486	Shield:Start:English (for 100V, 200V/LG)	9 - 2
C252 1487	Shield:Start: (CHN)	9 - 2
C252 1491	Bracket:Operation Sub-unit	9 - 13
C252 1492	Lens:LED	9 - 14
C252 1494	Shield:On Line:EU:R1 (EU)	9 - 3
C252 1495	Shield:Start:EU:R1 (EU)	9 - 2
C252 1711	Gear:Idler:2:Image Reading Unit	11 - 25
C252 1712	Gear:Transport Roller:Image Reading Unit	11 - 24
C252 1721	Guide Plate:Fix:Ass'y	11 - 3
C252 1732	Rack:Original:Guide	7 - 9
C252 1734	Side Fence:Original	7 - 5
C252 1735	Gear:Original:Guide	7 - 10
C252 1753	Screw:M3x8	11 - 31
C252 1784	Spacer:Roller:Open And Close	11 - 17
C252 1785	Spring Plate:Pressure:Paper Feed Roller	11 - 12
C252 1950	Positioning Pin:Coupling:Plotter:Ass'y	19 - 21
C252 1971	Decal:Open And Close:Plotter:Left	19 - 3
C252 1972	Decal:Open And Close:Plotter:Left	19 - 2

Part No.	Description	Page and Index No.
C252 2082	Guide Plate:Brake:Lower:Plotter:Sub-ass'y	21 - 2
C252 2085	Guide Plate:Brake:Upper:Plotter	21 - 1
C252 2092	Guide Plate:Thermal Head:Ass'y	21 - 19
C252 2133	Gear:Idler:1:Platen	11 - 26
C252 2133	Gear:Idler:1:Platen	21 - 26
C252 2134	Gear:Idler:Stepper Motor	11 - 27
C252 2134	Gear:Idler:Stepper Motor	21 - 27
C252 2142	Gear:Platen	19 - 11
C252 2157	Spring:Thermal Head:Both Ends	21 - 13
C252 2281	Discharge Brush:Cutter	19 - 1
C252 2281	Discharge Brush:Cutter	21 - 3
C252 2340	Screen:B4:Ass'y (for 200V/B4)	27 - 16
C252 2341	Screen:Legal:Ass'y (for 100V, 200V/LG)	27 - 16
C252 2370	Spacer:Drum Shaft:Right (for 100V, 200V/LG)	27 - 9
C252 2395	Plate:Thrust:Drum	27 - 13
C252 2396	Wedge:Plate:Thrust	27 - 12
C252 2397	Collar:Drum Shaft:Left	29 - 23
C252 2398	Spacer:Drum Shaft:Left (for 100V, 200V/LG)	29 - 22
C252 2410	Torsion Spring:Pawl:Master Ejection:Master	27 - 25
C252 2412	Friction Pad:Screen:B4 (for 200V/B4)	27 - 32
C252 2413	Friction Pad:Screen:Small (for 200V/B4)	27 - 31
C252 2414	Friction Pad:Screen:LG (for 100V, 200V/LG)	27 - 32
C252 2458	Oil Supply Roller:B4 (for 200V/B4)	29 - 13
C252 2459	Oil Supply Roller:LG (for 100V, 200V/LG)	29 - 13
C252 2470	Stay:Ink Sensor	29 - 10
C252 2475	Side Plate:Roller:Ink:Left	29 - 20
C252 2476	Side Plate:Roller:Ink:Right:Ass'y	29 - 2
C252 2485	Joint:Drum Shaft	29 - 31
C252 2492	Tension Spring:Ring:Roller:Drum	29 - 16
C252 2495	Plate:Side Plate:Roller:Ink	29 - 21
C252 2526	Grip:Drum:Upper	25 - 32
C252 2534	Grip:Drum:Lower	25 - 16
C252 2559	Spring:Pressure:Ink Cartridge	25 - 6

Part No.	Description	Page and Index No.
C252 2590	Metal Screen - B4 (for 200V/B4)	27 - 20
C252 2593	Metal Screen - Legal (for 100V, 200V/LG)	27 - 20
C252 2752	Paper Feed Tray	13 - 18
C252 2765	Lever:Lock:Side Fence	13 - 14
C252 2778	Collar:Start:Pressure:Paper Feed Tray	13 - 2
C252 2783	Knob:Lever:Pressure:Paper Feed Tray	11 - 11
C252 2783	Knob:Lever:Pressure:Paper Feed Tray	13 - 11
C252 2802	Roller:Paper Feed:Ass'y	15 - 6
C252 2806	Shaft:Drive:Paper Feed Roller:Ass'y	15 - 9
C252 2810	Grip Rings:MM8	15 - 4
C252 2820	Separation Pad:Ass'y	15 - 10
C252 2839	Slider:Separation Sub-unit	15 - 19
C252 2873	Feed Roller:Upper:Sub-ass'y	17 - 3
C252 2878	Spring:Pressure:Feed Roller	17 - 4
C252 2888	Pulley:Stepper Motor:Feed:23Z	37 - 15
C252 3140	Spring:Pressure:B4 (for 200V/B4)	23 - 14
C252 3486	Bushing:Pressure:MM6	35 - 9
C252 3487	Spring:Pressure:Roller:Master Ejection	35 - 8
C252 3492	Gear:Roller:50/84	35 - 20
C252 3525	Gear:Pressure:15/124	35 - 10
C252 3556	Spring:Pressure:Master Ejection:13.98N	35 - 15
C252 3684	Gear:Pressure Plate:Master Ejection	35 - 7
C252 3875	Timing Pulley:Drive:Hale Unit	31 - 6
C252 3876	Bushing:Hale Unit:EAK-3	31 - 4
C252 4052	Rack:Drive:Clamp	39 - 12
C252 4062	Guide:Positioning:Drum	39 - 11
C252 4063	Guide:Clamp:Master Feed	39 - 5
C252 4068	Gear:Drive:Rack	37 - 25
C252 4069	Gear:Slow Down	37 - 24
C252 4365	Pickoff Pawl:Exit	23 - 3
C252 4408	Knob:Side Fence:Paper Exit Sub-unit	33 - 3
C252 4415	Sheet:End Plate	33 - 10
C252 4425	Side Fence:Paper Exit Sub-unit	33 - 1

Part No.	Description	Page and Index No.
C252 8616	Installation Roller And Pad-ENG (for DX2330 NA/LDD745, DX2430 NA/AA/KOR)	7 - 32
C252 8618	Installation Roller And Pad (CHN)	7 - 32
C257 5807	Photo Reflection Sensor:GP2A25	17 - 13
C257 5854	Master Duct Sensor	21 - 17
C259 5821	Stepper Motor:DIA42:Plotter:Ass'y	11 - 29
C259 5821	Stepper Motor:DIA42:Plotter:Ass'y	21 - 23
C259 5821	Stepper Motor:DIA42:Plotter:Ass'y	35 - 11
C259 5821	Stepper Motor:DIA42:Plotter:Ass'y	37 - 21
C259 7052	Knob Screw:M4x10	33 - 18
C261 1055	Stay:Machine	15 - 2
C261 1055	Stay:Machine	41 - 2
C261 1056	Shaft:Stay:Machine Or Copier	17 - 1
C261 1062	Shaft:Arm:Paper Feed:Ass'y	13 - 3
C261 1151	Cover:Brushless Motor	41 - 11
C261 1156	Shaft:Belt Tensioner:Ass'y	39 - 16
C261 1160	Gear:Drive:Drum:Ass'y	39 - 2
C261 1171	Bearing Case	37 - 11
C261 1172	Side Plate:Drum Drive Sub-unit	37 - 2
C261 1176	Bracket:Hale:Drive:Ass'y	37 - 32
C261 1322	Guide:Rear:Cover:Plotter	7 - 17
C261 1324	Stopper:Rear:Cover:Plotter	41 - 13
C261 1361	Decal:Caution:ABS	7 - 23
C261 1362	Decal:Separation Change:ABS	7 - 20
C261 1364	Decal:Paper Feed Pressure:ABS (CHN)	7 - 7
C261 1365	Decal:Main Switch:ABS (CHN)	7 - 27
C261 1366	Decal:WEEE:TRF:ABS (EU)	7 - 29
C261 1551	Bracket:Plate:Panel	13 - 4
C261 1551	Bracket:Plate:Panel	23 - 1
C261 1660	Frame:Open And Close	11 - 16
C261 1670	Side Plate:Fix:Front:Ass'y	11 - 9
C261 1680	Side Plate:Fix:Rear:Ass'y	11 - 28
C261 1691	Base:Image Reading Unit	41 - 1

Part No.	Description	Page and Index No.
C261 1696	Stay:Fix:Image Reading Unit	11 - 8
C261 1702	Transport Roller:Fix:Image Reading Unit	11 - 6
C261 1706	Exit Roller:Fix:Image Reading Unit	11 - 5
C261 1737	Decal:Original Insert:ABS	7 - 6
C261 1738	Decal:Scale:ABS	11 - 2
C261 1757	Pressure Plate:Shading:Ass'y	11 - 15
C261 1762	Compression Spring:Pressure Plate	11 - 32
C261 1766	Guide Plate:Open And Close:Image Reading Unit:Right	11 - 19
C261 1767	Guide Plate:Open And Close:Image Reading Unit:Left	11 - 20
C261 1782	Paper Feed Roller:Open And Close	11 - 33
C261 1792	Exit Roller:Open And Close	11 - 18
C261 1801	Shaft:Grip:Open And Close	11 - 30
C261 1802	Hook:Open And Close:Front	11 - 23
C261 1803	Hook:Open And Close:Rear	11 - 14
C261 1804	Bracket:Grip:Open And Close	11 - 10
C261 1806	Tension Spring:Grip:Open And Close	11 - 13
C261 1955	Stay:Coupling:Plotter	19 - 20
C261 1961	Spring:Open And Close:Rear:Plotter	19 - 26
C261 1995	Stay:Inner Back:Main Ass'y:Plotter	17 - 28
C261 1996	Stay:Front:Main Ass'y:Plotter	17 - 27
C261 2010	Side Plate:Fix:Rear:Plotter:Ass'y	21 - 24
C261 2025	Base:Fix:Plotter	21 - 21
C261 2026	Base:Thermal Head	21 - 15
C261 2030	Rear Plate:Open And Close	19 - 8
C261 2036	Lever:Open And Close:Plotter	19 - 15
C261 2039	Spring:Lever:Lock:Plotter	19 - 13
C261 2040	Front Plate:Open And Close	19 - 16
C261 2045	Cover:Open And Close:Plotter	19 - 4
C261 2046	Guide Plate	19 - 5
C261 2052	Positioning Plate:Master	21 - 8
C261 2054	Spring:Positioning Plate:Master	21 - 10
C261 2063	Lever:Roller:Brake	21 - 5

Part No.	Description	Page and Index No.
C261 2065	Spring:Roller:Brake:Plotter	21 - 9
C261 2071	Stopper:Safety Switch:Scanner	37 - 27
C261 2077	Roller:Brake:Plotter	21 - 4
C261 2095	Guide Plate:Master	21 - 20
C261 2104	Platen:B4 (for 200V/B4)	19 - 28
C261 2105	Platen:A4 (for 100V, 200V/LG)	19 - 28
C261 2108	Cover:Open And Close:Lower	19 - 17
C261 2114	Roller:Tension:B4 (for 200V/B4)	19 - 6
C261 2115	Roller:Tension:LG (for 100V, 200V/LG)	19 - 6
C261 2151	Thermal Head:B4	21 - 11
C261 2156	Spring:Thermal Head:Middle	21 - 14
C261 2210	Holder:Master:Rear	19 - 22
C261 2220	Holder:Master:Front	19 - 19
C261 2271	Cutter Unit:B4:Ass'y	19 - 18
C261 2273	Bracket:On Off Detector:Plotter	21 - 28
C261 2279	Bracket:Sensor:Master	21 - 18
C261 2368	Shielding Plate:Drum	27 - 15
C261 2388	Stay:Screen:Front:B4 (for 200V/B4)	27 - 17
C261 2389	Stay:Screen:Rear:B4 (for 200V/B4)	27 - 18
C261 2390	Stay:Screen:Front:A4 (for 100V, 200V/LG)	27 - 17
C261 2391	Stay:Screen:Rear:A4 (for 100V, 200V/LG)	27 - 18
C261 2401	Clamp:Ass'y	27 - 1
C261 2402	Base:Clamp:Drum:Ass'y	27 - 3
C261 2405	Plate:Clamp	27 - 7
C261 2406	Shaft:Clamp:Drum	27 - 5
C261 2463	Stay:Main:Drum:B4 (for 200V/B4)	29 - 11
C261 2464	Stay:Main:Drum:A4 (for 100V, 200V/LG)	29 - 11
C261 2465	Stay:Sub:Drum:B4 (for 200V/B4)	29 - 14
C261 2466	Stay:Sub:Drum:LG (for 100V, 200V/LG)	29 - 14
C261 2471	Ink Sensor:Ass'y	29 - 9
C261 2520	Side Plate:Drum:Left	27 - 4
C261 2521	Side Plate:Drum:Right	27 - 14
C261 2530	Arm:Grip:Left	25 - 14

Part No.	Description	Page and Index No.
C261 2531	Arm:Grip:Right	25 - 10
C261 2533	Screw:Arm:Drum	25 - 19
C261 2535	Shaft:Contact Point:Arm:Drum	25 - 13
C261 2538	Bracket:Housing:Drum	25 - 21
C261 2543	Cover:Harness:Drum	25 - 18
C261 2552	Screw:Slider	25 - 1
C261 2553	Rail:Holder:Left	25 - 7
C261 2554	Rail:Holder:Right	25 - 8
C261 2556	Lever:Release:Holder:Ass'y	25 - 11
C261 2558	Base:Lever:Release	27 - 29
C261 2560	Spring:Lever:Release	25 - 12
C261 2561	Guide:Slider:Left	25 - 3
C261 2567	Stay:Coupling:Grip	25 - 27
C261 2601	Stay:Drum:Machine Or Copier:Ass'y	23 - 8
C261 2605	Positioning Pin:Drum:Ass'y	23 - 23
C261 2611	Bracket:Receptacle	17 - 22
C261 2629	Guide:Slider:Right:Option	25 - 5
C261 2750	Paper Feed Tray:Ass'y	13 - 17
C261 2753	Bracket:Paper Feed Tray:Right	13 - 21
C261 2754	Bracket:Paper Feed Tray:Left	13 - 22
C261 2757	Base:Paper Feed Tray:Ass'y	13 - 15
C261 2760	Side Fence:Paper Feed:Ass'y	13 - 13
C261 2766	Guide:Side Fence	13 - 16
C261 2767	Pad:Plate:Paper:Ass'y	13 - 12
C261 2771	Shaft:Pressure:Paper Feed Tray	13 - 23
C261 2773	Bracket:Pressure:Paper Feed Tray	13 - 24
C261 2774	Shaft:Bracket:Pressure:Paper Feed Tray	13 - 26
C261 2775	Arm:Pressure:Paper Feed Tray	13 - 9
C261 2779	Lever:Pressure:Paper Feed Tray:Peen	13 - 8
C261 2782	Lever:Pressure:Paper Feed Tray	13 - 10
C261 2786	Lever:Paper Feed Pressure:Peen	13 - 1
C261 2790	Arm:Change:Paper Feed Pressure	13 - 6
C261 2791	Spring:Pressure:Paper Feed Tray	13 - 7

Part No.	Description	Page and Index No.
C261 2808	Shaft:Paper Feed Roller	15 - 7
C261 2817	Bracket:Drive:Paper Feed Roller	37 - 1
C261 2824	Drum Stay:Paper Feed:Ass'y	15 - 15
C261 2827	Adjusting Pin:Separation Sub-unit	15 - 13
C261 2831	Holder:Spring:Separation	15 - 12
C261 2832	Compression Spring:Separation Pad	15 - 11
C261 2835	Adjusting Pin	15 - 14
C261 2838	Washer:Adjusting Pin	15 - 16
C261 2842	Lever:Separation Change	41 - 9
C261 2844	Stepped Screw	15 - 8
C261 2844	Screw:Separation Unit (CHN)	17 - 14
C261 2869	Bracket:Guide Plate:Front	17 - 19
C261 2870	Bracket:Guide Plate:Rear	17 - 17
C261 2872	Shaft:Swivel:Feed Roller:Upper	17 - 9
C261 2875	Arm:Pressure:Feed Roller:Ass'y	17 - 5
C261 2881	Feed Roller:Lower	17 - 2
C261 2885	Tension Spring	37 - 16
C261 2887	Bracket:Stepper Motor:Feed	37 - 14
C261 2891	Guide Plate:Feed Roller:Ass'y	17 - 18
C261 2900	Stay:Harness:Sensor:Ass'y	15 - 1
C261 3050	Pressure Roller:B4:Ass'y (for 200V/B4)	23 - 16
C261 3052	Pressure Roller:Legal:Ass'y (for 100V, 200V/LG)	23 - 16
C261 3100	Side Plate:Pressure:Left:Ass'y	23 - 24
C261 3103	Side Plate:Pressure:Right:Ass'y	23 - 15
C261 3110	Arm:Pressure Roller:Left:Ass'y	23 - 21
C261 3113	Arm:Pressure Roller:Right:Ass'y	23 - 17
C261 3116	Bracket:Stopper:Pressure Roller	23 - 20
C261 3117	Stopper:Pressure Roller	23 - 19
C261 3120	Anchor:Spring:Pressure:Left:Ass'y	23 - 27
C261 3123	Anchor:Spring:Pressure:Right:Ass'y	23 - 11
C261 3130	DC Solenoid:Left:Ass'y	23 - 25
C261 3131	Bracket:Pressure Release:Left	23 - 37
C261 3134	DC Solenoid:Right:Ass'y	23 - 12

Part No.	Description	Page and Index No.
C261 3135	Bracket:Pressure Release:Right	23 - 39
C261 3137	Spring:Pressure Release	23 - 26
C261 3141	Spring:Pressure:A4 (for 100V, 200V/LG)	23 - 14
C261 3160	Arm:Pressure Release:Left:Ass'y	23 - 38
C261 3165	Arm:Pressure Release:Right:Ass'y	23 - 34
C261 3466	Base:Master Ejection	35 - 12
C261 3467	Bracket:Sensor:Master Ejection Unit	35 - 28
C261 3469	Duct:Air Knife	35 - 23
C261 3470	Base:Air Knife	35 - 24
C261 3472	Cover:Sensor:Master Ejection Unit	35 - 31
C261 3484	Roller:Lower:Master Ejection Unit:Ass'y	35 - 13
C261 3485	Roller:Upper:Master Ejection Unit	35 - 14
C261 3501	Side Plate:Front	35 - 19
C261 3521	Side Plate:Rear	35 - 6
C261 3524	Bracket:Sensor:Pressure Plate	35 - 5
C261 3553	Arm:Pressure:Master Ejection	35 - 16
C261 3554	Shaft:Pressure:Master Ejection Unit	35 - 18
C261 3567	Guide Plate	35 - 3
C261 3577	Plate:Master	35 - 2
C261 3656	Pressure Plate:Master Ejection	35 - 17
C261 3801	Drum Stay:Paper Exit Sub-unit:Ass'y	41 - 3
C261 3855	Bracket:Fan:Hale Unit:Ass'y	31 - 10
C261 3861	Duct:Hale Unit	31 - 7
C261 3873	Shaft:Drive:Hale Unit:Ass'y	31 - 16
C261 3879	Transport Belt:Hale Unit:17	31 - 1
C261 3881	Bracket:Paper Exit	41 - 4
C261 3885	Discharge Brush:Long:Paper Exit	41 - 5
C261 3886	Discharge Brush:Short:Paper Exit	41 - 6
C261 3890	Guide:Hale Unit	31 - 15
C261 3895	Shaft:Drive:Hale Unit	31 - 3
C261 4001	Base:Clamp:Open And Close:Ass'y	39 - 7
C261 4055	Lever:Drive:Master Feed:Peen	39 - 6
C261 4059	Lever:Drive:Master Ejection:Peen	39 - 8

Part No.	Description	Page and Index No.
C261 4064	Side Plate:Drive Sub-unit:Clamp	37 - 22
C261 4349	Spring:Arm:Pickoff Pawl	23 - 28
C261 4350	Stepped Screw - M6	13 - 20
C261 4350	Stepped Screw - M6	33 - 17
C261 4401	Stay:Front:Paper Exit Sub-unit	33 - 12
C261 4402	Stay:Rear:Paper Exit Sub-unit	33 - 13
C261 4403	Guide Plate:Stay:Rear:Paper Exit	33 - 15
C261 4404	Guide Plate:Stay:Front:Paper Exit	33 - 14
C261 4409	Supporting Plate:Paper Exit	33 - 11
C261 4412	Bracket:End Plate:Ass'y	33 - 9
C261 4426	Stay:Side Fence:Paper Exit Sub-unit	33 - 2
C261 4441	Bracket:Paper Exit:Rear	33 - 16
C261 4481	Arm:Drive:Pickoff Pawl	23 - 2
C261 4482	Shaft:Pickoff Pawl	23 - 4
C261 4485	Bracket:Roller:Pressure Release	23 - 6
C261 5017	Power Supply Cord:EU:Ass'y (for DX2330 EU/DX2430)	37 - 12
C261 5019	Power Supply Cord:NA:Ass'y (for 100V/LG)	37 - 12
C261 5050	Photointerrupt:Master Ejection	35 - 27
C261 5150	PCB:Optics Sensor	35 - 25
C261 5200	Harness:DC Drive:Ass'y	37 - 3
C261 5220	Ground Wire:Paper Feed Tray:Ass'y	13 - 19
C261 5230	Harness:Master Ejection Unit:Ass'y	35 - 26
C261 5240	Harness:Imaging Unit:Ass'y	21 - 12
C261 5241	Harness:Stepper Motor:Ass'y	21 - 22
C261 5252	Harness:Connecting:Drum:Ass'y	17 - 20
C261 5253	Harness:Ink Sensor:Ass'y	29 - 24
C261 5270	Harness:Connecting:Sensor:Ass'y	17 - 12
C261 5280	Harness:CIS:Ass'y	11 - 7
C261 5281	Harness:Original Sensor:Ass'y	11 - 22
C261 5290	Harness:Brushless Motor:Ass'y	37 - 31
C261 5290	Harness:Brushless Motor:Ass'y	41 - 10
C261 5606	Lever:Safety Switch	37 - 28

Part No.	Description	Page and Index No.
C261 5610	Bracket:Home Position Sensor	37 - 19
C261 5611	Bracket:Sensor:Paper Feed Control	23 - 10
C261 5613	Bracket:Fix:Power Supply Unit	39 - 13
C261 5614	Bracket:Earth:Power Supply Unit	39 - 14
C261 5615	Bracket:Base:Fix	39 - 1
C261 5619	Bracket:Cover:Fix	39 - 17
C261 5686	Screw:Round Point:Safety Switch	23 - 32
C261 5686	Screw:Round Point:Safety Switch	37 - 26
C261 5800	Brushless Motor:DC24V:64.7W	41 - 12
C261 5825	Fan:Sirocco:DC24V:B054	35 - 30
C261 5876	Stepper Motor:MM56x54	37 - 13
C261 5879	Magnetic Clutch:Paper Feed Roller	37 - 18
C264 2898	Upper Registration Shaft1	17 - 7
C264 5830	Fan:MM50:24W	37 - 33
C267 2078	Bracket Shoe:Roller:Brake:Plotter	21 - 6
C267 2172	Lever:Safety Switch	23 - 31
C267 2176	Spring Plate:Safety Switch	23 - 33
C267 2176	Spring Plate:Safety Switch	37 - 30
C267 2267	Bearing Case:Transmission	17 - 23
C267 2312	Roller:Ink:B4:Ass'y (for 200V/B4)	29 - *
C267 2360	Flange:Drum:B4:Left:Ass'y	27 - 8
C267 2362	Flange:Drum:B4:Right:Ass'y	27 - 10
C267 2390	Sheet:Sensor:Drum	27 - 19
C267 2394	Spring Plate:Grip:Drum	25 - 33
C267 2395	Bracket:Stopper:Drum	25 - 28
C267 2396	Spring Plate:Stopper	25 - 25
C267 2424	Filter:Pump:Ink	27 - 33
C267 2427	DC MOTOR:PUMP UNIT	29 - 34
C267 2428	Pump Unit:Ink:Ass'y (for 200VB4)	29 - 1
C267 2429	Pump Unit:Ink:A4:Ass'y (for 100V, 200V/LG)	29 - 1
C267 2458	Ring:Front:Roller:Drum	29 - 15
C267 2459	Ring:Rear:Roller:Drum	29 - 18
C267 2468	Ground Plate:Oil Supply Roller:Ink	29 - 7

Part No.	Description	Page and Index No.
C267 2481	Drum Shaft:B4:Ass'y (for 200V/B4)	29 - 8
C267 2487	Drum Shaft:LG:Ass'y (for 100V, 200V/LG)	29 - 8
C267 2524	Stay:Grip:Drum:Left	25 - 31
C267 2525	Stay:Grip:Drum:Right	25 - 30
C267 2537	Housing:Ass'y (for 200V/B4)	25 - 2
C267 2538	Housing:Legal:Ass'y (for 100V, 200V/LG)	25 - 2
C267 2570	Bracket:Stopper:Turn	27 - 24
C267 2571	Shield:Holder:Ink Cartridge	25 - 9
C267 2572	Stopper:Turn	27 - 23
C267 2574	Slider:Housing	25 - 17
C267 2598	Blade:Front:Drum	29 - 27
C267 2599	Blade:Rear:Drum	29 - 28
C267 2641	Slider:Holder:Ink Cartridge:WLD	25 - 4
C267 2934	Knob:Lever	13 - 5
C267 2934	Knob:Lever	41 - 7
C267 3452	Roller:Rail:Drum	13 - 25
C267 3452	Roller:Rail:Drum	15 - 17
C267 3452	Roller:Rail:Drum	25 - 24
C267 4479	Bushing:Pickoff Pawl	23 - 30
C267 4665	Bearing Case:Roller:Ink	29 - 4
C267 5251	Harness:Connecting:Pump:B4:Ass'y (for 200V/B4)	29 - 3
C267 5254	Harness:Connecting:Pump:A4:Ass'y (for 100V, 200V/LG)	29 - 3
C267 5260	Harness:Hale Unit:Ass'y	31 - 13
C271 2321	Holder:Ink Cartridge:CHN:Ass'y	25 - 15
C271 2550	Holder:Ink Cartridge:CHN	25 - 22
C272 2855	Sensor Cleaning Lever (CHN)	17 - 10
C272 5887	Spacer:DC Fan Motor:Axial:MM119:24V	31 - 14
C274 1300	Cover:Door	7 - 25
C274 1302	Cover:Front	7 - 19
C274 1304	Cover:Plotter	7 - 15
C274 1305	Cover:Right	19 - 23
C274 1306	Cover:Rear	7 - 11

Part No.	Description	Page and Index No.
C274 1311	Hinge:Door:Lower:Peen	7 - 24
C274 1313	Hinge:Door:Upper:Peen	7 - 22
C274 1330	Decal:Master Set Instructions:ABS	19 - 24
C274 1341	Sheet:Emblem:RIC:AA (for DX2430 NA/AA/KOR)	7 - 21
C274 1342	Sheet:Emblem:RIC:LA (for 100V/LG)	7 - 21
C274 1345	Sheet:Emblem:RIC:CHN (for DX2432C)	7 - 21
C274 1346	Sheet:Emblem:RIC (for DD2433c)	7 - 21
C274 1350	Sheet:Emblem:GES:AA (for DX2430 NA/AA/KOR)	7 - 21
C274 1355	Sheet:Emblem:GES:CHN (for CP6202C)	7 - 21
C274 1357	Sheet:Emblem:GES (for CP6203c)	7 - 21
C274 1455	Operation Panel:English:MM:Ass'y (for DX2430 NA/AA/KOR)	9 - *
C274 1456	Operation Panel:English:Inch:Ass'y (for 100V/LG)	9 - *
C274 1457	Operation Panel:Chinese:Ass'y (for DX2432C/CP6202C)	9 - *
C274 1458	Operation Panel:EU:Ass'y (for DX2330 EU/DX2430 EU)	9 - *
C274 1459	Operation Panel:Chinese:Ass'y (for DD2433c/CP6203c)	9 - *
C274 1460	Case:Operation Panel	9 - 4
C274 1470	Keytop:10key	9 - 10
C274 1471	Keytop:Clear	9 - 9
C274 1472	Keytop:Try Print	9 - 6
C274 1473	Keytop:Start	9 - 7
C274 1474	Keytop:Start	9 - 8
C274 1480	Seal:Paper Jam:English:Inch (for DX2430 NA/AA/KOR)	9 - 1
C274 1481	Seal:Paper Jam:English:MM (for 100V/LG)	9 - 1
C274 1482	Seal:Paper Jam:Chinese (for DX2432C / CP6202C)	9 - 1
C274 1483	Seal:Paper Jam:EU:RI (for DX2330 EU/DX2430 EU)	9 - 1
C274 1484	Seal:Paper Jam:Chinese (for DD2433c/CP6203c)	9 - 1
C274 1731	Cover:Fix:Image Reading Unit	7 - 8
C274 1733	Cover:Open And Close	11 - 1

Part No.	Description	Page and Index No.
C274 1739	Contact Image Sensor:Image Reading Unit:Ass'y	11 - 4
C274 1910	Plotter:Uni:B4 (for 200V/B4)	19 - *
C274 1911	Plotter:Uni:Legal (for 100V, 200V/LG)	19 - *
C274 2020	Side Plate:Fix:Front:Plotter:Ass'y	21 - 16
C274 2057	Display Sub-unit:Leading Edge:Master:Printing	21 - 7
C274 2248	Flange:Master:35.5/20	19 - 25
C274 2948	Timing Belt - 140-XL-050	17 - 24
C274 3401	Master Ejection Unit:Ass'y	35 - *
C274 3520	Case:Master Ejection Unit:Ass'y	35 - 1
C274 3803	Hale Unit:Ass'y	31 - *
C274 4201	Paper Exit Sub-unit:Ass'y	33 - *
C274 4407	End Plate:Paper Exit Sub-unit	33 - 5
C274 5016	Power Supply Cord:Ass'y (CHN)	37 - 12
C274 5123	PCB:MPU:Ass'y	37 - 4
C274 5160	PCB:Operation Sub-unit:Ass'y	9 - 15
C274 5201	Harness:Motor:Ass'y	37 - 6
C274 5202	Harness:Main Switch:Ass'y	37 - 35
C274 5301	DC Power Supply:Main:Ass'y (for 100V/LG)	37 - 7
C274 5321	DC Power Supply:Main:200V:Ass'y (for 200V/LG, 200V/B4)	37 - 7
C274 5607	Bracket:On Off Detector:Plotter	37 - 29
C274 5608	Guide:Cover:Plotter	37 - 36
C274 5613	Bracket:Main Switch	37 - 37
C274 8610	Wall Chart:A3:AA (for DX2430 NA/AA/KOR)	7 - 30
C274 8615	Operating Instructions:CHN:RIC (DX2432C)	7 - 31
C274 8616	Operating Instructions:CHN:GES (CP6202C)	7 - 31
C274 8617	Operating Instructions:AA (for DX2430 NA/AA/KOR)	7 - 31
C274 8628	Operating Instructions:LA (for DX2330 NA/LDD745)	7 - 31
C274 8677	Wall Chart:A3:LA (for 100V/LG)	7 - 30
C274 8678	Wall Chart:A3 (CHN)	7 - 30
C275 2895	Arm:Feed Roller:Upper	17 - 6
C275 5685	Bracket:On Off Detector:Door	23 - 29
C279 1342	Decal:Passing Certificate	7 - 12

