




Easy Operation Guide


Standard Printing




Loading Paper



Adding Ink




Replacing the Master Roll




Removing the Used Master




Control Panel



- | | | |
|------------------------------|-------------------------------|------------------------------------|
| 1. [Quality Start] key | 13. [Full Size] key | 25. [Online] key |
| 2. [Security] key | 14. [Combine/Repeat] key | 26. [Auto Online] key |
| 3. [Skip Feed] key | 15. [Memory/Class] key | 27. Indicators |
| 4. Zoom Keys | 16. Speed keys | 28. [Escape] key |
| 5. [Edge Erase] key | 17. [Image Position] keys | 29. [◀] and [▶] keys |
| 6. [Tint] key | 18. Number keys | 30. [OK] key |
| 7. [Economy Mode] key | 19. [■] key | 31. [Program] key |
| 8. Error indicator (Red) | 20. [Clear/Stop] key | 32. [Clear Modes/Energy Saver] key |
| 9. Data In indicator (Green) | 21. [Fine] key | 33. [Auto Cycle] key |
| 10. [Job Reset] key | 22. [User Tools] key | 34. [Proof] key |
| 11. [Type of Original] key | 23. Special Feature indicator | 35. [Master Making] key |
| 12. [Reduce/Enlarge] key | 24. [Image Density] key | 36. [Print] key |




- | | |
|----------------------------------|-------------------------------------|
| 1. Front cover | 7. Paper feed side plates |
| 2. Control panel | 8. Paper feed tray |
| 3. Auto Document Feeder (option) | 9. Paper feed side plate lock lever |
| 4. Master tray | 10. Side tray fine adjusting dial |
| 5. Lower master tray | 11. Paper feed tray down key |
| 6. Feed roller pressure lever | 12. Behind cover |



- | | |
|-------------------------------|-----------------------------|
| 1. Main switch | 7. Chocks |
| 2. Master eject box | 8. Drum unit |
| 3. Paper alignment wings | 9. Drum unit lock lever |
| 4. Paper delivery side plates | 10. Ink holder |
| 5. Paper delivery end plate | 11. Drum position indicator |
| 6. Paper delivery tray | 12. Exposure glass |

When the Open Cover/Unit Indicator Lights



Clearing Misfeeds

Paper Misfeeds in the Paper Feed Section

"**r** + A"




"**r** + A + B"




Paper Wrapped Around the Drum

"**r** + B"




Paper Misfeeds in the Paper Exit Section

"**r** + C"




Master Misfeeds in the Master Feed Section

"**r** + D"



Master Misfeeds in the Master Eject Section

"**r** + B + E"



Original Misfeeds in the ADF

"**r** + P"



For details, see *Operating Instructions* on the CD.