


Easy Operation Guide


Standard Printing




Loading Paper



Adding Ink




Replacing the Master Roll




Removing the Used Master




Control Panel



- | | | |
|------------------------------|-------------------------------|------------------------------------|
| 1. [Quality Start] key | 13. [Full Size] key | 25. [Auto Online] key |
| 2. [Security] key | 14. [Combine/Repeat] key | 26. Indicators |
| 3. [Skip Feed] key | 15. [Memory/Class] key | 27. [Escape] key |
| 4. Zoom Keys | 16. Speed keys | 28. [◀] and [▶] keys |
| 5. [Edge Erase] key | 17. [Image Position] keys | 29. [OK] key |
| 6. [Tint] key | 18. Number keys | 30. [Program] key |
| 7. [Economy Mode] key | 19. [#] key | 31. [Clear Modes/Energy Saver] key |
| 8. Error indicator (Red) | 20. [Clear/Stop] key | 32. [Auto Cycle] key |
| 9. Data In indicator (Green) | 21. [User Tools] key | 33. [Proof] key |
| 10. [Job Reset] key | 22. Special Feature indicator | 34. [Master Making] key |
| 11. [Type of Original] key | 23. [Image Density] key | 35. [Print] key |
| 12. [Reduce/Enlarge] key | 24. [Online] key | |




- | | |
|----------------------------------|-------------------------------------|
| 1. Front cover | 7. Paper feed side plates |
| 2. Control panel | 8. Paper feed tray |
| 3. Auto Document Feeder (option) | 9. Paper feed side plate lock lever |
| 4. Master tray | 10. Side tray fine adjusting dial |
| 5. Lower master tray | 11. Paper feed tray down key |
| 6. Feed roller pressure lever | 12. Behind cover |




- | | |
|-------------------------------|-----------------------------|
| 1. Main switch | 7. Chocks |
| 2. Master eject box | 8. Drum unit |
| 3. Paper alignment wings | 9. Drum unit lock lever |
| 4. Paper delivery side plates | 10. Ink holder |
| 5. Paper delivery end plate | 11. Drum position indicator |
| 6. Paper delivery tray | 12. Exposure glass |

When the Open Cover/Unit Indicator Lights




Clearing Misfeeds


Paper Misfeeds in the Paper Feed Section




Paper Wrapped Around the Drum




Paper Misfeeds in the Paper Exit Section



Master Misfeeds in the Master Feed Section



Master Misfeeds in the Master Eject Section



Original Misfeeds in the ADF



For details, see *Operating Instructions* on the CD.