

**DF Type 55 (C578)**

## PARTS CATALOG


### INTRODUCTION

This chapter instructs you the numbers and names of parts on this machine.

### INDEX to PARTS CATALOG

|                                   |           |
|-----------------------------------|-----------|
| 1.Exterior (C578) .....           | 2         |
| 2.Paper Feed Unit (C578) .....    | 4         |
| 3.Paper Exit Section (C578) ..... | 6         |
| 4.Electrical Section (C578) ..... | 8         |
| 5.Decal And Document (C578).....  | 10        |
| <b>Parte Index .....</b>          | <b>13</b> |

1.Exterior (C578)




## 1.Exterior (C578)

| Index No. | Part No.  | Description                            | Q'ty Per Assembly |
|-----------|-----------|----------------------------------------|-------------------|
| 1         | A628 2131 | Left Cover                             | 1                 |
| 2         | A628 6021 | Original Size Decal                    | 1                 |
| 3         | A628 2174 | Front Cover Hinge                      | 1                 |
| 4         | A628 2176 | Front Magnet Catch                     | 1                 |
| 5         | A628 2177 | Feeler - Paper Size Detection          | 1                 |
| 6         | A628 2178 | Feeler Bracket - Paper Size Detecti    | 1                 |
| 7         | A628 2175 | Rear Magnet Catch                      | 1                 |
| 8         | A628 2171 | Fixing Bracket - Left Cover            | 1                 |
| 9         | A628 1261 | Original Entrance Guide                | 1                 |
| 10        | A628 1262 | Pad - Original Entrance Guide          | 1                 |
| 11        | A628 2167 | Fixing Bracket - Original Table        | 1                 |
| 12        | A628 2163 | Original Table Bracket                 | 1                 |
| 13        | A628 3115 | Knob Screw - M4                        | 1                 |
| 14        | A565 2161 | Side Fence                             | 1                 |
| 15        | A628 2151 | Side Fence Guide                       | 1                 |
| 16        | A628 2141 | Original Table                         | 1                 |
| 17        | A628 5730 | Relay Harness - Original Length Sensor | 1                 |
| 18        | AW01 0074 | Photo Refiection Sensor:PS-R11D1-E     | 1                 |
| 19        | A628 2161 | Original Table Cover                   | 1                 |
| 20        | A628 2121 | Upper Cover                            | 1                 |
| 21        | A661 1173 | Bracket:hinge                          | 1                 |
| 22        | A565 1172 | Sensor Actuator                        | 1                 |
| 23        | A628 2111 | Front Cover                            | 1                 |
| 24        | A628 3111 | Shoulder Screw - M5                    | 1                 |
| 25        | AC01 3004 | Exposure Glass                         | 1                 |
| 26        | A628 3192 | Original Scale - LT                    | 1                 |
| 27        | C229 5276 | Ground Wire:Bracket:Hinge:Ass'y        | 1                 |
| 28        | A628 2211 | Rear Guide Plate                       | 1                 |
| 29        | 5446 2824 | Screw - Duplex Guide Plate             | 1                 |
| 30        | A628 1251 | Anti-vibration Weight                  | 1                 |
| 31        | A628 6031 | Jam Removal Decal                      | 1                 |
| 32        | A628 6041 | Decal - Original Tray                  | 1                 |
| 33        | A628 2186 | Driven Roller - Pull Out               | 1                 |
| 34        | A628 2188 | Rear : Spring Plate : Pull Out         | 1                 |
| 35        | A628 2179 | Registration Sensor Shield             | 1                 |

| Index No. | Part No.   | Description                        | Q'ty Per Assembly |
|-----------|------------|------------------------------------|-------------------|
| 36        | A628 2170  | Clock Lever - Left Cover           | 1                 |
| 37        | A610 6051  | Decal - Document Set               | 1                 |
| 38        | A628 1178  | Df Baracket Cushion                | 1                 |
| 39        | A628 1174  | Right Ground Palte - Hinge Bracket | 1                 |
| 40        | A628 1177  | Left Ground Plate - Hinge Bracket  | 1                 |
| 42        | A661 2173  | Feeler - Original Feed             | 1                 |
| 43        | A661 2172  | Bracket - Feeler Original          | 1                 |
| 44        | A628 3112  | Shielding Sheet                    | 1                 |
| 45        | A193 1759  | Stepped Sctew                      | 1                 |
| 46        | A376 4599  | Side Fence Pad                     | 1                 |
| 101       | 0353 0060F | Philips Truss Head Screw - M3x6    |                   |
| 102       | 0314 0060B | Philips Pan Head Screw - M4x6      |                   |
| 103       | 0434 0122B | Tapping Screw - M4x12              |                   |
| 104       | 0453 3006Z | Tapping Screw - M3x6               |                   |
| 105       | 0802 5255  | Tapping Screw - M3x8               |                   |
| 106       | 0451 3006B | Tapping Screw - M3x6               |                   |
| 107       | 0452 3008  | Tapping Bind Screw - M3x8          |                   |

2.Paper Feed Unit (C578)




## 2. Paper Feed Unit (C578)

| Index No. | Part No.  | Description                  | Q'ty Per Assembly |
|-----------|-----------|------------------------------|-------------------|
| 1         | A628 1246 | Gear - 22Z                   | 1                 |
| 2         | A628 1245 | Pulley And Gear - 20T/22Z    | 1                 |
| 3         | A628 1242 | Pick-up Roller Shaft         | 1                 |
| 4         | A628 1243 | Pick-up Roller Holder        | 1                 |
| 5         | 5206 2686 | Snap Ring                    | 1                 |
| 6         | A628 1241 | Pick-up Roller               | 1                 |
| 7         | A628 1249 | Joint - Pick-up Roller       | 1                 |
| 8         | A628 1244 | Pulley - 20T                 | 1                 |
| 9         | A628 1248 | Timing Belt - 118MM          | 1                 |
| 10        | A628 1216 | Spring - Belt Drive Shaft    | 1                 |
| 11        | A628 1218 | Front Guide Plate            | 1                 |
| 12        | 5215 2621 | Snap Ring - M6               | 1                 |
| 13        | A628 1214 | Belt Drive Roller            | 1                 |
| 14        | A628 1211 | Holder - Belt Drive Roller   | 1                 |
| 15        | A628 1215 | Spring - Belt Guide Roller   | 1                 |
| 16        | A628 1212 | Shaft - Belt Guide Roller    | 1                 |
| 17        | A628 1213 | Belt Guide Roller            | 1                 |
| 18        | A628 1257 | Original Feed Belt           | 1                 |
| 19        | A628 1221 | Gear - 22Z                   | 1                 |
| 20        | A628 1220 | Bushing - 8mm                | 1                 |
| 21        | A628 1219 | Rear Guide Plate             | 1                 |
| 22        | A628 1222 | Drive Roller Shaft           | 1                 |
| 23        | A628 1594 | Left Transport Roller Holder | 1                 |
| 24        | A628 1591 | Left Transport Roller Shaft  | 1                 |
| 25        | A628 1592 | Left Transport Roller        | 1                 |
| 26        | A628 1184 | Shuft - Pull Out Roller      | 1                 |
| 27        | A628 1181 | Lower Right Stay             | 1                 |
| 28        | A628 1187 | Lower Transport Guide        | 1                 |
| 29        | A628 1188 | Seal - Lower Transport Guide | 1                 |
| 30        | AW02 0075 | Photointerrupter             | 1                 |
| 31        | A628 1161 | Upper Stay                   | 1                 |
| 32        | A628 1851 | Feed-in Clutch Ass'y         | 1                 |
| 33        | A628 1855 | Feed-in Clutch Bracket       | 1                 |
| 34        | AA08 0075 | Bushing - 8mm                | 1                 |
| 35        | A628 1225 | Bushing - 8mm                | 1                 |

| Index No. | Part No.   | Description                         | Q'ty Per Assembly |
|-----------|------------|-------------------------------------|-------------------|
| 36        | 5053 0447  | Bushing - 6mm                       | 1                 |
| 37        | A628 1595  | Spring Holder                       | 1                 |
| 38        | A628 1596  | Left Transport Roller Spring        | 1                 |
| 39        | A628 5735  | Relay Harness - ORIGINAL WIDTH SENS | 1                 |
| 40        | A628 1247  | Cushion - Pick-up Roller Holder     | 1                 |
| 42        | A628 1163  | Cushion - Original Entrance Guide   | 1                 |
| 101       | 0720 0040B | Retaining Ring - M4                 |                   |
| 102       | 0720 0060B | Retaining Ring - M6                 |                   |
| 103       | 0632 0100  | Parallel Pin - M2x10                |                   |
| 104       | 0720 0025E | Retaining Ring - M2.5               |                   |
| 105       | 0451 3006B | Tapping Screw - M3x6                |                   |
| 106       | 0720 0025B | Retaining Ring - M2.5               |                   |
| 107       | 0720 0030E | Retaining Ring - M3                 |                   |
| 108       | 0453 3006B | Tapping Bind Screw - M3x6           |                   |
| 109       | 0807 5066  | Washer - M8.1xM14x0.3               |                   |
| 110       | 0807 4072  | Washer - Core                       |                   |

3.Paper Exit Section (C578)




### 3.Paper Exit Section (C578)

| Index No. | Part No.  | Description                         | Q'ty Per Assembly |
|-----------|-----------|-------------------------------------|-------------------|
| 1         | A628 1541 | Pull Out Guide                      | 1                 |
| 2         | A628 1149 | Separation Guide                    | 1                 |
| 3         | A628 1562 | Right Transport Roller              | 1                 |
| 4         | 5447 2681 | Snap Ring                           | 1                 |
| 5         | A628 1512 | Separation Roller                   | 1                 |
| 6         | A628 1542 | Turn Guide Plate - Right            | 1                 |
| 7         | A628 1147 | Brracket - Pull Out Roller          | 1                 |
| 8         | 5053 0447 | Bushing - 6mm                       | 1                 |
| 9         | A134 2885 | Torque Limitter                     | 1                 |
| 10        | A628 1142 | Bracket - Feed Roller               | 1                 |
| 11        | A628 1141 | Left Stay                           | 1                 |
| 12        | AW01 0066 | Photosensor - PS-R50D1-B            | 1                 |
| 13        | A628 1144 | Spring Plate - Guide - Expo Glass   | 1                 |
| 14        | A628 1551 | Original Guide - Df Exposure Glass  | 1                 |
| 15        | AA14 3051 | Shoulder Screw - M4                 | 1                 |
| 16        | A628 1239 | Shaft - Original Stopper            | 1                 |
| 17        | A628 1563 | Upper Exit Roller                   | 1                 |
| 18        | A628 1561 | Upper Exit Guide                    | 1                 |
| 19        | AA12 0032 | Antistatic Brush                    | 1                 |
| 20        | A628 1574 | Lower Exit Guide                    | 1                 |
| 21        | 5936 2480 | Magnet Catch Ass'y                  | 1                 |
| 22        | A628 1566 | Rear Bushing - Exit Roller          | 1                 |
| 23        | A628 5740 | Relay Harness - Registration Sensor | 1                 |
| 24        | A628 1585 | Lower Exit Roller                   | 1                 |
| 25        | A628 1565 | Front Bushing - Exit Roller         | 1                 |
| 26        | A628 1136 | Belt Tightener                      | 1                 |
| 27        | A628 1837 | Pulley - 20T                        | 1                 |
| 28        | A628 1834 | Timing Belt - 220MM                 | 1                 |
| 29        | A628 1121 | Stepped Screw - M4                  | 1                 |
| 30        | A628 1119 | Magnet Holder                       | 1                 |
| 31        | A628 1833 | Pulley - T42/T20                    | 1                 |
| 32        | A628 1238 | Lever - Original Stopper            | 1                 |
| 33        | A628 1117 | Bracket - Cover Sensor              | 1                 |
| 34        | AW02 0075 | Photointerrupter                    | 1                 |
| 35        | A628 1126 | Belt Tightner                       | 1                 |

| Index No. | Part No.   | Description                     | Q'ty Per Assembly |
|-----------|------------|---------------------------------|-------------------|
| 36        | A607 2176  | Exit Cover Magnet               | 1                 |
| 37        | A628 1515  | Drive Shaft - Separation Roller | 1                 |
| 38        | A628 1836  | Gear - 20Z                      | 1                 |
| 39        | A628 1835  | Pulley - 30T                    | 1                 |
| 40        | G010 1106  | Exit Roller Spring              | 1                 |
| 41        | A628 1838  | Timing Belt - 200MM             | 1                 |
| 42        | A590 2214  | Screw - M3X5                    | 1                 |
| 101       | 0451 3006B | Tapping Screw - M3x6            |                   |
| 102       | 0720 0040B | Retaining Ring - M4             |                   |
| 103       | 0313 0120B | Philips Pan Head Screw - M3x12  |                   |
| 104       | 0741 3506  | Ball Bearing - 6x12x4 mm        |                   |
| 105       | 0353 0060B | Philips Pan Head Screw - M3x6   |                   |
| 106       | 5447 2769  | Stepped Screw                   |                   |

4.Electrical Section (C578)







## 4. Electrical Section (C578)

| Index No. | Part No.  | Description                         | Q'ty Per Assembly |
|-----------|-----------|-------------------------------------|-------------------|
| 1         | A628 1587 | Right Transport Roller              | 1                 |
| 2         | A628 1586 | Plate Spring - Lower Transport Guid | 1                 |
| 3         | A628 1588 | Right Transport Roller Shaft        | 1                 |
| 4         | A628 1521 | Lower Exit Guide                    | 1                 |
| 5         | A628 1517 | Guide - Exit                        | 1                 |
| 6         | A628 1229 | Tension Spring - Stepper Motor      | 1                 |
| 7         | C229 6071 | Timing Pulley - 63/20Z              | 1                 |
| 8         | A628 1532 | Knob - Release Lever                | 1                 |
| 9         | A628 1523 | Bracket - Platen Cover              | 1                 |
| 10        | C229 6061 | Sensor Bracket                      | 1                 |
| 11        | A628 1624 | Link - Original Holder Bracket      | 1                 |
| 12        | C200 3115 | Shoulder Screw - Sensor Actuator    | 1                 |
| 13        | A628 1613 | Original Holder Bracket             | 1                 |
| 14        | A628 1614 | Original Holder Pad                 | 1                 |
| 15        | A628 1615 | Original Holder Sheet               | 1                 |
| 17        | A628 1139 | Stopper Plate                       | 1                 |
| 18        | A628 1529 | Stud - Platen Cover                 | 1                 |
| 19        | AA14 3307 | Stepped Screw - M3                  | 1                 |
| 20        | C229 6062 | Stepper Motor:ass'y                 | 1                 |
| 21        | A628 1122 | Support Bracket - Platen Sheet      | 1                 |
| 22        | AA14 3347 | Lever Stopper Shaft                 | 1                 |
| 23        | A628 1151 | Middle Stay                         | 1                 |
| 24        | A628 1152 | Right Stay                          | 1                 |
| 25        | A628 1172 | Left Hinge Ass'y                    | 1                 |
| 26        | A628 1171 | Right Hinge Ass'y                   | 1                 |
| 28        | AW02 0075 | Photointerrupter                    | 1                 |
| 29        | A628 1129 | Bracket - Df Position Sensor        | 1                 |
| 30        | C229 6068 | Motor Bracket                       | 1                 |
| 31        | C229 5278 | Stay - ADF                          | 1                 |
| 32        | A628 5500 | DF Control Board                    | 1                 |
| 33        | A628 5720 | Harness - Df Main Motor             | 1                 |
| 34        | A628 5725 | Sensor Harness                      | 1                 |
| 35        | A628 1231 | Feed Belt Solenoid                  | 1                 |
| 36        | C229 6075 | Timing Belt - S2M148                | 1                 |
| 37        | A628 5745 | Grounding Wire                      | 1                 |

| Index No. | Part No.   | Description                   | Q'ty Per Assembly |
|-----------|------------|-------------------------------|-------------------|
| 38        | A628 1829  | Collar - 9 X 15 X 3           | 1                 |
| 39        | C229 6076  | Timing Belt - S2M160          | 1                 |
| 40        | A661 1153  | Ground Plate:pressure Plate   | 1                 |
| 41        | A628 1611  | Original Holder Sheet Ass'y   | 1                 |
| 42        | A628 1153  | Grounding Plate               | 1                 |
| 43        | A548 2113  | Motor Cushion                 | 1                 |
| 44        | A628 1154  | Bracket - Harness Clamp       | 1                 |
| 101       | 0314 0060B | Philips Pan Head Screw - M4x6 |                   |
| 102       | 0451 3006B | Tapping Screw - M3x6          |                   |
| 103       | 0451 4006B | Tapping Screw - 4x6           |                   |
| 104       | 1607 0912  | Ferrite Core : TR-25-15-12    |                   |
| 105       | 0313 0050B | Philips Pan Head Screw - M3x5 |                   |

5.Decal And Document (C578)

|                                                                                                                                                                                                                                                                                                                                                             |                                                                                                                                     |                                                                                                                                                                                            |                                                                                                                                       |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------|
| <p>1</p> <div data-bbox="210 469 530 1077"><div></div><div></div><div></div><div>&gt;PS&lt;</div></div> | <p>2</p> <div data-bbox="770 284 864 1273"></div> | <p>3</p> <div data-bbox="1059 518 1402 1123"><div>Face up</div><div>Mit der Schriftseite nach oben</div><div>Face imprimée dessus</div><div>Faccia in su</div><div>Boca arriba</div></div> | <p>4</p> <div data-bbox="1476 408 2036 611"></div> |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------|

## 5.Decal And Document (C578)

| Index No. | Part No.  | Description           | Q'ty Per Assembly |
|-----------|-----------|-----------------------|-------------------|
| 1         | A628 6031 | Jam Removal Decal     | 1                 |
| 2         | A628 6021 | Original Size Decal   | 1                 |
| 3         | A628 6041 | Decal - Original Tray | 1                 |
| 4         | A610 6051 | Decal - Document Set  | 1                 |

| Index No. | Part No. | Description | Q'ty Per Assembly |
|-----------|----------|-------------|-------------------|
|           |          |             |                   |

# **PARTS INDEX**

| Part No.  | Description                        | Page and Index No. |
|-----------|------------------------------------|--------------------|
| AA08 0075 | Bushing - 8mm                      | 5- 34              |
| AA12 0032 | Antistatic Brush                   | 7- 19              |
| AA14 3051 | Shoulder Screw - M4                | 7- 15              |
| AA14 3307 | Stepped Screw - M3                 | 9- 19              |
| AA14 3347 | Lever Stopper Shaft                | 9- 22              |
| AC01 3004 | Exposure Glass                     | 3- 25              |
| AW01 0066 | Photosensor - PS-R50D1-B           | 7- 12              |
| AW01 0074 | Photo Refiection Sensor:PS-R11D1-E | 3- 18              |
| AW02 0075 | Photointerrupter                   | 9- 28              |
| AW02 0075 | Photointerrupter                   | 7- 34              |
| AW02 0075 | Photointerrupter                   | 5- 30              |
| C200 3115 | Shoulder Screw - Sensor Actuator   | 9- 12              |
| C229 5276 | Ground Wire:Bracket:Hinge:Ass'y    | 3- 27              |
| C229 5278 | Stay - ADF                         | 9- 31              |
| C229 6061 | Sensor Bracket                     | 9- 10              |
| C229 6062 | Stepper Motor:ass'y                | 9- 20              |
| C229 6068 | Motor Bracket                      | 9- 30              |
| C229 6071 | Timing Pulley - 63/20Z             | 9- 7               |
| C229 6075 | Timing Belt - S2M148               | 9- 36              |
| C229 6076 | Timing Belt - S2M160               | 9- 39              |
| G010 1106 | Exit Roller Spring                 | 7- 40              |

| Part No.  | Description                        | Page and Index No |
|-----------|------------------------------------|-------------------|
| A134 2885 | Torque Limiter                     | 7- 9              |
| A193 1759 | Stepped Sctew                      | 3- 45             |
| A376 4599 | Side Fence Pad                     | 3- 46             |
| A548 2113 | Motor Cushion                      | 9- 43             |
| A565 1172 | Sensor Actuator                    | 3- 22             |
| A565 2161 | Side Fence                         | 3- 14             |
| A590 2214 | Screw - M3X5                       | 7- 42             |
| A607 2176 | Exit Cover Magnet                  | 7- 36             |
| A610 6051 | Decal - Document Set               | 3- 37             |
| A610 6051 | Decal - Document Set               | 11- 4             |
| A628 1117 | Bracket - Cover Sensor             | 7- 33             |
| A628 1119 | Magnet Holder                      | 7- 30             |
| A628 1121 | Stepped Screw - M4                 | 7- 29             |
| A628 1122 | Support Bracket - Platen Sheet     | 9- 21             |
| A628 1126 | Belt Tightner                      | 7- 35             |
| A628 1129 | Bracket - Df Position Sensor       | 9- 29             |
| A628 1136 | Belt Tightener                     | 7- 26             |
| A628 1139 | Stopper Plate                      | 9- 17             |
| A628 1141 | Left Stay                          | 7- 11             |
| A628 1142 | Bracket - Feed Roller              | 7- 10             |
| A628 1144 | Spring Plate - Guide - Expo Glass  | 7- 13             |
| A628 1147 | Brracket - Pull Out Roller         | 7- 7              |
| A628 1149 | Separation Guide                   | 7- 2              |
| A628 1151 | Middle Stay                        | 9- 23             |
| A628 1152 | Right Stay                         | 9- 24             |
| A628 1153 | Grounding Plate                    | 9- 42             |
| A628 1154 | Bracket - Harness Clamp            | 9- 44             |
| A628 1161 | Upper Stay                         | 5- 31             |
| A628 1163 | Cushion - Original Entrance Guide  | 5- 42             |
| A628 1171 | Right Hinge Ass'y                  | 9- 26             |
| A628 1172 | Left Hinge Ass'y                   | 9- 25             |
| A628 1174 | Right Ground Palte - Hinge Bracket | 3- 39             |
| A628 1177 | Left Ground Plate - Hinge Bracket  | 3- 40             |
| A628 1178 | Df Baracket Cushion                | 3- 38             |
| A628 1181 | Lower Right Stay                   | 5- 27             |

| Part No.  | Description                     | Page and Index No. |
|-----------|---------------------------------|--------------------|
| A628 1184 | Shut - Pull Out Roller          | 5- 26              |
| A628 1187 | Lower Transport Guide           | 5- 28              |
| A628 1188 | Seal - Lower Transport Guide    | 5- 29              |
| A628 1211 | Holder - Belt Drive Roller      | 5- 14              |
| A628 1212 | Shaft - Belt Guide Roller       | 5- 16              |
| A628 1213 | Belt Guide Roller               | 5- 17              |
| A628 1214 | Belt Drive Roller               | 5- 13              |
| A628 1215 | Spring - Belt Guide Roller      | 5- 15              |
| A628 1216 | Spring - Belt Drive Shaft       | 5- 10              |
| A628 1218 | Front Guide Plate               | 5- 11              |
| A628 1219 | Rear Guide Plate                | 5- 21              |
| A628 1220 | Bushing - 8mm                   | 5- 20              |
| A628 1221 | Gear - 22Z                      | 5- 19              |
| A628 1222 | Drive Roller Shaft              | 5- 22              |
| A628 1225 | Bushing - 8mm                   | 5- 35              |
| A628 1229 | Tension Spring - Stepper Motor  | 9- 6               |
| A628 1231 | Feed Belt Solenoid              | 9- 35              |
| A628 1238 | Lever - Original Stopper        | 7- 32              |
| A628 1239 | Shaft - Original Stopper        | 7- 16              |
| A628 1241 | Pick-up Roller                  | 5- 6               |
| A628 1242 | Pick-up Roller Shaft            | 5- 3               |
| A628 1243 | Pick-up Roller Holder           | 5- 4               |
| A628 1244 | Pulley - 20T                    | 5- 8               |
| A628 1245 | Pulley And Gear - 20T/22Z       | 5- 2               |
| A628 1246 | Gear - 22Z                      | 5- 1               |
| A628 1247 | Cushion - Pick-up Roller Holder | 5- 40              |
| A628 1248 | Timing Belt - 118MM             | 5- 9               |
| A628 1249 | Joint - Pick-up Roller          | 5- 7               |
| A628 1251 | Anti-vibration Weight           | 3- 30              |
| A628 1257 | Original Feed Belt              | 5- 18              |
| A628 1261 | Original Entrance Guide         | 3- 9               |
| A628 1262 | Pad - Original Entrance Guide   | 3- 10              |
| A628 1512 | Separation Roller               | 7- 5               |
| A628 1515 | Drive Shaft - Separation Roller | 7- 37              |
| A628 1517 | Guide - Exit                    | 9- 5               |

| Part No.  | Description                         | Page and Index No. |
|-----------|-------------------------------------|--------------------|
| A628 1521 | Lower Exit Guide                    | 9- 4               |
| A628 1523 | Bracket - Platen Cover              | 9- 9               |
| A628 1529 | Stud - Platen Cover                 | 9- 18              |
| A628 1532 | Knob - Release Lever                | 9- 8               |
| A628 1541 | Pull Out Guide                      | 7- 1               |
| A628 1542 | Turn Guide Plate - Right            | 7- 6               |
| A628 1551 | Original Guide - Df Exposure Glass  | 7- 14              |
| A628 1561 | Upper Exit Guide                    | 7- 18              |
| A628 1562 | Right Transport Roller              | 7- 3               |
| A628 1563 | Upper Exit Roller                   | 7- 17              |
| A628 1565 | Front Bushing - Exit Roller         | 7- 25              |
| A628 1566 | Rear Bushing - Exit Roller          | 7- 22              |
| A628 1574 | Lower Exit Guide                    | 7- 20              |
| A628 1585 | Lower Exit Roller                   | 7- 24              |
| A628 1586 | Plate Spring - Lower Transport Guid | 9- 2               |
| A628 1587 | Right Transport Roller              | 9- 1               |
| A628 1588 | Right Transport Roller Shaft        | 9- 3               |
| A628 1591 | Left Transport Roller Shaft         | 5- 24              |
| A628 1592 | Left Transport Roller               | 5- 25              |
| A628 1594 | Left Transport Roller Holder        | 5- 23              |
| A628 1595 | Spring Holder                       | 5- 37              |
| A628 1596 | Left Transport Roller Spring        | 5- 38              |
| A628 1611 | Original Holder Sheet Ass'y         | 9- 41              |
| A628 1613 | Original Holder Bracket             | 9- 13              |
| A628 1614 | Original Holder Pad                 | 9- 14              |
| A628 1615 | Original Holder Sheet               | 9- 15              |
| A628 1624 | Link - Original Holder Bracket      | 9- 11              |
| A628 1829 | Collar - 9 X 15 X 3                 | 9- 38              |
| A628 1833 | Pulley - T42/T20                    | 7- 31              |
| A628 1834 | Timing Belt - 220MM                 | 7- 28              |
| A628 1835 | Pulley - 30T                        | 7- 39              |
| A628 1836 | Gear - 20Z                          | 7- 38              |
| A628 1837 | Pulley - 20T                        | 7- 27              |
| A628 1838 | Timing Belt - 200MM                 | 7- 41              |
| A628 1851 | Feed-in Clutch Ass'y                | 5- 32              |

| Part No.  | Description                            | Page and Index No. |
|-----------|----------------------------------------|--------------------|
| A628 1855 | Feed-in Clutch Bracket                 | 5- 33              |
| A628 2111 | Front Cover                            | 3- 23              |
| A628 2121 | Upper Cover                            | 3- 20              |
| A628 2131 | Left Cover                             | 3- 1               |
| A628 2141 | Original Table                         | 3- 16              |
| A628 2151 | Side Fence Guide                       | 3- 15              |
| A628 2161 | Original Table Cover                   | 3- 19              |
| A628 2163 | Original Table Bracket                 | 3- 12              |
| A628 2167 | Fixing Bracket - Original Table        | 3- 11              |
| A628 2170 | Clock Lever - Left Cover               | 3- 36              |
| A628 2171 | Fixing Bracket - Left Cover            | 3- 8               |
| A628 2174 | Front Cover Hinge                      | 3- 3               |
| A628 2175 | Rear Magnet Catch                      | 3- 7               |
| A628 2176 | Front Magnet Catch                     | 3- 4               |
| A628 2177 | Feeler - Paper Size Detection          | 3- 5               |
| A628 2178 | Feeler Bracket - Paper Size Detecti    | 3- 6               |
| A628 2179 | Registration Sensor Shield             | 3- 35              |
| A628 2186 | Driven Roller - Pull Out               | 3- 33              |
| A628 2188 | Rear : Spring Plate : Pull Out         | 3- 34              |
| A628 2211 | Rear Guide Plate                       | 3- 28              |
| A628 3111 | Shoulder Screw - M5                    | 3- 24              |
| A628 3112 | Shielding Sheet                        | 3- 44              |
| A628 3115 | Knob Screw - M4                        | 3- 13              |
| A628 3192 | Original Scale - LT                    | 3- 26              |
| A628 5500 | DF Control Board                       | 9- 32              |
| A628 5720 | Harness - Df Main Motor                | 9- 33              |
| A628 5725 | Sensor Harness                         | 9- 34              |
| A628 5730 | Relay Harness - Original Length Sensor | 3- 17              |
| A628 5735 | Relay Harness - ORIGINAL WIDTH SENS    | 5- 39              |
| A628 5740 | Relay Harness - Registration Sensor    | 7- 23              |
| A628 5745 | Grounding Wire                         | 9- 37              |
| A628 6021 | Original Size Decal                    | 3- 2               |
| A628 6021 | Original Size Decal                    | 11- 2              |
| A628 6031 | Jam Removal Decal                      | 3- 31              |
| A628 6031 | Jam Removal Decal                      | 11- 1              |

| Part No.  | Description                 | Page and Index No |
|-----------|-----------------------------|-------------------|
| A628 6041 | Decal - Original Tray       | 3- 32             |
| A628 6041 | Decal - Original Tray       | 11- 3             |
| A661 1153 | Ground Plate:pressure Plate | 9- 40             |
| A661 1173 | Bracket:hinge               | 3- 21             |
| A661 2172 | Bracket - Feeler Original   | 3- 43             |
| A661 2173 | Feeler - Original Feed      | 3- 42             |

| Part No.  | Description                | Page and Index No. |
|-----------|----------------------------|--------------------|
| 5053 0447 | Bushing - 6mm              | 5- 36              |
| 5053 0447 | Bushing - 6mm              | 7- 8               |
| 5206 2686 | Snap Ring                  | 5- 5               |
| 5215 2621 | Snap Ring - M6             | 5- 12              |
| 5446 2824 | Screw - Duplex Guide Plate | 3- 29              |
| 5447 2681 | Snap Ring                  | 7- 4               |
| 5447 2769 | Stepped Screw              | 7-106              |
| 5936 2480 | Magnet Catch Ass'y         | 7- 21              |

| Part No.   | Description                     | Page and Index No. |
|------------|---------------------------------|--------------------|
| 0313 0050B | Philips Pan Head Screw - M3x5   | 9-105              |
| 0313 0120B | Philips Pan Head Screw - M3x12  | 7-103              |
| 0314 0060B | Philips Pan Head Screw - M4x6   | 3-102              |
| 0314 0060B | Philips Pan Head Screw - M4x6   | 9-101              |
| 0353 0060B | Philips Pan Head Screw - M3x6   | 7-105              |
| 0353 0060F | Philips Truss Head Screw - M3x6 | 3-101              |
| 0434 0122B | Tapping Screw - M4x12           | 3-103              |
| 0451 3006B | Tapping Screw - M3x6            | 9-102              |
| 0451 3006B | Tapping Screw - M3x6            | 5-105              |
| 0451 3006B | Tapping Screw - M3x6            | 3-106              |
| 0451 3006B | Tapping Screw - M3x6            | 7-101              |
| 0451 4006B | Tapping Screw - 4x6             | 9-103              |
| 0452 3008  | Tapping Bind Screw - M3x8       | 3-107              |
| 0453 3006B | Tapping Bind Screw - M3x6       | 5-108              |
| 0453 3006Z | Tapping Screw - M3x6            | 3-104              |
| 0632 0100  | Parallel Pin - M2x10            | 5-103              |
| 0720 0025B | Retaining Ring - M2.5           | 5-106              |
| 0720 0025E | Retaining Ring - M2.5           | 5-104              |
| 0720 0030E | Retaining Ring - M3             | 5-107              |
| 0720 0040B | Retaining Ring - M4             | 7-102              |
| 0720 0040B | Retaining Ring - M4             | 5-101              |
| 0720 0060B | Retaining Ring - M6             | 5-102              |
| 0741 3506  | Ball Bearing - 6x12x4 mm        | 7-104              |
| 0802 5255  | Tapping Screw - M3x8            | 3-105              |
| 0807 4072  | Washer - Core                   | 5-110              |
| 0807 5066  | Washer - M8.1xM14x0.3           | 5-109              |
| 1607 0912  | Ferrite Core : TR-25-15-12      | 9-104              |