

Tape Dispenser Type20 (C651)

Tape Dispenser Type20 (C651)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.Tapemarker (C651)	2
2.Decal and Documents (C651)	4
Parts Index	8

December 25, 2008

1.Tapemarker (C651)




1.Tapemarker (C651)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C532 2221	Lower Tape Guide	1
2	C532 2222	Upper Tape Guide	1
3	C532 2224	Roller Shaft	1
4	C532 2223	Roller	1
5	C532 2238	Spring	1
6	C651 2229	Bracket:Home Position Sensor	1
7	AW02 0141	Photointerruptor	1
8	C651 8110	Harness:Sensor	1
9	C651 5800	Stepper Motor:DIA35:24V	1
10	5203 1852	Bushing - 6x8x4mm	4
11	C532 2205	Tape Cover	1
12	C651 2228	Arm:Drive:Cutter	1
13	C651 2206	Frame:Ass'y	1
14	C651 8001	Motor Drive Board	1
15	C532 2220	Feed Roller	1
16	C532 2215	Gear - 16Z	1
17	C651 2241	Bracket:Printed Circuit Board	1
18	C532 2210	Cutter Drive Shaft	1
19	C532 2212	2nd Gear - 23/48Z	1
20	C200 3604	Coupled Gear - 16T & 50T	1
21	5205 2612	Gear - 19T	1
22	C532 2227	Cutter Cam	1
23	C532 2226	Cutter Cam Shaft	1
24	C532 2216	Gear - 26Z	1
25	C651 2230	Cutter:Ass'y	1
26	5507 4452	Spacer - 5x8x0.5mm	1
27	C532 2237	Spring	1
28	C651 2233	Shielding Plate:Home Position Sensor:Ass'y	1
29	C651 2563	Decal - Tape Set	1
30	C651 2404	Cover:Lower	1
31	C651 2111	Bracket:Install:Machine or Copier:EXP	1
32	C651 2562	Decal - Manual	1
33	C651 8231	Harness:Coupling:Main:EXP	1
34	C651 8115	Harness:Main Switch:Ass'y	1
35	C532 2231	Fix:Cutter	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	C651 8120	Harness:Push Switch:Ass'y	1
37	C651 2403	Cover:Upper	1
38	C532 2009	Knob Screw - M4	2
39	C532 6503	Auxiliary Bracket (C250/C256/C264/C268/C272)	1
39	C651 6501	Bracket:Auxiliary (C267)	1
39	C651 6502	Bracket:Auxiliary:Pink (C238/C247/C249)	1
39	C651 6503	Auxiliary Bracket (C269)	1
40	C532 2232	Move:Cutter	1
41	C651 2236	Cover:Cleaning Blade:Cutter	1
101	0354 0080N	Screw:M4x8	
102	0353 0030N	Screw:M3x3	
103	0720 0040E	Retaining Ring - M4	
104	0353 0040N	Screw - M3x4	
105	0701 0040E	Flat Washer - M4	
106	0720 0050E	Retaining Ring - M5	
107	0710 0030N	Hexagonal Nut:M3	
108	0720 0030E	Retaining Ring - M3	
109	1105 0360	CLAMP	
110	0622 0100E	Spring Pin - 2x10mm	
111	0708 0030N	Washer:DIA3	
112	1106 0418	Cord Bushing	
113	0703 0040N	Spring Washer:DIA4	
114	0354 0050N	Screw - M4x5	
115	0354 0250N	Screw:M4x25	
116	0450 3006N	Tapping Screw - M3x6	
117	0710 0040N	Hexagonal Nut:M4	

2.Decal and Documents (C651)

1



2



2. Decal and Documents (C651)

Index No.	Part No.	Description	Q'ty Per Assembly
1	C651 2563	Decal - Tape Set	1
2	C651 2562	Decal - Manual	1

Index No.	Part No.	Description	Q'ty Per Assembly

Parts Index

Parts Index

Part No.	Description	Page and Index No.
C651 2111	Bracket:Install:Machine or Copier:EXP	3 - 31
C651 2206	Frame:Ass'y	3 - 13
C651 2228	Arm:Drive:Cutter	3 - 12
C651 2229	Bracket:Home Position Sensor	3 - 6
C651 2230	Cutter:Ass'y	3 - 25
C651 2233	Shielding Plate:Home Position Sensor:Ass'y	3 - 28
C651 2236	Cover:Cleaning Blade:Cutter	3 - 41
C651 2241	Bracket:Printed Circuit Board	3 - 17
C651 2403	Cover:Upper	3 - 37
C651 2404	Cover:Lower	3 - 30
C651 2562	Decal - Manual	3 - 32
C651 2562	Decal - Manual	5 - 2
C651 2563	Decal - Tape Set	5 - 1
C651 2563	Decal - Tape Set	3 - 29
C651 5800	Stepper Motor:DIA35:24V	3 - 9
C651 6501	Bracket:Auxiliary (C267)	3 - 39
C651 6502	Bracket:Auxiliary:Pink (C238/C247/C249)	3 - 39
C651 6503	Auxiliary Bracket (C269)	3 - 39
C651 8001	Motor Drive Board	3 - 14
C651 8110	Harness:Sensor	3 - 8
C651 8115	Harness:Main Switch:Ass'y	3 - 34
C651 8120	Harness:Push Switch:Ass'y	3 - 36
C651 8231	Harness:Coupling:Main:EXP	3 - 33

Part No.	Description	Page and Index No.
C200 3604	Coupled Gear - 16T & 50T	3 - 20
C532 2009	Knob Screw - M4	3 - 38
C532 2205	Tape Cover	3 - 11
C532 2210	Cutter Drive Shaft	3 - 18
C532 2212	2nd Gear - 23/48Z	3 - 19
C532 2215	Gear - 16Z	3 - 16
C532 2216	Gear - 26Z	3 - 24
C532 2220	Feed Roller	3 - 15
C532 2221	Lower Tape Guide	3 - 1
C532 2222	Upper Tape Guide	3 - 2
C532 2223	Roller	3 - 4
C532 2224	Roller Shaft	3 - 3
C532 2226	Cutter Cam Shaft	3 - 23
C532 2227	Cutter Cam	3 - 22
C532 2231	Fix:Cutter	3 - 35
C532 2232	Move:Cutter	3 - 40
C532 2237	Spring	3 - 27
C532 2238	Spring	3 - 5
C532 6503	Auxiliary Bracket (C250/C256/C264/C268/C272)	3 - 39

Part No.	Description	Page and Index No.
AW02 0141	Photointerruptor	3 - 7

Part No.	Description	Page and Index No.
0353 0030N	Screw:M3x3	3 - 102
0353 0040N	Screw - M3x4	3 - 104
0354 0050N	Screw - M4x5	3 - 114
0354 0080N	Screw:M4x8	3 - 101
0354 0250N	Screw:M4x25	3 - 115
0450 3006N	Tapping Screw - M3x6	3 - 116
0622 0100E	Spring Pin - 2x10mm	3 - 110
0701 0040E	Flat Washer - M4	3 - 105
0703 0040N	Spring Washer:DIA4	3 - 113
0708 0030N	Washer:DIA3	3 - 111
0710 0030N	Hexagonal Nut:M3	3 - 107
0710 0040N	Hexagonal Nut:M4	3 - 117
0720 0030E	Retaining Ring - M3	3 - 108
0720 0040E	Retaining Ring - M4	3 - 103
0720 0050E	Retaining Ring - M5	3 - 106
1105 0360	CLAMP	3 - 109
1106 0418	Cord Bushing	3 - 112

