

RICOH

型番
照長田

リコープロジェクター IPSiO PJ交換用ランプ タイプ3 取扱説明書

ご使用前に

このたびはリコープロジェクター交換用ランプユニットをお買い上げいただき、ありがとうございます。ランプユニットを正しく使っていただくため、お使いになる前にこの「取扱説明書」をよくお読みください。お読みになった後は、いつでも見られるところに必ず保管してください。

ランプについて

IPSiO PJ交換用ランプ タイプ3は、リコープロジェクター専用のランプユニットです。

他の製品に使用すると、火災、故障の原因になりますので絶対に使用しないでください。

安全上のご注意



警告

下記の注意事項を無視して、誤った取扱いをすると、高温・火災などにより、死亡または重傷を負う可能性があります。

ランプを交換するときは、電源を切ってから1時間以上経って、本機が冷めてから交換してください。冷めないうちの交換は、内部および光源ランプユニットは高温となっている部分があるため、やけどやけがの原因になります。また、ランプユニットを交換する前に、必ず電源プラグをコンセントから抜いてください。電源プラグを抜かずに交換すると、感電や破裂の原因になります。

取りだしたランプをお子様の手の届くところや、燃えやすいものの近くには置かないでください。ランプが破損する場合があります。

ランプを抜いた後のランプ収納部に金属類や燃えやすい異物や手などを絶対に入れないでください。火災や感電の原因となります。

交換用ランプは確実に取り付けてください。取付不十分のときは、画面が暗くなったり、火災の原因となることがあります。

ご使用上の注意

- ランプのガラス面および鏡面部には、素手でさわらないでください。
（万一、汚れた場合は、乾いた柔らかい布で拭き取ってください。）
- ランプユニットはガラス製品のため不用意に力を加えたり、強い衝撃を与えないでください。
- 万一、ランプが割れた際には、ガラス片でけがなどをしないように取扱いに注意し、販売担当者またはサービス実施店に修理を依頼してください。
- その他ランプについては、 プロジェクターの取扱説明書もあわせてご覧ください。

ランプ交換のしかた

光源用ランプは消耗品です。長時間使用しますと暗くなったり、ランプが切れて点灯しなくなったりすることがあります。（ランプの寿命は使用状態によって異なります。）


このようなときは、次の手順にしたがって新しいランプに取り換えてください。

1 本体の電源を切り、排気ファンが停止してから電源プラグを抜きます。

使用直後のランプは高温になっています。電源プラグを抜いて1時間以上たってからランプを交換してください。


2 底面が見えるように、平らな面に本機を置きます。

3 ノブを反時計回りに回転させ、ふたを取りはずします。




CLB058

4 金属製の取っ手を起こします。




CLB069

5 取っ手を持ち、ランプユニットを垂直に引き上げます。



CLB070

6 新しいランプユニットを本機に挿入します。




CLB071

本体内部の突起がランプユニットの穴にしっかりと差し込まれているか確認してください。

7 ふたを装着します。

ランプカバーは正しく取り付けてください。正しく取り付けられていないと電源が入らない、ランプが点灯しないなど誤動作の原因となります。

8 ランプ時間をリセットします。



1. [電源] ボタン
2. [AVミュート] ボタン
3. [▼] ボタン

[電源] ボタン、[AVミュート] ボタン、[▼] ボタンを同時に押しながら、コンセントに電源プラグを差し込みます。

ランプ時間がリセットされます。


電源を入れ、「状態表示」の「ランプ時間」が“0H”になっているのを確認してください。

お知らせ

ランプ時間リセット後、電源を切るときは [電源] ボタンで電源を切ってから電源コードを抜いてください。

お願い

必ず新品のランプに交換してください。
新しいランプユニットには“新ランプ”
ラベルがはってあります。



CLB073

1. “新ランプ” ラベル

■使用済みのランプについて

本機のランプには環境に有害な微量の無機水銀が使われています。使用済みのランプは、破損させないように取扱いに注意し、地方自治体の条例または規則にしたがって処理していただくか、販売担当者またはサービス実施店までご連絡ください。

主な仕様

ランプ： 高圧水銀ランプ
 最大外形寸法： 約 $59 \times 73 \times 97$ mm
 (幅×高さ×奥行)
 質 量： 約 145 g

本機の仕様及び外観は、改良のため予告なく変更することがあります。ご了承ください。

Instruction Manual **Replacement Lamp Type 3 for Ricoh Projector**

BEFORE USE

Thank you for purchasing this replacement lamp unit for the Ricoh projector. Prior to using the purchased lamp unit, please take the time to read through this Instruction Manual to ensure that the lamp unit will be used properly. After reading through these instructions, be sure to keep the Manual in a safe place for future reference.

Concerning the lamp unit

Replacement Lamp Type 3 is designed to be exclusively used for Ricoh projectors. Do not use this lamp unit for other projectors, otherwise it may cause fire or trouble of the machine.

SAFETY PRECAUTIONS



WARNING

Mishandling of this product without regard to the cautionary items outlined below may lead to high temperature, fires, etc. which in turn can lead to death or serious injury.

Before replacing the lamp, turn off the power and wait at least one hour to allow the product to cool completely. If it is not completely cool, you may burn or injure yourself due to the inside of the product and lamp unit being hot. If you replace the lamp without unplugging the power cord from the power outlet, electric shock or explosion may occur.

Do not place the lamp you have removed within the reach of children or near any object which may catch fire easily. The lamp may break, which can be dangerous.

Keep foreign matter such as metal objects or articles which catch fire easily away from the lamp housing after the lamp has been removed. This is done to safeguard against the risk of fires and electrical shocks. Under no circumstances should you insert your hand inside the lamp housing because of the danger of electrical shocks and burns.

Install the replacement lamp properly and securely. If it is not installed properly, the screen may become dark or a fire may occur.

**LAMP(S) INSIDE THIS PRODUCT
CONTAIN MERCURY AND MUST
BE RECYCLED OR DISPOSED OF
ACCORDING TO LOCAL, STATE
OR FEDERAL LAWS.**

User Information on Electrical & Electronic Equipment

Users in the countries where this symbol shown in this section has been specified in national law on collection and treatment of E-waste

Our Products contain high quality components and are designed to facilitate recycling.

Our products or product packaging are marked with the symbol below.



The symbol indicates that the product must not be treated as municipal waste. It must be disposed of separately via the appropriate return and collection systems available. By following these instructions you ensure that this product is treated correctly and help to reduce potential impacts on the environment and human health, which could otherwise result from inappropriate handling. Recycling of products helps to conserve natural resources and protect the environment.

For more detailed information on collection and recycling systems for this product, please contact the shop where you purchased it, your local dealer or sales/service representatives.

All Other Users

If you wish to discard this product, please contact your local authorities, the shop where you bought this product, your local dealer or sales/service representatives.

For Turkey only

EEE Yönetmeliğine Uygundur.

Bu sistem sarf malzemeleri ve yedek parçaları da dahil olmak üzere EEE Yönetmeliğine Uygundur.

PRECAUTIONS FOR USE

- Do not touch the lamp's glass side or mirror surface area with bare hands.
(If it becomes dirty, wipe out with a soft dry cloth.)
- The lamp unit is made of glass: do not apply force to it or subject it to strong impacts out of negligence.
- In the event that the lamp breaks, be careful not to be injured by the glass fragments. Ask your sales representative to repair it.
- For more information on the lamp, see the projector instruction manual.

HOW TO REPLACE THE LAMP


The lamp will eventually begin to project dark or dull pictures and finally will not light up. (Lamp's life length depends on the use condition.) In such a case, follow the steps below to replace the lamp with new one.

- 1 Turn off the power first and unplug the power cord after the cooling fan stops.**


Since the lamp unit is still heated just after the power is turned off, make sure to replace the lamp unit at least one hour or more after the power cord is unplugged.

- 2 Turn over the projector and place it on a flat surface so that you can see the bottom of the projector.**


- 3 Turn the knob counterclockwise, and then open the lamp cover.**




4 Raise the metal handle.



5 Hold the handle, and then pull the lamp unit out of the projector.



6 Insert a new lamp unit.




Make sure that the small projections inside the projector are inserted into the holes of the lamp unit properly.

7 Close the lamp cover.

Correctly install the outer lamp cover. Incorrect installation may prevent the lamp or projector from turning on.

8 Reset the lamp time.



1. [Power] button
2. [AV Mute] button
3. [▼] button

While holding down the [Power] button, the [AV Mute] button, and the [▼] button simultaneously, plug the power cord into the power outlet.

The lamp time is automatically reset.


Turn the power on and check that "0H" appears on [Lamp Time] in [Display Status].

Note

After resetting the lamp time, turn off the projector using the [Power] button, then unplug the power cord from the mains outlet.

NOTES

Be sure to use a new lamp for replacement. There is a “NEW LAMP” label stuck on every new lamp unit.



CL8073

1. “NEW LAMP” label

Used Lamps

This projector's lamp contains trace amounts of environmentally harmful inorganic mercury. Be careful not to break used lamps, and dispose of them in accordance with local regulations or contact your sales representative or service representative.

SPECIFICATIONS

Lamp:	HID lamp
Maximum dimensions:	Approx. 59 (W) x 73 (H) x 97 (D) mm
Mass:	Approx. 145 g

The lamp's specifications and exterior are subject to change without notice due to improvements.