



Y0117508A

# RICOH

## Notes for Users

This supplement provides additional information on using this product, and errata for the description in Operating Instructions.

### Notes to users viewing 3D images

Pay attention to the following points when viewing images using 3D glasses with the projector:

- How 3D images are viewed may vary according to the individual.
- Do not use 3D glasses for viewing any material other than 3D images.
- Before viewing 3D images, make sure to read the manuals provided with your 3D glasses and 3D compatible content.
- Avoid viewing 3D images for a long period of time. Take a break of 15 minutes or longer after every hour of viewing.
- If you feel sick while viewing 3D images, stop viewing them. If you continue to feel sick, consult a doctor.
- When viewing 3D images in a room where an LED lighting system or fluorescent lights are used, you may feel that the light in the room flickers. If this is the case, dim the lights until you do not notice any flickers, or turn off the lights.
- If you or any member of your family has a history of light-sensitive seizures, consult a doctor before viewing 3D images.
- To view 3D images, sit in front of the screen so that your eyes are parallel and level with the screen.
- Viewing 3D images from a place that is too close to the screen may result in eye strain. The distance between the screen and you should be at least three times the height of the screen.
- Adult supervision is required for children using 3D glasses.
- Viewing 3D images is not recommended for children under 6 years old. It may negatively affect development of their vision. Consult a doctor before using 3D glasses.

## Errata

### 1. Preparations for Using the Projector > Projector Parts and Their Functions > Control Panel (Top View)

Error	Correction
1. [Power] button Turns the projector on and off. You can confirm the status of the projector with the indicator. <ul style="list-style-type: none"> <li>• Blue light: Power is on.</li> <li>• Flashing blue: Starting up or cooling.</li> <li>• Red light or flashing red: Standby.</li> <li>• Off: Power is off.</li> </ul>	1. [Power] button Turns the projector on and off. You can confirm the status of the projector with the indicator. <ul style="list-style-type: none"> <li>• On: Power is on.</li> <li>• Off: Power is off.</li> <li>• Flashing at 1 or 3 second intervals: Standby.</li> <li>• Flashing at short intervals: Starting up or cooling.</li> </ul>

### 2. Projecting an Image > Manipulating Images with the Remote Control > Enlarging the image

Error	Correction
Note The Magnify function is canceled automatically if any operation other than mute is performed.	Note The Magnify function is canceled automatically if any operation is performed.

### 2. Projecting an Image > Manipulating Images with the Remote Control > Temporarily blanking the image and muting the audio

Error	Correction
Note The mute function is canceled automatically if any operation is performed.	Note The mute function is canceled automatically if any button on the control panel is pressed.

## 5. Troubleshooting > Indicator Display List


Refer to the following information in place of the information presented in the original operating instructions.

### Indicator Display List

The projector uses the [Power] button, indicators, and beeps to notify you if a malfunction occurs. Check the indicator's status, and implement the following measures.

#### Indicator display image

The [Power] button is located on top of the projector. The indicators are on the front of the projector. For details, see "Projector Parts and Their Functions", Operating Instructions.



1. [Power] button
2. Lamp indicator
3. Temp indicator

Status	Causes	Solutions
The projector does not turn on. 	The projector is malfunctioning.	Disconnect the power cord, and contact your service representative.
"Hardware Error" was displayed, and the projector turned off during operation. 	The projector has an internal malfunction.	Disconnect the power cord, wait a while, and then turn on the projector again. If the problem cannot be resolved, contact your service representative.
The lamp turned off during operation, or it does not turn on. 	<ul style="list-style-type: none"> <li>• The lamp has overheated and cannot turn on.</li> <li>• The lamp's service life has expired.</li> <li>• The projector has malfunctioned.</li> </ul>	<ul style="list-style-type: none"> <li>• Disconnect the power cord, wait a while, and then turn on the projector again.</li> <li>• If the lamp burns out, replace it with a new lamp. For details of how to replace the lamp, see "Replacing the Lamp", Operating Instructions.</li> </ul>

Status	Causes	Solutions
The lamp does not turn off.  Flashing interval: 2 seconds	The projector has an internal malfunction.	Disconnect the power cord, wait a while, and then turn on the projector again. If the problem cannot be resolved, contact your service representative.
The projector turned off during operation, or it does not turn on.  Flashing interval: 1 second	The lamp cover is not installed correctly.	Disconnect the power cord, and reinstall the lamp cover correctly. For details of how to install the lamp cover, see "Replacing the Lamp", Operating Instructions.
"Temperature Error" was displayed, and the projector turned off during operation. 	<ul style="list-style-type: none"> <li>• The interior has overheated.</li> <li>• The projector is being used in a high-temperature environment.</li> </ul>	Place the projector so that the intake and exhaust vents are not blocked. Disconnect the power cord, wait a while, and then turn on the projector again.
"Fan Error" was displayed, and the projector turned off during operation. 	The cooling fan in the projector has malfunctioned.	Disconnect the power cord, and contact your service representative.
"Installation Error" was displayed, and the projector turned off during operation, or it does not turn on. 	The projector's angle is too great.	Place the projector at a proper angle, and then turn it on again.

#### Note

- "🔴" means the indicator is flashing.