


Mizar-PJ1

The parts catalog has been modified
See Y070 RTB 2

Also see Y093 RTB 1 and 2





PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1. Projector 1	1 P
2. Projector 2	3 P
3. Parts Index	5 P

1. Projector 1




1. Projector 1

Index No.	Part No.	Description	Q'ty Per Assembly
1	Y0421062	ADJUSTING PIN:RUBBER FOOT:M3:52.8VH04H001	2
2	Y0421063	ADJUSTING PIN:RUBBER FOOT:M4:52.8VH06H001	1
3	Y0583050	OPTICS SECTION:MERCURY LAMP:SP0000 (WX5460NA/X5460NA/X5460EU)	1
3	Y0583055	OPTICS SECTION:MERCURY LAMP:CHN:SP0000 (WX5460EU/WX5460CHN/X5460CHN/K5600CHN/K5200CHN)	1
4	Y0581155	COVER:MERCURY LAMP:WHITE:EXP:SP0000 (WX5460NA/WX5460EU/WX5460CHN/X5460NA/X5460EU/X5460CHN)	1
4	Y0601155	COVER:MERCURY LAMP:BLACK:EXP:SP0000 (K5600CHN/K5200CHN)	1
5	Y0421250	COVER:IO:51.8VH04H003	1
6	Y0581255	SEAL:IO:12:EXP:SP0000	1
7	Y0581651	COVER:UPPER:WHITE:NA/EU:SP0000 (WX5460NA/X5460NA/X5460EU)	1
7	Y0581751	COVER:UPPER:WHITE:CHN:SP0000 (WX5460EU/WX5460CHN/X5460CHN/K5200CHN)	1
7	Y0601751	COVER:UPPER:BLACK:CHN:SP0000 (K5600CHN)	1
8	Y0421671	KEY:OPERATION SUB-UNIT:WHITE:EXP:51.8VH26G051 (WX5460NA/WX5460CHN/WX5460EU/X5460NA/X5460EU/X5460CHN/K5200CHN)	1
8	Y0441671	KEY:OPERATION SUB-UNIT:BLACK:EXP:51.8VH26G041 (K5600CHN)	1
9	Y0421673	KEY:ENTER:WHITE:EXP:51.8VH27G041 (WX5460NA/WX5460CHN/WX5460EU/X5460NA/X5460EU/X5460CHN/K5200CHN)	1
9	Y0441673	KEY:ENTER:BLACK:EXP:51.8VH27G001 (K5600CHN)	1

Index No.	Part No.	Description	Q'ty Per Assembly
10	Y0421581	PCB:OPERATION SUB-UNIT:80.8WQ03G002:ASS'Y	1
11	Y0425151	HARNES:FFC:OPERATION SUB-UNIT:42.00304G101	1
12	Y0421561	LEVER:ZOOM:WHITE:51.8VH12H021 (WX5460NA/WX5460CHN/WX5460EU/X5460NA/X5460EU/X5460CHN/K5200CHN)	1
12	Y0441561	LEVER:ZOOM:BLACK:51.8VH12H001 (K5600CHN)	1
13	Y0206084	CABLE:RGB:42.00200G105	1
14	Y0426081	RIMOTE CONTROL:EXP:45.8YW01G001	1
15	Y0206076	POWER SUPPLY CORD:NA:42.50115G001 (WX5460NA/X5460NA)	1
15	Y0206077	POWER SUPPLY CORD:EU (X5460EU)	1
15	Y0206078	POWER SUPPLY CORD:CHN:42.81004G001 (WX5460EU/WX5460CHN/X5460CHN/K5600CHN/K5200CHN)	1
16	Y0426085	SOFT CASE:SP0000	1
17	Y0586072	CD-ROM:EXP:SP0000:ASS'Y (X5460NA/X5460EU)	1
17	Y0586074	CD-ROM:CHN:SP0000:ASS'Y (WX5460EU/WX5460CHN/X5460CHN/K5600CHN/K5200CHN)	1
18	Y0586053	INSTALLATION PROCEDURE:NA/EU:SP0000 (X5460NA/X5460EU)	1
18	Y0586055	INSTALLATION PROCEDURE:CHN:SP0000 (WX5460EU/WX5460CHN/X5460CHN/K5600CHN/K5200CHN)	1
101	04523008P	BINDING SELF-TAPPING SCREW:3X8	
102	04523006P	TAPPING SCREW - M3X6	

2. Projector 2



3

[illegible]

3. Parts Index

Part No.	Description	Page and Index No.
03130040N	SCREW:M3X4	2 - 101
04523006P	TAPPING SCREW - M3X6	1 - 102
04523008P	BINDING SELF-TAPPING SCREW:3X8	1 - 101
Y0206076	POWER SUPPLY CORD:NA:42.50115G001 (WX5460NA/X5460NA)	1 - 15
Y0206077	POWER SUPPLY CORD:EU (X5460EU)	1 - 15
Y0206078	POWER SUPPLY CORD:CHN:42.81004G001 (WX5460EU/WX5460CHN/X5460CHN/K5600CHN/K5200CHN)	1 - 15
Y0206084	CABLE:RGB:42.00200G105	1 - 13
Y0421051	BASE:PRINTING:75.8VH02G062	2 - 17
Y0421062	ADJUSTING PIN:RUBBER FOOT:M3:52.8VH04H001	1 - 1
Y0421063	ADJUSTING PIN:RUBBER FOOT:M4:52.8VH06H001	1 - 2
Y0421250	COVER:IO:51.8VH04H003	1 - 5
Y0421561	LEVER:ZOOM:WHITE:51.8VH12H021(WX5460NA/WX5460CHN/ WX5460EU/X5460NA/X5460EU/X5460CHN/K5200CHN)	1 - 12
Y0421581	PCB:OPERATION SUB-UNIT:80.8WQ03G002:ASS'Y	1 - 10

Part No.	Description	Page and Index No.
Y0421610	CAP:LENS:23.8QG01G001	2 - 9
Y0421671	KEY:OPERATION SUB-UNIT:WHITE:EXP:51.8VH26G051 (WX5460NA/WX5460CHN/ WX5460EU/X5460NA/X5460EU/X5460CHN/K5200CHN)	1 - 8
Y0421673	KEY:ENTER:WHITE:EXP:51.8VH27G041 (WX5460NA/WX5460CHN/WX5460EU/X5460NA/ X5460EU/X5460CHN/K5200CHN)	1 - 9
Y0422156	PUSH SWITCH:SENSOR:COVER:MERCURY LAMP:75.87U02G001	2 - 3
Y0422158	TAPE:HOUSING:MERCURY LAMP:SP0000	2 - 13
Y0422163	WIRE:FIX:HARNESS:FAN:SP0000	2 - 16
Y0422170	SHEET:HIGH TEMPERATURE:HOUSING:SP0000	2 - 14
Y0423123	OPTICAL FILTER:CW:23.8QJ19G002	2 - 6
Y0423125	PCB:SENSOR:CW:80.8VH04G002	2 - 7
Y0423261	RING:FOCUS:WHITE:51.8VH14H022 (X5460NA/X5460CHN/X5460EU/K5200CHN)	2 - 11
Y0425151	HARNESS:FFC:OPERATION SUB-UNIT:42.00304G101	1 - 11
Y0425153	HARNESS:BALLAST:42.00425G001	2 - 12
Y0426081	RIMOTE CONTROL:EXP:45.8YW01G001	1 - 14

Part No.	Description	Page and Index No.
Y0426085	SOFT CASE:SP0000	1 - 16
Y0441561	LEVER:ZOOM:BLACK:51.8VH12H001 (K5600CHN)	1 - 12
Y0441671	KEY:OPERATION SUB-UNIT:BLACK:EXP:51.8VH26G041 (K5600CHN)	1 - 8
Y0441673	KEY:ENTER:BLACK:EXP:51.8VH27G001 (K5600CHN)	1 - 9
Y0443263	RING:FOCUS:WXGA:BLACK:SP0000(K5600CHN)	2 - 11
Y0581083	SPEAKER:SP0000	2 - 1
Y0581155	COVER:MERCURY LAMP:WHITE:EXP:SP0000(WX5460NA/WX5460EU/ WX5460CHN/X5460NA/X5460EU/X5460CHN)	1 - 4
Y0581255	SEAL:IO:12:EXP:SP0000	1 - 6
Y0581651	COVER:UPPER:WHITE:NA/EU:SP0000 (WX5460NA/X5460NA/X5460EU)	1 - 7
Y0581751	COVER:UPPER:WHITE:CHN:SP0000 (WX5460EU/WX5460CHN/X5460CHN/K5200CHN)	1 - 7
Y0582050	FAN:MERCURY LAMP:SP0000	2 - 2
Y0582162	FAN:MM75X25:SP0000	2 - 4
Y0582250	FAN:DMD:DIA50X20:SP0000	2 - 15

Part No.	Description	Page and Index No.
Y0583050	OPTICS SECTION:MERCURY LAMP:SP0000 (WX5460NA/X5460NA/X5460EU)	1 - 3
Y0583055	OPTICS SECTION:MERCURY LAMP:CHN:SP0000 (WX5460EU/WX5460CHN/X5460CHN/K5600CHN/ K5200CHN)	1 - 3
Y0583100	OPTICS SECTION:SP0000 (WX5460NA/WX5460CHN/WX5460EU/K5600CHN)	2 - 5
Y0583130	THERMOSTAT:SP0000	2 - 8
Y0585055	POWER SUPPLY UNIT:BALLAST:SP0000	2 - 10
Y0586053	INSTALLATION PROCEDURE:NA/EU:SP0000 (X5460NA/X5460EU)	1 - 18
Y0586055	INSTALLATION PROCEDURE:CHN:SP0000 (WX5460EU/WX5460CHN/X5460CHN/K5600CHN/K5200CHN)	1 - 18
Y0586072	CD-ROM:EXP:SP0000:ASS'Y(X5460NA/X5460EU)	1 - 17
Y0586074	CD-ROM:CHN:SP0000:ASS'Y (WX5460EU/WX5460CHN/X5460CHN/K5600CHN/K5200CHN)	1 - 17
Y0593100	OPTICS SECTION:MIZAR-PJ1X:SP0000 (X5460CHN/X5460NA/X5460EU/K5200CHN)	2 - 5
Y0601155	COVER:MERCURY LAMP:BLACK:EXP:SP0000 (K5600CHN/K5200CHN)	1 - 4
Y0601751	COVER:UPPER:BLACK:CHN:SP0000 (K5600CHN)	1 - 7