


RICOH PJ WXL5670
RICOH PJ WUL5670
RICOH PJ LW5000
RICOH PJ LU5000
RICOH PJ LX550

PARTS CATALOG


This catalog gives the numbers and names of parts on this machine.

1. Projector 1	1 P
2. Projector 2	3 P
3. Parts Index.....	5 P

1. Projector 1



Accessories




1. Projector 1

Index No.	Part No.	Description	Q'ty Per Assembly
1	Y0946084	CABLE:RGB:WHITE:42.00200G115 (WXL5670/WUL5670/LW5000/LU5000)	1
1	Y0206084	CABLE:RGB:42.00200G105 (LX550)	1
2	Y0A41020	ADJUSTING PIN:RUBBER FOOT:52.8ZC12H002	1
3	Y0206076	POWER SUPPLY CORD:NA:42.00102G000:ASS'Y (WXL5670/WUL5670)	1
3	Y0206077	POWER SUPPLY CORD:EU:42.00120G011 (WXL5670/WUL5670)	1
3	Y0A46078	POWER SUPPLY CORD:CHN:42.81004G011 (WXL5670/WUL5670/LW5000/LU5000)	1
3	Y0206078	POWER SUPPLY CORD:CHN:42.81004G001 (LX550)	1
4	Y0AW1181	COVER:FRONT:NA/EU:75.71G02G071 (WXL5670/WUL5670)	1
4	Y0B41181	COVER:FRONT:CHN:75.71G02G061 (WXL5670/LW5000)	1
4	Y0B51181	COVER:FRONT:CHN:75.71G02G062 (WUL5670/LU5000)	1
4	Y0B71181	COVER:FRONT:CHN:75.71G02G051 (LX550)	1
5	Y0B45001	PCB:MAIN CONTROL BOARD:80.77L01G001 (WXL5670/LW5000)	1
5	Y0B55001	PCB:MAIN CONTROL BOARD:80.77M01G001 (WUL5670/LU5000)	1
5	Y0B75001	PCB:MAIN CONTROL BOARD:80.78F01G001 (LX550)	1
6	Y0AW1123	COVER:UPPER:NA/EU:75.77M01H001 (WXL5670/WUL5670)	1
6	Y0B51123	COVER:UPPER:CHN:75.77M01H011 (WXL5670/WUL5670/LW5000/LU5000)	1
6	Y0B71123	COVER:UPPER:CHN:75.77M01H021 (LX550)	1

Index No.	Part No.	Description	Q'ty Per Assembly
7	Y0B51183	COVER:IOB:70.77L20GR01 (WXL5670/WUL5670/LW5000/LU5000)	1
7	Y0B71183	COVER:IOB:70.78F20GR01 (LX550)	1
8	Y0B51187	COVER:LEFT:70.77C15GR01 (WXL5670/WUL5670/LW5000/LU5000)	1
8	Y0B71187	COVER:LEFT:70.76J16GR01 (LX550)	1
9	Y0B51201	COVER:RIGHT:51.71G06H011 (WXL5670/WUL5670/LW5000/LU5000)	1
9	Y0B71201	COVER:RIGHT:51.71G06H001 (LX550)	1
10	Y0B55010	PCB:CONTROL BOARD:80.75C12G001	1
11	Y0B55045	HARNESS:RS232C:42.004GXG002	1
12	Y0B55046	HARNESS:ECP:42.004FQG001	1
13	Y0B55400	TEMPERATURE SENSOR:80.8HM06G001	1
14	Y0B55403	PCB:OPTICAL FILTER:80.79113G001	1
15	Y0B55404	PCB:SENSOR:INFRARED:80.71Q05G001	1
16	Y0B55406	PCB:OPERATION KEY PAD:80.71G03G001	1
17	Y0AW6012	CD-ROM:NA/EU:36.77M02G001 (WXL5670/WUL5670)	1
17	Y0B56012	CD-ROM:CHN:36.77M03G001 (WXL5670/WUL5670/LW5000/LU5000/LX550)	1
18	Y0AS6022	REMOTE CONTROL:NA/EU:45.76U01G001 (WXL5670/WUL5670)	1
18	Y0B56021	REMOTE CONTROL:CHN:45.76U01G002 (WXL5670/WUL5670/LW5000/LU5000/LX550)	1
19	Y0B55401	PCB:USB:80.71Q14G001	1

2. Projector 2



2. Projector 2

[illegible][illegible]

3. Parts Index

Part No.	Description	Page and Index No.
Y0206076	POWER SUPPLY CORD:NA:42.00102G000:ASS'Y (WXL5670/WUL5670)	2 - 3
Y0206077	POWER SUPPLY CORD:EU:42.00120G011 (WXL5670/WUL5670)	2 - 3
Y0206078	POWER SUPPLY CORD:CHN:42.81004G001 (LX550)	2 - 3
Y0206084	CABLE:RGB:42.00200G105 (LX550)	2 - 1
Y0946084	CABLE:RGB:WHITE:42.00200G115 (WXL5670/WUL5670/LW5000/LU5000)	2 - 1
Y0A41020	ADJUSTING PIN:RUBBER FOOT:52.8ZC12H002	2 - 2
Y0A46078	POWER SUPPLY CORD:CHN:42.81004G011 (WXL5670/WUL5670/LW5000/LU5000)	2 - 3
Y0AS6022	REMOTE CONTROL:NA/EU:45.76U01G001 (WXL5670/WUL5670)	2 - 18
Y0AW1123	COVER:UPPER:NA/EU:75.77M01H001 (WXL5670/WUL5670)	2 - 6
Y0AW1181	COVER:FRONT:NA/EU:75.71G02G071 (WXL5670/WUL5670)	2 - 4
Y0AW6012	CD-ROM:NA/EU:36.77M02G001 (WXL5670/WUL5670)	2 - 17
Y0B41181	COVER:FRONT:CHN:75.71G02G061 (WXL5670/LW5000)	2 - 4
Y0B43001	ENGINE:OPTICS:70.77L22GR01 (WXL5670/LW5000)	4 - 1
Y0B45001	PCB:MAIN CONTROL BOARD:80.77L01G001 (WXL5670/LW5000)	2 - 5
Y0B51010	SPEAKER:10W:49.71G02G001	4 - 2
Y0B51123	COVER:UPPER:CHN:75.77M01H011 (WXL5670/WUL5670/LW5000/LU5000)	2 - 6
Y0B51181	COVER:FRONT:CHN:75.71G02G062 (WUL5670/LU5000)	2 - 4
Y0B51183	COVER:IOB:70.77L20GR01 (WXL5670/WUL5670/LW5000/LU5000)	2 - 7

Part No.	Description	Page and Index No.
Y0B51185	COVER:BASE:70.77L21GR01 (WXL5670/WUL5670/LW5000/LU5000)	4 - 12
Y0B51187	COVER:LEFT:70.77C15GR01 (WXL5670/WUL5670/LW5000/LU5000)	2 - 8
Y0B51201	COVER:RIGHT:51.71G06H011 (WXL5670/WUL5670/LW5000/LU5000)	2 - 9
Y0B52030	FAN:AXIAL:MM92:49.78801G002	4 - 3
Y0B52040	FAN:SIROCCO:49.79201G001	4 - 4
Y0B53001	ENGINE:OPTICS:70.77M20GR01 (WUL5670/LU5000)	4 - 1
Y0B53010	OPTICAL FILTER:CW:70.77C12GR01	4 - 5
Y0B53400	LIGHT SOURCE:LD UNIT:70.77C13GR01	4 - 6
Y0B53401	OPTICS SENSOR:ENGINE:80.79104G001	4 - 7
Y0B55001	PCB:MAIN CONTROL BOARD:80.77M01G001 (WUL5670/LU5000)	2 - 5
Y0B55010	PCB:CONTROL BOARD:80.75C12G001	2 - 10
Y0B55030	POWER SUPPLY UNIT:75.71QP1G001	4 - 8
Y0B55045	HARNESS:RS232C:42.004GXG002	2 - 11
Y0B55046	HARNESS:ECP:42.004FQG001	2 - 12
Y0B55400	TEMPERATURE SENSOR:80.8HM06G001	2 - 13
Y0B55401	PCB:USB:80.71Q14G001	2 - 19
Y0B55402	PCB:LASER DIODE DRIVER:80.79111G002	4 - 9
Y0B55403	PCB:OPTICAL FILTER:80.79113G001	2 - 14
Y0B55404	PCB:SENSOR:INFRARED:80.71Q05G001	2 - 15
Y0B55405	POSITIONING SENSOR:80.71G07G001	4 - 10
Y0B55406	PCB:OPERATION KEY PAD:80.71G03G001	2 - 16
Y0B55500	PUSH SWITCH:SAFETY SWITCH:75.8AA15G001	4 - 11
Y0B56012	CD-ROM:CHN:36.77M03G001 (WXL5670/WUL5670/LW5000/LU5000/LX550)	2 - 17
Y0B56021	REMOTE CONTROL:CHN:45.76U01G002 (WXL5670/WUL5670/LW5000/LU5000/LX550)	2 - 18
Y0B71123	COVER:UPPER:CHN:75.77M01H021 (LX550)	2 - 6

