

Model Regulus-PJ2
(Y006/Y007/Y008/Y009/Y010)

Model Regulus-PJ2 (Y006/Y007/Y008/Y009/Y010)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1. Projector Unit (Y006-Y010)	2
2. Interior (Y006-Y010)	4
3. Decals and Accessories (Y006-Y010)	6
Parts Index	9

April 1, 2011

1.Exterior (Y006-Y010)




1.Exterior (Y006-Y010)

Index No.	Part No.	Description	Q'ty Per Assembly
1	Y002 0136	Cover:Open And Close:Mercury Lamp:Ass'y	1
2	Y006 1321	Cover:Front:Y006/Y009:Sub-ass'y	1
2	Y007 1321	Cover:Front:Y007/Y008/Y010:Sub-ass'y	1
3	Y006 1349	Cover:Upper:Ass'y:Y006/Y009	1
3	Y007 1349	Cover:Upper:Ass'y:Y007/Y008/Y010	1
4	Y006 1300	Cover:Rear:Sub-ass'y:Y006/Y009	1
4	Y007 1300	Cover:Rear:Sub-ass'y:Y007/Y010	1
4	Y008 1300	Cover:Rear:Sub-ass'y (Y008)	1
5	Y001 1301	Fan:Mercury Lamp	1
6	Y001 1302	Speaker:REG-1A	1
7	Y001 0138	Cap:Lens:Ass'y:Y006/Y009	1
7	Y002 0138	Cap:Lens:Ass'y (Y007/Y008)	1
7	Y005 0138	Cap:Lens:Y010:Ass'y	1
8	Y001 0112	Stand:Ass'y	1

Index No.	Part No.	Description	Q'ty Per Assembly

2.Interior (Y006-Y010)





2.Interior (Y006-Y010)



Index No.	Part No.	Description	Q'ty Per Assembly
1	Y001 1162	Fan:Power Supply Unit	1
2	Y001 1143	Fan:Right:Optical Unit	1
3	Y001 1144	Fan:Left:Optical Unit	1
4	Y006 5100	Power Supply Unit	1
5	Y006 5700	PCB:Main (Y006)	1
5	Y007 5700	PCB:Main (Y007)	1
5	Y008 5700	PCB:Main (Y008)	1
5	Y009 5700	PCB:Main (Y009)	1
5	Y010 5700	PCB:Main (Y010)	1
6	Y001 5300	Power Supply Unit:Ballast	1
7	Y007 5723	PCB:Remocon	1
8	Y001 0310	Optical Unit:Y006:Ass'y	1
8	Y004 0310	Optical Unit:Y009:Ass'y	1
8	Y005 0310	Optical Unit:Y010:Ass'y	1
8	Y007 0310	Optical Unit:Y007/Y008:Ass'y	1
9	Y001 1501	Thermostat:Mercury Lamp	1
10	Y001 5101	Harness:PSU-PCB	1
11	Y001 5301	Harness:Ballast-PSU	1
12	Y001 5302	Harness:Ballast-PCB	1
13	Y001 5501	Harness:PCB-Remocon	1
14	Y006 1141	Temperature Sensor:Duct:Optical Unit	1

Index No.	Part No.	Description	Q'ty Per Assembly

3.Decals and Accessories (Y006-Y010)

1			2			3			4			5															
6	 • Remove this screw when replacing the lamp. • Diese Schraube entfernen, wenn Sie die Lampe auswechseln. • Retirer cette vis lors du remplacement de la lampe. • Retire este tornillo al reemplazar la lámpara. • Remova este parafuso quando substituir a lâmpada. • 更換灯管时拆除该螺丝。・ランプ交換時は、このネジを外してください。						8							9													
7																											
10							11							12							13						
14			15			16			17			18			19			20			101						

3.Decals and Accessories (Y006-Y010)

Index No.	Part No.	Description	Q'ty Per Assembly
1	J012 1508	Plate:Logo:RIC	1
2	Y006 8211	Decal:Caution:Base:EXP	1
3	Y006 8212	Decal:Lamp:Exchangeable:EXP	1
4	Y006 8213	Decal:H-temp Warning:EXP	1
5	Y006 8215	Decal:Caution:Screw:EXP	1
6	Y006 8214	Decal:Caution:Lens	1
7	Y002 8214	Decal:Windows:Sticker	1
8	Y006 8217	Decal:Lens:Front:EXP	1
9	Y001 6161	Cable:RGB	1
10	Y006 6161	Power Supply Cord:NA	1
10	Y006 6162	Power Supply Cord:230V	1
11	Y001 6140	Remote Control (Y006/Y008/Y009)	1
11	Y002 6140	Remote Control:Y007/Y010	1
12	Y002 6141	Remote Control:Receiver:Y007/Y010	1
13	Y001 8120	Soft Case:Y006/Y009	1
13	Y002 8120	Soft Case:Y007/Y008/Y010	1
14	Y001 4501	Binding Head Screw:M2.6x6:Hard	9
15	Y001 4502	Binding Head Tapping Screw:M2.6x6	1
15	Y001 4503	Binding Head Tapping Screw:M2.6x12	4
15	Y001 4505	Binding Head Tapping Screw:M2x6	2
16	Y001 4506	Binding Head Tapping Screw:M2.6x8:Black	8
17	Y001 4512	Binding Head Screw:M3x6:Hard	2
18	Y001 4510	Binding Head Tapping Screw:M2.6x20	1
19	Y001 4513	Binding Head Tapping Screw:M3x8	1
20	Y001 4504	Tapping Screw:Flat Point:M5x10	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	1607 0892	Ferrite Core - Zcat1518-0730	

Parts Index

Parts Index

Part No.	Description	Page and Index No.
Y006 1141	Temperature Sensor:Duct:Optical Unit	5 - 14
Y006 1300	Cover:Rear:Sub-ass'y:Y006/Y009	3 - 4
Y006 1321	Cover:Front:Y006/Y009:Sub-ass'y	3 - 2
Y006 1349	Cover:Upper:Ass'y:Y006/Y009	3 - 3
Y006 5100	Power Supply Unit	5 - 4
Y006 5700	PCB:Main (Y006)	5 - 5
Y006 6161	Power Supply Cord:NA	7 - 10
Y006 6162	Power Supply Cord:230V	7 - 10
Y006 8211	Decal:Caution:Base:EXP	7 - 2
Y006 8212	Decal:Lamp:Exchangeable:EXP	7 - 3
Y006 8213	Decal:H-temp Warning:EXP	7 - 4
Y006 8214	Decal:Caution:Lens	7 - 6
Y006 8215	Decal:Caution:Screw:EXP	7 - 5
Y006 8217	Decal:Lens:Front:EXP	7 - 8

Part No.	Description	Page and Index No.
J012 1508	Plate:Logo:RIC	7 - 1

Part No.	Description	Page and Index No.
Y001 0112	Stand:Ass'y	3 - 8
Y001 0138	Cap:Lens:Ass'y:Y006/Y009	3 - 7
Y001 0310	Optical Unit:Y006:Ass'y	5 - 8
Y001 1143	Fan:Right:Optical Unit	5 - 2
Y001 1144	Fan:Left:Optical Unit	5 - 3
Y001 1162	Fan:Power Supply Unit	5 - 1
Y001 1301	Fan:Mercury Lamp	3 - 5
Y001 1302	Speaker:REG-1A	3 - 6
Y001 1501	Thermostat:Mercury Lamp	5 - 9
Y001 4501	Binding Head Screw:M2.6x6:Hard	7 - 14
Y001 4502	Binding Head Tapping Screw:M2.6x6	7 - 15
Y001 4503	Binding Head Tapping Screw:M2.6x12	7 - 15
Y001 4504	Tapping Screw:Flat Point:M5x10	7 - 20
Y001 4505	Binding Head Tapping Screw:M2x6	7 - 15
Y001 4506	Binding Head Tapping Screw:M2.6x8:Black	7 - 16
Y001 4510	Binding Head Tapping Screw:M2.6x20	7 - 18
Y001 4512	Binding Head Screw:M3x6:Hard	7 - 17
Y001 4513	Binding Head Tapping Screw:M3x8	7 - 19
Y001 5101	Harness:PSU-PCB	5 - 10
Y001 5300	Power Supply Unit:Ballast	5 - 6
Y001 5301	Harness:Ballast-PSU	5 - 11
Y001 5302	Harness:Ballast-PCB	5 - 12
Y001 5501	Harness:PCB-Remocon	5 - 13
Y001 6140	Remote Control (Y006/Y008/Y009)	7 - 11
Y001 6161	Cable:RGB	7 - 9
Y001 8120	Soft Case:Y006/Y009	7 - 13
Y002 0136	Cover:Open And Close:Mercury Lamp:Ass'y	3 - 1
Y002 0138	Cap:Lens:Ass'y (Y007/Y008)	3 - 7
Y002 6140	Remote Control:Y007/Y010	7 - 11
Y002 6141	Remote Control:Receiver:Y007/Y010	7 - 12
Y002 8120	Soft Case:Y007/Y008/Y010	7 - 13
Y002 8214	Decal:Windows:Sticker	7 - 7
Y004 0310	Optical Unit:Y009:Ass'y	5 - 8
Y005 0138	Cap:Lens:Y010:Ass'y	3 - 7
Y005 0310	Optical Unit:Y010:Ass'y	5 - 8

Part No.	Description	Page and Index No.
Y007 0310	Optical Unit:Y007/Y008:Ass'y	5 - 8
Y007 1300	Cover:Rear:Sub-ass'y:Y007/Y010	3 - 4
Y007 1321	Cover:Front:Y007/Y008/Y010:Sub-ass'y	3 - 2
Y007 1349	Cover:Upper:Ass'y:Y007/Y008/Y010	3 - 3
Y007 5700	PCB:Main (Y007)	5 - 5
Y007 5723	PCB:Remocon	5 - 7
Y008 1300	Cover:Rear:Sub-ass'y (Y008)	3 - 4
Y008 5700	PCB:Main (Y008)	5 - 5
Y009 5700	PCB:Main (Y009)	5 - 5
Y010 5700	PCB:Main (Y010)	5 - 5
1607 0892	Ferrite Core - Zcat1518-0730	7 - 101