RICOH

Notes for Users

This supplement includes notes for the Operating Instructions provided with the projector.

The following settings have been added to [Security] in [Network Application Settings].

Item	Default
Application Authentication	Off
When projecting images using an application installed on a smart device, specify whether or not to enter the application password.	
Application Password Enter the application password up to 32 characters.	(blank)

VNote

Application Authentication setting may not be available depending on the application you are using. See the application's help for details.