



PJ WX5150/PJ WX5140/PJ X5140 (Y018/Y019/Y023) PARTS CATALOG

First edition, April 2012

Ricoh Company, LTD.

Input Document Property ModelCode

PARTS CATALOG


This catalog gives the numbers and names of parts on this machine.

CONTENTS

1. Projector 1 (Y018/Y019/Y023)	2
2. Projector 2 (Y018/Y019/Y023)	4
Parts Index	8


April 25, 2012

1.Projector 1 (Y018/Y019/Y023)





2.Projector 2 (Y018/Y019/Y023)



2.Projector 2 (Y018/Y019/Y023)

Index No.	Part No.	Description	Q'ty Per Assembly
1	Y018 5057	Power Pack:(Y018)	1
1	Y019 5057	Power Pack:(Y019/Y023)	1
2	Y018 5065	Wire:Mercury Lamp	1
3	Y018 5067	Wire:Control:Driver	1
4	Y018 2702	Pan Head Screw:M3x5	13
5	Y018 5083	PCB:Control:(Y018)	1
5	Y019 5083	PCB:Control:(Y019)	1
5	Y023 5083	PCB:Control:(Y023)	1
6	Y018 5096	Ground Plate:Base:Upper	7
7	Y018 5052	Power Supply Unit:(Y018)	1
7	Y019 5052	Power Supply Unit:(Y019/Y023)	1
8	Y018 5074	Safety Switch	1
9	Y018 2071	Fan:Axial:Optical Unit:(Y018)	1
10	Y018 2079	Case:Lamp	1
11	Y018 2055	Blower:Lamp	1
12	Y018 2060	Fan:Cooling:(Y018)	1
13	Y018 1211	Rubber Foot:Front	1
14	Y018 1210	Rubber Foot:Rear	2
15	Y018 1061	Cover:Lower:(Y018)	1
15	Y019 1061	Cover:Lower:(Y019/Y023)	1
16	Y018 3052	Optical Unit:Color:Wheel	1
17	Y018 2711	Pan Head Screw:M2.6x6	5
18	Y018 5094	Ground Plate:Base:Lower	1
19	Y018 3051	Optical Unit:(Y018)	1
19	Y019 3051	Optical Unit:(Y019)	1
19	Y023 3051	Optical Unit:(Y023)	1
			

Index No.	Part No.	Description	Q'ty Per Assembly

Parts Index

Parts Index

Part No.	Description	Page and Index No.
Y018 1061	Cover:Lower:(Y018)	5 - 15
Y018 1064	Cap:Lens	3 - 12
Y018 1083	Cover:Rear:(Y018)	3 - 3
Y018 1096	Speaker	3 - 2
Y018 1110	Cover:Front	3 - 11
Y018 1123	Cover:Upper:EXP	3 - 1
Y018 1133	Keytop:EXP	3 - 5
Y018 1134	PCB:Keytop	3 - 6
Y018 1136	Wire:Keytop	3 - 8
Y018 1140	Cover:Lamp:5140	5 - 2
Y018 1140	Cover:Lamp:Ass'y:(Y018)	3 - 19
Y018 1150	Filter:Left:Ass'y:CHN	3 - 17
Y018 1155	Filter:Right:Ass'y:CHN	3 - 18
Y018 1204	Ring:Zoom:(Y018/Y019)	3 - 7
Y018 1206	Holder:Ring:Zoom:(Y018/Y019)	3 - 9
Y018 1210	Rubber Foot:Rear	5 - 14
Y018 1211	Rubber Foot:Front	5 - 13
Y018 2055	Blower:Lamp	5 - 11
Y018 2060	Fan:Cooling:(Y018)	5 - 12
Y018 2071	Fan:Axial:Optical Unit:(Y018)	5 - 9
Y018 2079	Case:Lamp	5 - 10
Y018 2702	Pan Head Screw:M3x5	3 - 10
Y018 2702	Pan Head Screw:M3x5	5 - 4
Y018 2704	Hexagon Head Bolt	3 - 4
Y018 2711	Pan Head Screw:M2.6x6	5 - 17
Y018 3051	Optical Unit:(Y018)	5 - 19
Y018 3052	Optical Unit:Color:Wheel	5 - 16
Y018 5052	Power Supply Unit:(Y018)	5 - 7
Y018 5057	Power Pack:(Y018)	5 - 1
Y018 5067	Wire:Control:Driver	5 - 3
Y018 5074	Safety Switch	5 - 8
Y018 5083	PCB:Control:(Y018)	5 - 5
Y018 5094	Ground Plate:Base:Lower	5 - 18
Y018 5096	Ground Plate:Base:Upper	5 - 6
Y018 6082	Rimote Control:EXP	3 - 16

Part No.	Description	Page and Index No.
Y018 6090	Soft Case	3 - 14
Y019 1061	Cover:Lower:(Y019/Y023)	5 - 15
Y019 1084	Cover:Rear:(Y019)	3 - 3
Y019 1140	Cover:Lamp:5140:(Y019/Y023)	3 - 19
Y019 3051	Optical Unit:(Y019)	5 - 19
Y019 5052	Power Supply Unit:(Y019/Y023)	5 - 7
Y019 5057	Power Pack:(Y019/Y023)	5 - 1
Y019 5083	PCB:Control:(Y019)	5 - 5
Y023 1085	Cover:Rear:(Y023)	3 - 3
Y023 1204	Ring:Zoom:(Y023)	3 - 7
Y023 1206	Holder:Ring:Zoom:(Y023)	3 - 9
Y023 3051	Optical Unit:(Y023)	5 - 19
Y023 5083	PCB:Control:(Y023)	5 - 5

Part No.	Description	Page and Index No.
Y020 6076	Power Supply Cord:NA	3 - 13
Y020 6077	Power Supply Cord:EU	3 - 13
Y020 6078	Power Supply Cord:CHN	3 - 13
Y020 6079	Cable:RGB	3 - 15

Part No.	Description	Page and Index No.