

Model PJ X5260  
( Y017 )

## **Model PJ X5260 ( Y017 )**


### **PARTS CATALOG**

This catalog gives the numbers and names of parts on this machine.

|                            |           |
|----------------------------|-----------|
| 1.Projector 1 (Y017) ..... | 2         |
| 2.Projector 2 (Y017) ..... | 4         |
| 3.Projector 3 (Y017) ..... | 6         |
| <b>Parts Index</b> .....   | <b>11</b> |

**March 1, 2012**

## 1.Projector 1 (Y017)




## 1.Projector 1 (Y017)

| Index No. | Part No.  | Description                  | Q'ty Per Assembly |
|-----------|-----------|------------------------------|-------------------|
| 1         | Y017 1143 | Cover:Lamp:EXP:Printing      | 1                 |
| 2         | Y017 2700 | Pan Head Screw:M3x6          | 13                |
| 3         | Y017 1111 | Cover:Upper:EXP:Printing     | 1                 |
| 4         | Y017 1210 | Cover:Sensor:IR:UpperR       | 1                 |
| 5         | Y017 1116 | Keytop:Printing              | 1                 |
| 6         | Y017 1125 | PCB:Keyboard Switch          | 1                 |
| 7         | Y017 1121 | Keytop:Enter:EXP             | 1                 |
| 8         | Y017 1126 | Wire:Control:Keyboard Switch | 1                 |
| 9         | Y017 1077 | Filter                       | 1                 |
| 10        | Y017 2710 | Pan Head Screw:M3x8          | 2                 |
| 11        | Y017 1205 | Ring:Zoom                    | 1                 |
| 12        | Y017 1206 | Holder:Ring                  | 1                 |
| 13        | Y017 1080 | Cover:Front                  | 1                 |
| 14        | Y018 1064 | Cap:Lens                     | 1                 |
| 15        | Y018 6090 | Soft Case                    | 1                 |
| 16        | Y018 6082 | Remote Control:EXP           | 1                 |
| 17        | Y020 6076 | Power Supply Cord:NA         | 1                 |
| 17        | Y020 6077 | Power Supply Cord:EU         | 1                 |
| 18        | Y020 6079 | Cable:RGB                    | 1                 |

| Index No. | Part No. | Description | Q'ty Per Assembly |
|-----------|----------|-------------|-------------------|
|           |          |             |                   |

## 2.Projector 2 (Y017)




## 2.Projector 2 (Y017)

| Index No. | Part No.  | Description                                  | Q'ty Per Assembly |
|-----------|-----------|----------------------------------------------|-------------------|
| 1         | Y017 5082 | Wire:Power Source:MB                         | 1                 |
| 2         | Y017 2700 | Pan Head Screw:M3x6                          | 21                |
| 3         | Y017 5091 | Power Pack                                   | 1                 |
| 4         | Y017 5094 | Wire:Control                                 | 1                 |
| 5         | Y017 5093 | Wire:Power Source:Power PackK                | 1                 |
| 6         | Y017 2703 | Pan Head Screw:Toothed Lock WasherR:<br>M3x6 | 1                 |
| 7         | Y017 5081 | Power Supply Unit                            | 1                 |
| 8         | Y017 5070 | Speaker                                      | 1                 |
| 9         | Y017 5101 | Base:Control:Ass'y                           | 1                 |
| 9         | Y017 5103 | PCB:MB                                       | 1                 |
| 10        | Y017 2709 | Hexagon Head Bolt                            | 8                 |
| 11        | Y017 1095 | Cover:Rear:EXP                               | 1                 |
| 12        | Y017 2706 | Pan Head Screw:Plain Washer:M3x8             | 2                 |
| 13        | Y017 2708 | Pan Head Screw:Toothed Lock Washer:<br>M4x5  | 1                 |
| 14        | Y017 5050 | Power Supply Cord:Ass'y                      | 1                 |
| 15        | Y017 2056 | Fan:Axial:DLP                                | 1                 |
| 16        | Y017 2702 | Pan Head Screw:Plain Washer:M3x26            | 1                 |
| 17        | Y017 5102 | Ground Plate:Upper                           | 1                 |
| 18        | Y017 1070 | Bracket:Base                                 | 1                 |
| 18        | Y017 5100 | Bracket:Base:Base                            | 1                 |
| 19        | Y017 5104 | PCB:IO                                       | 1                 |
| 20        | Y017 5105 | PCB:LAN                                      | 1                 |

| Index No. | Part No. | Description | Q'ty Per Assembly |
|-----------|----------|-------------|-------------------|
|           |          |             |                   |

### 3.Projector 3 (Y017)



### 3.Projector 3 (Y017)

| Index No. | Part No.  | Description               | Q'ty Per Assembly |
|-----------|-----------|---------------------------|-------------------|
| 1         | Y017 5062 | Wire:Mercury Lamp         | 1                 |
| 2         | Y017 5063 | Safety Switch:Lamp        | 1                 |
| 3         | Y017 2065 | Fan:Axial:MM105           | 1                 |
| 4         | Y017 2066 | Cushion:Fan               | 4                 |
| 5         | Y017 2705 | Stepped Screw:M2.6x12     | 4                 |
| 6         | Y017 2704 | Pan Head Screw:M2.6x5     | 2                 |
| 7         | Y017 3052 | Optical Unit:CW           | 1                 |
| 8         | Y017 2700 | Pan Head Screw:M3x6       | 4                 |
| 9         | Y017 3051 | Optical Unit:DLP          | 1                 |
| 10        | Y017 2075 | Thermofuse                | 1                 |
| 11        | Y017 2712 | Stepped Screw:M2.6x33     | 2                 |
| 12        | Y017 2072 | Cushion:Sirocco           | 2                 |
| 13        | Y017 2071 | DC Fan Motor:Sirocco:Lamp | 1                 |
| 14        | Y017 2701 | Pan Head Screw:M2.6x5:BK  | 2                 |
| 15        | Y017 2050 | DC Fan Motor:Sirocco:CW   | 1                 |
| 16        | Y017 1213 | Rubber Foot:FIX           | 1                 |
| 17        | Y017 1062 | Cover:Base:Printing       | 1                 |
| 18        | Y017 1056 | Nut:Rubber Foot           | 3                 |
| 19        | Y017 1212 | Rubber Foot               | 3                 |

| Index No. | Part No. | Description | Q'ty Per Assembly |
|-----------|----------|-------------|-------------------|
|           |          |             |                   |

# Parts Index

## Parts Index

| Part No.  | Description                              | Page and Index No. |
|-----------|------------------------------------------|--------------------|
| Y017 1056 | Nut:Rubber Foot                          | 7 - 18             |
| Y017 1062 | Cover:Base:Printing                      | 7 - 17             |
| Y017 1070 | Bracket:Base                             | 5 - 18             |
| Y017 1077 | Filter                                   | 3 - 9              |
| Y017 1080 | Cover:Front                              | 3 - 13             |
| Y017 1095 | Cover:Rear:EXP                           | 5 - 11             |
| Y017 1111 | Cover:Upper:EXP:Printing                 | 3 - 3              |
| Y017 1116 | Keytop:Printing                          | 3 - 5              |
| Y017 1121 | Keytop:Enter:EXP                         | 3 - 7              |
| Y017 1125 | PCB:Keyboard Switch                      | 3 - 6              |
| Y017 1126 | Wire:Control:Keyboard Switch             | 3 - 8              |
| Y017 1143 | Cover:Lamp:EXP:Printing                  | 3 - 1              |
| Y017 1205 | Ring:Zoom                                | 3 - 11             |
| Y017 1206 | Holder:Ring                              | 3 - 12             |
| Y017 1210 | Cover:Sensor:IR:UpperR                   | 3 - 4              |
| Y017 1212 | Rubber Foot                              | 7 - 19             |
| Y017 1213 | Rubber Foot:FIX                          | 7 - 16             |
| Y017 2050 | DC Fan Motor:Sirocco:CW                  | 7 - 15             |
| Y017 2056 | Fan:Axial:DLP                            | 5 - 15             |
| Y017 2065 | Fan:Axial:MM105                          | 7 - 3              |
| Y017 2066 | Cushion:Fan                              | 7 - 4              |
| Y017 2071 | DC Fan Motor:Sirocco:Lamp                | 7 - 13             |
| Y017 2072 | Cushion:Sirocco                          | 7 - 12             |
| Y017 2075 | Thermofuse                               | 7 - 10             |
| Y017 2700 | Pan Head Screw:M3x6                      | 5 - 2              |
| Y017 2700 | Pan Head Screw:M3x6                      | 7 - 8              |
| Y017 2700 | Pan Head Screw:M3x6                      | 3 - 2              |
| Y017 2701 | Pan Head Screw:M2.6x5:BK                 | 7 - 14             |
| Y017 2702 | Pan Head Screw:Plain Washer:M3x26        | 5 - 16             |
| Y017 2703 | Pan Head Screw:Toothed Lock WasherR:M3x6 | 5 - 6              |
| Y017 2704 | Pan Head Screw:M2.6x5                    | 7 - 6              |
| Y017 2705 | Stepped Screw:M2.6x12                    | 7 - 5              |
| Y017 2706 | Pan Head Screw:Plain Washer:M3x8         | 5 - 12             |
| Y017 2708 | Pan Head Screw:Toothed Lock Washer:M4x5  | 5 - 13             |
| Y017 2709 | Hexagon Head Bolt                        | 5 - 10             |

| Part No.  | Description                   | Page and Index No. |
|-----------|-------------------------------|--------------------|
| Y017 2710 | Pan Head Screw:M3x8           | 3 - 10             |
| Y017 2712 | Stepped Screw:M2.6x33         | 7 - 11             |
| Y017 3051 | Optical Unit:DLP              | 7 - 9              |
| Y017 3052 | Optical Unit:CW               | 7 - 7              |
| Y017 5050 | Power Supply Cord:Ass'y       | 5 - 14             |
| Y017 5062 | Wire:Mercury Lamp             | 7 - 1              |
| Y017 5063 | Safety Switch:Lamp            | 7 - 2              |
| Y017 5070 | Speaker                       | 5 - 8              |
| Y017 5081 | Power Supply Unit             | 5 - 7              |
| Y017 5082 | Wire:Power Source:MB          | 5 - 1              |
| Y017 5091 | Power Pack                    | 5 - 3              |
| Y017 5093 | Wire:Power Source:Power PackK | 5 - 5              |
| Y017 5094 | Wire:Control                  | 5 - 4              |
| Y017 5100 | Bracket:Base:Base             | 5 - 18             |
| Y017 5101 | Base:Control:Ass'y            | 5 - 9              |
| Y017 5102 | Ground Plate:Upper            | 5 - 17             |
| Y017 5103 | PCB:MB                        | 5 - 9              |
| Y017 5104 | PCB:IO                        | 5 - 19             |
| Y017 5105 | PCB:LAN                       | 5 - 20             |

| Part No.  | Description           | Page and Index No. |
|-----------|-----------------------|--------------------|
| Y018 1064 | Cap:Lens              | 3 - 14             |
| Y018 1096 | Speaker               | 5 - 8              |
| Y018 6082 | Rimote Control:EXP    | 3 - 16             |
| Y018 6090 | Soft Case             | 3 - 15             |
| Y020 6076 | Power Supply Cord:NA  | 3 - 17             |
| Y020 6077 | Power Supply Cord:EU  | 3 - 17             |
| Y020 6078 | Power Supply Cord:CHN | 3 - 17             |
| Y020 6079 | Cable:RGB             | 3 - 18             |

| Part No. | Description | Page and Index No. |
|----------|-------------|--------------------|
|          |             |                    |