



1 Preparation

❖ Starting the Machine




2 Starting a Meeting


❖ Selecting the Destination from the Destination List



❖ Searching the Destination from the Destination List




❖ Connecting to an Unregistered Destination





3 What You Can Do

❖ Sharing the Computer Screen



4 Leaving the Meeting



© 2015 Ricoh Co., Ltd.
 Printed in Japan
 EN (GB) EN (US)
 E0A5-7004



E0A57004