

Notes for Users

This machine supports Mopria.

Mopria is a standard that allows an Android device to print over a wireless network. Your Android device will detect Mopria-accessible printers and MFPs automatically on the same network as the device. For more information about Mopria, please visit: <http://mopria.org/how-to-print>.

If no connection can be established by using the following procedure, contact your service representative.

■ Printing with Mopria

Notes on the Print Function

- When performing a print job using Mopria, configure the setting so that User Authentication is not used. For details, see "Administrator Login Method" in the Security Guide manual supplied with the main unit.
- When printing with Mopria, multiple jobs cannot be accepted at a time. After printing a current job, proceed to print the next job.

If you cannot use Mopria, check that IPP and Bonjour are enabled. [Active] is specified as the default. For details about login, see "Administrator Login Method", Security Guide.

Configuration Procedure for Printing using Mopria

1. Log in to Web Image Monitor as a network administrator.
2. Point to [Device Management], and then click [Configuration].
3. Click [IPv4] in [Network].
4. Check that [IPP] is set to [Active].
If [Active] is not selected, select it.
5. Click [OK] to proceed.
6. Click [Bonjour] in [Network].
7. Check that either of [IPv4] or [IPv6] in [Bonjour] is set to [Active].
If [Active] is not selected, select it.
8. Click [OK].



Mopria and the Mopria logo are trademarks of Mopria Alliance, Inc.