

PostScript3 Unit Type M29 (D3DW)
 DataOverwriteSecurity Unit Type M19 (D3BS)
 XPS Direct Print Option Type M29 (D3DW)
 IEEE 1284 Interface Board Type M19 (D3C0)
 File Format Converter Type M19 (D3BR)
 SD Card for Fonts Type D (D641)
 IEEE 802.11a/g/n Interface Unit Type M19 (D3BR)
 USB Device Server Option Type M19 (D3BC)
 Extended USB Board Type M19 (D3BS)

Key Counter Bracket Type M3 (D739)
 OCR Unit Type M13 (D3AC)
 Enhanced Security HDD Option Type M10 (D792)
 NFC Card Reader Type M29 (D3E3)
 External Keyboard Bracket Type M19 (D3BR)
 Optional Counter Interface Unit Type M12 (B870)
 Platen Cover PN2000 (D700)
 Caster Table Type M3 (D178)

PARTS CATALOG


This catalog gives the numbers and names of parts on this machine.

CONTENTS


1. Controller Options 1.....	2 P
2. Controller Options 2.....	4 P
3. Other Options 1.....	6 P
4. Other Options 2.....	8 P
5. Other Options 3.....	10 P
6. Parts Index.....	12 P

1. Controller Options 1


PostScript3 Unit Type M19 (D3DW-05,06,07)




IEEE 1284 Interface Board Type M19 (D3C0-17)




IEEE 802.11a/g/n Interface Unit Type M19 (D3BR-01)
NA/EU/TWN only




DataOverwriteSecurity Unit Type M19
(D3BS-03)




File Format Converter Type M19 (D3BR-04)




USB Device Server Option Type M19 (D3BC-28,29)
NA/EU/AA/KOR/TWN only




XPS Direct Print Option Type M29
(D3DW-25,26,27)



SD Card for FontsType D (D641-54)



Extended USB Board Type M19 (D3BS-01)




1. Controller Options 1


[illegible][illegible]

2. Controller Options 2


Key Counter Bracket Type M3 (D739-09)




NFC Card Reader Type M19 (D3E3-21)



OCR Unit Type M13 (D3AC-23,24,25)



Enhanced Security HDD Option Type M10 (D792-09)
NA/EU only




2. Controller Options 2


[illegible][illegible]

3. Other Options 1

External Keyboard Bracket Type M19 (D3BR-10)



Optional Counter Interface Unit Type M12 (B870-21)




3. Other Options 1

[illegible][illegible]

4. Other Options 2

Platen Cover PN2000 (D700-01)

AA/KOR/TWN/CHN only




4. Other Options 2

[illegible][illegible]

5. Other Options 3

Caster Table Type M3 (D178-02)



5. Other Options 3

[illegible][illegible]

6. Parts Index

Part No.	Description	Page and Index No.
0360 3008N	SCREW:M3X8	5 - 101
0360 4010N	SCREW:M4X10	11 - 101
0450 4012N	TAPPING SCREW:4X12	9 - 101
0451 3006N	TAPPING SCREW - 3X6	7 - 106
0451 4014N	TAPPING SCREW:4X14	7 - 101
0452 4008N	BINDING SELF-TAPPING SCREW:4X8	5 - 102
0454 3008N	TAPPING SCREW:ROUND POINT:3X8	7 - 102
0454 3008N	TAPPING SCREW:ROUND POINT:3X8	11 - 102
0454 3014Q	TAPPING SCREW:3X14	7 - 103
1105 0042	WIRE BAND	7 - 104
1105 0046	HARNESS BAND	7 - 107
1105 0047	TY - WRAP	3 - 101
1105 0195	PCB STUD	7 - 108
1105 0488	CLAMP:LWS-1211Z	5 - 103
1105 0508	HARNESS CLAMP - LWS-0711	7 - 109
1105 0664	CLAMP:NK-3N	5 - 104
1105 0688	CLAMP:KS-15	3 - 9
1105 0688	CLAMP:KS-15	7 - 105
1607 2247	FERRITE CORE:K3 NF-55(N)BK0	5 - 105
1607 2595	FERRITE CORE:GRFC-13	3 - 102
AA14 3830	GUIDE PIN:PRESSURE PLATE:HINGE	9 - 11
B129 5008	CAP - LAN CONNECTOR	3 - 10
B154 5865	CAP:CONNECTOR:USB	3 - 14
B452 1055	BRACKET:KEY COUNTER HOLDER:ASS'Y	5 - 1
B452 1063	PLATE NUT:KEY COUNTER HOLDER	5 - 3
B452 1260	COVER:KEY COUNTER HOLDER	5 - 2
B870 5511	HARNESS:IOB:MKB	7 - 10

Part No.	Description	Page and Index No.
C410 6032	CASTER:DIA30	11 - 1
D149 1268	COVER:RIGHT:LOWER	11 - 5
D178 1064	STUD:POSITIONING:TABLE:CASTER	11 - 7
D202 5680	PCB:MKB	7 - 9
D351 1119	CASTER:DIA50H59:STOPPER:YES	11 - 3
D351 1121	CASTER:DIA50H59:STOPPER:NO	11 - 4
D377 5698	VELCRO FASTENER:COVER:ANTENNA:250	3 - 8
D3A7 5130	CABLE:120:POWER_CONNECT	3 - 12
D3AC 1410	IC CARD:NFC_RW:TF:TR63036	5 - 12
D3AC 1411	CABLE:USB:NFC	5 - 9
D3AC 5023	SD-CARD:OCR:15S:ASS'Y	5 - 5
D3BC 5628	PCB:PRINT-SERVER:ASS'Y	3 - 11
D3BR 1100	PAN HEAD TAPPING SCREW:M5X13:PIAS	7 - 8
D3BR 1211	CASE:KEYBOARD:OPTION	7 - 1
D3BR 1212	COVER:IC CARD:ASS'Y	7 - 2
D3BR 1215	COVER:IC CARD:BLANK	7 - 3
D3BR 1216	BASE:KEYBOARD	7 - 4
D3BR 1217	BRACKET:KEYBOARD:OPTION	7 - 5
D3BR 5204	PCB:WLAN_RIO4_EXT:ASS'Y	3 - 7
D3BR 5603	PCB:MLB32:ASS'Y	3 - 5
D3BS 5003	SD-CARD:Z_V4:ASS'Y	3 - 2
D3BS 5201	PCB:AIR-PRINT:ASS'Y	3 - 13
D3BS 5500	IC CARD:NFC_RW:ASS'Y	5 - 11
D3C0 5601	PCB:IEEE1284:ASS'Y	3 - 4
D3DW 5005	SD-CARD:PS3:ASS'Y	3 - 1
D3DW 5025	SD-CARD:XPS:ASS'Y	3 - 3
D3E3 1211	COVER:FRONT:UPPER:IC CARD	5 - 7

Part No.	Description	Page and Index No.
D3E3 1212	COVER:IC CARD:ASS'Y	5 - 8
D593 1396	HOLDER:ORIGINAL	9 - 7
D641 6154	SD-CARD:FONTSD:11A:ASS'Y	3 - 6
D693 1221	COVER:ARM	11 - 2
D700 1358	TAPE:PRESSURE PLATE:UPPER	9 - 1
D700 1359	BRACKET:PRESSURE PLATE:ASS'Y	9 - 3
D700 1371	SHEET:PRESSURE PLATE:ASS'Y	9 - 2
D700 1384	FEELER:ON OFF DETECTOR:PRESSURE PLATE	9 - 8
D700 1385	GUIDE:FEELER	9 - 10
D700 1393	COVER:PRESSURE PLATE:REAR	9 - 6
D700 1395	COVER:PRESSURE PLATE:FRONT	9 - 5
D739 1224	SPONGE:20X20	5 - 10
D739 1224	SPONGE:20X20	7 - 6
D739 1225	SPACER:IC CARD	7 - 7
D739 5404	HARNESS:KEY COUNTER:CT	5 - 4
G329 1350	FLEX HINGE - PLATEN COVER	9 - 4
G329 1355	HINGE:PRESSURE PLATE:ASS'Y	9 - 9
G832 7900	SCREW:SPRING WASHER:ROUND POINT:M4X10	11 - 6
RE01 0393	HDD:320GB:FIPS	5 - 6
		-
		-
		-
		-
		-
		-
		-
		-
		-

Part No.	Description	Page and Index No.
		-
		-
		-
		-
		-
		-
		-
		-
		-
		-
		-
		-
		-
		-
		-
		-
		-
		-
		-
		-
		-