⇨Please put this guide above your machine⇦

*The shape of the machine, screen displays, procedures, and titles in references vary depending on the machine you are using. Also, not all functions are available on all machines.

Tips

Paper Size

B5 ? ? A4

Paper Size
You can check the paper size using the scale on the exposure glass.

Auto Image Density
Dark texture originals will be copied so that background will not be reproduced.

Auto Paper Select
Selects a suitable size of paper automatically.

1. 【Home】key
Press to display the [Home] screen.
2. **Function keys**
No functions are registered to the function keys as a factory default. You can register often used functions, programs, and Web pages.
3. **Display panel**
4. 【Reset】key
Press to clear the current settings.

5. 【Program】key
Press to register frequently used settings, or to recall registered settings.
6. 【Interrupt】key
7. **Main power indicator**
8. 【Energy Saver】key
9. 【Login/Logout】key
10. 【User Tools/Counter】key

11. 【Simple Screen】key
12. 【#】key (Enter key)
13. 【Start】key
Press to start copying, printing, scanning, or sending.
14. 【Sample Copy】key
15. 【Stop】key
Press to stop a job in progress, such as copying, scanning, faxing, or printing.

16. 【Clear】key
Press to delete a number entered.
17. **Number keys**
18. 【Check Status】key
19. **Media access lamp**
20. **Media slots**

How to make Copies... (Placing Originals, Paper Specifications and Adding Paper, Basic Copying)

1 Press the 【Home】key on the top left of the control panel, and press the [Copier] icon on the [Home] screen.
2 Press the 【Reset】key.
3 Place the originals.
• Exposure Glass (Face down)
• Auto Document Feeder (Face up)
4 Make desired settings.
5 Enter the number of copies.
6 Press the 【Start】key.

How to select a color mode... (Color Copying)

1 Select a color mode.

Auto Color Select
Full Color
Black & White

How to Reduce/Enlarge... (Basic Copying)

Auto Reduce/Enlarge

1 Press [Auto Reduce / Enlarge].
2 Select the paper size.
3 Place the originals, and then press the 【Start】key.

Auto Reduce / Enlarge

Preset Reduce/Enlarge

1 Press [Reduce / Enlarge].
2 Select a ratio, and then press [OK].
3 Place the originals, and then press the 【Start】key. (Paper size is selected automatically.)

Reduce / Enlarge

How to save paper... (Basic Copying)

1 See if original is 1-sided or 2-sided (duplex).
2 Press [Dup./Combine/Series].
3 Select the original and copy types and/or the orientation.
4 Place the originals, and then press the 【Start】key.

Dup./Combine/Series

Duplex

1-Sided → 2-Sided
Copies two 1-sided pages on one 2-sided page.

2-Sided → 2-Sided
Copies one 2-sided page on one 2-sided page.

Combine

1-sided Combine
Copies multiple 1-sided or 2-sided originals on one side of copy paper.

2-sided Combine
Copies multiple 1-sided originals on two sides of copy paper.

Copies multiple 2-sided originals on two sides of copy paper.

! For more functions on Combine, see "Basic Copying", Copy/ Document Server.

How to finish your document... (Basic Copying)

Staple

1 Press [Finishing].
2 Press [Finisher] when the key is displayed.
3 Select one of the stapling positions (Copies will be sorted automatically).
4 Press [OK].
5 Enter the number of copies.
6 Place the originals, and then press the 【Start】key.

Punch

1 Press [Finishing].
2 Press [Finisher] when the key is displayed.
3 Select one of the punch hole positions (Copies will be hole punched).
4 Press [OK].
5 Enter the number of copies.
6 Place the originals, and then press the 【Start】key.

! Staple and Punch can be done at the same time.

! Availability of finishing depends on your configuration.

Document Server (Basic Copying)

Why use it...

• To store often used documents centrally and print on demand.
• To reduce network load.

How to use in copy mode...

1 Press [Store File].

Store File

2 Enter a user name, file name, or password if necessary.

User Name | COPY0017 File Name | Password

3 When [Target Folder to Store] is displayed, specify a folder in which to store the document if necessary.
4 Press [OK].
5 Place the originals.
6 Make the scanning settings for the original.
7 Press the 【Start】key.

The machine stores scanned originals in memory and makes one set of copies.
To find your document, press the 【Home】key on the top left of the control panel, and press the [Document Server] icon on the [Home] screen.

! For more functions on Document Server, see "Document Server", Copy/ Document Server.

Simple Screen

When you press the 【Simple Screen】key, the screen changes to the simple screen. Letters and keys are displayed at a larger size, making operations easier.
Only the main functions can be used.

Advanced features (Basic Copying, Advanced Copying)

Reduce/Enlarge

• Zoom: You can specify the reproduction ratio in increments of 1%.
• Magnification: You can specify the horizontal and vertical reproduction ratios, individually.

Series Copies

• Separately copies the front and back of a 2-sided original onto two sheets.

Booklet/Magazine

• Copies two or more originals in page order.

Edit/Stamp

• Image Repeat/Double Copies: The original image is copied repeatedly.
• Centering: Moves image to the center.
• Erase: Erases the center and/or all four sides of the original image.
• Stamps: Copies with the date, page numbers, etc.

Cover/Slip Sheet

• Covers: Create cover sheets.
• Designate: Copies certain pages of the original onto designation sheets.