

# Notes for Users

Thank you for purchasing the IPDS Unit Type 1357.

If you use WebInterface to change the form setting of a tray, a maximum of approximately 12 seconds is required for the change to be applied.

If print processing is begun while a setting is being changed, the printing might not reflect the change to the IPDS Tray setting.

For this reason, after using WebInterface to change a form setting and clicking [OK] in the IPDS Tray setting window, wait until the setting is reflected in the IPDS window before printing.

Tray	Tray Mapping	Tray Mapping Parameter (0 - 254)	Form
Tray 1	<input checked="" type="radio"/> Auto <input type="radio"/> IPDS Tray		form01
Tray 2	<input checked="" type="radio"/> Auto <input type="radio"/> IPDS Tray		form01
Tray 3	<input checked="" type="radio"/> Auto <input type="radio"/> IPDS Tray		form01
Tray 4	<input checked="" type="radio"/> Auto <input type="radio"/> IPDS Tray		form01
Tray 5	<input checked="" type="radio"/> Auto <input type="radio"/> IPDS Tray		form01
Tray 6	<input checked="" type="radio"/> Auto <input type="radio"/> IPDS Tray		form01
Tray 7	<input checked="" type="radio"/> Auto <input type="radio"/> IPDS Tray		form01
Interposer Upper Tray	<input checked="" type="radio"/> Auto <input type="radio"/> IPDS Tray		form01
Interposer Lower Tray	<input checked="" type="radio"/> Auto <input type="radio"/> IPDS Tray		form01

To allow the change to the setting to be applied, wait at least 12 seconds before printing.

Copyright © 2010

Printed in USA

EN (GB) EN (US) M004-7519



M0047519