

Reissued: 01-Dec-15

Model: M-G1W	Date: 29-Jul-11	No.: RJ023001b
--------------	-----------------	----------------

RTB Reissue

The items in bold italics have been corrected or added.

Subject: Firmware Release Note: Engine/Controller		Prepared by: Y. Gaman	
From: 1st Tech Service Sect.MFP/Printer Tech Service Dept.,			
Classification:	<input type="checkbox"/> Troubleshooting <input type="checkbox"/> Mechanical <input type="checkbox"/> Paper path <input type="checkbox"/> Product Safety	<input type="checkbox"/> Part information <input type="checkbox"/> Electrical <input type="checkbox"/> Transmit/receive <input checked="" type="checkbox"/> Other (Firmware)	<input type="checkbox"/> Action required <input type="checkbox"/> Service manual revision <input type="checkbox"/> Retrofit information <input checked="" type="checkbox"/> Tier 2

This RTB has been issued to announce the firmware release information for the **Engine/Controller**.

Version	Program No.	Effective Date	Availability of RFU
1.04	J0235617C	July 2015 production	Not Available
1.02	J0235617B	February 2012 production	Not Available
1.01	J0235617A	1st Mass production	Not Available

Note: Definition of Availability of RFU via @Remote

"Available" The firmware can be updated via RFU or SD card.

"Not available": The firmware can only be updated via SD card.

Version	Modified Points or Symptom Corrected
1.04	Symptom corrected: <ul style="list-style-type: none"> - <i>Supports update of the mainframe firmware from Windows 8 and Windows Server 2012.</i> - <i>The notification email may not show the destination addresses depending on the mailer software.</i> - <i>SC974 may occur while printing.</i>
1.02	Symptom corrected: If the power plug is pulled out of the outlet while a firmware upgrade is in progress, sometimes the printer will not boot up after that.
1.01	1st Mass production

Model: M-G1W		Date: 20-Dec-11	No.: RJ023002
Subject: Change in the Cleaning Cartridge Storage Period		Prepared by: Y. Murata	
From: 3rd Tech Service Sect., MFP/P Tech Service Dept.			
Classification:	<input type="checkbox"/> Troubleshooting <input type="checkbox"/> Mechanical <input type="checkbox"/> Paper path <input type="checkbox"/> Product Safety	<input type="checkbox"/> Part information <input type="checkbox"/> Electrical <input type="checkbox"/> Transmit/receive <input checked="" type="checkbox"/> Other (Specification change)	<input type="checkbox"/> Action required <input type="checkbox"/> Service manual revision <input type="checkbox"/> Retrofit information

Important Information about the Cleaning Cartridge Storage Period

- The recommended **storage period for the cleaning cartridge** has been changed from eighteen months to **five years**. This is because it was found that the liquid in the cartridge is able to hold its key chemical properties for years when stored in a regular environment.
- Due to this change:
 - For cartridges produced before December 2011:
You can use these cartridges up to **42 months after** the “Recommended to use before” date on the cartridge decal. On these cartridges, the date mentioned is 18 months after production.
 - For cartridges produced in **December 2011 or later**:
You can use these cartridges up to **60 months (five years) after** the lot number printed on the cartridge (The decal has been removed).

Lot No.: **Y M D D # # # # #**

Y: Last digit of the year of production

M: Month of production (Oct: “X”, Nov: “Y”, Dec: “Z”)

D: Day of production