

# **Browser Unit**

**Operating Instructions** 

1 Overview of Browser Unit

2 Setting Browser Unit

- 3 Starting Device Browser
- 4) Appendix

Read this manual carefully before you use this product and keep it handy for future reference.

#### Introduction

This manual contains detailed instructions and notes on the operation and use of this machine. For your safety and benefit, read this manual carefully before using the machine. Keep this manual in a handy place for quick reference.

#### Important

Contents of this manual are subject to change without prior notice. In no event will the company be liable for direct, indirect, special, incidental, or consequential damages as a result of handling or operating the machine.

#### Notes

Some illustrations in this manual might be slightly different from the machine.

Certain options might not be available in some countries. For details, please contact your local dealer.

# How to Read This Manual

## Symbols

This manual uses the following symbols:

#### ∰Important

Indicates points to pay attention to when using the machine, and explanations of likely causes of paper misfeeds, damage to originals, or loss of data. Be sure to read these explanations.

#### Limitation

This symbol indicates numerical limits, functions that cannot be used together, or conditions in which a particular function cannot be used.

#### 🖉 Note

Indicates supplementary explanations of the machine's functions, and instructions on resolving user errors.

#### 

This symbol is located at the end of sections. It indicates where you can find further relevant information.

#### [ ]

Keys built into the machine's control panel.

#### [ ]

Keys that appear on the machine's display panel.

# TABLE OF CONTENTS

How to Read This Manual	i
Symbols	i

#### 1. Overview of Browser Unit

## 2. Setting Browser Unit

Preparation	3
Device Browser Settings	4
Browser Default Settings	4
Temporary File Management	

#### 3. Starting Device Browser

Device Browser Start	17
Starting Up Device Browser	17

#### 4. Appendix

Troubleshooting	
INDEX	

# 1. Overview of Browser Unit

# What is Browser Unit?

Installing Browser Unit enables you to display information obtained from server applications on the display panel of network devices as Web pages.

In this manual, these device functions are referred to as Device Browser functions.

Device Browser enables a server application and device to communicate, allowing scanned data to be sent to the server application, where the user can perform various operations.



#### **1.** Network device (this machine)

Information acquired from the server application is displayed on the display panel of the network device as Web pages.

Sends scanned documents to a server application.

#### 2. Server applications

Processes data sent from the network device using the appropriate server application.

AKU001S

#### 3. Client computer

Receives e-mails and scanned documents that are sent from server applications.

# 2. Setting Browser Unit

# Preparation

The following settings are required to use Device Browser after Browser Unit is installed:

- Network device settings Make network device settings for obtaining Web page information from a server application and sending scanned data using Device Browser.
- Server application settings Make settings for acquiring data from Device Browser.

#### ₽ Reference

For details about network device settings, see p.4 "Device Browser Settings". For details about server application settings, see the relevant manual.

# **Device Browser Settings**

You can make the following Device Browser settings:

- Browser Default Settings Make proxy server settings and add URLs for Web pages you want to browse. Make settings to link certain server applications to Device Browser.
- Temporary File Management Set the maximum HDD space for temporary files, or delete files. Displayed Web page files are saved in the network device as temporary files. To view Web pages again, using temporary files allows them to open faster.

#### Limitation

□ If settings are not reflected when the screen changes, undo the settings for using temporary files.

#### 

For details about network device operations, see the network device manuals.

#### **Browser Default Settings**

Make settings for connecting to a server application using Device Browser.

#### Press the [User Tools / Counter] key.

The User Tools / Counter / Enquiry screen appears.

**2** Press [Extended Feature Settings].



The Extended Feature Setting Menu screen appears.

# B Press [Browser].

📱 Extended Feature Setting Me	nu Exit
Extended Feature Settings	Browser

The Browser Settings screen appears.

# Press [Browser Default Settings].

The Browser Default Settings screen appears.

Browser Settings					Exit
Browser Default Temporary File Vi Settings Management Vi	ew Logs				
Use Proxy Server On		Server	Connection Tir	neout	90 seconds
Default URL /hdd/ts	/8395				
Program / Change / Delete URL					
Software Version File Ve	r.1.4				
Auto Reset Timer Off					
Number of Resends 2 tim	e(s)				
Use Cookies On					
	Sy	stem Status	Job List		2007/ 3/14 14:38

# **5** Make settings for Device Browser, and then press [Exit].

 Use Proxy Server Press [Use Proxy Server].

Browser Settings					Exit
Use Proxy Server					Exit
Select item(s).					
On	Off				
▶Proxy Server Name				Change	
▶Proxy Port	0			Change	
	< 0 to 65535 >				
▶Proxy User Name				Change	1/2
▶Proxy Password	Change				A Previous
					▼ Next
		System Status	Job List		2005/11/22 17:56

Press [Next] to display the screen below.

Browser Settings	Exit
Use Proxy Server	Exit
Select item(s).	
On Off	
►Exceptional Addresses	
Do not use proxy server for addresses beginning with:	
Change	
Use comma (.) to separate entries.	
	2/2
	A Previous
	V Next
System Status Job List	2005/11/22 17:57

To use a proxy server for connecting to a server application, select **[On]**, and then press **[Exit]**.

If **[On]** is selected, the following items can be entered:

- Proxy Server Name
- Proxy Port
- Proxy User Name
- Proxy Password
- Exceptional Addresses
- Default URL
   Press [Default URL].

Browser Settings			Exit
Default URL	(	Cancel	ОК
Select a default URL, then press [OK].			
1 /hdd/ts/83951876/browser/usr/hel	2 Not Programmed		
3 Not Programmed	4 Not Programmed		
5 Not Programmed	6 Not Programmed		
7 Not Programmed	8 Not Programmed		
9 Not Programmed	10 Not Programmed		
	System Status Job List		2005/11/22

Select the URL of the Web page you want to display when Device Browser starts, and then press **[OK]**.

#### ③ Program / Change / Delete URL Press [Program / Change / Delete URL].

Browser Settings	Exit
Program / Change / Delete URL	Exit
Select a URL to program or change. Program / Change Delete	
1 /hdd/ts/83951876/browser/usr/hel	2 Not Programmed
3 Not Programmed	4 Not Programmed
5 Not Programmed	6 Not Programmed
7 Not Programmed	8 Not Programmed
9 Not Programmed	10 Not Programmed
	System Status Job List 17:57

Add URLs 1 to 4 under the server application. They cannot be added, changed, or deleted from the network device.

Add or modify a URL by selecting URLs 5 to 10.

If adding or modifying a URL, press **[Program / Change]** and make settings on the screen that is displayed by selecting URLs 5 to 10, and then press **[Exit]**.

If deleting URL, press [Delete] and select URLs 5 to 10, and then press [Exit].

Browser Settings					Exit
Program / Change URL				Cancel	ОК
Select item(s).					
►URL Name				Change	
▶URL				Change	
►Default HTTP Request Method	POST		GET		
►Text Size	Small	Medium	Large		
					1/2
					A Previous
					▼ Next
		System Status	Job List		007/ 3/14 4:40

Press [Next] to display the screen below.

Browser Settings		Exit Exit
Program / Change URL		Cancel OK
Select item(s).		
►Max HDD Space for Downloaded Files	3000 кв < 0 to 5000 >	Change
►Auto Delete Downloaded Files	1 days < 1 to 999 >	Change
▶Default Character Code Set	UTF-8 Shift-JIS	5 ISO-2022-JP 2/2 −1 ISO-8859-2 ▲ Previous ▼ Next
	System Status Jc	2007/ 3/14 b List 14:40

If [Program / Change] is selected, the following items can be entered:

- URL Name
- URL
- Default HTTP Request Method
- Text Size
- Max HDD Space for Downloaded Files The maximum space to save files that are downloaded from the delivery server connected to the machine, to the machine's hard disk.
- Auto Delete Downloaded Files The period after which downloaded files are deleted.
- Default Character Code Set Set character code that is used for displaying the HTML file, when it is not set in the file.

#### 🖉 Note

- □ On **[Default HTTP Request Method]**, select a format to connect to the added URL.
- ④ Software Version

#### Press [Software Version].

Check the Device Browser version information, and then press [Exit].

#### ⑤ Auto Reset Timer Press [Auto Reset Timer].

Auto Reset Timer	Cancel	ОК
Enter the time with the Number keys, then pre-	əss [OK].	
On Off		
30 seconds		Clear
< 30 to 999 >		#

To reset the display when the network device is not used for a specified period, select **[On]**. Enter the time that must elapse before the reset, and then press **[OK]**.

#### 🖉 Note

- □ When the display resets, the Web page specified with the default URL appears.
- Number of Resends Press [Number of Resends].



Enter the number of resends you want to perform if nothing responds after the period specified in **[Server Connection Timeout]** elapses, or a sending error occurs when scanned data is sent to server applications. Then press **[OK]**.

⑦ Use Cookies

#### Press [Use Cookies].

Depending on the Web page, you can use cookies for saving settings. This makes settings easier to make and saves time.

Use Cookies		Cancel	ОК
Select item, then press [O	K].		
On	Off		

To use cookies, select [On], and then press [OK].

#### Server Connection Timeout Press [Server Connection Timeout].



Enter the duration period for which the connection to the server is attempted, and then press **[OK]**.

#### 🖉 Note

- □ If you set a long period for the **[Server Connection Timeout]**, there may be several seconds before the screen appears.
- Ø Exit
   Ø

Changes made to settings are saved.

#### **6** Press [Exit].

The User Tools / Counter / Enquiry screen reappears.

#### **7** Press [Exit].

The setting screen closes.

#### **Temporary File Management**

You can save displayed Web page files to network devices as temporary files. To view Web pages again, using temporary files allows them to open faster.

You can make the following settings for managing temporary files:

- Use Temporary Files
- Max HDD Space for Temporary Files
- Auto Delete Temporary Files
- Delete All Temporary Files

#### Limitation

□ If settings are not reflected when the screen changes, undo the settings for using temporary files.

#### Press the [User Tools / Counter] key.

The User Tools / Counter / Enquiry screen appears.

#### Press [Extended Feature Settings].

		miller readures	
enance	6	Scanner Features	5
unter	Ŀ	Extended Feature Set	tings
		System Status	Job List

The Extended Feature Setting Menu screen appears.

#### B Press [Browser].

🔄 Extended Feature Setting Menu		Exit
Extended Feature Settings	Browser	

The Browser Settings screen appears.

#### Press [Temporary File Management].

The Temporary File Management screen appears.

Browser Settings		Exit
Browser Default Settings Management View Logs		
Use Temporary Files Off		
Max HDD Space for Temporary Files 500 KB		
Auto Delete Temporary Files 1 5 days		
Delete All Temporary Files		
	System Status Job List	2007/ 3/14 14:42

## **5** Make settings for temporary files, and then press [Exit].

 Use Temporary Files Press [Use Temporary Files].

Use Temporary Files		Cancel	ОК
Select item, then press [OK	].		
<b>_</b>			
On	Off		

Displayed Web page files are saved in the network device as temporary files. To view Web pages again, using temporary files allows them to open faster.

To use temporary files, select [On], and then press [OK].

#### Limitation

□ If settings are not reflected when the screen changes, undo the settings for using temporary files.

#### ② Max HDD Space for Temporary Files Press [Max HDD Space for Temporary Files].



Enter the maximum HDD space for storing temporary files in the network device, and then press **[OK]**.

#### 🖉 Note

- □ If the volume of saved temporary files exceeds the specified space, files are deleted in the saved order (earliest first).
- ③ Auto Delete Temporary Files Press [Auto Delete Temporary Files].



Enter the period after which temporary files are deleted, and then press **[OK]**.

④ Delete All Temporary Files Press [Delete All Temporary Files].

Are you sure you want to delete all temporary files?		
NO	YES	

Press [Yes] to delete all temporary files saved in the network device.

# **6** Press [Exit].

The User Tools / Counter / Enquiry screen reappears.

# **2** Press [Exit].

The setting screen quits.

# 3. Starting Device Browser

# **Device Browser Start**

A Device Browser starting key is assigned when options are installed to the network device.

For details about the relevant key, ask your network device administrator.

## **Starting Up Device Browser**

Start up Device Browser as follows:

#### Press the key assigned to Device Browser.

Device Browser starts, and the default URL Web page is displayed.

#### 🖉 Note

- □ If displaying other web pages, press the **[Program]** key, and then select the URL.
- □ If returning to the Home of the web page, press the **[Clear Modes]** key.
- □ If performing regular operations, press the function keys such as **[Copy]** and **[Printer]**.

#### 

For details about operations on the displayed Web page, see the relevant server application manual.

# 4. Appendix

# Troubleshooting

Problems	Causes and solutions
The display panel of a network device displays the message "Could not con- nect to URL or URL was not found."	Check the network environment settings. The server is operating incorrectly, or the URL is incorrect.
If you press a function key such as <b>[Copy]</b> or <b>[Scanner]</b> while scanning a document using Device Browser, the display panel does not change.	Press the appropriate function key when document scanning is completed.
If you press keys on the control panel, the display panel does not change.	If you perform another operation within the duration specified in <b>[Server Connection Timeout]</b> on the Browser Settings screen, the display panel may not change. Wait a few seconds, and then perform the operation again.
When you turn ON the <b>[Power]</b> key, the copy function screen appears. However, if you press a function key such as <b>[Scanner]</b> or <b>[Facsimile]</b> or the <b>[User Tools / Counter]</b> key, the dis- play panel does not change.	A function other than the copy function is starting. Start times may differ depending on functions. Wait a few seconds, and then perform the operation again.

# INDEX

#### В

Browser Default Settings, 4 Browser Unit, 1

#### D

Device Browser Settings, 4

#### S

Setting Browser Unit, 3 Starting Device Browser, 17

#### Т

Temporary File Management, 12 Troubleshooting, 19

Copyright © 2005-2007

# Browser Unit Operating Instructions

