


RICOH

OPERATOR'S MANUAL

RICOH FAX5600L



Please read all of these instructions and keep this manual by your machine.

Optional Equipment

Memory (Fax Memory Type 30 1MB-II, Fax Memory Type 30 2MB)

Either a 1-Mbyte memory card, a 2-Mbyte memory card, or a 40-Mbyte hard disk can be added.

ISDN G4 Kit (ISDN Option Type 90)

This allows you to send and receive messages using the ISDN (Integrated Services Digital Network).

PC Printer Interface Kit (Printer Interface Type 60)

This allows you to use the machine as a laser printer for an IBM ¹ or compatible personal computer.

High Resolution Printer Memory Card (400 dpi Option Type 90)

This allows you to print received fax messages at high resolution when the other party transmits them at Super Fine (400 x 400 dpi) resolution. Note that even if you install this option, the maximum resolution is 300 x 300 dpi when printing from the computer using the PC Printer Interface.

Paper Feed Unit (Paper Feed Unit Type 30)

Up to four 500-sheet paper feed units can be added to the base machine, for a total capacity of 2,250 sheets.

Telephone Handset (Handset Type 20/30)

This permits voice communication (over the PSTN).

Cabinet (Cabinet Type 40)

This provides a base with wheels for you to move the machine around easily.

Note

The PC Printer Interface kit and the 40 Mb hard disk cannot both be installed together on the same machine.

The PC Printer Interface kit and the ISDN G4 kit cannot both be installed together on the same machine.

¹Copyright Notice

IBM is a registered trademark of International Business Machines Corporation.

WARNING: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

★ **CAUTION:** Use of control or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

Class A

This Digital Apparatus does not exceed the Class A limits for Radio noise emissions from Digital Apparatus as set out in the Interference-causing equipment entitled "Digital Apparatus", ICES-003 of the Department of Communications.

Cet appareil numérique respecte les limites de bruits radioélectriques applicables aux appareils numériques de classe A prescrites dans la norme sur le matériel brouilleur : "Appareils Numériques", NMB-003 édictée par le ministre des Communications.

Notice about the Telephone Consumer Protection Act (Valid in the USA only)

Attention please!

The Telephone Consumer Protection Act of 1991 among other things makes it unlawful for any person to send any message via a telephone fax machine unless such message clearly contains in a margin at the top or bottom of each transmitted page or on the first page of the transmission, the date and time it is sent and an identification of the business or other entity, or other individual sending the message and the telephone number of the sending machine or such business, other entity, or individual. This information is transmitted with your document by the TTI (Transmit Terminal Identification) feature.

In order for you to meet the requirement, your machine must be programmed by following the instructions in the accompanying Operation Manual. In particular, please refer to the "Getting Started" and/or "Programming" sections. Also refer to the TTI (Transmit Terminal Identification) programming procedure to enter the business identification and telephone number of the terminal or business. Do not forget to set the date and time.

Thank you

IMPORTANT SAFETY INSTRUCTIONS

1. Read all of these instructions.
2. Save these instructions for later use.
3. Follow all warnings and instructions marked on the product.
4. Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
5. Do not use this product near water.
6. Do not place this product on an unstable cart, stand, or table. The product may fall, causing serious damage to the product or injuring the user.
7. Slots and openings in the cabinet and the back or bottom are provided for ventilation; to ensure reliable operation of the product and to protect it from overheating, these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should not be placed in a built-in installation unless proper ventilation is provided.
8. This product should be operated from the type of power source indicated on the marking label. If you are not sure of the type of power available, consult an authorized sales person or your local power company.
9. This product is equipped with a 3-wire grounding type plug, a plug having a third (grounding) pin. This plug will only fit into a grounding-type power outlet. This is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to replace your obsolete outlet. Do not defeat the purpose of the grounding type plug. (This does not apply in countries in which the 2-wire, non-grounded type of plug is used.)
10. Do not allow anything to rest on the power cord. Do not locate this product where persons will walk on the cord.
11. If an extension cord is used with this product, make sure that the total of the ampere ratings on the products plugged into the extension cord do not exceed the extension cord ampere rating. Also, make sure that the total of all products plugged into the wall outlet does not exceed 15 amperes.
12. Never push objects of any kind into this product through cabinet slots as they may touch dangerous voltage points or short out parts that could result in a risk of fire or electric shock. Never spill liquid of any kind on the product.
13. Do not attempt to service this product yourself, as opening or removing covers may expose you to dangerous voltage points or other risks. Refer all servicing to qualified service personnel.
14. Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:
 - A. When the power cord or plug is damaged or frayed.
 - B. If liquid has been spilled into the product.
 - C. If the product has been exposed to rain or water.
 - D. If the product does not operate normally when the operating instructions are followed. Adjust only those controls that are covered by the operating instructions since improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to normal operation.
 - E. If the product has been dropped or the cabinet has been damaged.
 - F. If the product exhibits a distinct change in performance, indicating a need for service.

CONTENTS

IMPORTANT SAFETY INSTRUCTIONS

INTRODUCTION

WHAT DOES A FAX MACHINE DO?	1
TELEPHONE LINE PROBLEMS AFFECT FAX COMMUNICATION	1
SOME OF THE THINGS THAT THIS MACHINE CAN DO	2

HOW TO USE THIS MANUAL

MANUAL OVERVIEW	4
CONVENTIONS	5
STORING TELEPHONE NUMBERS	7
STORING NAMES AND LABELS	7
IF YOU MAKE A MISTAKE	8
ON/OFF SWITCHES AND USER PARAMETERS	9

GENERAL PRECAUTIONS

POWER AND GROUNDING	14
COLD WEATHER POWER-UP	15
THUNDERSTORMS	15
COPY PAPER	16
TONER CARTRIDGES	16
OPERATING PRECAUTIONS	16
GENERAL	17

GUIDE TO COMPONENTS

COMPONENT DIAGRAM	18
-------------------	----

OPERATION PANEL

OPERATION PANEL DIAGRAM	19
-------------------------	----

INSTALLING THE MACHINE

LOCATION	21
CONNECTING THE MACHINE	22

BEFORE YOU SEND YOUR FIRST FAX

SOME ITEMS MUST BE PROGRAMMED FIRST	23
Overview	23
Language Selection	23
Date and Time	24
Daylight Saving Time	24
Terminal Identification	25
RTI (Remote Terminal Identification)	26
TTI (Transmit Terminal Identification)	26
CSI (Called Subscriber Identification)	27
Telephone Line Type	28
QUICK DIAL, SPEED DIAL, AND GROUP DIAL	29
Three Convenient Ways to Dial	29
Quick Dial and Speed Dial	29
Groups	30
Programming Quick Dial	31
Programming a New Quick Dial	31
Editing a Quick Dial	32
Erasing a Quick Dial	33
Programming Speed Dials	34
Programming a New Speed Dial	34
Editing a Speed Dial	36
Erasing a Speed Dial	37
Programming Groups	38
Entering Group Programming Mode and Selecting a Group	38
Storing Numbers in a Group	39
Checking Which Numbers are Already in the Group	40
Storing a Label for this Group	40
Storing a Group Transfer Station	41
Erasing the Group	42
Limits on the Use of Stored Telephone Numbers	43
DEALING WITH JUNK FAX MAIL	44
OTHER ITEMS TO PROGRAM AT YOUR LEISURE	44

ROUTINE OPERATION

SENDING A FAX MESSAGE	45
Precautions Concerning Unacceptable Document Types	45
Transmission Procedure at a Glance	47
Overview	47
Immediate Transmission	47
Memory Transmission	48
Sending to Just One Location	49
Sending to More Than One Location (Broadcasting)	51
Check your Destinations Before Dialing	52
Possible Problems	53

Contrast, Resolution, and Halftone Modes	54
Contrast	55
Resolution	55
Halftone	55
Selecting the Halftone Type	56
Home Position Setting Adjustments	57
Dialing with the Telephone Directory	58
Optional Features for Transmission	59
Personal Code	59
Send Later	60
Transmission Deadline (TRD)	61
Page Count (Immediate Transmission only)	62
Auto Reduce	63
On/Off Selection Switch	63
Auto Reduce Home Position Adjustment	64
TTI	64
ID Transmission	65
Economy Transmission	66
On/Off Selection Switch	67
Storing the Economy Transmission Time	67
Voice Request (This feature requires a handset)	67
Direct Fax Number Entry	68
Immediate Transmission	69
Procedure	69
Converting Immediate Transmission to Memory Transmission	69
Transmission Mode Home Position Adjustment	70
Using the Stamp	71
Changing the Stamp On/Off Home Position Setting	71
Redialing	72
Automatic Redialing	72
Using the AI (Artificial Intelligence) Redial Key	73
RECEIVING FAX MESSAGES	74
Selecting the Reception Mode	74
Manual Receive Mode	74
Auto Receive Mode	75
Substitute Reception	75
Overview	75
Switching Substitute Reception On or Off	76
TELEPHONE CALLS	77
Making a Telephone Call	77
Using On Hook Dial	77
Using the Handset	78
Using AI Redial	78
Answering the Telephone	79
Phoning and Faxing on the Same Call	79
To Talk Before Sending a Fax (On Hook Dial)	79
To Talk After Sending a Fax	80

ADVANCED FEATURES

NETWORKING	81
Overview	81
What Networking Features Does This Machine Have?	82
Preparing the Machine for Networking Operations	83
Storing the Country Code	83
Storing your Machine's Own Telephone Number	84
Storing your Area Code Prefix	84
Storing the ID Code	85
Groups	86
Transfer Request	87
Combining Transfer Request with Broadcasting	90
Two-step Transfer	91
Digital Link	91
Analog Link	92
Multi-step Transfer	93
Your Machine as a Transfer Station (Memory Card or Hard Disk Required)	94
Transfer Request by Tonal Signals	94
Setting the Machine up for Transfer Request by Tonal Signals	94
Storing the Remote ID	95
Switching Transfer Request by Tonal Signals On/Off	95
Procedure for Transfer Request by Tonal Signals	96
Full Procedure	96
Example Procedure (for Quick Reference)	97
Beep Tones	98
TRANSMISSION	99
Keystroke Programs	99
Overview	99
Storing a Keystroke Program	100
Labeling a Program	101
Using a Program	102
Transmission Program	102
Free Polling Reception Program	102
Erasing a Program	103
Confidential Transmission	104
Overview	104
Procedure	105
Confidential ID Override Option	105
Auto Document	106
Overview	106
Storing an Auto Document	107
Labeling an Auto Document	107

Using an Auto Document	108
Printing the Contents of an Auto Document	108
Erasing an Auto Document	109
Restricting Access to the Machine	110
Overview	110
Programming the Personal Codes	110
Storing a Personal Code	111
Editing or Erasing a Personal Code	112
Switching on Restricted Access	113
Operating the Machine with Restricted Access Switched On	114
Tonal Signals	115
Chain Dialing	116
Secure Transmission	117
Overview	117
Changing the Secure Transmission On/Off Home Position Setting	117
Making a Secure Transmission	118
Specified Image Area	118
Overview	118
Changing the Specified Image Area On/Off Home Position Setting	119
Specifying an Image Area	119
Label Insertion	120
Closed Network (Transmission)	121
Protection Against Wrong Connections	122
ECM (Error Correction Mode) and Page Retransmission	123
Batch Transmission	124
Overview	124
Changing the Batch Transmission On/Off Home Position Setting	125
Well Log Transmission	125
RECEPTION	126
Confidential Reception (Memory Card or Hard Disk Required)	126
Overview	126
Storing a Confidential ID	127
Printing a Confidential Fax Message	127
Confidential File Report	128
Memory Lock (Memory Card or Hard Disk Required)	129
Overview	129
Storing a Memory Lock ID	129
Switching Memory Lock On/Off	130
Printing from Memory Lock (Memory Card or Hard Disk Required)	130
Rejection of Messages from Unidentified Senders	131
Authorized Reception	132
Overview	132
Programming the Authorized Senders	133
Switching Authorized Reception On/Off	134
Forwarding (Memory Card or Hard Disk Required)	134
Overview	134
Programming the Forwarding Feature	136

Editing the Forwarding Feature	138
Switching Forwarding On/Off	140
Enabling and Disabling the Forwarding Mark	140
Specified Cassette Selection (Optional Paper Feed Unit Required)	141
Overview	141
Programming the Specified Cassette Selection Feature	142
Switching Specified Cassette Selection On/Off	143
Wild Cards	144
Reverse Order Printing (Memory Card or Hard Disk Required)	145
Multi-sort Document Reception (Memory Card or Hard Disk Required)	146
Center Mark	147
Checkered Mark	148
Reception Time	149
Length Reduction	150
Two in One	151
Closed Network (Reception)	152
OTHER	153
Polling	153
Overview	153
Polling Transmission	154
Free Polling	154
Secured Polling	155
Stored ID Override	156
Polling Reception	158
Operating Procedure	158
Stored ID Override Option	159
Continuous Polling Reception	159
File Management	160
File Retention Time and File Retransmission	160
File Retransmission	160
Erasing a File from Memory	161
Printing a File	162
User Function Keys	163
User Function Codes	163
Function Programs	164
Storing a Function Program	164
Using a Function Program	165
Deleting a Function Program	165
OMR Sheets	166
Introduction	166
Using an OMR Sheet	166
Completing an OMR Sheet	167
The Five Types of OMR Sheets	170
User Parameter Program Sheet	170
Quick/Speed Dial Program Sheet	170
Group Program Sheet	171
Transmission Program Sheet	172

Transfer Request Program Sheet	173
Procedures	174
To Print an OMR Sheet	174
Using an OMR Sheet to Send a Fax Message	174
Using an OMR Sheet to Program the Machine	175
Errors	175
Power Saver	176
Overview	176
Programming Procedure	177
Switching the Power Saver On or Off	178
Counters	179
Communication Result Display	179
Entering PC Printer Mode (Printer Interface Required)	180
Selecting the Paper Feed Cassette for Printer Mode (Printer Interface and Paper Feed Unit Required)	180
Copying	181
Dual Access	182
Inch-to-millimeter Conversion	182
RDS (Remote Diagnostic System)	183
Overview	183
Switching RDS On/Off	183
Short Preamble	184
AI Short Protocol	184

REPORTS

AUTOMATICALLY PRINTED REPORTS	185
Descriptions of the Available Reports	185
TCR (Transmission Confirmation Report)	185
Transmission Result Report	185
Error Report	185
Communication Failure Report	185
Memory Storage Report	185
Power Failure Report	186
Transfer Result Report	186
Polling Reserve Report	186
Polling Result Report	186
Polling Clear Report	186
Confidential File Report (Memory Card or Hard Disk Required)	186
Transmission Deadline Report/Polling Confirmation List	187
Switching Reports On/Off	187
Printing a Sample of Data on the Reports	188
Report Formats	189
USER-INITIATED REPORTS	191
Descriptions of Available Reports	191
TCR	191
File List	191

Quick Dial List	192
Speed Dial List	192
Group Dial List	192
Program List	192
User Function List	192
Personal Code List	192
Authorized Reception List	192
Forwarding List	193
Specified Cassette Selection List	193
User Parameter List	193

LOOKING AFTER THE MACHINE

REPLACING PAPER	194
REPLACING THE TONER CASSETTE	195
Replacement Procedure	195
Ordering Toner	197
Switching the Ordering Toner Feature On/Off	197
Ordering Toner Procedure	198
REPLACING THE STAMP	199
CHANGING THE PAPER SIZE OF THE CASSETTE	200
Upper Cassette	200
Lower Cassette(s)	202
USER MAINTENANCE PROCEDURES	203
User Maintenance Table	203
User Maintenance Procedure	204
Scanner	204
Main Body	208
Lower Paper Feed Unit(s) (If one or more are installed)	212

SOLVING PROBLEMS

DOCUMENT JAMS	213
Clearing a Document Jam	213
Adjusting the Document Feeder	214
COPY JAMS	215
Cassette Entrance	215
Inside the Machine	216
Copy Feed-out Area	217
Lower Cassette Entrance	218
COMMUNICATION PROBLEMS	218
OPERATING DIFFICULTIES	219
DISPLAYED ERROR MESSAGES	223
ERROR CODES	225
CALLING THE SERVICE STATION (SERVICE REPORT TRANSMISSION)	227
Switching Service Report Transmission On/Off	227
Sending a Service Report	228
DEDICATED TRANSMISSION PARAMETERS	228

SPECIFICATIONS

TABLE OF SPECIFICATIONS

229

APPENDIX

APPENDIX A. PAPER FEED UNIT 230

Operation 230

Maintenance 230

Copy Jams 230

APPENDIX B. FAX MEMORY TYPE 90 40 MB HD 231

General 231

Operation 231

APPENDIX C. ISDN G4 OPTION TYPE 90 232

Introduction 232

Setting up the Group 4 Interface 233

Subaddress Key 233

Own ISDN-G4 Number 233

Own ISDN-G3 Number 234

Next Transfer Station 235

Operation 236

Dialing and Storing Telephone Numbers 236

Overview 236

Transmission Procedure 237

Storing a Telephone Number 238

Automatic Fallback from Group 4 Mode to Group 3 Mode 240

Terminal ID 240

Explanation of the Items in the Group 4 Identifier 241

Transmitter and Receiver Terminal IDs 241

Date and Time 241

Page Number 241

Switching the Command Information Line On/Off 242

Terminal ID Verification 243

Troubleshooting 243

Call Progress Signals (CPS) 243

GLOSSARY 244

INDEX

OFFICIAL NOTICE TO USERS

FUNCTION LIST

INTRODUCTION

Thank you for purchasing this product. This multi-function office machine offers a wide range of fax, printer, and convenience features.

WHAT DOES A FAX MACHINE DO?

When you write a letter, you normally seal it in an envelope, attach a stamp, and post it in the nearest mail box. Then, in a few days, depending on the postal service, the letter will arrive at its destination. However, you may not be aware of its arrival until you get a return letter.

A fax machine speeds up this process. After you have written your letter, place it face down in your fax machine's document feeder, dial the destination's fax number, then press the Start key.

The fax machine scans your letter, and converts it into a series of black and white dots (the number of dots that there are across and down the page depends on the resolution that you selected; refer to the specifications section of this manual for details). This series of dots is transformed into an electrical signal and sent out over the telephone line to the destination fax machine.

The receiving fax machine reconstructs your letter from the incoming signal, and prints it.

If you are worried about whether the message arrived at the destination, you can check a report called the TCR (Transaction Confirmation Report). When you print this report, you will see the results of the most recent fax communications made by your machine.


You can use your fax machine to send and receive many types of document, even photographs.

TELEPHONE LINE PROBLEMS AFFECT FAX COMMUNICATION

Quick and accurate transmission of fax messages depends on the condition of the telephone line. If the line condition is very good, this machine will transmit a letter-size page in about 6 seconds. However, if the line is noisy, the speed may be reduced significantly, and the data may be damaged.

The symptoms of data loss caused by a noisy telephone line are seen on the printouts of received messages. An example is shown opposite. Note that lines are missing from the page at the indicated locations. ECM (Error Correction Mode) is an effective countermeasure against this type of error; you have the choice of having the ECM feature switched on or off. It is switched on before the machine leaves the factory. (Refer to page 123 for more information about ECM).


The line condition is affected by the weather; thunderstorms can cause electrical noise on telephone lines. In addition, the operation of the equipment in the telephone company's control office can also cause noise on the line.




SOME OF THE THINGS THAT THIS MACHINE CAN DO

This machine has many features. Here is a sample of what the machine can do.


Sending a Fax to More Than One Location




Network Features, including Transfer Request




Restricting Access to the Machine




Quick Dial, Speed Dial, and Group Dial




Sending a Fax Later



Confidential Communication




Keystroke Programs




See page 99.

User Function Keys




See page 163.

Auto Document (sends a commonly transmitted page with one touch)




See page 106.

Authorized Reception (cuts out junk fax mail)




See page 132.

Forwarding




See page 134.

Batch Transmission




See page 124.

Transmission Deadline



See page 61.

Protection against Wrong Connections



See page 122.

HOW TO USE THIS MANUAL

MANUAL OVERVIEW

Your facsimile machine is equipped with a wide range of labor-saving and cost-saving features. This manual explains each of these features, and how you can put them to use. Note that the external appearance of the machine in some illustrations may be slightly different from the actual machine.

The manual consists of the following sections.

- ❑ **How to Use this Manual** - This is the section that you are now reading. It contains an overview of the manual and the conventions used by the authors. It also contains quick reference sections on how to input telephone numbers and names, and how to correct errors that you may inadvertently make when operating the machine.
- ❑ **General Precautions** - This section lists precautions that you should keep in mind when operating the machine. Read this section before you begin to use your machine.
- ❑ **Guide to Components** - This contains a diagram that shows where the main components of your machine are situated.
- ❑ **Operation Panel** - This describes the functions of the various buttons and indicators that are on your machine's operation panel.
- ❑ **Installing the Machine** - If you are setting up your machine for the first time, a service technician will do the physical installation, so that is not described here. However, this section tells you the best type of place to install your machine. So, please refer to it when you plan to move the machine to another location.
- ❑ **Before you Send your First Fax** - This section explains the things that you have to do before you can send your first fax message and lists important features that will make faxing more convenient.
- ❑ **Routine Operation** - This section describes the features and settings that you will normally be using every day.
- ❑ **Advanced Features** - This section explains how to take advantage of the special features of your fax machine, including how to set up networks for economical distribution of fax messages over long distances.
- ❑ **Reports** - This section explains the reports that the machine generates.
- ❑ **Looking After the Machine** - This section shows you what to do when consumable supplies run out. The user maintenance procedure in this section should be done every six months if you want to keep your machine in top condition.
- ❑ **Solving Problems** - If your machine cannot communicate, or if it generates error codes or experiences paper jams, refer to this section. Many routine problems do not need to be solved by an experienced technician.
- ❑ **Specifications** - This is a list of technical data you might like to refer to occasionally.
- ❑ **Appendix** - This describes the optional hard disk, paper feed unit, and ISDN Group 4 kit. The PC Printer Interface Kit comes with a separate manual.
- ❑ **Quick Reference Guide** - This indicates how to use this machine at a glance.

CONVENTIONS


The following conventions were used when writing this manual.

Keynames

These have been printed in a different typeface and enclosed by a box.

For example: " **Start** " means "Press the Start key on the operation panel".

If you see something like " **#** x 3", this means that you have to press the **#** key 3 times.



On the operation panel, there is a circular key with four arrows (up, down, left, right) printed on it. This is the scroll key. It is often used in the operating procedures to gain access to various features. For example, if you see **←** in the manual, you are being asked to press the left-pointing arrow on the scroll key.

Displays

Messages seen on the display are shown in a larger box, normally on the right hand side of the page, directly opposite the step that brought it up on the screen. After following a step in a procedure, check the display to see if it corresponds to the one in the manual. This may help you to check whether you are following the procedure successfully. The following examples show three common types of display.

Example A: The keys that can be pressed are shown on the screen in small boxes. In this example, you can press the Yes, No, or Clear keys, or the down arrow on the scroll key (see the arrow at the top right).

MEMORY TRANS.	OPTI ONS	↓
PRESS YES OR CLR · NO		
2125551234		

Example B: The choices of settings for a feature are shown on the screen. The current setting is highlighted (white on black). If you press the right-pointing arrow on the scroll key, the setting will be changed to OFF.

OPTI ON	SELECT	←	→	YES	TO END
AUTO REDUCE		ON		OFF	
				TTI	↓

Example C: The ABC in the bottom right of the display indicates that you can input letters using the Quick Dial Keys, and numbers using the ten-key pad on the operation panel.

QUI CK DI AL	ENTER LABEL
01	
	ABC

HOW TO USE THIS MANUAL

Most procedures start from standby mode, that is, when the display is as shown on the right. The value after "MEMORY" shows how much memory space is remaining.

MEMORY TRANS.	APR. 4. 12:25 PM
SET DOCUMENT	MEMORY 100%

NOTE: If you start a procedure and do not enter anything at the operation panel for more than 5 minutes, the machine returns to standby mode.

Symbols

The text contains a few symbols that highlight important points or direct you towards other parts of the manual that are related to the feature currently being described.



indicates a hint (for example, indicating a page number where related information can be found).



indicates that you can access the current feature by pressing a User Function Key provided, if you have already programmed a User Function Key to perform a particular function.

Using Function 35, you can program User Function Keys as short cuts to access some features. (See page 163 for more about programming the User Function Keys).



indicates that you can switch the current feature on or off using Function 81 or Function 91. Some features must be switched on before they will work.





indicates that you can operate this feature with an OMR Sheet as well as from the operation panel. (See page 166 and the pages following for full details concerning OMR Sheets.)

STORING TELEPHONE NUMBERS

To dial a telephone number or store it as a Quick Dial or Speed Dial, type it into the machine at the ten-key pad on the operation panel.

STORING NAMES AND LABELS

You can enter names using the Quick Dial Keys. Use Quick Dial Keys 01 to 26 for the letters of the alphabet (or 33 to 58 if the quick dial label plate on the operation panel is flipped over to the right), and use Quick Dial 30 (or 62) as a spacebar. The letters are printed on the surface of each key. If you wish to enter a digit from 0 to 9, use the ten-key pad.

The cursor appears on the screen as a black dash below the cursor position. If you wish to move the cursor while editing a name or number, press the  and  arrows on the circular scroll key on the operation panel.


If you wish to enter a punctuation mark or symbol, use Quick Dial 31 (or 63). See "Punctuation Marks and Symbols" on the next page for more details.

Quick Dial 32 (or 64) can be used as a Shift key, to select upper or lower case letters.

KEY	DESCRIPTION	KEY	DESCRIPTION	KEY	DESCRIPTION
01/33	A	12/44	L	23/55	W
02/34	B	13/45	M	24/56	X
03/35	C	14/46	N	25/57	Y
04/36	D	15/47	O	26/58	Z
05/37	E	16/48	P	27/59	Not used
06/38	F	17/49	Q	28/60	
07/39	G	18/50	R	29/61	
08/40	H	19/51	S	30/62	Space
09/41	I	20/52	T	31/63	Punctuation Marks and Symbols
10/42	J	21/53	U		
11/43	K	22/54	V	32/64	Shift key (see p. 8)

Punctuation Marks and Symbols

If you press **[31]** or **[63]** while entering a label, a menu of symbols will appear, as shown on the right.



- ☐ To select a symbol, press the required key on the ten-key pad. For example, if you wish to enter a '#', press **[3]**. Then move the cursor forward with the scroll key so that you can enter the next letter, digit, or symbol in the item that you are typing into the display.
- ☐ If the symbol that you need is not on the screen, scroll through the pages of symbols with the **[↑]** and **[↓]** keys.

Shift Key

As shown in example C on page 5, 'ABC' can be seen in the bottom right of the display while you are inputting a label. This indicates that upper case letters will be stored. If you wish to input lower case letters, press **[32]** or **[64]**. The 'ABC' will change to 'abc', and the letters that you type in will be stored as lower case letters. To change back to upper case letters, press **[32]** or **[64]** again.

IF YOU MAKE A MISTAKE

If you make a mistake when inputting a name or number, either:

- ☐ Press **[No]** to erase the entire name or number and start again.
- ☐ Press **[Clear]** to erase the last letter or digit that you entered.

If you enter the wrong function number, either:

- ☐ Press **[No]** then input the correct function number.
- ☐ Press **[Function]** to return to standby mode and start again.

If you dialed the wrong number, either:

- ☐ Press **[No]**. If scanning has already begun, press **[Stop]**.
- ☐ If you already programmed the number into the machine by pressing Yes, remove the document from the document feeder and start again, or use the destination reviewing feature (option 08) to cancel that particular destination only (see page 52).

ON/OFF SWITCHES AND USER PARAMETERS

Some of the features in this machine can be switched on or off, and some of them do not work unless they are switched on first. Other features can be adjusted in various ways. Each adjustment or on/off switch is explained in the relevant sections of the manual.

There are two user functions to help you adjust these features and switch them on/off.

- ❑ Function 81 (On/Off Switches)
- ❑ Function 91 (User Parameters)

On/Off Switches

This feature allows you to switch some of the major features of the machine on or off. The overall procedure is explained below. However, each of the adjustments that can be made using this procedure are explained in the relevant parts of the manual.

As well as a series of on/off switches, Function 81 allows access to the following features.

❑ Telephone Line Type

DP: Pulse Dial

TT: Touch Tone

❑ Halftone Type

SPD MODE: The machine will use the Basic Halftone Process

STD MODE: The machine will use the higher quality Error Diffusion Process.

1. **Function** **6** **0** **2** **2** **2** **2**
8 **1**



PSTN LINE TYPE	SELECT	←	→
DP	TT	↑	↓
	YES TO END		


The first displayed item is the telephone line type: DP = Pulse Dial, TT = Touch Tone. In the above display, TT is currently selected.

2. Scroll through the list of features with **↑** and **↓** until the required feature appears.
Example: Authorized Reception - press **↓** once.

AUTHORI Z. RX	SELECT	←	→
ON	OFF	↑	↓
	YES TO END		

HOW TO USE THIS MANUAL

3. Change the setting by using  or  .

AUTHORI Z. RX	SELECT		
ON	OFF		
	YES TO END		

4. Either:
- ☐ Change another setting: Go to step 2.
 - ☐ Finish: **Yes** **Function**

A table showing the order of appearance of the switches is given below. Some of these switches may not be seen depending on the options that you have installed with the machine (1:Optional Memory or hard disk required, 2: Optional paper feed unit required, 3: Optional printer interface kit required).

*:This only appears if you have asked a service technician to switch RDS on.




Feature	↓	Feature	↓
Telephone Line Type	None	Halftone Type	8 times
Authorized Reception	Once	Daylight Saving Time/Summer Time	9 times
Memory Lock ¹	Twice	File Retention Time	10 times
Forwarding ¹	3 times	Cassette used for Printer Mode ³	11 times
Specified Cassette Selection ²	4 times		
Power Saver	5 times		
RDS *	6 times		
Confidential File Report ¹	7 times		


User Parameter Settings

A wide range of features can be switched on or off by using the User Parameters. However, this feature is more difficult to use than the On/Off Switches. The switches and adjustments are presented on the screen as rows of digits. Each digit can be either 0 or 1. Each feature is allocated one or more digit. The value of the digit determines the status of the feature.

The overall procedure is explained below. However, each of the adjustments that can be made using this procedure are explained in the relevant parts of the manual.

1. **Function** **6** **0** **2** **2** **2** **2**
9 **1**

USER PARAMETER	PRI NT LI ST	
DEFAULT:	01000000	
SW TCH00:	01000000	YES TO END 

- ☐ At this time, you can print a User Parameter List if you press  **Start** .

2. The current settings for switch 00 are now displayed on the bottom line of the display. If the settings for this switch are the way that you want them, go to step 4.
 - ☐ The top line shows the settings normally seen in a machine just delivered from the factory.
3. To change the required setting, press a number from 0 to 7 corresponding to the digit that you wish to change.

Example: **0** . The value of the digit changes, in this case from 0 to 1.

USER PARAMETER	PRI NT LI ST	→
DEFAULT:	01000000	↑
SW TCH00:	01000001	↓
	YES TO END	

Each switch contains 8 digits, which act as on/off switches for various features. The digits are numbered from 7 to 0; the setting of digit 7 is shown at the left side of the display and digit 0 is at the right.


4. Either:
 - ☐ Scroll through the switches with **↑** and **↓** until the required switch appears. Then go to step 3.
 - ☐ Finish: **Yes** **Function**

The user parameter switches are outlined below.

Switch 00 - Home position settings

Digit	Purpose						
0	Stamp	0: Off 1: On (successfully scanned documents will be marked)					
1	Resolution	Digit 2	Digit 1	Setting	Digit 2	Digit 1	Setting
2		0	0	Normal	1	0	Darken
		0	1	Lighten	1	1	Do not use this.
3	Resolution	Digit 4	Digit 3	Setting	Digit 4	Digit 3	Setting
4		0	0	Standard	1	0	Super Fine
		0	1	Detail	1	1	Do not use this.
5	Transmission mode			0: Memory transmission 1: Immediate transmission			
6	If you change any of the contrast, resolution, transmission mode, stamp, or halftone settings before making a transmission, then: 0: The setting(s) will not return to the home position after the transmission. 1: The setting(s) will return to the home position after the transmission.						
7	Halftone			0: Off		1: On	

Switch 01 - Printing of various items on received messages

Digit	Purpose
0	Mark to be printed at the receiving side to distinguish messages that are sent from your machine when it is acting as a forwarding station (Memory card or hard disk required) 0: Off 1: On Forwarding mark: 
1	Center mark 0: Off 1: On The center mark is not printed when the machine is used for making copies
2	Reception time 0: Off 1: On
3	TSI printing 0: Off 1: On
4	Checkered mark 0: Off 1: On
5	Printing of the Command Information Line (ISDN kit required) 0: Off 1: On This has the same effect as the TTI On/Off setting.
6, 7	Do not change these settings.

Switch 02 - Automatic printing of reports

Digit	Purpose
0	Transmission result report (memory transmission) 0: Off 1: On
1	Do not change this setting.
2	Memory storage report 0: Off 1: On
3	Polling reserve report (polling reception) 0: Off 1: On
4	Polling result report (polling reception) 0: Off 1: On
5	Transmission result report (immediate transmission) 0: Off 1: On
6	Polling clear report 0: Off 1: On
7	TCR 0: Off 1: On

Switch 03 - Automatic printing of reports, Various

Digit	Purpose
0	Inclusion of part of the image on the following reports: Transmission Result Report, Memory Storage Report, Polling Clear Report, Communication Failure Report, Transfer Result Report, Transmission Deadline Report, Polling Confirmation List 0: No 1: Yes
1	Do not change this setting.
2	Transfer Request by Tone Dial 0: Disabled 1: Enabled
3	Secure Transmission home position 0: Off 1: On
4	Batch Transmission home position 0: Off 1: On
5	Specified Image Area home position 0: Off 1: On
6 to 7	Do not change these settings.

Switch 04 - Various

Digit	Purpose
0	Do not change these settings.
1	
2	Auto reduce 0: Off 1: On
3	Do not change these settings.
4	
5	Restricted Access 0: Off 1: On
6	Service Report Transmission 0: Disabled 1: Enabled If this is set to 1, store your dealer's fax number in Quick Dial Key 63. Then, when you need to order toner, use the procedure on page 227. If you wish to use Quick Dial 63 for a number other than that of your dealer, set this bit to 0. Quick Dial Key 63 can now be programmed in the same way as other Quick Dial Keys. However, you will not be able to use the Service Report Transmission feature.
7	Ordering Toner 0: Disabled 1: Enabled If this is set to 1, store your dealer's fax number in Quick Dial Key 64. Then, when you need to order toner, use the procedure on page 197. If you wish to use Quick Dial 64 for a number other than that of your dealer, set this bit to 0. Quick Dial Key 64 can now be programmed in the same way as other Quick Dial Keys. However, you will not be able to use the Ordering Toner feature.

HOW TO USE
THIS MANUAL**Switch 05 - Various**

Digit	Purpose
0	Substitute reception 0: Off 1: On
1	Reverse order printing (Memory card or hard disk required) 0: Off 1: On
2	Two in One 0: Off 1: On
3	Memory reception if no RTI or CSI received 0: Possible 1: Not possible
4 to 7	Do not change these settings.

Switches 06 and 07 - Do not use

GENERAL PRECAUTIONS




WARNING: Do not attempt any maintenance or troubleshooting other than that mentioned in this manual. This machine contains a laser beam generator and direct exposure to laser beams can cause permanent eye damage.

POWER AND GROUNDING

Pay attention to the following.

Power Supply

1. Power requirements: 115 V, 60 Hz
2. Insert the power plug securely into the wall socket.
3. Make sure that the wall outlet is near the machine and readily accessible.
4. Do not connect other equipment to the same socket.
5. Do not step on or set anything on the power cord.
6. Do not connect other equipment to the same extension cord.
7. Be sure that the power cord is not in a position where it would trip someone.
8. The wall outlet must be easily accessible.



Grounding

Ground the machine and the lightning protection circuit in accordance with regulations. Do not ground to gas or water pipes, or to a telephone ground plug. Proper grounding is to the ground terminal of the power outlet. Be sure that the ground terminal of the power outlet is properly grounded.


The lightning protection circuit for the machine requires the machine to be properly grounded. If proper grounding is provided, about 90% of lightning damage can be prevented. For safety, be sure to connect the machine to a three-prong grounded outlet.

COLD WEATHER POWER-UP

Avoid raising the room temperature abruptly when it is below 57°F, or condensation may form inside the machine.

1. Raise the room temperature to 68°F at less than 18°F per hour.
2. Wait for 30 to 60 minutes.
3. Turn the power on.

Do not use the machine near a humidifier.




GENERAL
PRECAUTIONS

THUNDERSTORMS

With proper grounding, about 90% of lightning damage can be prevented. However, if possible, during severe electric storms turn the power switch off and disconnect the power cord and telephone line cord.

Note for users with no hard disk

All fax messages stored in the memory may be erased if power is switched off for more than an hour.



GENERAL PRECAUTIONS

COPY PAPER

- ☐ 15-20 lb. copy paper is recommended: letter or legal sizes are the most commonly used
- ☐ Do not use damp paper, or copies will be defective.
- ☐ Do not touch copy paper if your fingers are wet or oily; fingerprints may appear on the copy.
- ☐ Keep paper in a vinyl bag if it will not be used for a long time.
- ☐ Store in a cool dry place.
- ☐ Store flat. Do not stand upright.
- ☐ The following materials cannot be used in the paper trays: Post cards, Tracing paper, OHP sheets, Adhesive labels
- ☐ Do not overload the paper trays.
- ☐ If multi-sheet feeding occurs or dog-eared copies are made when using recycled paper in the paper tray, fan the recycled paper and load it in the paper tray again.

TONER CARTRIDGES

- ☐ Store in a cool, dark place.
- ☐ Never store where they may be exposed to heat.
- ☐ Keep out of the reach of children.
- ☐ Do not eat toner.
- ☐ Do not lay heavy objects on toner cartridges.
- ☐ Do not incinerate toner or toner containers. Toner dust may cause flashback when exposed to an open flame.

OPERATING PRECAUTIONS

- ☐ While the machine is in operation, do not turn off the main switch or unplug the power cord.
- ☐ Keep corrosive liquids, such as acid, off the machine.
- ☐ Do not allow paper clips, staples, or other small metallic objects to fall inside the machine.
- ☐ The fusing unit may be very hot. Be careful when handling it.

GENERAL

- ☐ Read the Important Safety Information at the front of this manual.
- ☐ Since some parts of the machine are supplied with high voltage, make sure that you do not attempt any repairs or attempt to access any part of the machine except those described in this manual.
- ☐ Do not make modifications or replacements other than those mentioned in this manual.
- ☐ When not using the machine for a long period, disconnect the power cord.

OZONE

The machine generates ozone during operation. Normally, the ozone level is safe for operators. However, during a long copy run or while printing a long message, ozone odor may appear; in such a case, ventilate the room.

WARNING:




This symbol is attached to some components to alert the user not to touch them, because they may be very hot.




This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the machine.

GUIDE TO COMPONENTS



1	Document Table	8	Scanner Release
2	Document Guide	9	Lifting Handle
3	Operation Panel	10	Front Cover Release
4	Telephone : optional	11	Cassette
5	Manual Feed Button	12	Copy Tray
6	Document Tray	13	Lower Cassette(s) or Drawers: optional Up to 4 units can be added below the upper cassette
7	Power Switch (on the rear)	14	Base : optional (labelled Cabinet Type 40 on the carton)


OPERATION PANEL



OPERATION
PANEL

1.	Power Indicator	Lights when the power switch is on. To use the machine, turn the switch to 'On'.
	Communicating Indicator	Lights when a fax message is being transmitted or received.
	Receive File Indicator	Lights when an incoming message was received into memory because the machine was out of paper or jammed.
	Confidential File Indicator	Lights when a confidential file has been received and stored in the memory. Blinks when a message has been stored using Memory Lock, if no confidential files are present.
	Reception Mode Selector Key	Press to select Auto Receive or Manual Receive.
	Stamp Key	Press to enable or disable the stamp feature.
	Line Fail Indicator	Blinks when transmission fails.
	Clear Copy Indicator	Blinks when paper has jammed in the printer.
	Add Toner Indicator	Blinks when the toner cartridge is almost empty, and lights when it is empty.
	Call Service Indicator	Blinks when the machine diagnostics detect a problem that requires service.
	Clear Original Indicator	Blinks when a document has jammed in the scanner.
	Add Paper Indicator	Lights when a cassette is empty.
	Close Cover Indicator	Blinks when a cover is open.

OPERATION PANEL

2.	Display	Displays prompts, warnings, and selected modes.
	Function Key	Press to use one of the numbered functions.
	Yes/No Keys	Use to answer questions on the display.
	Scroll Key	When an arrow is shown on the display, use this key to access the options, items, or functions shown by the arrow. Also use it to move the cursor when programming or editing a displayed item.
3.	PC Printer Option Indicators	These indicators are only used when the optional Printer Interface Kit is installed. See the operation manual for the Printer Interface Kit for full details.
	Halftone Key	Press this to use halftone mode.
	Contrast Selector Key	Press this to select either Darken, Normal, or Lighten.
	Resolution Selector Key	Press this to select either Standard, Detail, or Super Fine.
	Memory Key	If the indicator is lit, your document will be stored before transmission. If it is not lit, your document will be sent immediately without being stored. Press the key to change the mode.
	G4/G3 Selector Key	When dialing, press this key to light the indicator that corresponds with the type of network that you wish to communicate on. The G4 setting is only available if you have installed the optional ISDN Interface Kit.
4.	Quick Dial Keys	<p>Each of these can be programmed with a telephone number, a group, or a keystroke program. You can also use these keys to type names and labels such as the RTI and TTI.</p> <p>To access keys 01 to 32, flip the number plate over to the right.</p> <p>To access keys 33 to 64, flip the number plate over to the left.</p> 
5.	User Function Keys	Each of these can be programmed for rapid access to frequently used features. If the light under a key is on, the feature can be used.
6.	Speed Dial/Tel Directory Key	Press this to dial using Speed Dial or the Telephone Directory Feature.
	AI Redial Key	Press this to redial one of the last ten numbers that was dialed.
	On Hook Dial Key	Press this to dial without picking up the handset.
	Pause Key	Press this if you need to insert a pause when dialing.
	Clear Key	Use this as a backspace key during programming.
	Ten Key Pad	Use this as a telephone keypad, or to enter Speed Dial codes.
	Stop Key	Press this to stop the machine and return it to standby mode.
	Start Key	Press this to start fax communication.
	Copy Key	Press this to copy the document now in the feeder.


INSTALLING THE MACHINE

LOCATION

For the best possible performance, install your machine in a place which satisfies the following conditions.

- ☐ Not exposed to direct sunlight
- ☐ Well ventilated (air turnover at least three times per hour); to avoid the build-up of ozone, make sure to locate the machine in a large well-ventilated room which has an air turnover of more than 30 yd³/hr per person.
- ☐ Level
- ☐ Not subject to vibration
- ☐ Away from other electronic equipment, to avoid interference
- ☐ Away from areas containing corrosive gas
- ☐ Dust-free
- ☐ Condensation-free
- ☐ Temperature 63 to 82 °F
- ☐ Humidity 40 to 70% RH (do not install near a humidifier)
- ☐ Away from heaters and air conditioners, to avoid sudden changes of temperature
- ☐ Within 5 yards of a three-pin grounded power outlet (115 Volts, 60 Hz)
- ☐ With the clearance as shown on the right

INSTALLING THE
MACHINE




NOTE: This machine generates a certain amount of ozone. Although the amount generated is within safety requirements, it is recommended that, to avoid ozone buildup, you install the machine in a room which can be air-conditioned or well ventilated.

CONNECTING THE MACHINE

A service technician will install the machine.

Before using the machine:

- ☐ Make sure that it is properly connected to the telephone line and the power outlet, as shown below.



CAUTION

Do not switch on until everything is connected properly.
If you wish to move the machine to a new location, contact a service technician.

- ☐ Program the Telephone Line Type setting (use Function 81; see page 28). If your telephone normally sends out tones when dialing, use the TT setting; if it normally sends out pulses, use the DP setting. Also, make sure that the switch on the handset is set up correctly.

IMPORTANT POINTS ABOUT POWER CONNECTION

- ☐ The wall outlet supply must not vary more than 20 V either side of 115 Vac.
- ☐ The power cord should not be laid in a place where it might trip somebody.
- ☐ Do not lay anything on the power cord.
- ☐ If you have to use an extension cord, make sure that it is capable of carrying 125V/15A, and that your facsimile terminal is the only piece of equipment connected to that cord.

BEFORE YOU SEND YOUR FIRST FAX

SOME ITEMS MUST BE PROGRAMMED FIRST

Overview

After you have installed your new machine and connected it to the telephone line, there are a few things that you have to do before you start to send fax messages from your new machine.

You should set up your machine's clock and identification. In fact, for faxes sent to from, or within the United States, the United States' Federal Communications Commission (FCC) states that the fax message must contain header information that identifies the sender (or the sender's organization), and the date and time that the fax was sent. To do this, program the following features.

- ☐ Date and Time/Daylight Saving Time: see page 24.
- ☐ RTI (Remote Terminal Identification): see page 26.
- ☐ TTI (Transmit Terminal Identification): see page 26.
- ☐ CSI (Called Subscriber Identification): see page 27.

In addition, you also have to make sure that the fax machine's dialing circuits are set up correctly. There are two settings: Pulse Dial, and Tone Dial. If you select the wrong setting, your machine will not be able to dial fax numbers. If you are not sure which setting to use, contact your telephone company. To change this setting, see the following section of the manual.

- ☐ Telephone Line Type: see page 28.

Also, if you have a handset attached to your fax machine, make sure that its dialing circuit is also set up correctly (there is probably a switch on the side of the handset).

Language Selection

If your native language is Spanish or French, you can have the machine display instructions and print reports in either of these languages instead of in English.

1. **Function** **6** **0** **2** **2** **2** **2**
9 **4**

LANGUAGE	SELECT	←	→
ENGLISH	FRENCH	SPANISH	
		YES	TO END

2. Use the **←** and **→** arrows on the scroll key to move the cursor to the correct language. Press **Yes** **Function** to finish.

- ☐ Once you have done this, all displays and reports will be in the selected language.

BEFORE YOU SEND
YOUR FIRST FAX

Date and Time

Your fax machine has an internal clock. It controls the following features.

- ☐ The time display on the operation panel while the machine is idle.
- ☐ Operation of time-delay features like Send Later.
- ☐ The date and time that is printed out on pages that you receive, if Reception Time is switched on.
- ☐ The date and time that is printed out at the other end on pages received from your machine.

Program the correct date and time when you install the machine.

Cross-references:

Send Later: see page 60.

Reception Time: see page 149.

Economy Transmission: see page 66.

1. **Function** **6** **0** **2** **2** **2** **2** **9** **2**

CLOCK	INPUT DATE/ TIME	
FEB	01 1992 (SAT)	01:56PM
<input type="button" value="←"/> <input type="button" value="→"/> <input type="button" value="YES"/>		TO END

2. Use the and arrows on the scroll key to move the cursor across the display. Use the keypad to correct the individual elements.

- ☐ To change the month, move the cursor to the month and scroll through the months with the and keys.
- ☐ To change from AM to PM and vice versa, move the cursor to the time, and press or .
- ☐ Press **Yes** **Function** when the display is correct.

Daylight Saving Time



Whenever local custom requires advancing the clock or setting the clock back, use this feature. You can easily move the clock forwards when daylight saving time begins, and back when it ends.

- ☐ When you install the machine for the first time, take care that the setting is correct before you set the date and time.

1. **Function** **6** **0** **2** **2** **2** **2** **8** **1**
then until the screen is as shown opposite.

DAYLIGHT SAVING TIME	SELECT	<input type="button" value="←"/>	<input type="button" value="→"/>
ON	OFF	<input type="button" value="↑"/>	
<input type="button" value="YES"/>		TO END <input type="button" value="↓"/>	


2. Use the ☐ and ☐ arrows on the scroll key to switch this feature on or off.
3. To store your setting: ☐ **Yes**

Terminal Identification

There are three labels which identify yourself to the operator at the other end. These labels are called the RTI, the TTI, and the CSI.

- ☐ **RTI (Remote Terminal Identification) and CSI (Called Subscriber Identification):** These appear at the other end in the display on the operation panel during communication, and on reports after communication.
- ☐ **TTI (Transmit Terminal Identification):** This is printed at the other end at the top of each page received from your machine.

You can see the RTI, TTI, and CSI of the other party during the communication (see the following diagram) and on reports printed by the machine later.



BEFORE YOU SEND
YOUR FIRST FAX

Some machines may reject your transmitted fax messages if you have not stored the RTI, TTI, or CSI in advance.

Note: You can switch the TTI off for a particular transmission if you do not wish it to be printed on your pages as they are printed at the other end. See page 64.

RTI (Remote Terminal Identification)

Your RTI appears on the other party's operation panel during communication, if the other machine was made by the same manufacturer as yours. The RTI can have up to 20 characters (numbers and letters can be used, along with some punctuation marks). Program something easy to recognize, such as your name, company name, or department name within the company.

1. **Function** **6** **0** **2** **2** **2** **2**

6 **1** then **↓** until the screen is as shown opposite.

RTI	
YES TO SET	PREVIOUS ↑
NO TO CANCEL	NEXT ↓

2. **Yes**

RTI	
NO TO CANCEL	ABC
[REDACTED]	

3. Input the RTI that you will be using.
Example: XYZ COMPANY

Note: Not more than 20 characters.



Input and editing are explained on page 7.

RTI		YES OR CLR · NO
XYZ COMPANY		ABC

4. **Yes** **Function**

TTI (Transmit Terminal Identification)

Your TTI is printed at the other end on the top edge of each page that you send. The TTI can have up to 32 characters (numbers and letters can be used, along with some punctuation marks). Program something easy to recognize, such as your name, company name, or department name within the company.

1. **Function** **6** **0** **2** **2** **2** **2**

6 **1** then **↓** until the screen is as shown opposite.

TTI	
YES TO SET	PREVIOUS ↑
NO TO CANCEL	NEXT ↓

2. **Yes**

TTI		LABEL I NSERTI ON
SELECT	[REDACTED]	YES TO END
1. I NPUT	2. COPY RTI	

3. Either:

- ☐ Copy the RTI across and store that as the TTI: **2** . Then go to step 5.
(Or, if you wish to edit the TTI: **↑** **Yes**)
- ☐ Input a new TTI or edit the TTI that is already there: **1** . Go to step 4.

TTI	NO TO CANCEL
<div style="background-color: black; width: 100px; height: 1.2em; margin-bottom: 2px;"></div>	ABC
<div style="background-color: black; width: 100px; height: 1.2em;"></div>	

4. Input the TTI that you will be using.
Example: XYZ COMPANY HEAD OFFICE

Note: Not more than 32 characters.



Input and editing are explained on page 7.

TTI	YES OR CLR · NO
<div style="background-color: black; width: 100px; height: 1.2em; margin-bottom: 2px;"></div> XYZ CO. HEAD OFFI CE	ABC
<div style="background-color: black; width: 100px; height: 1.2em;"></div>	

5. **Yes** **Function**

CSI (Called Subscriber Identification)

Your CSI appears on the other party's operation panel during communication instead of your RTI, if the other party's machine is another manufacturer's product. The CSI can have up to 20 characters (only numbers and spaces can be used). Enter your fax machine's telephone number, because some features of your machine may not work if the CSI is not the same as the telephone number.

BEFORE YOU SEND
YOUR FIRST FAX

1. **Function** **6** **0** **2** **2** **2** **2**
6 **1** then **↓** until the screen is as shown opposite.

CSI	YES TO SET	PREVI OUS ↑
	NO TO CANCEL	NEXT ↓

2. **Yes**

CSI	YES TO END
<div style="background-color: black; width: 100px; height: 1.2em; margin-bottom: 2px;"></div>	
<div style="background-color: black; width: 100px; height: 1.2em;"></div>	

3. Input your telephone number.

Note: Not more than 20 digits.

- ☐ If you wish to input a "+" sign, to signify your international dial access code (this is a common practice in Europe): **31**

CSI	YES OR CLR · NO
<div style="background-color: black; width: 100px; height: 1.2em; margin-bottom: 2px;"></div> 212-555-6789	
<div style="background-color: black; width: 100px; height: 1.2em;"></div>	

4. **Yes** **Function**

Telephone Line Type

If the setting of this feature is incorrect, you will not be able to dial using the machine's keypad or automatic dialer.

There are two basic types of telephone company exchange:

- ☐ Exchanges using Tone Dialing (also known as DTMF, TT, or sometimes PB)
- ☐ Exchanges using Pulse Dialing (also known as PD or DP)

The telephone line type setting in your fax machine must match the type of exchange that you are connected to. If you are not sure what type your local exchange is, ask the telephone company.

Note: If there is a handset connected to your fax machine, make sure that it is also set up in the correct dialing mode.

Change the setting for the fax machine using Function 81.

1. **Function** **6** **0** **2** **2** **2** **2** **8** **1**

PSTN LI NE TYPE	SELECT	←	→
DP	TT	↑	↓
	YES	TO END	


The first displayed item is the telephone line type: DP = Pulse Dial, TT = Touch Tone. In the above display, TT is currently selected.

2. Change the setting by using **←** or **→**.

3. Finish: **Yes** **Function**

QUICK DIAL, SPEED DIAL, AND GROUP DIAL

Three Convenient Ways to Dial



Instead of dialing the full number on the fax machine's keypad, you can use Speed Dial, Quick Dial or Group Dial.

These features allow you to store telephone numbers in your machine's memory. (A stored number will remain in the memory, and you can use it as many times as you wish without having to reprogram it.)

Then, when you need to dial a number, just call it up (for example, by pressing the required Quick Dial Key).

Quick Dial and Speed Dial

Quick Dial and Speed Dial are very convenient for dialing numbers that you often call, especially if these numbers are very long (like international numbers).

These features greatly improve the convenience of operating your machine. However, first, you have to program the telephone numbers that you need into the Quick Dial Keys and Speed Dial Codes in your machine.

After programming your Quick Dials and Speed Dials, you can dial a telephone number with very few keystrokes.

- ☐ For Quick Dial, just press a Quick Dial Key then press Start.
 - ☐ For Speed Dial, press the key on the operation panel labeled "Speed Dial", enter a two-digit Speed Dial Code, then press Start.
- You can also access Speed Dial codes using the Telephone Directory feature (see page 58).

BEFORE YOU SEND YOUR FIRST FAX

You can store up to 64 Quick Dial Keys and 100 Speed Dial Codes in this model.

When you store a Quick Dial or Speed Dial, you can also store the name of the other party as a quick reference (this name will be displayed on the operation panel before you press the Start key, so you can check whether you have selected the correct number). This label is used with features such as Telephone Directory or Label Insertion.

For the Quick Dial Keys, you can also attach adhesive labels to the quick dial plate.

Cross-references

Telephone Directory: see page 58.

Label Insertion: see page 120.

Groups

If you frequently send the same message at the same time to more than one place, program these telephone numbers into a group. Then you can send the messages to all the addresses in that group with just a few keystrokes.

You can also program a name for that group (for example, "Branch Offices"), which will be displayed before you press the Start key. This helps you to check whether you selected the correct group.

You can store up to 10 Groups in this machine.

Groups can be used with the following features.

- ☐ Sending to More Than One Location (Broadcasting); see page 51.
- ☐ Transfer Request; see page 87.
- ☐ Polling Reception; see page 158.

Caution: There are limits on the number of addresses that can be dialed with each of these features. Do not store more numbers in the group than the capacity of the feature that you plan to use it with. These limits are:

Broadcasting: 200 addresses

Transfer Request: 30 addresses

Polling Reception: 200 addresses

Programming Quick Dial



This machine has 64 Quick Dial Keys (01 to 64), each of which can be programmed as **one** of the following: Quick Dial Key, Group, Auto Document, or Keystroke Program. The page number in the following table shows the location of the programming procedure.

1	Quick Dial	A fax or telephone number	This page
2	Group	A set of fax numbers that you often wish to send the same fax to at the same time.	Page 38
3	Keystroke Program	A program of settings, features, and destinations.	Page 99
4	Auto Document	A page that you often send, such as a map.	Page 106

Using the following procedure, you can store telephone numbers as Quick Dials. You can also store a label with each number for use with the Label Insertion feature.

Cross-reference

Label Insertion: see page 120.

Note: You cannot use the following procedure to store Groups, Keystroke Programs or Auto Documents.

BEFORE YOU SEND
YOUR FIRST FAX

Programming a New Quick Dial

1. **Function** **3** **1**

- ☐ At this time, you can print a Quick Dial List if you press **→** **Start** .

2. Press the Quick Dial Key that you wish to program. Example: **01**

- ☐ If you pressed the wrong key, press **No** .

3. **Yes**

4. Enter the telephone number at the operation panel's ten key pad.

If your machine is behind a PBX, include the access code and a pause before the tel. number. For an international number, place a pause after the country code. To input a pause, press the Pause key.

BEFORE YOU SEND YOUR FIRST FAX

5. **Yes**

QUI CK DI AL	ENTER LABEL
<input checked="" type="checkbox"/> 01	<div style="background-color: black; width: 150px; height: 1.2em; display: inline-block;"></div> ABC

6. Either:

- ☐ Input a label using the Quick Dial keys. Then press **Yes**.

? Inputting and editing labels: see page 7.

- ☐ Do not program a label:
Press **Yes**.

QUI CK DI AL	OPTI ON SETT I NG
LABEL I NSERTI ON	ON OFF
SELECT	<input type="button" value="←"/> <input type="button" value="→"/> <input type="button" value="YES"/> TO END

7. Switch Label Insertion on or off.

Use the and arrows on the scroll key to select the required setting.
Then: **Yes**

QUI CK DI AL	CHOOSE KEY
<input checked="" type="checkbox"/> <div style="background-color: black; width: 20px; height: 20px; display: inline-block;"></div>	PRI NT LI ST <input type="button" value="→"/>
	<input type="button" value="NO"/> TO CANCEL

8. Either

- ☐ Program another: Go to step 2
☐ Finish: **Function**

Editing a Quick Dial

1. **Function** **3** **1**

QUI CK DI AL	CHOOSE KEY
<input checked="" type="checkbox"/> <div style="background-color: black; width: 20px; height: 20px; display: inline-block;"></div>	PRI NT LI ST <input type="button" value="→"/>
	<input type="button" value="NO"/> TO CANCEL

2. Press the Quick Dial key that you wish to edit. Example: **01**

- ☐ If the wrong number is displayed, use the and keys to scroll through the Quick Dial Keys on the screen.

QUI CK DI AL	<input type="button" value="YES"/> OR <input type="button" value="NO"/>
<input checked="" type="checkbox"/> 01	XYZ CO. NEWYORK
	2125551234
	<input type="button" value="↑"/> <input type="button" value="↓"/>

3. **Yes**

QUI CK DI AL	<input type="button" value="YES"/> OR <input type="button" value="CLR"/> · <input type="button" value="NO"/>
<input checked="" type="checkbox"/> 01	<div style="background-color: black; width: 150px; height: 1.2em; display: inline-block;"></div>
	2125551234

4. Edit the number.

- ☐ Use and to move the cursor, and use to delete the character at the cursor.

After entering the new number, press **Yes**.

QUI CK DI AL	<input type="button" value="YES"/> OR <input type="button" value="CLR"/> · <input type="button" value="NO"/>
<input checked="" type="checkbox"/> 01	XYZ CO. NEWYORK
	<div style="background-color: black; width: 150px; height: 1.2em; display: inline-block;"></div> ABC

5. Either

- ☐ Change the label: Edit the existing label, then press **Yes** .
- ☐ Keep the label as it is: **Yes**



Inputting and editing labels: see page 7.

QUI CK DI AL	OPTI ON SETTI NG
LABEL I NSERTI ON	ON OFF
SELECT	← → YES TO END

6. Switch Label Insertion on or off.

Use the **←** and **→** arrows on the scroll key to select the required setting.
Then: **Yes**

QUI CK DI AL	CHOOSE KEY
■	PRI NT LI ST →
—	NO TO CANCEL

7. Either

- ☐ Program another: Go to step 2.
- ☐ Finish: **Function**

Erasing a Quick Dial1. **Function** **3** **1**

QUI CK DI AL	CHOOSE KEY
■	PRI NT LI ST →
—	NO TO CANCEL

2. Press the Quick Dial key that you wish to erase. Example: **01**

- ☐ If the wrong number is displayed, use the **↑** and **↓** keys to scroll through the Quick Dial Keys on the screen.

QUI CK DI AL	YES OR NO
■ 01 XYZ CO. NEWYORK	↑
2125551234	↓

3. **Yes**

QUI CK DI AL	YES OR CLR NO
■ 01	
2125551234	

4. Erase the number: **No** .

QUI CK DI AL	ENTER FAX NUMBER
■ 01	NO TO CANCEL

After erasing a number, you may store a new one to replace it if you wish.
If you do not wish to store a new number, press **No** again. Then go to step 2 to continue or press **Function** if you have finished.

Programming Speed Dials



Using this feature, you can store telephone numbers as Speed Dial Codes. You can also store a label with each telephone number for use with the Telephone Directory and Label Insertion features.

Telephone Directory

This makes using Speed Dial Codes more convenient.

When you program a Speed Dial Code, you can program a name and a telephone number. Then, instead of having to refer to the latest Speed Dial Code list when you want to dial that number, you can type in the first letter of the name, and scroll through the list of names that begin with that letter until you find the right one.

You may also program the letter under which you wish to file the label. For example, if a Speed Dial Code has the label HOTEL NEW YORK, you may wish to file this label under N instead of under H if your Telephone Directory contains a lot of hotels. This would make it easier to find using the Telephone Directory feature; type in N instead of H, then scroll through the N's until you find the HOTEL NEW YORK.

Cross-reference

Label Insertion: see page 120.

Telephone Directory: see page 58.

Programming a New Speed Dial

1. **Function** **3** **2**

- ☐ At this time, you can print a Speed Dial List if you press **→** **Start** .

SPEED DI AL	ENTER SPEED CODE
<input checked="" type="checkbox"/> 00	PRI NT LI ST →
—	NO TO CANCEL

2. Input the Speed Dial Code that you wish to program (from 00 to 99).

Example: **00** **00**

- ☐ If you input the wrong code, press **No** .

SPEED DI AL	YES OR NO
<input checked="" type="checkbox"/> 00	↑
	↓

3. **Yes**

SPEED DI AL	ENTER FAX NUMBER
<input checked="" type="checkbox"/> 00	NO TO CANCEL
0000000000	

4. Enter the telephone number at the operation panel's ten key pad.

SPEED DI AL	YES OR CLR . NO
<input checked="" type="checkbox"/> 00	
01144715551234	

If your machine is behind a PBX, include the access code and a pause before the telephone number.

For an international number, place a pause after the country code. To input a pause, press the Pause key.

5. **Yes**

SPEED DI AL	ENTER LABEL
<input checked="" type="checkbox"/> 00	ABC

6. Either:

- ☐ Input a label using the Quick Dial keys (such as XYZ CO. LONDON). Then press **Yes**.

? Inputting and editing labels: see page 7.

SPEED DI AL	YES OR CLR . NO
<input checked="" type="checkbox"/> 00	ABC
I NPUT: X	

- ☐ Do not program a label for this number: Press **Yes**. Go to step 9.

7. The letter shown next to "I NPUT" will be used with the Telephone Directory feature when searching for a name.

Either:

- ☐ Do not change the letter : press **Yes**.
- ☐ If you wish to use another letter, input the letter.
Example: Change to "L" for London;

Clear **L** **Yes**

SPEED DI AL	OPTI ON SETTI NG
LABEL I NSERTI ON	ON OFF
SELECT ← → YES TO END	

8. Switch Label Insertion on or off.

Use the **←** and **→** arrows on the scroll key to select the required setting. Then: **Yes**

SPEED DI AL	ENTER SPEED CODE
<input checked="" type="checkbox"/> —	PRI NT LI ST →
	NO TO CANCEL

9. Either:

- ☐ Program another: Go to step 2.
- ☐ Finish: **Function**

BEFORE YOU SEND
YOUR FIRST FAX

Editing a Speed Dial

1. **Function** **3** **2**

SPEED DI AL	ENTER SPEED CODE
<input checked="" type="checkbox"/> 00	PRI NT LI ST →
—	NO TO CANCEL

2. Input the Speed Dial Code that you wish to edit. Example: **00**

- ☐ If the wrong number is displayed, press **No** or use the **↑** and **↓** keys to scroll through the Speed Dial Codes on the screen.

SPEED DI AL	YES OR NO
<input checked="" type="checkbox"/> 00 XYZ CO. LONDON	↑
01144715551234	↓

3. **Yes**

SPEED DI AL	YES OR CLR . NO
<input checked="" type="checkbox"/> 00	
01144715551234	

4. Edit the number.

- ☐ Use **←** and **→** to move the cursor, and use **Clear** to delete the cursor character.

After entering the new number, press **Yes** .

SPEED DI AL	YES OR CLR . NO
<input checked="" type="checkbox"/> 00	
XYZ CO. LONDON	ABC

5. Either

- ☐ Change the label: Edit the existing label, then press **Yes** .
- ☐ Keep the label as it is: **Yes**



? Inputting and editing labels: see page 7.

SPEED DI AL	YES OR CLR . NO
<input checked="" type="checkbox"/> 00	
I NPUT: X	ABC



6. Either:

- ☐ Change the letter in the INPUT column (for example, to P): **Clear** **P** **Yes**
- ☐ Do not change the letter: **Yes** .

SPEED DI AL	OPTI ON SETT I NG
LABEL I NSERTI ON	ON OFF
SELECT ← →	YES TO END

7. Switch Label Insertion on or off. Use the  and  arrows on the scroll key to select the required setting.



Then: **Yes**

SPEED DI AL	ENTER SPEED CODE
<input checked="" type="checkbox"/> 	PRI NT LI ST 
—	NO TO CANCEL



8. Either
- ☐ Program another: Go to step 2.
 - ☐ Finish: **Function**

Erasing a Speed Dial

1. **Function** **3** **2**

SPEED DI AL	ENTER SPEED CODE
<input checked="" type="checkbox"/> 	PRI NT LI ST 
—	NO TO CANCEL

2. Input the Speed Dial Code that you wish to erase. Example: **0** **0**


- ☐ If the wrong number is displayed, press **No** or use the  and  keys to scroll through the Speed Dial Codes on the screen.

SPEED DI AL	YES OR NO
<input checked="" type="checkbox"/> 00 XYZ CO. LONDON	
01144715551234	

3. **Yes**

SPEED DI AL	YES OR CLR . NO
<input checked="" type="checkbox"/> 00	
01144715551234	

4. Erase the number: **No** .

SPEED DI AL	ENTER FAX NUMBER
<input checked="" type="checkbox"/> 00	NO TO CANCEL
	

After erasing a number, you can store a new one to replace it.

If you do not wish to store a new number, press **No** again, then go to step 2 to continue or press **Function** if you have finished.

BEFORE YOU SEND
YOUR FIRST FAX

Programming Groups



Groups allow you to combine some numbers into one group, for easy sequential transmission to all the numbers in that group. These numbers can be selected from those already stored in Quick Dial Keys or Speed Dial Codes, or you can select other numbers by entering them at the keypad.

You can also store a label with each Group. This label will be displayed when you select the Group.

Note: See page 51 to see how to dial a group.

The Group programming procedure has several modules. Entering Group Programming mode will be explained first, followed by each of the modules.

Entering Group Programming Mode and Selecting a Group

1. **Function** **3** **3**

- ☐ At this time, you can print a Group List if you press **→** **Start** .

GROUP DI AL	GROUP SETTI NG
G <input type="checkbox"/>	PRI NT LI ST →
—	NO TO CANCEL

2. Input the number of the group that you wish to program.

- ☐ There are 10 groups, from 01 to 10.

Example: Group 01, **0** **1** **Yes**

- ☐ If this group already exists, go to step 4.
☐ If you input the wrong group number, press **No** .

GROUP DI AL	CHOOSE KEY
G 01 <input type="checkbox"/>	YES TO SKI P
—	NO TO CANCEL

3. Press the Quick Dial Key in which you wish to store this new group.

Example: **08**

- ☐ If you pressed the wrong key: **No**

GROUP DI AL	YES OR NO
G 01 <input type="checkbox"/> 08	↑
	↓

4. **Yes**

GROUP DI AL	SELECT <input type="checkbox"/>
G 01 <input type="checkbox"/> 08 DEST. 0 YES TO END	
1. ADDRESS 2. CHECK 3. LABEL	↓

You are now ready to access one of the five Group Programming Modules. These are explained on the following pages.

Storing Numbers in a Group

First, enter Group Programming mode as explained on page 38. Then:

1. Press **1** .

GROUP DI AL	ENTER FAX NUMBER
G 01 <input type="checkbox"/> 08 DEST. 0	<input type="button" value="NO"/> TO CANCEL
<div style="background-color: black; height: 15px; width: 100%;"></div>	

2. Input the number that you wish to store in the group. For example:

- ☐ Quick Dial 25: **25**

GROUP DI AL	<input type="button" value="YES"/> OR <input type="button" value="CLR"/> . <input type="button" value="NO"/>
G 01 <input type="checkbox"/> 08 DEST. 0	
<input type="checkbox"/> 25 XYZ COMPANY ROME	

- ☐ Speed Dial 00: **Speed Dial** **0** **0**

GROUP DI AL	<input type="button" value="YES"/> OR <input type="button" value="CLR"/> . <input type="button" value="NO"/>
G 01 <input type="checkbox"/> 08 DEST. 0	
<input checked="" type="checkbox"/> 00 XYZ COMPANY PARI S	

- ☐ Full number: Input at the keypad on the operation panel.

GROUP DI AL	<input type="button" value="YES"/> OR <input type="button" value="CLR"/> . <input type="button" value="NO"/>
G 01 <input type="checkbox"/> 08 DEST. 0	
<div style="background-color: black; height: 15px; width: 100%;"></div> 011-44-21-5842261	

3. Store the number in the group: **Yes**

- ☐ The number after DEST has increased by 1. The number after DEST shows how many telephone numbers are stored in the group.

GROUP DI AL	ENTER FAX NUMBER
G 01 <input type="checkbox"/> 08 DEST. 1	<input type="button" value="NO"/> TO CANCEL
<div style="background-color: black; height: 15px; width: 100%;"></div>	

NOTE: Do not store more than 200 numbers in a Group. If you plan to use this Group for Transfer Requests, do not store more than 30 in it.

4. Either:

- ☐ Input another number: Go to step 2.
☐ Finish storing numbers in this group: **No** .

GROUP DI AL	SELECT <div style="background-color: black; width: 20px; height: 15px; display: inline-block;"></div>
G 01 <input type="checkbox"/> 08 DEST. 0	<input type="button" value="YES"/> TO END
1. ADDRESS 2. CHECK 3. LABEL <div style="background-color: black; width: 15px; height: 15px; display: inline-block; vertical-align: middle;"></div>	

Now, you can either:

- ☐ Use another module (press a key from 1 to 5).
☐ Start working on another Group (press **Yes** then go to step 2 of the procedure on page 38).
☐ Return to standby mode by pressing **Function** .

BEFORE YOU SEND
YOUR FIRST FAX

Checking Which Numbers are Already in the Group

First, enter Group Programming mode as explained on page 38. Then:

1. Press **2** .

GROUP DI AL	NO TO CANCEL
G 01 <input checked="" type="checkbox"/> 08 DEST. 1 / 25 CLR: CLR	
XYZ COMPANY ROME	

2. Press **↓** to scroll through the numbers on the display.

☐ To erase the displayed number:

Clear .

☐ When you have finished checking this group: **No** .

3. Now, you can either:

☐ Use another module (press a key from 1 to 5).

☐ Start working on another Group

(press **Yes** then go to step 2 of the procedure on page 38).

☐ Return to standby mode by pressing **Function** .

GROUP DI AL	SELECT ↓
G 01 <input checked="" type="checkbox"/> 08 DEST. 0 YES TO END	
1. ADDRESS 2. CHECK 3. LABEL ↓	

Storing a Label for this Group

First, enter Group Programming mode as explained on page 38. Then:

1. Press **3** .

GROUP DI AL	ENTER LABEL
G 01 <input checked="" type="checkbox"/> 08	
_____	ABC

2. Input a label for the group using the Quick Dial keys.

Example: EUROPE BRANCHES



Inputting and editing labels: see page 7.

GROUP DI AL	YES OR CLR . NO
G 01 <input checked="" type="checkbox"/> 08	
EUROPE BRANCHES	ABC

3. Press **Yes** .

GROUP DI AL	SELECT ↓
G 01 <input checked="" type="checkbox"/> 08 DEST. 0 YES TO END	
1. ADDRESS 2. CHECK 3. LABEL ↓	

Now, you can either:

☐ Use another module (press a key from 1 to 5).


☐ Start working on another Group (press **Yes** then go to step 2 of the procedure on page 38).

☐ Return to standby mode by pressing **Function** .

Storing a Group Transfer Station

The Group Transfer Station is one of the features of this machine that allows you to set up fax transmission networks.

Briefly, the Group Transfer Station allows another party to send you a fax message and instruct your machine to send it to each number in the same Group, through the Group Transfer Station, which acts as a broadcaster. This means that your machine will relay the fax message to the Group Transfer Station, and that station will then send it on to each of the numbers stored in that Group. All this will be done automatically, without requiring your presence at the machine.



The use of the Group Transfer Station is described in more detail in the section entitled "Networking".

To store a Group Transfer Station for a particular Group, first, enter Group Programming mode as explained on page 38. Then:

1. Press **4** .

GROUP DI AL		ENTER TRANSF. STN	
G 01	<input checked="" type="checkbox"/> 08	DEST. 0	<input type="checkbox"/> NO TO CANCEL
<div style="background-color: black; height: 15px; width: 100%;"></div>			

2. Store the telephone number of the terminal that you wish to act as the Group Transfer Station for this group.




☐ Input the number as a Quick Dial, Speed Dial, or full number at the keypad.

Example: Quick Dial 15, press **15** .

GROUP DI AL		<input type="checkbox"/> YES OR <input type="checkbox"/> CLR <input type="checkbox"/> NO	
G 01	<input checked="" type="checkbox"/> 08	DEST. 0	
<input checked="" type="checkbox"/> 15	XYZ COMPANY LONDON		

BEFORE YOU SEND YOUR FIRST FAX

3. **Yes**

GROUP DI AL	SELECT	
G 01		08 DEST. 0 YES TO END
1. ADDRESS 2. CHECK 3. LABEL 		

Now, you can either:


- ☐ Use another module (press a key from 1 to 5).
- ☐ Start working on another Group (press **Yes** then go to step 2 of the procedure on page 38).
- ☐ Return to standby mode by pressing **Function** .

Erasing the Group

This procedure deletes this Group and all the numbers stored in it. The Speed Dial Codes and Quick Dial Keys that you used in this Group will not be deleted from the memory; you can continue to use them for other purposes.




First, enter Group Programming mode as explained on page 38. Then:

1. Press **5** .

GROUP DI AL	
G 01	 08 W L L B E A L L C L E A R E D
CLEAR?	YES . NO

2. Either:

- ☐ To delete the group: **Yes**
- ☐ To keep the group: **No**

GROUP DI AL	SELECT	
G 01	 08 DEST. 0 YES TO END	
1. ADDRESS 2. CHECK 3. LABEL 		

Now, you can either:

- ☐ Use another module (press a key from 1 to 5).
- ☐ Start working on another Group (press **Yes** then go to step 2 of the procedure on page 38).
- ☐ Return to standby mode by pressing **Function** .

Limits on the Use of Stored Telephone Numbers

When you use the three features listed in the following table, you can dial more than one number. However, there are some limitations, as explained on this page.

COMMUNICATION FEATURE	PAGE	MAX. NUMBER OF ADDRESSES/FAX MESSAGE	TOTAL FAXES	TOTAL ADDRESSES FOR ALL FAXES	MAX. STORED PAGES
Broadcasting	51	200	200	500 (Note: Any fax number can be used for more than one fax message at the same time)	1200 (*4)
Transfer Request (*1)	87	30			
Polling Reception	158	200			

The following table shows how many telephone numbers you can store in the machine.

Quick Dials	64
Speed Dials	100
Ten Key Pad (*2)	65
Groups (*3)	10

- *1 The limitations on this feature are imposed by the capacity of the broadcasting machine.
- *2 This is the number of full telephone numbers that can be input into the machine at any one time. For example, if there is a broadcasting operation in memory using 64 full numbers, you can only input one more full number for any operation, including storage in groups, until the broadcast has finished. Also, if you have stored, say, 30 numbers at the ten key pad into your groups, then you will only be able to input 35 full dial numbers at any one time for other operations, such as broadcasting.
- *3 You can program up to 10 groups. Each group can contain up to 200 numbers; however, if you plan to use a Group for Transfer Request, make sure that this group does not have more than 30 numbers. You can store any Quick Dial or Speed Dial number in a group. You may also store up to 65 numbers that are not programmed as Quick or Speed Dials; see Note 2 above for the restrictions on the use of these numbers.
- *4 This is the theoretical maximum number of pages that can be stored. In practice, you will only be able to store this number of pages if you install the optional hard disk unit.

DEALING WITH JUNK FAX MAIL

The following features will help you to reject unwanted junk fax mail.

- ☐ Authorized Reception: see page 132.
- ☐ Closed Network (Reception): see page 152.
- ☐ Rejection of messages from unauthorized senders: see page 131.

OTHER ITEMS TO PROGRAM AT YOUR LEISURE

The following features will help you use the machine more quickly and efficiently.

- ☐ Auto Document: see page 106.
- ☐ User Function Keys: see page 163.
- ☐ Function Programs: see page 164.
- ☐ Keystroke Programs: see page 99.
- ☐ Chain Dialing: see page 116.
- ☐ Ordering Toner: see page 197.

To use the full range of features provided by this fax machine, you need to program other items. These procedures are all given in the relevant sections of the manual.


ROUTINE OPERATION

SENDING A FAX MESSAGE

Precautions Concerning Unacceptable Document Types

Before you send your document, make sure that it meets the following requirements.

Caution: Documents that do not meet these requirements can cause your machine to jam or may cause some components of the machine to become damaged or dirty.



ROUTINE
OPERATION

Correct Size for the Document Feeder

Thickness: 2 to 8 mils (20 lb paper)

Length and Width: See the above diagram.

If the page is too short, put it inside a document carrier or enlarge it with a copier.

If the page is too long, divide it into two or more sheets.

Clearly Written

Small faint characters may not be transmitted clearly.

Uniform Page Size


Do not use different sizes of document in the same transmission.

Dry Ink


All ink must be dry before you place the document in the feeder.

Page Condition

Do not place damaged pages in the automatic document feeder.



Originals that contain the following materials should not be placed in the document feeder. Make copies of these originals and scan the copies.



Note: Copies made with a copier that uses silicone oil may cause a misfeed. To avoid this, do not scan such copies until five or ten minutes after copying.


Transmission Procedure at a Glance

Overview

There are two ways to send a fax message.

- ☐ Immediate Transmission
- ☐ Memory Transmission


Immediate Transmission



Immediate Transmission is convenient when:

- ☐ You wish to send a message immediately
- ☐ You quickly wish to check whether you have successfully connected with the other party
- ☐ Your machine's memory is getting full

The machine dials immediately after you press Start (or at the specified later time, if you used a time-delay feature like Send Later). The message is scanned and transmitted page by page without being stored in memory.

Memory Transmission

Memory Transmission is convenient because:

- ☐ Fax messages can be scanned much more quickly (you can take your document away from the fax machine without waiting too long).
- ☐ While your fax message is being sent, another user can operate the machine (people will not have to wait by the fax machine too long).
- ☐ You can send the same message to more than one place with the same operation.

After you press Start, the machine doesn't dial until all the pages of your fax message have been stored in the memory.

The default mode of this machine is Memory Transmission, so the procedures described in this manual will be based on the assumption that you are using Memory Transmission. Immediate Transmission is described in a separate section.


Cross-references

Send Later: see page 60.




Economy Transmission: see page 66.

Sending to Just One Location**1. Make sure that the machine is in standby mode:**

- ☐ The display on the operation panel must be as shown on the right.

**2. Carefully place your fax message into the auto document feeder.**

- ☐ To dial without placing the message in the feeder first, see Direct Fax Number Entry on page 68.
- ☐ If you only wish to scan a part of the document, use the Specified Image Area feature. See page 118 for details.



ROUTINE OPERATION





- ☐ The pages must be placed face down in the feeder, with the first page at the bottom of the stack.
- ☐ Feed the pages in so that the top edge goes in first.
- ☐ Do not feed in more than 50 pages.
- ☐ Do not use unsuitable types of original (see pages 45 and 46).
- ☐ Adjust the document guides to fit the width of the pages.
- ☐ Do not use pages of different sizes.
- ☐ The pages should be arranged loosely, but the leading edges should be tidy, as shown above.



Selecting Contrast and Resolution: See page 54.
 Options for Sending a Message: See page 59.
 Scanning only a part of the document (Specified Image Area): See page 118.

3. Dial in one of the following ways.

MEMORY TRANS.	OPTI ONS
PRESS <input type="button" value="YES"/> OR <input type="button" value="CLR"/> · <input type="button" value="NO"/>	
2125551234	

a) Ten Key Pad	b) Quick Dial	c) Speed Dial	d) Handset *
	<p>Example : QuickDial I2</p> 	<p>Example:SpeedDial IO</p> 	

★ : Only if the telephone handset is installed.

If your machine is behind a PBX, dial the access code, then a pause, then the telephone number.
For an international number, press the Pause key after entering the country code.

4. **Start**

The machine stores your fax message.


STORI NG	MEMORY 99%
PAGE	1
FI LE NO.	0056

5. The machine dials, and the line to the other party is connected.

Note: Watch the display. The identification of the other party will appear.


6. After sending the message, the machine hangs up automatically.

Sending to More Than One Location (Broadcasting)



- 1. Make sure that the machine is in standby mode (see page 49).
- 2. Make sure that the Memory indicator is lit. If it is not, press **Memory** .
- 3. Place your fax message face down into the feeder.

☐ If you only wish to scan a part of the document, use the Specified Image Area feature. See page 118 for details.
To broadcast without placing the message in the feeder first, see page 68.




? Selecting Contrast and Resolution: See page 54.
Options for Sending a Message: See page 59.
Scanning only a part of the document (Specified Image Area): See page 118.

- 4. Dial in one of the following ways.



You can program a User Function Key for use with Group Dial. See below.



a) Ten Key Pad	b) Quick Dial	c) Speed Dial	d) Group Dial ☆
	Example: Quick Dial 12 	Example: Speed Dial 10 	Example: Group 1, stored in Quick Dial Key 08 Method 1: 08 Method 2: F4 1

☆ : Method 1: Press the Quick Dial Key the Group is stored in (in the example, press key 08).
Method 2: If you do not know which Quick Dial Key the Group is stored in but you do know the Group number, use Method 2. You must have programmed one of the User Function Keys in advance with code 02 (Group Dial), using Function 35 (see page 163). In the above example, F4 has been made the Group Dial key; press F4 then input the Group number.

If your machine is behind a PBX, dial the access code, then a pause, then the telephone number. For an international number, place a pause after the country code. To input a pause, press the Pause key.

ROUTINE
OPERATION

5. **Yes**

Here, DEST: 2 indicates that the machine is asking you to input the second telephone number in your list of destinations for this fax message.

MEMORY TRANS.	OPTI ONS	↓
ENTER NO. OR	START	DEST: 2
[Redacted]		

6. Either

- ☐ Dial another number: Go to step 4.
- ☐ Press **Start** .

STORI NG	MEMORY 99%
PAGE	1
FI LE NO.	0056

The machine will dial the first destination (or, if you selected Send Later, it will return to standby mode and the fax message will be sent at the time that you selected).

NOTE: In theory, you can send the same fax message to up to 200 different destinations using the above procedure. However, this number depends on how many numbers are currently waiting in memory to be dialed. See the table on page 43 for more information concerning the limitations to this feature.

Check your Destinations Before Dialing

If you wish to send a fax message to more than one location, you can scroll through the list of telephone numbers that you have input so far to check whether you have missed any out or entered any wrong numbers.

This feature is useful when using features such as Broadcasting, Transfer Request, and Polling Reception.

Cross-reference

Broadcasting: see page 51.

Transfer Request: see page 87.

Polling Reception: see page 158.

1. Press **↓** **0** **8**

- ☐ The number after DEST shows how many numbers you have input so far.

CHECK DEST.	PRESS	YES	OR	NO
01	XYZ CO. NEWYORK			
DEST. : 2		↓		

2. Use the **↓** arrow to scroll through the list of destinations that you have already input.

- ☐ To cancel a destination that you have input by mistake: **No**
- ☐ To finish checking: **Yes**

Possible Problems**You want to take out the document**

Press the scanner release button, open the scanner, and take out the document.

Caution: Do not pull out the document without opening the scanner, or you will damage the machine.

You want to send more than 50 pages

While the last page is being fed in, place more pages (up to 50) in the feeder.



You made a mistake while dialing

If you already pressed **Start**, press **Stop** immediately.

If you haven't pressed **Start** yet, either:


- ☐ **No**. The entire number is deleted. Enter a new number.
- ☐ **Clear**. Only the last digit is deleted.

Indicators are blinking

- ☐ If the Clear Original indicator () is blinking:
Take out the document (see page 213). Then redial the destination.
- ☐ If the Line Fail indicator () on the operation panel is blinking:
If the Communicating lamp is not lit, press **Stop**.
If the Communicating lamp is lit, wait until it goes out, then press **Stop**.


The buzzer is ringing

The other party wishes to speak with you. Proceed as shown below.



Contrast, Resolution, and Halftone Modes

You may wish to send many different types of fax message. Some of these may be difficult to reproduce at the other end. However, your machine has three settings that you can adjust to help you transmit your document with the best possible image quality.



If you are not sure whether your settings are suitable, make a copy of the document using these settings. The printout shows how the fax message will look when it is printed at the other end.

- ❑ If your fax message has more than one page, you can select different settings for each page. For example, if you wish to use a different resolution just for page 2, change the resolution setting while page 1 is being scanned. Then, while page 2 is being scanned, you can return the resolution setting to the original setting.

Contrast

The text and diagrams in your document must stand out clearly from the paper they are written on. If your document has a darker background than normal (for example, a newspaper clipping), or if the writing is faint, adjust the contrast.

There are three grades.

Normal: Suitable for most documents

Darken: Use for documents with faint writing (such as those written in pencil)

Lighten: Use for documents that have a dark or patchy background

Resolution

If your document contains fine print or detailed diagrams, use a higher resolution setting.

Standard: Suitable for most typewritten documents

Detail: Use for documents with small print or fine details

Fine: Use this for high quality reproduction

Super Fine: 400 dpi memory option required

Note: Super fine is available when the sender and receiver each have the 400 dpi option. This machine has 4 resolution modes, but there are 3 resolution indicators on the operation panel. So, when you would like to know which mode you are using, see the mode column on the TCR report.

Halftone

If your document contains a photograph, or diagrams with complex shading patterns or grays, switch Halftone Mode onto achieve optimum image quality.



Without Halftone



With Halftone

Selecting the Halftone Type

This model has two types of Halftone, the Dither Process, and the higher quality Error Diffusion Process. To change the currently used Halftone type, perform the following procedure.

1. **Function** **6** **0** **2** **2** **2** **2** **8** **1**

PSTN LINE TYPE	SELECT	←	→
DP	TT	↑	↓
	YES TO END		

2. Scroll through the list of features with the **↑** and **↓** keys until SELECT HALFTONE appears.

SELECT HALFTONE	SELECT	←	→
SPD MODE	STD MODE	↑	↓
	YES TO END		

3. Change the setting by using **←** or **→**.

SPD MODE: The machine will use the Basic Halftone Process.
STD MODE: The machine will use the higher quality Error Diffusion Process.

4. Finish: **Yes** **Function**

Halftone Mode slows down the transmission speed, and may increase your communication costs, especially if you use the Error Diffusion process. Higher resolutions also do this. This is because these settings create larger amounts of data to be sent.

Messages are transmitted the fastest if you use the standard resolution setting, and keep Halftone off.

Home Position Setting Adjustments

For the contrast, resolution, and halftone, you can select whether the settings return to home position at the end of transmission (in a new machine, they do). Also, you can change the home positions of these settings.

If you need other adjustments, contact a service representative.

The procedure is as follows (see page 10 if you need more information about the User Parameter settings adjustment procedure).

1. **Function** **6** **0** **2** **2** **2** **2** **9** **1**

USER PARAMETER	PRINT LIST	→
DEFAULT:	01000000	↑
SW TCH00:	01000000	YES TO END ↓

- At this time, you can print a User Parameter List if you press **→** **Start** .

7 6 4 3 2 1

2. The settings for switch 00 are now shown on the bottom line of the display.

SWITCH00: 00000000

The settings that you may need to change are those for digits 1, 2, 3, 4, 6, and 7. The functions of these are as follows.

Digit	Purpose					
1	Resolution home position					
2	Digit 2	Digit 1	Setting	Digit 2	Digit 1	Setting
	0	0	Normal	1	0	Darken
	0	1	Lighten	1	1	Do not use this.
3	Resolution home position					
4	Digit 4	Digit 3	Setting	Digit 4	Digit 3	Setting
	0	0	Standard	1	0	Super Fine
	0	1	Detail	1	1	Do not use this.
6	If you change any of the contrast, resolution, transmission mode, stamp, or halftone settings before making a transmission, then: 0: The setting(s) will not return to the home position after the transmission. 1: The setting(s) will return to the home position after the transmission.					
7	Halftone on/off home position		0: Off		1: On	

3. If you wish to change one of the settings, press the key on the ten key pad that corresponds to the digit that you wish to change.

Example: **3** . The value of digit 3 changes.

4. Finish: **Yes** **Function**

Dialing with the Telephone Directory

This can be done for any number that you have stored as a Speed Dial Code with a label programmed for it.

Example: You wish to dial "XYZ CO. LONDON".

1. Make sure that the machine is in standby mode (see page 49).
2. Place your document in the feeder.

MEMORY TRANS.	OPTI ONS	↓
ENTER FAX NUMBER		
<div style="background-color: black; height: 15px; width: 100%;"></div>		

3. **Speed Dial/Tel Directory**

MEMORY TRANS.	OPTI ONS	↓
ENTER FAX NUMBER		
<div style="background-color: black; height: 15px; width: 100%;"></div>		

4. Press the first letter of the name: **X**
(Quick Dial Key **24** or **48**)

Press **X** repeatedly until the correct number is displayed.

TELEPHONE DI RECTORY		
SCROLL: X	PRESS	YES OR NO
<div style="background-color: black; height: 15px; width: 100%;"></div>		

5. **Yes**

MEMORY TRANS.	OPTI ONS	↓
PRESS YES OR CLR • NO		
<div style="background-color: black; height: 15px; width: 100%;"></div>		

6. **Yes** again.

MEMORY TRANS.	OPTI ONS	↓
ENTER NO. OR START DEST: 2		
<div style="background-color: black; height: 15px; width: 100%;"></div>		

7. Either:
 - ☐ Dial more numbers.
 - ☐ Press **Start** .



Programming Speed Dial Codes: See page 34.

Optional Features for Transmission

When you make a routine transmission, you can access a few optional features.

These options are only available if "OPTI ONS"  can be seen in the top right corner of the display.

Personal Code



ROUTINE
OPERATION

Personal Codes do the following.

- ☐ They allow you to keep track of machine usage (for example, for billing purposes). If everybody uses a Personal Code when they use the fax machine, the codes, or the names programmed into the codes, will be printed on the report that is called the TCR (Transaction Confirmation Report). This will help you to check on who has been using the machine, and how often.
- ☐ They allow personalization of documents and printed reports. For example, if you use Label Insertion and store your name with your Personal Code, the receiver of your fax message will see your name at the top of the printout. This eliminates the need for a cover page.
- ☐ They allow you to restrict use of the machine to authorized personnel only. If you switch the Restricted Access feature on, users have to enter their personal code before they can use the machine. The personal code must have already been stored in the machine. This may deter unauthorized personnel from casually using the machine.

Cross-references

Programming Personal Codes: see page 110.

Label Insertion: see page 120.


Restricted Access: see page 110.



TCR: see page 185

If you input your Personal Code, your name will appear on the TCR and Transmission Result Report.

1. Either:

☐ Press **↓** **0** **1**

☐  If you have programmed one of the User Function Keys to activate this feature, just press that key and go to step 2.

PERSONAL CODE	ENTER CODE
	
	[NO] TO END



2. Example: **7** **3** **6** **2**

☐ The display shows the name that was stored with the code that you selected. In this example, it is SMITH.


PERSONAL CODE	PRESS [YES] OR [NO]
7362	SMI TH

3. **[Yes]**

☐ See page 110 for details on how to program the Personal Codes and their labels.

MEMORY TRANS.	OPTI ONS 
ENTER FAX NUMBER	
	

Send Later



Using this feature, you can instruct the machine to delay transmission of your fax message until a later time, which you specify. This allows you to take advantage of off-peak telephone line charges without having to be by the machine at the time.

CAUTION

If your machine's memory is full, you will have to keep the message in the document feeder. This means that nobody can use the document feeder unless they remove your document. This would automatically cancel the Send Later operation.

1. Press **↓** **0** **2**

SEND LATER	ENTER START TIME	
	:	AM/PM: #
NOW	12:15 PM	NO TO END

2. Example: Send at 11:30 pm

1 **1** **3** **0**

- ☐ To change AM to PM or the other way around, press **#**.


SEND LATER	PRESS YES OR NO	
TODAY	11:30 PM	AM/PM: #

3. **Yes**

- ☐ The Send Later time cannot be more than 24 hours into the future.

MEMORY TRANS.	OPTI ONS ↓
ENTER FAX NUMBER	

Transmission Deadline (TRD)



ROUTINE
OPERATION

If your message has to be sent to the other end before a certain time, use the Transmission Deadline option and input this deadline.

If the line is busy, the machine will redial at set intervals either until the message gets through or until the deadline passes. Before the deadline passes, there is no limit to the number of times that the machine can redial.

After the deadline passes, the machine will print a report which indicates whether or not your message was sent within the deadline. Then, the message will be erased from memory.

This feature is only available with Memory Transmission.

Cross-reference

Transmission Deadline Report: see page 187.

1. Press **↓** **0** **3**

TRD	ENTER TRD TIME	
	:	AM/ PM: #
NOW	12: 15	PM NO TO END

2. Example: The deadline is 12:50 pm.

1 **2** **5** **0**


- ☐ The TRD time cannot be more than 24 hours into the future.
- ☐ To change AM to PM or the other way around, press **#**.

TRD	PRESS YES OR NO	
TODAY	12: 50	PM AM/ PM: #

3. **Yes**

MEMORY TRANS.	OPTI ONS ↓
ENTER FAX NUMBER	

Page Count (Immediate Transmission only)



When your fax message is printed at the other end, page numbers will be printed on the top of each page. Using the Page Count feature, you can select the format in which the page numbers are printed.

If you use Page Count:

- ☐ Page numbers will be printed in batch-numbering format (for example, p1/3, p2/3, and p3/3 for a three-page message). This makes it easy for the other party to see how many pages you sent, and if any are missing. However, you have to input the number of pages at the keypad before sending.

If you do not use Page Count:

- ☐ Page numbers will be printed only as a sequence (for example, p1, p2, p3). This makes it difficult for the other party to tell at a glance whether any pages are missing (for example, due to a double feed in your machine's document feeder).

Note: If you do not select Immediate Transmission, Page Count is automatically switched on, and the pages are counted automatically.

1. Press

PAGE COUNT	SET COUNT
	PAGE(S)
	TO END

2. Example: 10 pages

PAGE COUNT	PRESS OR
10	PAGE(S)

- 3.

MEMORY TRANS.	OPTI ONS
ENTER FAX NUMBER	

Auto Reduce



If the fax message that you are sending is wider than the printer paper in the receiving machine, the condition of the printout at the other end depends on whether or not Auto Reduce is switched on. (It is switched on in a new machine at the factory.)

If Auto Reduce is on:

- ☐ Your machine will reduce the image so that it will fit on the printer paper.
- ☐ During transmission, the display panel will inform you of the type of reduction that is being done. For example, "B4 TO A4 TRANSMI T" means that your B4-width [10.1"] original is being reduced to A4-width [8.3"] before being sent out.

If you have switched Auto Reduce off:

- ☐ Your machine will not reduce the image. Parts of your image at the left and right edges will not be printed at the other end. However, the central part of the document will be printed without any reduction.

On/Off Selection Switch

1. Press

OPTI ON	SELECT		TO END
AUTO REDUCE			OFF
			TTI

2. If you wish to change the AUTO REDUCE setting, press or until the displayed setting is correct.
3. when you have finished.

Auto Reduce Home Position Adjustment

You can change the home position of the Auto Reduce setting if you wish. Do not do this unless the current home position is inconvenient for you, and you often find yourself having to change the Auto Reduce setting before sending a fax.

The procedure is as follows (see page 10 for more information about the User Parameter settings adjustment procedure).

1. **Function** **6** **0** **2** **2** **2** **2** **9** **1**

USER PARAMETER	PRI NT LI ST	→
DEFAULT:	01000000	↑
SW TCH00:	01000000	YES TO END ↓

- ☐ At this time, you can print a User Parameter List if you press **→** **Start** .

2. The settings for switch 00 are now shown on the bottom line of the display.

SWITCH00: 00000000

3. Press **↓** until the settings for switch 04 are shown. You need to change digit 2.

SWITCH04: 00000000

Digit 2
0: Auto Reduce is Off
1: Auto Reduce is On.

4. If you wish to change the setting, press **2** .

5. Finish: **Yes** **Function**

TTI



Normally, the TTI programmed in your machine is printed at the top of each of the pages you transmit when they are received at the other end. The top of the image will be overprinted if there is no margin at the top of the transmitted page.

In some cases, you may wish the other party to receive an unmarked copy of your original. In this case, you can switch TTI off.

Note: If you switch TTI off, make sure that Label Insertion is also off if you want the image received at the other end to be unmarked.

Cross-reference

TTI: see page 26.

Label Insertion: see page 120



1. Either:

- ☐ Press **↓** **0** **7**

- ☐ If you have previously programmed this feature as a User Function Key, press that key.


OPTI ON	SELECT	←	→	YES	TO END
AUTO REDUCE		ON		OFF	
				TTI	↓

2. Press  until "TTI ON OFF" is displayed.

If you wish to change the TTI setting, press  or  until the displayed setting is correct.

3. **Yes** when you have finished.

ID Transmission



You must have stored an ID Code before you can use this feature; see page 85.

If you switch ID Transmission on, transmission will only take place if the other terminal's ID Code is the same as yours. This feature can stop you from accidentally sending information to the wrong place, if you co-ordinate ID Codes with the other party.

This feature works in the same way as Closed Network. To enable Closed Network, you must have it switched on by a service technician; it then stays on for all communications until you have it switched off. However, you can use ID Transmission for whichever transmissions you like. For receptions, ID Transmission does not work; you will have to use Closed Network if you wish to use this type of feature for your received fax messages.




ID Transmission may not be reliable when communicating with terminals produced by another maker.

Cross-reference



ID Code: see page 85.

Closed Network: see page 121.

1. Press  **0** **7**


OPTI ON	SELECT			YES	TO END
AUTO REDUCE		ON		OFF	
				TTI	

2. Press  until "I D TRANSMI T ON OFF" is displayed.

If you wish to change the I D TRANSMI T setting, press  or  until the displayed setting is correct.

3. **Yes** when you have finished.

Economy Transmission



This feature is similar to Send Later. However, it has the added bonus of automatically combining two cost-saving features: use of off-peak rates, and Batch Transmission. Also, you do not have to input the required transmission time every time, like you do with Send Later. However, with Send Later, you can input a different time of transmission for each fax message.

If you select Economy Transmission, your fax message will be sent at the time that you previously stored for this feature using Function 74 (see the next page). Also, all messages that were stored for sending to the same destination using this feature will be batched automatically.

Cross-reference

Send Later: see page 60.

Batch Transmission: see page 124.

On/Off Selection Switch

1. Either:

☐ Press **↓** **0** **7**

☐



If you have previously programmed this feature as a User Function Key, press that key.

OPTI ON	SELECT	←	→	YES	TO END
AUTO REDUCE		ON		OFF	
				TTI	↓

2. Press **↓** until "ECONOMY TRANS. ON OFF" is displayed.

If you wish to change the ECONOMY TRANS. setting, press **←** or **→** until the displayed setting is correct.

3. **Yes** when you have finished.

Storing the Economy Transmission Time

Before using Economy Transmission, you must use Function 74 to program a time for Economy Transmissions to start. This should be the start of the off-peak rate period for your area. After you have stored this, you will not need to change it again until your telephone company changes the starting time of the off-peak rate period.


1. **Function** **6** **0** **2** **2** **2** **2** **7** **4**

ECONOMY TX	
TIME=	11 :00 AM
← →	YES TO END

2. Input the time that you always wish Economy Transmissions to start.
☐ To change from AM to PM and vice versa, press ***** or **#**.

3. Press **Yes** **Function** when the display is correct.

Voice Request (This feature requires a handset)



Using this feature, you can have a telephone conversation with the other party, on the same call, after your fax message has been sent out. This is useful if you wish to discuss the contents of the fax message with the other party.

You can save overall telephone line costs because you don't have to redial the other party to have the conversation.

Note: This feature cannot be used with Memory Transmission.

The following procedure tells you how to set up a Voice Request. However, refer to "Talk After Sending a Fax" on page 80 for details on how to answer the phone when it rings.

1. Press **↓** **0** **7**

OPTI ON	SELECT	←	→	YES	TO END
AUTO REDUCE		ON		OFF	
				TTI	↓

2. Press **↓** until "VOI CE REQUEST ON OFF" is displayed.

If you wish to change the VOI CE REQUEST setting, press **←** or **→** until the displayed setting is correct.

3. **Yes** when you have finished.

Direct Fax Number Entry



This feature allows you to input destination fax numbers before placing the document in the feeder. This is useful when you would like to read the destination fax number off the document without having to write it down on the reverse side or on another scrap of paper.

1. Either:

☐ **Function** **1** **6**

☐ If you have previously programmed this feature as a User Function Key, press that key.

MEMORY TRANS.	OPTI ONS	↓
ENTER FAX NUMBER		
<div style="background-color: black; height: 20px; width: 100%;"></div>		

2. Input the destination telephone number(s).

MEMORY TRANS.	OPTI ONS	↓
PRESS YES OR CLR · NO		
2125551234		

3. Place your document in the feeder and press **Start** .

Immediate Transmission**Procedure**

If you do not wish to store the fax message in memory before sending it out, use the following procedure.

- ☐ The merits and demerits of Immediate Transmission and Memory Transmission are discussed on pages 47 and 48.

1. Make sure that the machine is in standby mode (see page 49).

2. **Memory**

- ☐ The Memory indicator should go out.

3. Place the document face down into the feeder.

I M M E D I A T E T X	O P T I O N S
ENTER FAX NUMBER	
<div style="background-color: black; height: 15px; width: 100%;"></div>	

4. Dial (only one destination).



See page 50 for how to dial.

I M M E D I A T E T X	O P T I O N S
PRESS YES OR CLR · NO	
<div style="background-color: black; height: 15px; width: 100%;"></div>	

5. **Start**

D I A L I N G	
<div style="background-color: black; height: 15px; width: 100%;"></div>	
2125551234	
F I L E N O. 0046	

 ROUTINE
OPERATION

6. The machine dials and the line to the other party is connected. The number that you dialed is displayed (or if you used Quick Dial or Speed Dial, the Quick Dial or Speed Dial Label stored for that number is displayed).

Converting Immediate Transmission to Memory Transmission

If there is a message still waiting in the document feeder, you can convert it into a memory file if you press **Memory** **Start**. The document will be scanned and stored into memory, leaving the document feeder free for others to use.

Transmission Mode Home Position Adjustment

The default mode of your machine is Memory Transmission. If you wish, you can change this home position to Immediate Transmission.

The procedure is as follows (see page 10 if you need more information about the User Parameter settings adjustment procedure).

1. **Function** **6** **0** **2** **2** **2** **2** **9** **1**

USER PARAMETER	PRINT LIST	→
DEFAULT:	01000000	↑
SW TCH00:	01000000	YES TO END ↓

- ☐ At this time, you can print a User Parameter List if you press → **Start** .

2. The settings for switch 00 are now shown on the bottom line of the display. The setting that you need to change is that for digit 5.

SWITCH00: 00000000

Digit 5
0: Memory Transmission
1: Immediate Transmission

3. If you wish to change the setting, press **5** .
4. Finish: **Yes** **Function**

Using the Stamp



If press the Stamp key to light the Stamp indicator, the machine stamps the bottom of each page. During memory transmission, the stamp indicates that the page was successfully stored. For immediate transmission, it shows that the page was sent successfully. You must switch the stamp on before you press **Start**, or the machine will not stamp the first page.

- ☐ If you wish the stamp to be at the top of each page instead of at the bottom, contact your service representative.

Changing the Stamp Home Position Setting

If you wish to change the Stamp home position setting, do the following.

(See page 10 if you need more information about the User Parameter settings adjustment procedure).

1. **Function** **6** **0** **2** **2** **2** **2** **9** **1**

USER PARAMETER	PRI NT LI ST	→
DEFAULT:	01000000	↑
SW TCH00:	01000000	↓
	YES TO END	

- ☐ At this time, you can print a User Parameter List if you press **→** **Start**.

2. The settings for switch 00 are now shown on the bottom line of the display. The setting that you need to change is that for digit 0.
3. If you wish to change the setting, press **0**.
4. Finish: **Yes** **Function**

SWITCH00: 00000000

Digit 0

0: The stamp home position is "Off". If you press the Stamp key to use the Stamp, the Stamp will be disabled at the end of the transmission.

1: The stamp home position is "On". After the transmission, the Stamp will stay enabled.

Redialing

If a message was not transmitted successfully, that does not mean that you have to enter the telephone number again. In many cases, the machine will redial the destination automatically. Or, with the AI Redial key, you can redial with just a few keystrokes.

Automatic Redialing

The machine will automatically redial the other party if any of the following conditions occurred.

- ☐ The other party was busy
- ☐ There was no reply from the other party
- ☐ The message was rejected by the machine at the other end because of excessive errors (in this case, redialing will only take place if Memory Transmission was used)

Redialing is done 4 times at 5 minute intervals (for a memory transmission) or 2 times at 2 minute intervals (for an immediate transmission).

- ☐ The number of redials and the redial interval may be adjusted by a service technician.

During redialing, the number being dialed is displayed in brackets at the top of the screen, as shown on the right.

[2125551234]	
MEMORY TRANS.	APR. 4. 12:25 PM
<div style="border: 1px solid black; padding: 5px; display: inline-block;"> SET DOCUMENT MEMORY 99% </div>	

If redialing fails for an immediate transmission, the display appears as shown opposite. You can convert this communication to a memory transmission to free up the machine for other users. Press **Memory** then **Start**.

REDI AL STANDBY OR SELECT MEMORY MODE (PRESS MEMORY + START)
--

Using the AI (Artificial Intelligence) Redial Key

The machine learns and remembers the last 10 telephone numbers that you input. Then, if you have to redial one of these numbers, just press the AI Redial key until the number or name of the party you wish to redial is displayed, then press the Start key.

This feature has the following uses.

- ☐ If the machine is waiting to redial the other party, you do not have to wait for the redialing interval to expire.

Press the AI Redial key until the required telephone number or name is displayed, then press the Start key.

- ☐ If you wish to send another message to the same address that you just sent one to recently, you don't have to dial the full number again if it is still in the AI Redial memory.

Place the message in the feeder, then press the AI Redial key until the required telephone number or name is displayed, then press the Start key.

- Notes:**
- ☐ Using AI Redial, you cannot retry a failed Memory Transmission. However, you can redial the telephone number, as explained above.
 - ☐ AI Redial employs the AI Short Protocol feature.
 - ☐ The AI Redial key does not work if you used the handset to dial.

Cross-reference



AI Short Protocol: see page 184.

ROUTINE
OPERATION


To send a fax using AI Redial, do the following:

1. Make sure that the machine is in standby mode (see page 49).
2. Place your document into the feeder.
3. **AI Redial**

AI REDI AL NO. DI RECTORY	
1 SCROLL 	PRESS <input type="checkbox"/> YES <input type="checkbox"/> OR <input type="checkbox"/> NO
<input checked="" type="checkbox"/> 01 XYZ CO. NEWYORK	

4. Scroll through the numbers in the AI Redial memory using the  and  arrows of the scroll key.

- ☐ To select a number: **Yes** x 2

MEMORY TRANS.	OPTI ONS 
ENTER NO. OR <input type="checkbox"/> START	DEST: 2
<div style="background-color: black; height: 20px; width: 100%;"></div>	

5. Either
 - ☐ Select another number: go to step 4.
 - ☐ Start the transmission: **Start**

RECEIVING FAX MESSAGES

Selecting the Reception Mode

There are two ways to set up your machine to receive fax messages.

- ☐ Auto Receive Mode
- ☐ Manual Receive Mode


Press the reception mode key to switch between the modes.

Manual Receive Mode

This mode is selected when the Manual Receive indicator is lit.

This setting is convenient if you wish to use your fax machine's handset to answer telephone calls coming in on the same line as fax messages. However, your fax machine cannot automatically receive fax messages; you have to be by the machine if a fax message comes in.

The machine operates as follows.



1. The machine rings continuously until you answer the call. Pick up the handset.
2. If you hear a voice from the other end, speak in reply.
If you hear a tone every few seconds, the other end is a fax terminal.


Note: Remove any documents that are in the feeder.

3. If the person at the other end wishes to send you a fax message, press **Start** to receive the message. Then hang up the handset.
4. The machine starts to receive the message.
The Communicating indicator lights.


Auto Receive Mode

This mode is selected when the Auto Receive indicator is lit.

Incoming faxes are received automatically. You do not have to be by the machine if the power switch is kept on. Use this mode when you must leave the machine.



1. The telephone rings once.
2. The machine automatically starts to receive the message.

Substitute Reception**Overview**

If the printer is jammed or out of supplies, you will still be able to receive fax messages; any messages coming in will be stored in the machine's memory.

If the "Receive File" indicator is lit, a message has been stored in the memory using the Substitute Reception feature.

Check the following:

- ☐ The printer paper may be used up. If so, add paper: see page 194.
- ☐ The toner may have finished. If so, add toner: see page 195.
- ☐ The printer paper may have jammed. If so, remove the jam: see page 215.
- ☐ If the Call Service indicator is lit, your machine needs to be repaired.
- ☐ If there appears to be no problem, somebody may be making copies while a fax message is coming in.

The messages received into memory will be printed and erased after the machine has been returned to normal operation.

Switching Substitute Reception On or Off

There are two conditions under which you may wish to disable this feature.

- ❑ **If you do not like keeping received fax messages in memory:** After your machine has received a fax message to memory, it sends an OK signal to the other end. However, if something happens to your machine and you lose the fax message before you have a chance to read it, the sender will not be informed. Therefore, you may not wish to use the Substitute Reception feature.
- ❑ **If you do not wish to have your memory full of mail from unknown senders:** If you have not enabled the Authorized Reception feature, you can receive fax messages from anybody. However, you can see who they are from because their identifier (the TTI) is printed at the top of each page. If the other party has not programmed their identifiers (perhaps in an attempt to hide their identity), you may not wish to receive their messages into memory, which would take up valuable space.

Cross-reference

ECM: see page 123.

Authorized Reception: see page 132.

If you wish to switch Substitute Reception on or off, do the following procedure. (See page 10 if you need more information about the User Parameter settings adjustment procedure).

1. **Function** **6** **0** **2** **2** **2** **2** **9** **1**

❑ At this time, you can print a User Parameter List if you press **→** **Start** .

USER PARAMETER	PRI NT LI ST	→
DEFAULT:	01000000	↑
SW TCH00:	01000000	YES TO END ↓

2. The settings for switch 00 are now shown on the bottom line of the display.

SWITCH00: 00000000

3. Press **↓** until the settings for switch 05 are shown.
The settings that you need to change are those for digits 0 and 3.

SWITCH05: 00000000

3 0

The meanings of these settings are as follows.

Digit	Purpose
0	Substitute Reception under all circumstances (for example, if you have limited memory space) 0: Disabled, 1: Enabled
3	Reception to memory (including Substitute Reception, Memory Lock, Forwarding, and Transfer Requests from another station) when no RTI or CSI identifiers were received from the other party 0: Enabled, 1: Disabled

4. If you wish to change the setting, press **0** or **3** .

5. Finish: **Yes** **Function**

TELEPHONE CALLS

A handset is required to execute the procedures in this section.

You can use your fax machine for dialing in the same way as you would use a telephone. This is useful when calling fax machines that are usually kept in Manual Receive Mode, as well as for telephone conversations.

- ☐ You can dial using Quick Dial Keys or Speed Dial Codes.
- ☐ With the On Hook Dial feature, you do not have to pick up the handset before dialing.
- ☐ You can send a fax message after finishing the conversation, without having to make a new call.

Cross-reference

Manual Receive Mode: see page 74.

Making a Telephone Call

Using On Hook Dial

Using On Hook Dial is like using the handset (see the next page), except that you do not have to pick it up before dialing. Just press the On Hook Dial key, and dial the number. When you hear the other party on the fax machine's built-in speaker, you can pick up the handset. This keeps both hands free for referring to telephone numbers while you are dialing.

ROUTINE
OPERATION

1. **On Hook Dial**

Note: Do not pick up the handset.

ON HOOK MODE

2. Dial.



See page 50 for how to dial.
Do not use the handset.

Note: Do not press **Start** .

- ☐ If you wish to cancel the call, press **On Hook Dial** .

ON HOOK MODE

PRESS **START** AFTER TONE

2125551234

3. Listen to your machine's built-in speaker. When the other party answers, pick up the handset.

4. Replace the handset when you have finished.

Using the Handset

Using the fax machine's built-in or optional handset, you can use the fax machine in the same way as a normal telephone. Pick up the handset and dial on the fax machine's ten-key pad (or use a Quick Dial Key or Speed Dial Code if you wish).

1. Pick up the handset.

HANDSET MODE
<div style="background-color: black; height: 20px; width: 100%;"></div>

2. Dial.



See page 50 for how to dial.

Note: Do not press **Start** .

HANDSET MODE
PRESS START AFTER TONE
<div style="background-color: black; height: 20px; width: 100%;"></div>



3. Continue as for a normal telephone conversation.

Using AI Redial

Use AI Redial if you wish to redial a number that you dialed recently.

1. **On Hook Dial** **AI Redial**

AI REDIAL NO. DIRECTORY
1 SCROLL  PRESS YES OR NO
<div style="background-color: black; height: 20px; width: 100%;"></div>

2. Scroll through the numbers in the AI Redial memory using the  and  arrows of the scroll key. When the correct number is displayed, press **Yes** .

☐ The number will be dialed immediately.


ON HOOK MODE
PRESS START AFTER TONE
<div style="background-color: black; height: 20px; width: 100%;"></div>

Answering the Telephone

If the telephone rings just once:

A fax is coming in. Do not pick up the handset.

If the telephone rings continuously:



1. Pick up the handset and speak to the other party.
 - ☐ If you hear a high-pitched tone, a fax is coming in. Press **Start** then hang up.
2. If the caller wants to send you a fax, press **Start** after speaking. Then hang up.
 - ☐ If nothing happens after you press **Start**, the power may be switched off or the telephone may not be connected up correctly.

 ROUTINE
OPERATION

Phoning and Faxing on the Same Call

To Talk Before Sending a Fax (On Hook Dial)

1. **On Hook Dial**
2. Dial.

Note: Do not use the handset.
Do not press **Start**.
3. If you hear a voice from the machine's built-in speaker, pick up the handset and speak to the other party.
 - ☐ If you hear a high-pitched tone instead of a voice, place your fax message in the feeder, then press **Start**.
4. When you are ready to send your fax message, place your message in the feeder, then ask the other party to press **Start**.
5. When you hear a high-pitched tone, press **Start**.

6. Replace the handset.

- ☐ Do not replace the handset if you wish to speak to the other party again.
When your machine emits a tone, press **Stop** then speak.

To Talk After Sending a Fax

Use the Voice Request option (see page 67). Then, during transmission:

1. When your machine emits a tone, pick up the handset, press **Stop** and speak.

- ☐ If the machine did not emit a tone, the other party did not answer the call.

2. After speaking, hang up.

- ☐ Do not hang up if you have more pages to send. Instead:

1. Place the pages into the feeder.
2. Ask the other party to press **Start**.
3. When you hear a high-pitched tone, press **Start**.

Speaker and Buzzer Volume Adjustments

Your machine has a built in speaker. With this speaker, you can listen to the telephone line without picking up the handset. The speaker will be automatically switched off just before the start of facsimile data communication.

When you are sending a fax message, you will be able to hear the line after the machine has dialed. If the line is busy, you can press the Stop key and start another operation without having to wait for the machine to disconnect the line.

If the speaker volume is not satisfactory, you can adjust it.

1. **Function** **6** **0** **2** **2** **2** **2** **9** **3**

MONI TOR VOL UME	SET VOL UME
TRANSMI SSI ON:	← >>>> →
PRESS START	YES TO END

2. ☐ Increase: **→**
- ☐ Decrease: **←**
- ☐ Test the current setting: **Start**.
Press **Stop** when you have finished the test.
- ☐ Accept: **Yes**

MONI TOR VOL UME	SET VOL UME
RECEPTI ON:	← >>>> →
PRESS START	YES TO END

3. Repeat step 2 for each adjustment that appears on the screen.

ADVANCED FEATURES


NETWORKING

Overview

This section explains how you can use this machine to distribute fax messages over networks of fax machines.

As we have seen (Sending to More Than One Location, page 51), you can send the same fax message directly from your machine to more than one location. The diagram in that section shows your machine sending the same fax to three locations. This feature is commonly known as Broadcasting.

However, with Broadcasting, you or your organization has to pay for three fax calls. If these are all long distance calls, that can be quite expensive. If you use the networking features provided with this machine, you will be able to reduce costs by sending the fax message only once, to a Transfer Station, and that Transfer Station will distribute your fax message.



ADVANCED
FEATURES

You can take advantage of your machine's Group Dial, Broadcasting, and Transfer Request features to set up extensive facsimile networks. Such networks can save time and cost if you set them up to perform commonly-used broadcasting operations, especially if long-distance communications are involved.

Cross-references

Groups: see page 30.

Broadcasting: see page 51.

Transfer Request: see page 87.

What Networking Features Does This Machine Have?

The machine's networking features are summarized below.

- ❑ **Transfer Request:** This allows you to send a fax message to a number of destinations via a single Transfer Station (see page 87). Transfer Request can be combined with Broadcasting to set up more complex networks (see page 90).
- ❑ **Two-step Transfer:** This process adds a Relaying Terminal between you and the Transfer Station. The Relaying Terminal could be a machine in your area that has access to a long-distance high-speed digital link, which would pass on your fax message to the Transfer Station, which would then distribute your fax message over low-speed local lines. See page 91 for details on this feature.
- ❑ **Multi-step Transfer:** This allows you to set up a string of Transfer Stations in different areas. The Transfer Station in each area would distribute your message to destinations in the same area, and pass on your message to the next Transfer Station in the chain. See page 93 for more on this feature.

When you look at these procedures later in this section, they may seem rather complex. However, once you have decided upon a certain operation, and if you plan to use it frequently, program it as a Keystroke Program. Next time, this will allow you to start the operation with only one keystroke.

Note

Your sales or service representative will be able to help make all the necessary group and transfer station number programming in the various broadcasting terminals throughout your proposed network. Please co-ordinate with your sales representative to obtain correct programming at the time of installation.

Cross-references

Transfer Request: see page 87.

Transfer Request combined with Broadcasting: see page 90.

Two-step Transfer: see page 91.

Multi-step Transfer: see page 93.

Keystroke Programs: see page 99.

Preparing the Machine for Networking Operations

Before you can start to set up fax communication networks, there are some items that you have to program in your machine. These are as follows.

- ☐ Your Country Code
- ☐ Your Fax Machine's Own Telephone Number
- ☐ Your Area Code Prefix (normally not necessary in the USA)
- ☐ The ID Code (the ID Code of your machine and all the Relaying Terminals and Transfer Stations must be the same)

If you install the optional Group 4 ISDN kit, there are some other items that you will have to program. These are dealt with in Appendix C, which covers the ISDN kit.

You will also have to plan how you program your Groups (in co-ordination with other people at other locations who will use your machine as a Transfer Station), and you must also know how all the Relaying Terminals and Transfer Stations have programmed their Groups.

Storing the Country Code

The Country Code is the code that callers in other countries have to input when dialing a number inside your own country. For the USA, this code is '1'.

1. **Function** **6** **0** **2** **2** **2** **2** **6** **1**

COUNTRY CODE	
<input type="checkbox"/> YES TO SET	PREVIOUS <input type="button" value="↑"/>
<input type="checkbox"/> NO TO CANCEL	NEXT <input type="button" value="↓"/>

2. **Yes**

COUNTRY CODE	
ID SETTING	<input type="checkbox"/> YES TO END
<div style="background-color: black; width: 100px; height: 1.2em;"></div>	

3. Input only your country code. Do not input your international dial access code.
Example: USA - **1**

COUNTRY CODE	
<input type="checkbox"/> YES OR <input type="checkbox"/> CLR	<input type="checkbox"/> NO
<div style="background-color: black; width: 100px; height: 1.2em;"></div>	


4. **Yes** **Function**

Storing your Machine's Own Telephone Number

Store your fax terminal's telephone number using this feature. If you do not do this, you will not be able to use the Transfer Request feature.


If your fax machine's telephone number changes, do not forget to change the stored telephone number data.

1. **Function** **6** **0** **2** **2** **2** **2**

6 **1** 

OWN ANALOG NUMBER

YES TO SET

PREVIOUS 

NO TO CANCEL

NEXT 

2. **Yes**

OWN ANALOG NUMBER



YES TO END

3. Input your fax terminal's telephone number.

☐ **The format of the number must be as follows:**

International Dial Prefix, Your Country Code, Your Area Code, **then you must add a Pause**, followed by your telephone number.

Check the International Dialing Prefix and the Country Code with your local telecommunications operator. The example shown is for the USA; the codes to add are 011 and 1.

NOTE: Use the **Pause** key to add a pause.

OWN ANALOG NUMBER

YES OR **CLR** **NO**

0111212-5551234

4. **Yes** **Function**

Storing your Area Code Prefix

The Area Code Prefix is the digit that is added to area codes when you dial another area within your own country. In many countries, this code is just a zero. In Spain, a '9' is used, and in the USA, the setting is just left blank.

1. **Function** **6** **0** **2** **2** **2** **2**

6 **1**  

AREA CODE PREFIX

YES TO SET

PREVIOUS 

NO TO CANCEL

NEXT 


2. **Yes**

AREA CODE PREFIX	
212-5551234	
<input type="text"/>	: 0 - 9 <input type="button" value="YES"/> TO END

3. Input the area code prefix.

4. **Yes** **Function**

Storing the ID Code



Before programming the ID Code, confer with other users in your fax network to agree on an ID Code. This is because communications using ID Codes will fail if the codes are not the same.

The ID Code can be any four-digit code (using digits 0 to 9 and letters A to F), except 0000 and FFFF.

In addition to the networking features described in this section, ID Codes are used with the following communication features. The same code must be used by all members of your fax network and all people you wish to communicate with using these features.

- ☐ Polling: see page 153.
- ☐ Closed Network: see pages 121 and 152.
- ☐ ID Transmission: see page 65.

Features using ID Codes can only be used between terminals made by the same maker.

To store an ID Code, do the following.

1. **Function** **6** **0** **2** **2** **2** **2**
6 **1** then **↓** until the screen is as shown opposite.

I D CODE	
<input type="button" value="YES"/> TO SET	PREVIOUS ↑
<input type="button" value="NO"/> TO CANCEL	NEXT ↓

2. **Yes**

I D CODE	
I D SETTING	
<input type="button" value="YES"/> TO END	

3. Input the ID Code that you will be using.

Example: **4** **3** **6** **3**

☐ Do not use 0000 or FFFF.

I D CODE	
<input type="button" value="YES"/> OR <input type="button" value="CLR"/> <input type="button" value="NO"/>	
4363	

4. **Yes** **Function**

Groups

The way to program a Group has already been explained and will not be repeated here. See page 38 and the pages following that for all the procedures. However, there are two points to keep in mind when you are setting up Groups for networking operations.

Limitations on the size of a Group: You can store up to 200 destinations in a Group. However, the networking features can only handle Groups that have up to 30 destinations. If you are programming a Group for networking purposes, do not put more than 30 numbers in that Group.


Group Transfer Station: You can specify a Group Transfer Station for each of your Groups. Then another party can send you a fax message and instruct your machine to send it to each number in a Group, through the Group Transfer Station, which acts as a broadcaster. Your machine will then relay the fax message to that group's Group Transfer Station, which will then send the fax message to each of the numbers stored in that Group. You should store Group Transfer Stations for Groups that you wish to use with the Two-step and Multi-step Transfer features. For instructions on how to store a Group Transfer Station for a Group, see page 41.

Transfer Request



Transfer Request helps you save costs when you send the same message to more than one place in a distant area.

- ☐ Your machine sends the message to the Transfer Station, which holds it in memory.
- ☐ The Transfer Station then sends it on to each of the End Receivers in sequence.
- ☐ After broadcasting, the Transfer Station sends your machine a Transfer Result Report to tell you if there were any problems with the communication.



- Note:**
- ☐ This feature can only be used if the Transfer Station was made by the same maker as your machine.
 - ☐ The ID Code of your machine must be the same as the ID Code of the Transfer Station.
 - ☐ Your fax machine's telephone number must have been programmed in advance.
 - ☐ The Transfer Station must have memory space available, and must be able to act as a Transfer Station (some machines cannot do this, or can but the capability has been switched off).

You cannot dial the End Receivers as full numbers on your ten-key pad, and you cannot use your own stored Speed Dials, Quick Dials, and Groups. You must use the numbers that are stored in the Transfer Station. Always keep a copy of the Transfer Station's Telephone Lists (Quick Dial, Speed Dial, and Group Lists) near the machine if you plan to use Transfer Request.

Cross-reference

Quick Dial and Speed Dial: see pages 29 and 31.
ID Code: see page 85.

Groups: see page 30.
Telephone Lists: see p. 192.


1. Make sure that the machine is in standby mode (see page 49).

2. Place your document in the feeder.

MEMORY TRANS.	OPTI ONS	↓
ENTER FAX NUMBER		
<div style="background-color: black; height: 20px; width: 100%;"></div>		

3. Either:

☐ **Function** **1** **2**



If you have programmed one of the User Function Keys to activate this feature, press that key and go to step 4.

TRANSFER	OPTI ONS	↓
TRANSF. 1	<div style="background-color: black; width: 100px; height: 15px;"></div>	

- ☐ If you cannot use Function 12, you forgot to store your country code, your fax machine's telephone number, or your ID code (Function 61). See pages 83, 84, and 85.
- ☐ If you have installed the ISDN Option Kit, you must also program the machine's Own ISDN G4 and Own ISDN G3 numbers (use Function 61; see pages 233 and 234). Your G4 Terminal ID and your ISDN subscriber numbers for G4 and G3 must also have been stored (this is normally done by the service representative when installing the ISDN kit).

4. Input the telephone number of the first transfer broadcasting station, then press **Yes**.

- ☐ This machine must be of the same manufacturer as yours, and it must be able to act as a Transfer Station.

Note: Do not use the handset.

TRANSFER	
TRANSF. 1	12125551234
RECV 1	<div style="background-color: black; width: 100px; height: 15px;"></div>

5. Input the destinations for this transfer broadcaster.


You must use Quick Dials, Speed Dials, or Groups that are stored in the transfer broadcaster. There is a shorthand notation for this purpose. See the following examples:

- ☐ Quick Dial Key 01: **#** **0** **1** **Yes**
- ☐ Speed Dial Code 10: **#** ***** **1** **0** **Yes**
- ☐ Group 01: **#** ***** ***** **0** **1** **Yes**

TRANSFER	NEXT NO. OR	START
TRANSF. 1	12125551234	
RECV 2	<div style="background-color: black; width: 100px; height: 15px;"></div>	TRNSF. ↓

NOTE: You can select up to 30 Transfer Stations, and up to 30 End Receivers for each Transfer Station. (This number depends on how many numbers are currently waiting in memory to be dialed. See the table on page 43 for more information concerning the limitations to this feature.)

6. Either:

- ☐ Enter more destinations for this transfer broadcaster - go to step 5.
- ☐ Input another transfer broadcaster and its destinations:  - go to step 4.
- ☐ Start the transfer request: **Start**


NOTE: You may use some transmission options, such as Send Later.

See page 59.

If you wish your machine to be a Transfer Station for other parties to use for their Transfer Requests, you must install a memory card or a hard disk.

Combining Transfer Request with Broadcasting

If you wish to set up complex fax message distribution networks, you can make a Transfer Request using more than one Transfer Station. When you do this, you can send the same message to up to 30 Transfer Stations, and each Transfer Station can pass the message on to 30 End Receivers.



Assume that your machine is in San Francisco and you wish to send the same message to various locations in the U.S.A. Of course, doing a simple broadcast, sending to each terminal directly from your machine, would get the job done, but you would not be taking advantage of the cost-cutting features of the machine.

However, if you incorporate Transfer Request, as shown below, your machine would only make 4 calls, instead of the 10 that would be necessary if Transfer Request was not used. This saves costs.


- ☐ Your machine can play any part in a Transfer Request network of this type, provided that you have programmed all the required features as explained earlier in this section.
- ☐ The ID codes of the requester (San Francisco) and the Transfer Stations (New York and Houston) must be the same. The requester must have its own fax number programmed.
- ☐ The model used by the requester (San Francisco) must be able to make Transfer Requests through more than one Transfer Station.
- ☐ Reports indicating success or failure will be returned to San Francisco from the terminals in Houston and New York.

To do this procedure, use the broadcasting procedure on page 51. The destinations should be as follows:

- ☐ Los Angeles
- ☐ Seattle
- ☐ A Group containing Boston, Hartford, Philadelphia, Buffalo, and Atlantic City, with New York as the Group Transfer Station
- ☐ A Group containing Dallas, New Orleans, and Oklahoma City, with Houston as the Group Transfer Station

Two-step Transfer

Digital Link



If your machine (A), in Sacramento in the above example, does not have access to a digital network, it can use a digital link between San Francisco (B) and Tokyo (C) to send a fax message to various locations in Japan (D to F). This speeds up communication and reduces costs. Terminals B and C must be G4 fax machines from the same manufacturer, must have the Two-step Transfer feature, and must have programmed a number known as the Next Transfer Station.

The Next Transfer Station is a feature that is provided when you install the optional G4 ISDN kit. For details on this feature and how to program it, see page 235.

To start the operation, the user at terminal A makes a transfer request, specifying terminal B as the transfer station and stations D to F as end receivers. B will send the message to C, and C will then distribute it to D, E, and F.

Note that the following programming must be done in terminals B and C if Two-step Transfer is to work using a digital link.

- ☐ The ID codes of terminals A, B, and C must be the same.
 - ☐ The fax number of terminal C must be stored in terminal B as the Next Transfer Station.
 - ☐ The fax number of terminal B must be stored in terminal C as the Next Transfer Station.
 - ☐ Terminals B and C may need adjustment; contact a service technician.
- If the line between A and B is Group 3 (analog), then the lines from C to D, C to E, and C to F must also be Group 3, unless the operation was done using Groups stored in terminal C; in that case, the destinations (D, E, F) can be a mixture of Group 3 and Group 4 terminals.

If the line between A and B is digital, the destinations can be a mixture of Group 3 and Group 4 terminals.


Cross-reference

Transfer Request: see page 87.
ID Code: see page 85.

Next Transfer Station: see page 235.

Analog Link

Two-step Transfer can also be done if the link between terminals B and C is analog (Group 3 on the PSTN).



The operator at terminal A makes a transfer request. However, it must dial using a group stored in terminal B, using the shorthand notation described for Transfer Request on page 88. For example, if the required group in terminal B is group 1, terminal A must dial #**01.

Note that the following programming must be done if Two-step Transfer is to work using an analog link.

- ☐ The ID codes of terminals A, B, and C must be the same.
- ☐ Terminals D, E, and F must be programmed in a group at terminal B (for example, Group 1). Terminal C must be programmed as the Group Transfer Station for that group (see page 41).

Caution

If terminal C is **not** programmed in terminal B as the transfer station for the group, the message will be sent out to D, E, and F using terminal B as the broadcaster. If the link between B and C is long-distance, this would not be much help in reducing your communication costs, as you can see from the diagram.

Cross-reference


Transfer Request: see page 87.

ID Code: see page 85.

Group Transfer Station: see page 41.

Multi-step Transfer

The principles of the Two-step Transfer feature can be used to build up a multi-step facsimile network. This will work using either analog (Group 3) or digital (Group 4) lines. An example follows.



To set up this network, the following programming must be done:

- ☐ Terminal C must contain two preprogrammed groups. Group 1 must contain terminals I and J. Group 2 must contain terminals E, F, G, and H. In Group 1, terminal D must be specified as the Group Transfer Station.
- ☐ Terminal B must contain a preprogrammed group (Group 1). This group must contain two numbers, #**01, and #**02. These specify transfer using groups 1 and 2 that are stored in the Group Transfer Station. In Group 1, C must be specified as the Group Transfer Station.
- ☐ The ID codes of terminals A, B, C, and D must be the same.

To start the operation, terminal A does a transfer request using terminal B as the broadcaster and #**01 as the end receiver; this specifies transmission to the numbers stored in Group 1 at terminal B.

Cross-reference

Group Transfer Station: see page 41.

Your Machine as a Transfer Station (Memory Card or Hard Disk Required)

Your machine can be a Transfer Station for other people to use for their Transfer Requests.

If the requesting party is using a machine of the same manufacturer as your machine, they must perform the Transfer Request procedure given after page 87. Any requesting party must have the same ID Code as your machine's.

However, if the requesting party is using a machine made by another manufacturer, or if they couldn't get the Transfer Request procedure to work, you will have to set up the Transfer Request by Tonal Signals feature in your machine (see below).

- ☐ If you do not wish to have your machine available as a Transfer Station, contact a service technician and ask to have this feature switched off.
- ☐ Another way to restrict use of this feature is to make sure that all requesting parties must have their identifiers stored, so that you do not receive Transfer Requests from unknown parties. See the bottom of page 131 for more details on this.

Transfer Request by Tonal Signals



This feature allows your machine to accept Transfer Requests made from the requesting side using Dial Tones. An operation of this type can succeed only if the following conditions have been met.

- ☐ The requester's fax machine must be connected to a telephone line that can accept DTMF (tone dial) signals, or must be able to generate Tonal Signals (see page 115).
- ☐ Your fax machine's reception mode must be Auto Receive.
- ☐ Your fax machine's remote ID must have been programmed.
- ☐ Transfer Request by Tonal Signals must have been switched on.

Setting the Machine up for Transfer Request by Tonal Signals

You must do the following to use this feature:

- ☐ Set up the machine in Auto Receive mode (see page 74).
- ☐ **Program the Remote ID (Function 61, see below)**
The other party will have to enter this code every time they access your machine to make a Transfer Request using a machine that is not of the same manufacturer as this machine.
- ☐ **Switch Transfer Request by Tonal Signals On (Function 91, see below).**
In a new machine, it is switched on in the factory.

Storing the Remote ID

As a new machine has a Remote ID of 0000 when it leaves the factory, we recommend that you store a new Remote ID immediately.

1. **Function** **6** **0** **2** **2** **2** **2**

6 **1** then **↓** until the screen is as shown opposite.

REMOTE I D	
YES TO SET	PREVI OUS ↑
NO TO CANCEL	NEXT ↓

2. **Yes**

REMOTE I D	
I D SETTI NG	
0000	YES TO END

3. Input the Remote ID that you will be using. Example: **6** **7** **5** **4**

REMOTE I D	
YES OR CLR NO	
6754	

4. **Yes** **Function**

Switching Transfer Request by Tonal Signals On/Off

To switch this feature on or off, do the following. (See page 10 for more information about the User Parameter settings adjustment procedure).

1. **Function** **6** **0** **2** **2** **2** **2** **9** **1**

USER PARAMETER	PRI NT LI ST
DEFAULT: 01000000	↑
SW TCH00: 01000000	YES TO END ↓

2. The settings for switch 00 are now shown on the bottom line of the display.

SWITCH00: 00000000

3. Press **↓** until the settings for switch 03 are shown.
The setting you need to use is digit 2.

SWITCH03: 00000000

Digit 2
0: The feature is disabled.
1: The feature is enabled.

4. If you wish to change the setting, press **2**.

5. Finish: **Yes** **Function**

Procedure for Transfer Request by Tonal Signals

If an operator of a machine of a different manufacturer than yours wishes to use your machine as a Transfer Station, they will have to do the following procedure.

Full Procedure

A quick reference version of this procedure is given on the next page.

1. First, the requesting party must dial your fax machine using an external telephone.
2. Immediately after hearing fax tones from your machine, they must press **#** . The tone will stop, and a single high-pitched beep of about one second duration will be heard. This is an ACK tone (Acknowledgment).
3. The requesting party must then enter your Remote ID then press **#** .
☐ See the notes at the bottom of the next page.
4. After hearing an ACK tone, they must press **2 4 #** .
5. After hearing an ACK tone, they must press *** * *** .
6. After hearing an ACK tone, they must dial the number which the Transfer Result Report must go to (their own terminal). This must be programmed in your machine as a Speed Dial or Quick Dial.

The requesting party has to dial the end receivers in the shorthand format used for Transfer Request (see the quick reference procedure on the next page for an example). Then they must press **#** .

For example:


- ☐ Quick Dial Code 01: **0 1 #**
- ☐ Speed Dial Code 01: *** 0 1 #**
- ☐ Group 01: *** * 0 1 #**

7. After hearing an ACK tone, the requesting party must enter the telephone number of the first fax terminal that they wish to receive the fax message, then press **#** . This number must also be input in the Transfer Request shorthand notation style.
8. The requesting party must repeat step 7 for all the end receiver numbers. If there are no more numbers, the requesting party should press **#** twice.
9. Communication begins after three ACK tones. When the requesting party hears fax tones again, they must press **Start** on their fax machine.

Example Procedure (for Quick Reference)

- ☐ Remote ID: 1111
- ☐ Transfer Result Report Destination: Speed Dial 04 in your machine.
- ☐ End Receivers, as programmed in your machine: Quick Dial 01, Speed Dial 02, Group Dial 03.

1. The requesting party must dial your machine using an external telephone, and wait for the fax tones.
2. When the fax tones come in, the requesting party must immediately input the following sequence. (ACK: Wait for the ACK tone)



3. When the requesting party hears fax tones again, they must press Start.

Notes

- ☐ The remote ID code must have been programmed earlier.
- ☐ After entering the ID code, if there is an interval of more than 5 seconds followed by three short beeps repeated three times, enter the remote ID again.
- ☐ If you enter the wrong remote ID, you will hear three short beeps. Try to enter the code again. If you enter the wrong code five times, the remote control services will not be available until you go back to the machine and reprogram the ID (this is a security measure to prevent other people getting access to your machine).

Beep Tones

Sometimes during a Remote Transfer, you may hear one or more beeps. The following table explains the meanings of these signals.


Sound	Reason	Required Action
One high beep	Acknowledgment	No problem; keep going.
A short beep three times	Rejection	Operation error. Try again. Also see the third note on the previous page.
A high beep three times	Service code accepted	No problem; keep going.
A mixed beep five times	Service code rejected	Operation error. Input the correct code.
A mixed beep five times followed by two high beeps	Transfer destination fax number rejected	Input another fax number for the destination of the remote transfer.
Three short beeps repeated three times	Wrong Remote ID code.	Input the correct Remote ID.

TRANSMISSION

Keystroke Programs

Overview

If you regularly transmit to a particular destination or set of destinations using the same features, you can save a lot of repetitive keypad operation by storing the features and destinations in a Keystroke Program.



Keystroke Programs are stored as Quick Dial Keys.

- ☐ If you store a Keystroke Program into a Quick Dial Key, that Quick Dial Key cannot be used for any other purpose.
- ☐ Be sure to store your Keystroke Program in a vacant Quick Dial Key.

Example: Let us say that you normally send a daily report to locations A, B, and C at 11 pm (using Send Later). Store these instructions as a Keystroke Program. Then every day, you will only have to place the report in the document feeder, then press that key to set up the transmission.

Cross-reference

Send Later: see page 60.

Storing a Keystroke Program

1. Make sure that the machine is in standby mode (see page 49).
2. Place a sheet of paper in the feeder.
 - ☐ Skip step 2 if you are making a Polling Reception program.

MEMORY TRANS.	OPTI ONS
<div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">ENTER FAX NUMBER</div> <div style="background-color: black; height: 20px; width: 100%;"></div>	

3. Select all required features (such as Transfer Request) and telephone numbers as you would normally do.
 - ☐ Contrast, resolution, and halftone cannot be stored in a keystroke program.

MEMORY TRANS.	OPTI ONS
<div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;"> ENTER NO. OR START </div> <div style="display: flex; justify-content: space-between; padding: 0 10px;"> DEST: 2 </div> <div style="background-color: black; height: 20px; width: 100%;"></div>	

4. Press the Quick Dial key that you wish to store the program in.
Example: 01
 - ☐ Make sure that this key is vacant.

PROGRAM? <div style="display: flex; justify-content: center; gap: 10px;"> YES OR NO </div>	
--	--

5. To complete the program: Yes

Note: The procedure that you just stored will now begin. If you do not wish to use the procedure now, press Stop immediately.

Labeling a Program

If you store a label for your keystroke programs, the label will appear on the display when you use the program. Also, you can attach an adhesive label to the Quick Dial Key if you wish.

1. **Function** **3** **4**
☐ If you press **→** **Start** , a Program List will be printed.

PROGRAM	CHOOSE KEY
<input type="checkbox"/>	PRI NT LI ST
<input type="button" value="NO"/> TO CANCEL	

2. Press the Quick Dial key that holds the program that you wish to label.
Example: **01** **Yes**

PROGRAM	ENTER LABEL
<input type="checkbox"/> 08	ABC

3. Input your label, using the Quick Dial keys.

Inputting labels: see page 7.

PROGRAM	<input type="button" value="YES"/> OR <input type="button" value="CLR"/> . <input type="button" value="NO"/>
<input type="checkbox"/> 08	TRANSMI T DAI LY REPORT ABC

4. **Yes**

PROGRAM	CHOOSE KEY
<input type="checkbox"/>	PRI NT LI ST
<input type="button" value="NO"/> TO CANCEL	

5. Either:
☐ Label another program: Go to step 2.
☐ Return to standby: **Function**

Using a Program

Before using a program, make sure that the machine is in standby mode (see page 49 for details).

Transmission Program

1. Place your document in the feeder.

MEMORY TRANS.	OPTI ONS	↓
ENTER FAX NUMBER		
<div></div>		

2. Press the programmed Quick Dial Key.

- ☐ The program begins at once, or at the later time specified by the program. You do not need to press **Start** .

Free Polling Reception Program

1. Press the programmed Quick Dial Key.

PROGRAMMED

The program begins at once, or at the later time specified by the program.

Cross-reference:

Polling Reception: see page 158.

Erasing a Program

When you wish to delete a keystroke program, do the following.

1. **Function** **3** **4**
☐ If you press **→** **Start** , a Program List will be printed.

PROGRAM	CHOOSE KEY
<input type="checkbox"/> 	PRINT LIST →
	NO TO CANCEL

2. Press the Quick Dial key that holds the program that you wish to erase.
Example: **08**

PROGRAM	YES	OR	NO
<input type="checkbox"/> 08	TRANSMIT DAILY REPORT		↑
	CLR:	CLR	↓

3. To delete the program: **Clear** **Yes**

PROGRAM	CHOOSE KEY
<input type="checkbox"/> 	PRINT LIST →
	NO TO CANCEL


4. Either:
☐ Erase another program: Go to step 2.
☐ Return to standby: **Function**

Confidential Transmission



Overview

Use this feature if you do not want your message to be picked up casually by anybody at the other end. The message will be stored in the memory at the other end. It will not be printed until an ID known as the Confidential ID is entered.



- Note:**
- ☐ The machine at the other end must have memory space available and it must have the Confidential Reception feature.
 - ☐ This is a proprietary feature, and as such it only functions with machines produced by the same maker that have this feature.
 - ☐ Before sending a confidential message, it is recommended that you call the receiver and advise them that you are sending a fax message in this manner.

There are two types of Confidential Transmission.

1. Normal Confidential Transmission

The other party can print the message by entering the ID that was previously stored using the Confidential ID feature.

2. Confidential ID Override

If you wish to send a confidential message to a particular person at the other end, you can specify the Confidential ID that person has to enter to see that message. Anybody entering the machine's Confidential ID will not be able to see the message. Before you send the message, don't forget to tell the intended receiver what code must be entered to print the message.

Note: The receiving machine's Confidential ID is not changed by this process.

If the intended receiver has a Personal Code with a Confidential ID stored with it, you can override the receiving machine's ID with that Confidential ID. Then:

- ☐ The receiver can print the message by inputting the Confidential ID that is stored with that person's Personal Code.
- ☐ The intended receiver will also be informed personally by a Confidential File Report; this report will have the name of the receiver on it, if the name was stored with the Personal Code.

Cross-references

Confidential ID: see page 127.

Confidential File Report: see page 186.

Confidential Reception: see page 126.

Personal Codes: see page 110.

TCR: see page 185.


Procedure

To set up a confidential transmission, do the following.


1. Place your document in the feeder.

2. Either:

☐ **Function** **1** **1**

☐  If you have programmed one of the User Function Keys to activate this feature, press that key and go to step 3.

3. Dial then press **Yes**.


 See page 51 for how to dial.

4. Either:

☐ Dial another number: Go to step 3.

☐ Do a Confidential ID Override (see below).

☐ Press **Start**.



ADVANCED
FEATURES

Confidential ID Override Option

This procedure will override the Confidential ID stored in the other party's machine. The override is only effective for this one transmission.


If OPTI ONS  is displayed:

1.  **0** **5**



2. Enter the Confidential ID that you wish to use for this message.

Example: **2** **5** **6** **7** **Yes**

CONF. TRANS.	OPTI ONS 
ENTER NO. OR START	DEST: 2
<div style="background-color: black; height: 20px; width: 100%;"></div>	


3. Dial and press **Start** .



For how to use other options, see page 59 and the pages following.

Auto Document

Overview



If you often find that you have to send a particular page to people (for example, a map, a standard attachment, or a set of instructions), store that page in the memory as an Auto Document, using a Quick Dial Key.

Then, when you need to send that page to somebody, press the Quick Dial Key that you stored it in, place any other pages that you wish to send into the feeder, dial, and press Start. At the other end, the Auto Document will be printed first.

The Auto Document is transmitted as is; you cannot write anything on it like you can with a cover sheet. If you wish the machine to place your name on your transmitted documents, try using the Label Insertion feature (see page 120).

Storing an Auto Document

1. Make sure that the machine is in standby mode (see page 49).
2. Take the document that you want to be an Auto Document and place it into the feeder.
 - ☐ If you only wish to scan a part of the document, use the Specified Image Area feature. See page 118 for details.

MEMORY TRANS. OPTI ONS [Down Arrow]

ENTER FAX NUMBER

[Redacted]

3. Press the Quick Dial Key that you wish to store the Auto Document in.
Example: **08**

- ☐ Be sure that this Quick Dial Key is vacant.

STORE AS AUTO DOCUMENT

[YES] OR [NO]

3. **Yes**

Labeling an Auto Document

If you store a label for your Auto Document, the label will appear on the display when you use the document. Also, you can attach an adhesive label to the Quick Dial Key if you wish.

1. **Function** **3** **6**
 - ☐ If you press **→** **Start**, a Program List will be printed.

AUTO DOCUMENT CHOOSE KEY

[Selection Box] PRINT LIST [Right Arrow]

[NO] TO CANCEL

2. Press the Quick Dial Key that holds the Auto Document that you wish to label.
Example: **08** **Yes**

AUTO DOCUMENT ENTER LABEL

[Selection Box] 08

[Redacted] ABC

3. Input your label, using the Quick Dial Keys.

? Inputting labels: see page 7.

AUTO DOCUMENT [YES] OR [CLR] [NO]

[Selection Box] 08

OFFICE LOCATION MAP ABC

4. **Yes**

5. Either:
 - ☐ Label another: Go to step 2.
 - ☐ Finish: **Function**

AUTO DOCUMENT CHOOSE KEY

[Selection Box] PRINT LIST [Right Arrow]

[NO] TO CANCEL

Using an Auto Document

1. Make sure that the machine is in standby mode (see page 49).
2. If you wish to attach a fax message to your Auto Document, place the fax face down into the feeder.

MEMORY TRANS.	OPTI ONS	↓
ENTER FAX NUMBER		
<div style="background-color: black; height: 20px; width: 100%;"></div>		

3. Press the Quick Dial Key that contains the Auto Document that you need.
Example: **08**

SEND AUTO DOCUMENT	
YES	OR NO

4. **Yes**

MEMORY TRANS.	OPTI ONS	↓
ENTER FAX NUMBER		
<div style="background-color: black; height: 20px; width: 100%;"></div>		

5. Dial the destination(s), then press **Start**.

Printing the Contents of an Auto Document

If you need to remind yourself of what one of your stored Auto Documents looks like, do the following procedure.

1. **Function** **5** **3**

AUTO DOCUMENT	CHOOSE KEY
■ <div style="background-color: black; width: 30px; height: 20px; display: inline-block;"></div>	PRI NT LI ST →
	NO TO CANCEL

2. Press the Quick Dial Key that holds the Auto Document that you wish to see.
Example: **08** **Yes**


AUTO DOCUMENT	NO TO CANCEL
■ 08	OFFI CE LOCATI ON MAP
PRESS START	

3. **Start**

Erasing an Auto Document

If you wish to delete an Auto Document, do the following.

1. **Function** **3** **6**

AUTO DOCUMENT	CHOOSE KEY
<input type="checkbox"/> 08	PRINT LIST 
	NO TO CANCEL


2. Press the Quick Dial Key that contains the Auto Document that you wish to erase.

Example: **08**

AUTO DOCUMENT	YES OR NO
<input type="checkbox"/> 08	OFFICE LOCATION MAP
	CLR: CLR

3. To erase the Auto Document:

Clear **Yes**

AUTO DOCUMENT	CHOOSE KEY
<input type="checkbox"/> 08	PRINT LIST 
	NO TO CANCEL


4. Either:

- ☐ Erase another Auto Document: Go to step 2.
- ☐ Return to standby mode: **Function**

Restricting Access to the Machine



Overview




When your machine arrives from the factory and is installed for the first time, anybody can use it. However, using a system of Personal Codes, the machine can be set up to prevent unauthorized persons from using the machine. The necessary procedures are given in the following sections.

- ☐ Programming the Personal Codes: see below.
- ☐ Switching on Restricted Access: see page 113.

Programming the Personal Codes

The main advantage of Personal Codes is that they allow you to track machine usage and restrict access to the machine. If you do not wish to restrict access to the machine, you can still use Personal Codes to personalize your fax messages, by using the Label Insertion feature.

The Personal Code is a four digit code. It can have any value from 0001 to 9999.



Each user can be given a Personal Code. While programming, you can store the following items with each Personal Code:

- ❑ A name: This will be printed on reports, such as the TCR, to identify the users of the machine. It is also used with the Label Insertion feature.
- ❑ A Confidential ID: This must be different for each Personal Code, and different from your machine’s Confidential ID. If somebody sends you a confidential message, they can override your machine’s Confidential ID with the Confidential ID stored with your Personal Code, if you inform them of this ID. If so, the machine will print a Confidential File Report that will inform you when the message has arrived. Then, you must input this Confidential ID to print the message.

You can only store Confidential IDs if you have an optional memory card or hard disk.

Note: You cannot register more than 50 Personal Codes with Names and Confidential IDs in this machine. This means that if you switch Restricted Access on, only 50 people can use the machine.

Cross-references

Using Personal Codes: see pages 59, 105, 113, and 128.
Label Insertion: see page 120.
TCR: see page 185.
Confidential ID: see page 127.

Confidential File Report: see page 186.
Confidential Reception: see page 126.

Storing a Personal Code

1. **Function** **6** **0** **2** **2** **2** **2**
7 **1**

❑ At this time, you can print a Personal Code List if you press **→** **Start** .

PERS. CODE
[REDACTED]
—

ENTER I D CODE
PRI NT LI ST **→**
NO TO CANCEL

2. Input a Personal Code that you want to store in your machine for later use.
Example: **5** **4** **7** **7**

❑ If you input the wrong code, press **No** .

PERS. CODE
5477

YES OR **NO**
CLR: **CLR**

3. Store the code: **Yes**

PERS. CODE
5477
[REDACTED]
—

ENTER LABEL
ABC

ADVANCED
FEATURES

4. Input a name for this Personal Code using the Quick Dial keys.

Example: JOHNSON



Inputting and editing labels: see page 7.

- ☐ If you do not wish to store a label: **Yes** . Go to step 6.

5. Store the name: **Yes**

PERS. CODE	YES	OR	CLR	.	NO
5477					
JOHNSON					ABC

6. Either:

- ☐ If you do not have an optional memory card or hard disk, go to step 8.
- ☐ Input a Confidential ID for the personal code used by this user.

Example **4 6 5 6**

If you do not wish to store an ID: **No** . Go to step 8.

PERS. CODE	CONF. I D SETTING	
5477	JOHNSON	
		YES TO END

PERS. CODE	YES	OR	CLR	.	NO
5477	JOHNSON				
	4656				

7. Store the ID: **Yes**

PERS. CODE	ENTER I D CODE	
		PRI NT LI ST →
		NO TO CANCEL

8. Either:

- ☐ Enter another code: Go to step 2.
- ☐ Finish: **Function**

Editing or Erasing a Personal Code

1. **Function 6 0 2 2 2 2**
7 1

PERS. CODE	ENTER I D CODE	
		PRI NT LI ST →
		NO TO CANCEL

2. Input the Personal Code that you wish to edit.

Example: **5 4 7 7**

- ☐ If you input the wrong code, press **No** .

PERS. CODE	YES	OR	NO
5477	JOHNSON		
	CLR: CLR		

3. Either:
- ☐ Erase this Personal Code: **Clear** **Yes**
Go back to step 2.
 - ☐ Edit the contents of this code: **Yes** .
Go to step 4.

PERS. CODE	YES	OR	CLR	.	NO
5477					
JOHNSON					ABC

4. Edit the name stored with this code.
When the name is correct,
press **Yes** .



Inputting and editing labels: see page 7.

PERS. CODE	YES	OR	CLR	.	NO
5477	JOHNSON				
4656					

5. Either:
- ☐ If you do not have an optional memory card or hard disk, go to step 6.
 - ☐ Edit the Confidential ID stored with this code.
When the ID is correct, press **Yes** .

PERS. CODE	ENTER I D CODE	
	PRI NT LI ST →	
	NO	TO CANCEL

6. Either:
- ☐ Enter or edit another code: Go to step 2.
 - ☐ Finish: **Function**

Switching on Restricted Access

Restricted Access allows you to keep a closer track of machine usage, and deters passers-by from casually using your machine.

If this feature is switched on, users have to enter their Personal Code before they can use the machine. The Personal Code must have already been stored in the machine.

However, the user can enter codes directly at the keypad. Therefore, if you are serious about using this feature to stop casual users from operating the machine, you must allocate relatively obscure codes to all authorized users, and try to avoid obvious numbers such as 0001.

To switch Restricted Access On or Off, do the following:

If you wish to switch Restricted Access on or off, do the following procedure. (See page 10 if you need more information about the User Parameter settings adjustment procedure).

1. **Function** **6** **0** **2** **2** **2** **2** **9** **1**

USER PARAMETER	PRI NT LI ST	→
DEFAULT:	01000000	↑
SW TCH00:	01000000	YES TO END ↓

2. The settings for switch 00 are now shown on the bottom line of the display.

SWITCH00: 00000000

3. Press **↓** until the settings for switch 04 are shown.

The setting that you need to change is digit 5.

SWITCH04: 00000000

Digit 5
0: Restricted Access is Off
1: Restricted Access is On

4. If you wish to change the setting, press **5** .

5. Finish: **Yes** **Function**

Operating the Machine with Restricted Access Switched On

If you have switched Restricted Access on, the display is as shown below when the machine is in standby mode.

Before you can use the machine, you must enter your personal code that you have already registered in the machine. See page 110 for how to store Personal Codes.

RESTRI CTED ACCESS	ENTER CODE
CODE	██████████
DEC. 4. 11:50 AM	

1. Enter your personal code.

Example: **7** **3** **6** **2**

2. After a second, the normal standby display will appear, and you can use the machine. If NOT PROGRAMMED appears, you entered a personal code that is not stored in the machine.

If you decide that you do not wish to use the machine now, you should return the machine to Restricted Access standby mode. To do this, either:

- ☐ Insert a page into the document feeder and remove it immediately.
- ☐ Press **Function** twice.

Tonal Signals



Some organizations offer you special services by telephone, which you can access by transmitting Touch Tone or DTMF tones. If your phone service provides only pulse dialing, or if you are calling over a digital network, the ability to generate Tonal Signals will allow you to access these services.

First, dial the other party. When you are through to the other end, press the Tone key and enter the code number that is needed to access the required feature at the other terminal.

You do not need to press the Tone key if your machine is set up for dialing in Tone Dial (DTMF) mode.

Before you can use this feature, you must program one of the User Function Keys as the Tone key. See page 163 for how to do this. In the following procedure, suppose that we have already programmed the **F1** key as a Tone key.

1. Make sure that the machine is in standby mode, and that there is no document in the feeder.
2. Pick up the telephone handset, or press **On Hook Dial** .
3. Dial the remote facility. Do not press **Start** .
4. After your line is connected to the remote facility, do the following:
 - ☐ If your telephone line type is DTMF (Tone Dial): Go to step 5.
 - ☐ If your telephone line type is Pulse Dial: Press **F1** . A dot appears on the display.
5. Input the digits that you need to use the remote facility. These digits will depend on the remote facility.
Note: Do not press **Start** .
6. After you have finished your business with the remote facility, hang up.

Cross-reference

Tone Dial (Telephone Line Type): see page 28.

Chain Dialing

This feature allows you to compose a telephone number from various parts, some of which may be stored as Quick Dial Keys or Speed Dial Codes, and some of which may be input at the keypad.

For example, you can program commonly used area or country codes into Speed Dial Codes or Quick Dial Keys.

This feature is convenient if:

- ☐ You often communicate with many terminals for which the area code, or international code is the same.
- ☐ You often make international calls.
For example, if you often call Tokyo, Japan, program 011813 (Overseas to Tokyo from the USA) as Quick Dial Key 01. This will save work at the operation panel when dialing a Tokyo number.
- ☐ Your PBX requires an ID code before the destination number.
For example, if your ID is 1234567, and the destination is stored in Quick Dial Key 01, enter 1234567 at the keypad, press Pause, then press Quick Dial Key 01.

Note: Do not store any labels with the Quick Dials and Speed Dials that you are using with Chain Dialing. This is because Label Insertion does not work with Chain Dialing.

Cross-reference

Quick Dial and Speed Dial: see page 29.

Label Insertion: see page 120.

Example: 01133-1-5553333 (From the USA to Paris).

Assume that the following Quick Dial and Speed Dial numbers have already been programmed.

- ☐ Quick Dial 01 = 01133 (Overseas to France)
- ☐ Quick Dial 02 = 1 (Paris)
- ☐ Speed Dial 10 = 555

When the machine asks you to dial:

On Hook Dial or Handset Mode:

Press **[01]** **[02]** **[Speed Dial]** **[1]** **[0]** then **[3]** **[3]** **[3]** **[3]**

Other:

Press **[01]** **[Pause]** **[02]** **[Pause]** **[Speed Dial]** **[1]** **[0]** **[Pause]** then **[3]** **[3]** **[3]** **[3]**

Secure Transmission



Overview

This feature allows some degree of data security when sending a fax message. However, care should be taken because the method used for data encryption is quite simple, unlike the methods used in data scramblers or in the DES (Data Encryption Standard) used in some software packages.

The transmitting machine will encrypt the data, and the receiving machine will recover the original data from the encrypted signal before printing.

The ID code for Secure Transmission is fixed. When sending a fax message by Secure Transmission, the supplier is not responsible for the interception or decoding of the message by an unauthorized party.

Before using this feature, you must program one of the User Function Keys to activate this feature (Function 35; see page 163).

Changing the Secure Transmission on/off Home Position Setting

To change the Secure Transmission on/off home position setting, do the following procedure. (See page 10 if you need more information about the User Parameter settings adjustment procedure).

1. **Function** **6** **0** **2** **2** **2** **2** **9** **1**

USER PARAMETER	PRINT LIST
DEFAULT: 01000000	↑
SW TCH00: 01000000	YES TO END ↓

ADVANCED
FEATURES

2. The settings for switch 00 are now shown on the bottom line of the display.

SWITCH00: 00000000

3. Press **↓** until the settings for switch 03 are shown.
The setting that you need to change is digit 3.

SWITCH03: 00000000

Digit 3

0: The home position is "Off". If you use Secure Transmission, it will be automatically disabled after the transmission.

1: The home position is "On". If you use Secure Transmission, it will stay enabled after the end of the transmission (the light under the User Function Key will stay on).

4. If you wish to change the setting, press **3**.
5. Finish: **Yes** **Function**

Making a Secure Transmission

1. Make sure that the machine is in standby mode (see page 49 for details), then place your document in the feeder.
2. Press the User Function Key that you have programmed for Secure Transmission (if the light under that key is off).
3. Dial in the normal manner.



See page 51 for how to dial.

4. Press **Start**. The fax message will be printed automatically at the other end.


Secure Transmission only works if the machine at the other end is equipped with the same feature.

Specified Image Area



Overview

If you only wish to transmit a part of the page, use this feature. You tell the machine what area to scan by specifying two parameters: The Skip Length, and the Scan Length. See the following diagram.



This feature cannot be used when you are transmitting using an OMR sheet, immediate transmission, when you are making a copy.

Before you can use the feature during a transmission, you must:

- ☐ Set up the feature using Function 96 (see the next page).
- ☐ Program one of the User Function Keys so that you can activate this feature during the transmission procedure.

Note: If skip length is longer than the paper, the machine stops scanning.

Changing the Specified Image Area On/Off Home Position Setting

In a new machine, this setting is off. If you change this setting to "On", the image area that you input (using Function 96; see below) will be used for all of your transmitted pages, unless you switch off the light under the User Function Key that you programmed for this feature.

1. **Function** **6** **0** **2** **2** **2** **2** **9** **1**

USER PARAMETER	PRI NT LI ST	→
DEFAULT:	01000000	↑
SW TCH00:	01000000	YES TO END ↓

2. The settings for switch 00 are now shown on the bottom line of the display.

SWITCH00: 00000000

3. Press **↓** until the settings for switch 03 are shown.
The setting that you need to change is digit 5.

SWITCH03: 00000000

4. If you wish to change the setting, press **4**

5. Finish: **Yes** **Function**

Digit 5
0: The home position is "Off". After transmission, Specified Image Area will switch itself off.
1: The home position is "On". After transmission, Specified Image Area will stay active and the lamp under the User Function Key will stay lit.

Specifying an Image Area

1. **Function** **6** **0** **2** **2** **2** **2** **9** **6**

I M A G E A R E A	YES TO END	↓
SKI P LENGTH:	000	MM
SCAN LENGTH:	000	MM

2. Input the skip length then press **↓** .
You must enter a three digit value.
For example, for 75 mm, input 075.

I M A G E A R E A	YES TO END	↓
SKI P LENGTH:	075	MM
SCAN LENGTH:	000	MM

3. Input the scan length then press **↓** .
You must enter a three digit value.
For example, for 95 mm, input 095.

4. Finish: **Yes**

The machine returns to the transmission procedure.

☐ 1 inch is 25.4 mm. You must input the dimensions in mm.

Specified Image Area is available only when you are doing one of the following:

- ☐ Memory Transmission (including Confidential Transmission and Transfer Request)
- ☐ Storing a document for Polling Transmission
- ☐ Storing an Auto Document

Label Insertion

This feature supplements the TTI. It uses the Personal Code and the Quick Dial or Speed Dial Label to inform the other party who is sending the message, and to state who the message is for.


To use this feature, you must:

- ☐ Switch Label Insertion on for each Quick Dial and Speed Dial that you wish to use this feature with (see the procedures starting on pages 31 and 34).
- ☐ Program the Personal Codes of the machine's users, and store their names with their codes (see page 110).
- ☐ Program labels with the Speed Dial and Quick Dial numbers (see the procedures starting on pages 31 and 34).
- ☐ When you make a transmission, use a Quick or Speed Dial, and select the Personal Code option (see page 59).

Note: TTI on/off has no effect on this feature.

Example:

Your fax message as received at the other end



In the above example, the message was sent using Johnson's personal code. The Quick Dial or Speed Dial used to dial the destination had MR SMITH as the label.

Notes

If you later reprogram the Speed/Quick Dial, be sure to reprogram or delete the label as well.

The top of the image will be overprinted if there is no margin at the top of the transmitted page (this is also true for the TTI).

Cross-reference


Quick Dial and Speed Dial: see page 29.

Personal Codes: see pages 59 and 110.

Closed Network (Transmission)

This feature helps to stop you from accidentally sending a fax message to a terminal that is outside your fax network.

The ID Codes of the communicating machines are checked. If they are not the same, the communication is stopped.



This feature is similar to the ID Transmission option, but it cannot be switched on/off for individual transmissions.

Contact a service technician if you are interested in this feature.

Note: This feature may not be reliable if you are communicating with a terminal produced by a different manufacturer.

Cross-references

ID Codes: see page 85.


ID Transmission: see page 65.

Closed Network (Reception): see page 152.

Protection Against Wrong Connections

This feature prevents the automatic switching equipment in the telephone network from accidentally connecting you to the wrong fax terminal.

However, it does not help you if you dialed the wrong number yourself. So, even if this feature is switched on, you should still check your operation panel display to check whether you have reached the correct terminal, and be ready to press Stop if the wrong terminal's RTI or CSI is displayed.



Your machine compares the number that you dialed with the CSI received from the other end. (Only the last 8 digits are checked, and spaces and pauses in the telephone number are ignored.) If the CSI is not the same as the telephone number, the transmission is stopped.


This feature has to be switched on by a service technician.

Note: If you cannot send a message to a certain location using this feature, contact the other end and make sure that they have stored their CSI correctly. (If the other party is using a machine made by another maker, they may not be familiar with the term CSI. Explain that you are interested in the telephone number that they stored in the machine for identification purposes.)

Cross-references

CSI: see pages 25 and 27.

ECM (Error Correction Mode) and Page Retransmission



ECM is a signaling system that greatly reduces the chance of data being lost because of a bad telephone line. ECM is useful if you frequently communicate over poor telephone lines.

With ECM switched on, the communication cost will increase if the line is bad, but the data will be sent much more reliably.

If ECM is switched off, Page Retransmission will be used. The whole page will be resent (unless you used Immediate Transmission, in which case damaged data cannot be resent at all). ECM is more efficient, because it only resends the damaged parts of the data, and the maximum possible number of retransmission attempts is much higher, and it also works with Immediate Transmission.

If you wish reliable communication and do not mind paying extra communication charges when the line is noisy, keep ECM switched on. However, if you are more worried about communication costs, contact a service technician and ask to have ECM switched off and Page Retransmission switched on.

- ☐ If Page Retransmission is on, pages can be sent up to 3 times before the machine gives up. If you wish to change the number of retries, contact a service technician.


ECM is switched on in your machine when it leaves the factory, to provide you with the ability to send accurate and complete documents as reliably as possible.

Batch Transmission



Overview

This feature will save communication costs if you often send more than one message to the same location.



Example:

If various people in your office send messages to the Tokyo branch office, sending all these messages on separate calls can be expensive. It is cheaper to send them all together on the same call. You can further cut costs by sending out batches during off-peak hours. To do so, simply create Keystroke Programs that use Send Later or Economy Transmission to send to those common destinations.

Instruct people in your office to store all faxes for the Tokyo branch in the memory, using Send Later or Economy Transmission. For Send Later, the selected time of transmission must be the same for each message that you wish to include in the batch. Then, when that time comes, the messages will all be sent out on the same call, or 'batched'.

You must program a User Function Key to allow you to use Batch Transmission.

- ☐ If the light under that key is on, Batch Transmission is active.
- ☐ If the light is off, Batch Transmission is disabled. Press the User Function Key to use Batch Transmission.

You can set up more than one batch. In the example shown in the diagram above, you have set up two batches; one is for destination A and one is for destination B. In another example, you could set up a batch for Tokyo at, say, 1 am, a batch for Hong Kong at 2 am, a batch for London at 3 am, and so on.

Also, when you send a fax message, if there is a message in the memory waiting for transmission to the same telephone number, it will be sent out with your message. This will only happen if the message already in the memory is waiting for retransmission (for example, because the line was busy on the first attempt).

Note: You can have up to 50 fax messages in the same batch.
Messages using Confidential Transmission cannot be put into a batch.

Cross-reference
Send Later: see page 60.

Economy Transmission: see page 66.

Changing the Batch Transmission Home Position Setting On/Off

In a new machine, this setting is "On". If you wish to change this setting, use the following procedure. (See page 10 if you need more information about the User Parameter settings adjustment procedure).

1. **Function** **6** **0** **2** **2** **2** **2** **9** **1**

USER PARAMETER

PRI NT LI ST

DEFAULT: 01000000

SW TCH00: 01000000

YES TO END

2. The settings for switch 00 are now shown on the bottom line of the display.

SWITCH00: 00000000

3. Press **↓** until the settings for switch 03 are shown.
The setting that you need to change is digit 4.

SWITCH03: 00000000

4. If you wish to change the setting, press **4**.
5. Finish: **Yes** **Function**

Digit 4
0: The home position setting is "Off". Batch Transmission will be disabled after transmission. Use this if you only wish certain transmissions to be batched. However, you will have to press the Batch Transmission User Function Key for every transmission you wish to be batched.
1: The home position is "On". If you use Batch Transmission, it will stay on for all transmissions, until you turn off the lamp under the User Function Key.

ADVANCED
FEATURES

Well Log Transmission

Using this feature, you can transmit a document that is longer than the maximum limit, without having to cut it up into separate sheets. However, you must contact a service technician to have this feature switched on. The name of this feature is taken from oil well borehole surveying. A well log is a vertical profile of a borehole, drawn to scale, showing important data. A well log can be several yards long.

Caution
If this feature is switched on permanently, users must stay by the machine while their documents are being scanned. This is because, if the document jams, the machine may take much longer than usual to recognize the jam; this could result in excessive wear and tear of the mechanical components of the scanner.
If a jam does occur, press the Stop key immediately.


RECEPTION

Confidential Reception (Memory Card or Hard Disk Required)

Overview

If the other party sent you a message using Confidential Transmission, the message is stored in the memory, and not printed. The "Confidential File" indicator on the operation panel lights up to inform you when a confidential message has come in. Also, if you have switched Confidential File Report on, the machine will print a report whenever a confidential message comes in.

There is no need to do anything immediately. When you want to print the message, input the Confidential ID.



- Notes:**
- ☐ For this feature to work properly, you must have stored a Confidential ID in advance.
 - ☐ If the machine's Confidential ID does not have any effect, contact the sender and check whether they used Confidential ID Override to override your ID. Print the TCR to find out who the sender is, if necessary.
 - ☐ If you have forgotten the machine's Confidential ID, print a User Parameter List, or call a service technician for assistance.

Cross-references

Confidential ID: see page 127.

TCR: see page 185.

Confidential File Report: see page 186.

Confidential Transmission: see page 104.


Confidential ID Override: see page 104.

User Parameter List: see page 193.



Storing a Confidential ID

This can be any four-digit code (using digits 0 to 9). It must be used to print any confidential messages that your machine has received.


1. **Function** **6** **0** **2** **2** **2** **2**

6 **1** then  until the screen is as shown opposite.

- ☐ If no memory card or hard disk is installed, you will not see this prompt.

CONFIDENTIAL ID	
YES TO SET	PREVIOUS 
NO TO CANCEL	NEXT 

2. **Yes**

CONFIDENTIAL ID	
ID SETTING	YES TO END
	

3. Input the Confidential ID that you will be using. Example: **6** **7** **5** **4**

CONFIDENTIAL ID	
YES OR CLR NO	
6754	

4. **Yes** **Function**

If you do not store a Confidential ID, you will not be able to receive confidential messages.

ADVANCED
FEATURES


Printing a Confidential Fax Message




If the Confidential File indicator is lit, do the following to print the message.

1. Either:

- ☐ **Function** **5** **5**

- ☐  If you programmed a User Function Key to activate this feature, press that key and go to step 2.

PRT CONF. RX	ENTER CONF. ID
CONFIDENTIAL ID:	
	NO TO CANCEL

2. Input the ID. Example: **4** **7** **3** **9**

- ☐ If you cannot output a confidential file with this ID, you have input the wrong ID or the sender may have over-ridden your ID. Contact the sender.

PRT CONF. RX	PRESS START
CONFIDENTIAL ID:

3. **Start**

NOTE: If the Confidential File indicator is blinking, an incoming fax message has been stored in the memory using the Memory Lock feature. To print the message, see page 130.

Confidential File Report

This report informs you when a confidential message has been received.

You can store a separate Confidential ID with each of the Personal Codes. If the sender of the message uses Confidential ID Override, the sender can specify one of these IDs. If so, the Confidential File Report will contain the name stored with that Personal Code, drawing the attention of the intended receiver of the confidential message.

You can switch this report on or off using Function 81. In a new machine, it is switched on at the factory.

1. **Function** **6** **0** **2** **2** **2** **2** **8** **1**

PSTN LINE TYPE	SELECT ← →
DP	TT ↑
	YES TO END ↓

2. Scroll through the list of features with ↑ and ↓ until CONF. FILE REPORT appears.

3. Change the on/off setting by pressing ← or → .

4. Finish: **Yes** **Function**

Cross-reference

Personal Codes: see page 110.


If you wish, you can prevent unidentified senders from sending you confidential messages. See page 131.



Memory Lock (Memory Card or Hard Disk Required)



Overview



To use Memory Lock, you must first:

- ☐ Store a Memory Lock ID.
- ☐ Switch Memory Lock on.

If Memory Lock is switched on, the machine will not print any incoming fax messages. They will be kept in memory until you enter the Memory Lock ID that you previously stored in the machine. Messages received by Confidential Reception will not be printed when you input the Memory Lock ID.

Cross-reference

Confidential Reception: see page 126.

ADVANCED
FEATURES

Storing a Memory Lock ID

This can be any four-digit code (using digits 0 to 9 and letters A to F), except 0000 and FFFF.

1. **Function** **6** **0** **2** **2** **2** **2**

6 **1** then **↓** until the screen is as shown opposite.

- ☐ If no memory card or hard disk is installed, you will not see this prompt.

2. **Yes**

3. Input the Memory Lock ID that you will be using. Example: **6** **7** **5** **4**

- ☐ You must input this ID when you wish to print an incoming message that was stored under the protection of the Memory Lock feature.

4. Store the ID: **Yes** **Function**

MEMORY LOCK I D	
YES TO SET	PREVIOUS ↑
NO TO CANCEL	NEXT ↓

MEMORY LOCK I D	
I D SETTING	
6	YES TO END

MEMORY LOCK I D	
YES OR CLR · NO	
6754	

Switching Memory Lock On/Off

Before you can use Memory Lock, you have to switch it on using Function 81.

After you switch Memory Lock on, (MEMORY LOCK) will appear on the display when the machine is in standby mode.

Note: If you switch Memory Lock on, Forwarding will be automatically disabled.

1. **Function** **6** **0** **2** **2** **2** **2** **8** **1**

PSTN LINE TYPE	SELECT	←	→
DP	TT	↑	↓
	YES	TO END	

2. Scroll through the features with **↑** and **↓** until MEMORY LOCK appears.
3. Change the on/off setting by pressing **←** or **→**.
4. Finish: **Yes** **Function**

If you wish, you can prevent unidentified senders from sending you messages while Memory Lock is on. See page 131.

Printing from Memory Lock (Memory Card or Hard Disk Required)

If the Confidential File indicator is blinking, a message has been stored using Memory Lock. Print it using the following procedure.

1. **Function** **5** **6**

PRT MEM. LOCK	ID SETTING
MEMORY LOCK I D:	■■■■■
	NO TO CANCEL

2. Input the Memory Lock ID.
Example: **4** **6** **3** **3**

PRT MEM. LOCK	PRESS	START
MEMORY LOCK I D:	■■■■■	

3. **Start**

NOTE: If the Confidential File indicator is blinking, a message has been stored using Memory Lock. However, if the Confidential File indicator is lit, a message has been stored using Confidential Reception, and the indicator no longer clearly shows the presence of files stored using Memory Lock.

Rejection of Messages from Unidentified Senders



If you wish, you can make the machine reject incoming messages that require storage to your machine’s memory, if they are not accompanied with an identifier such as the RTI or CSI. Features that would be affected are Substitute Reception, Memory Lock, and Confidential Reception, Forwarding, and Action as a Transfer Station.

The procedure is as follows (see page 10 if you need more information about the User Parameter settings adjustment procedure).

1. **Function** **6** **0** **2** **2** **2** **2** **9** **1**

USER PARAMETER	PRI NT LI ST	→
DEFAULT:	01000000	↑
SW TCH00:	01000000	YES TO END ↓

- ☐ At this time, you can print a User Parameter List if you press → **Start** .
2. The settings for switch 00 are now shown on the bottom line of the display.
3. Press ↓ until the settings for switch 05 are shown.
The setting that you need to change is that for digit 3.
4. If you wish to change the setting, press **3** .
5. Finish: **Yes** **Function**

SWITCH00: 00000000

SWITCH05: 00000000

Digit 3
0: Messages are not rejected.
1: Messages are rejected.

ADVANCED
FEATURES


Cross-references	
Substitute Reception: see page 75.	Confidential Reception: see page 126.
Memory Lock: see page 129.	Forwarding: see page 134.
Action as a Transfer Station: see page 87.	

Authorized Reception



Overview

This feature helps you to reject junk fax mail. It lets you specify which terminals you wish to receive fax messages from; all others will be shut out.



To authorize reception from a particular sender:

- ☐ Program the RTI or CSI of the sender. (Ask the sending party what their RTI/CSI is. Or make a communication with that terminal, print a TCR and read off the RTI/CSI.)
If the other party is using a machine made by another maker, they may not be familiar with the terms RTI or CSI. Explain that you are interested in the telephone number that they stored in the machine for identification purposes.
- ☐ Switch Authorized Reception on.

If the RTI/CSI is not the same as any of those that you have programmed into this feature, the message will not be accepted.

The number of RTI/CSI's that you can store for use with this feature is limited to 50. However, you can use Wild Cards to extend the number of RTI/CSI's that you can specify.

Note: If one of the authorized terminals changes their RTI/CSI, you have to change the stored RTI/CSI also. Otherwise, you will not be able to accept messages from that sender any more.

Cross-references

RTI and CSI: see page 25.
TCR: see page 185.

Wild Cards: see page 144.

Programming the Authorized Senders

1. **Function** **6** **0** **2** **2** **2** **2**
7 **2**

DEST. 6 on the opposite display shows that there are 6 RTIs/CSIs programmed so far. In a new machine, you will see DEST. 0.

- ☐ At this time, you can print an Authorized Reception List by pressing **→** **Start** .

AUTHORI Z. RX SELECT	
DEST. 6	PRI NT LI ST →
1. RTI PROG 2. RTI NO TO CANCEL	

2. Either:
☐ Store some RTIs/CSIs: **1** . Go to step 3.

AUTHORI Z. RX	ENTER RTI / CSI
	NO TO CANCEL
<div></div> ABC	

- ☐ View the RTIs/CSIs that you have stored so far: **2** . Go to step 6.
DEST. 1 / 6 means that there are 6 RTIs/CSIs programmed so far, and the first in the list is now displayed.

AUTHORI Z. RX	NO TO CANCEL
DEST. 1 / 6	CLR: CLR
XYZ. CO. ↓	

- ☐ Finish: **Yes**

3. Type in an RTI or CSI, then press **Yes** .

AUTHORI Z. RX	
STORE AS W LD CARD?	YES . NO
XYZ. CO.	

? Label input and editing: see page 7.

4. Either:
☐ Store this RTI as a wild card: **Yes**
☐ Otherwise: **No**

AUTHORI Z. RX	ENTER RTI / CSI
	NO TO CANCEL
<div></div> ABC	

5. Either:
☐ Enter another RTI or CSI: Go to step 3.
☐ Finish: **No** . Go to step 2.

6. Scroll through the stored RTIs/CSIs on the screen with **↓** .

- ☐ It is not possible to edit an RTI/CSI; if you wish to do so, you must delete the incorrect entry and re-input it.
☐ To delete the displayed RTI/CSI: **Clear** . Go to step 2.
☐ When you have finished: **No** . Go to step 2.

Switching Authorized Reception On/Off

Before you use Authorized Reception, you have to switch it on using Function 81. If it is switched off, the machine will accept any incoming fax message.

1. **Function** **6** **0** **2** **2** **2** **2** **8** **1**



2. Scroll through the list of features with and until AUTHORIZED RECEPTION appears.
3. Change the on/off setting by pressing or .
4. Finish: **Yes** **Function**


Forwarding (Memory Card or Hard Disk Required)



Overview

Using this feature, you can send fax messages coming in from certain locations on to another fax machine. The terminals that receive your forwarded messages are called "forwarding terminals".

If other fax machines in your organization have this feature, you can use Forwarding to set up distribution chains for incoming fax messages.



To set up Forwarding, program your machine as follows:

- ☐ Program the phone numbers of the forwarding terminals that you will use.
- ☐ Program the RTI or CSI of each sender, allocating it to one of the forwarding terminals. (Ask the sending party what their RTI/CSI is. Or make a communication with that terminal, print a TCR and read off the RTI/CSI.)
If the other party is using a machine made by another maker, they may not be familiar with the terms RTI or CSI. Explain that you are interested in the telephone number that they stored in the machine for identification purposes.
- ☐ Switch Forwarding on.

If the RTI/CSI of the machine sending you a fax is not the same as any of those that you have programmed into this feature, the message will not be forwarded.

In this machine, you can specify up to 5 forwarding stations, and a total of up to 30 RTI/CSI's. However, you can use Wild Cards to extend the number of RTI/CSI's that you can specify.

Notes:

Your machine prints all the messages that it forwards. If you do not want it to do this, contact a service representative.

You can select whether or not your machine transmits a forwarding mark to be printed at the other end on the top of each page of the output. This mark brings to the other party's attention that this message has been forwarded. See page 140 for more about the Forwarding Mark.

If one of the senders changes their RTI/CSI, you must change the stored RTI/CSI, or you will not be able to forward messages from that sender.

Cross-references

RTI and CSI: see page 25.
TCR: see page 185.

Wild Cards: see page 144.

Programming the Forwarding Feature

This section shows you how to set up your machine to forward incoming fax messages to another location or locations. After you have done this procedure, you must switch Forwarding on for it to take effect (using Function 81); see page 140 for how to do this.

Read through these procedures before you use them, as they are a little complicated.

1. **Function** **6** **0** **2** **2** **2** **2**

7 **5**

- ☐ At this time, you can print a Forwarding List by pressing **→** **Start** .

FORWARDI NG	SET FORWARD. CODE
No. —	PRI NT LI ST →
	NO TO CANCEL

2. Input a two-digit code from 01 to 05 for a forwarding station number.

- ☐ The forwarding station is the number that you wish to direct incoming messages to.

Example: **0** **2**

- ☐ DEST. 0 on the opposite display shows that there are no RTIs/CSIs stored so far for this forwarding station.

FORWARDI NG	YES OR NO
No. 02	DEST. 0
	↑ ↓

3. **Yes**

FORWARDI NG	ENTER FAX NUMBER
No. 02	NO TO CANCEL
—	

4. Input the telephone number of this forwarding station.

- ☐ If your machine is behind a PBX, add the access code before the number, unless this forwarding station is an extension connected to the same PBX as your machine.

Then press **Yes** .



See page 50 for how to dial.
Do not use the handset.

FORWARDI NG	SELECT —
No. 02 DEST. 0	
1. RTI PROG 2. RTI	YES TO END

5. Either:

- ☐ If you wish **all** incoming messages to be forwarded to this station:

Do not store any RTIs/CSIs for it.

Instead: **Yes**.

Then either go to step 2 to program another forwarding station,
or press **Function** to finish.

- ☐ If you only wish messages from certain senders to be forwarded to this station:

Input their RTIs or CSIs (messages from senders other than these will not be forwarded to this station):

Press **1**, then go to step 6.

FORWARDI NG	ENTER RTI / CSI
	NO TO CANCEL
<div style="background-color: black; height: 1.2em; width: 100%;"></div> ABC	

- ☐ View the RTIs/CSIs that you have stored so far: **2**. Go to step 9.

DEST 1 / 6 means that there are 6 RTIs/CSIs stored so far, and the first in the list is now displayed.

FORWARDI NG	NO TO CANCEL
No. 01	DEST. 1 / 6 CLR: CLR
XYZ. CO.	

- ☐ Finish storing RTIs/CSIs for this forwarding station and input another forwarding station number: **Yes**. Go to step 2.

- ☐ Finish: **Function**

6. Type in an RTI or CSI, then press **Yes**.

- ☐ You can input up to 30 RTIs/CSIs for each forwarding station.

FORWARDI NG
STORE AS W LD CARD? YES . NO
XYZ. CO.

7. Either:

- ☐ Store this RTI as a wild card: **Yes**

- ☐ Otherwise: **No**

FORWARDI NG	ENTER RTI / CSI
	NO TO CANCEL
<div style="background-color: black; height: 1.2em; width: 100%;"></div> ABC	

8. Either:

- ☐ Enter another RTI or CSI: Go to step 6.

- ☐ Finish: **No**. Go to step 5.


9. Scroll through the stored RTIs/CSIs on the screen with **↓**.

- ☐ To delete the displayed RTI/CSI: **Clear**

- ☐ When you have finished: **No**. Go to step 5.

Editing the Forwarding Feature

1. **Function** **6** **0** **2** **2** **2** **2**
7 **5**

FORWARDI NG	SET FORWARD. CODE
No. ████	PR I NT LI ST 
NO TO CANCEL	

2. Input the code number of the forwarding station that you wish to edit.

Then press **Yes** .

- ☐ See the Forwarding List for a list of these codes.

FORWARDI NG	YES OR CLR . NO
No. 01	
2125553456	

3. Either:

- ☐ Erase this forwarding station number and all RTIs/CSIs stored with it:
 Press **No** x 2, then **Yes** to erase.
 Go to step 2.

- ☐ Edit this forwarding station's telephone number.

If it is correct: **Yes**

DEST. 6 on the opposite display shows that there are 6 RTIs/CSIs programmed so far for this forwarding station.

FORWARDI NG	SELECT ████
No. 01 DEST. 6	
1. RTI PROG 2. RTI	YES TO END

4. Either:

- ☐ To add RTIs/CSIs to this number: **1**
 Go to step 6.


FORWARDI NG	
STORE AS W L D CARD? YES . NO	
XYZ. CO.	

- ☐ To view or delete RTIs/CSIs allocated to this number: **2** .
 Go to step 5.


DEST. 1 / 6 means that there are 6 RTIs/CSIs programmed so far for this forwarding station, and the first in the list is now displayed.

FORWARDI NG	NO TO CANCEL
No. 01 DEST. 1 / 6	CLR: CLR
XYZ. CO.	


- ☐ If you wish to view another forwarding station number: **Yes** .
 Go to step 2.

FORWARDI NG	SET FORWARD. CODE
No. ████	PR I NT LI ST 
NO TO CANCEL	

- ☐ Finish: **Function**

5. ☐  until the RTI/CSI that you wish to delete appears.


To delete the RTI/CSI: **Clear** , then go to step 4.

FORWARDI NG	SELECT	
No. 02 DEST. 0		
1. RTI PROG 2. RTI	YES	TO END

- ☐ It is not possible to edit an RTI/CSI; if you wish to do so, you must delete the incorrect label and store a new one.

Caution: If you delete all the RTIs and CSIs for a forwarding station, you must also delete the forwarding station (see step 3). **If you do not do this, all incoming messages will be forwarded to that station.**

6. Type in an RTI or CSI, then press **Yes** .

 Inputting labels: see page 7.

FORWARDI NG
STORE AS W L D CARD? YES . NO
XYZ. CO.

7. Either:
- ☐ Store this RTI as a wild card: **Yes**
 - ☐ Otherwise: **No**

8. Either
- ☐ Input another RTI/CSI for this forwarding station: go to step 6.
 - ☐ Finish working on this forwarding station: **No** . Go to step 4.
 - ☐ Finish: **Function**

Switching Forwarding On/Off




Before you use Forwarding, you have to switch it on using Function 81. If it is switched off, the machine will not forward any incoming fax messages.

After you switch Forwarding on, (FORWARDI NG) is displayed on the operation panel when the machine is in standby mode.

You can also program a User Function Key to switch Forwarding on/off (use Function 35, see page 163). If you have done that, just press that key whenever you wish to switch Forwarding on or off.


Note: Forwarding cannot be switched on if Memory Lock is switched on. If you wish to use Forwarding, you must switch Memory Lock off.

1. **Function** **6** **0** **2** **2** **2** **2** **8** **1**



2. Scroll through the list of features with and until FORWARDI NG appears.
3. Change the on/off setting by pressing or .
4. Finish: **Yes** **Function**


Enabling and Disabling the Forwarding Mark



The forwarding mark is printed at the receiving end on the top of each page of the fax messages that are forwarded from your machine. This mark will help the operator at the other end to recognize messages that have been forwarded. If you wish, you can switch this mark off.


To switch the Forwarding Mark on or off, do the following procedure. (See page 10 if you need more information about the User Parameter settings adjustment procedure).

1. **Function** **6** **0** **2** **2** **2** **2** **9** **1**



2. The settings for switch 00 are now shown on the bottom line of the display.

SWITCH00: 00000000

3. Press  until the settings for switch 01 are shown.


The setting that you need to change is digit 0.



SWITCH01: 

Digit 0

0: Forwarding Mark is Off


1: Forwarding Mark is On

4. If you wish to change the setting, press  .

5. Finish:  

Specified Cassette Selection (Optional Paper Feed Unit Required)

Overview



ADVANCED
FEATURES

This feature is only available if your machine has more than one cassette. Using this feature, you can direct fax messages from certain senders to be printed from a cassette of your choice.

Example:

Put yellow paper in one cassette. Then, messages from head office can be printed out on yellow paper; this will make it easy for you to see when a message from head office has arrived.

To direct messages from a particular sender to a special cassette:

- ☐ Program the RTI or CSI of the sender. (Ask the sending party what their RTI/CSI is. Or make a communication with that terminal, print a TCR, and read off the RTI/CSI.)

If the other party is using a machine made by another maker, they may not be familiar with the terms RTI or CSI. Explain that you are interested in the telephone number that they stored in the machine for identification purposes.

- ☐ Switch Specified Cassette Selection on.

If the RTI/CSI is not the same as any of those that you have programmed into this feature, the incoming message will be printed on paper from the normally-used cassette.

The number of RTI/CSI's that you can store for use with this feature is 10. You can use Wild Cards to extend the number of RTI/CSI's that you can specify.

Note: If one of the senders changes their RTI/CSI, you have to change the stored RTI/CSI also. Otherwise, messages from that sender will no longer be sent to the required cassette.

Cross-references

RTI and CSI: see page 25.
TCR: see page 185.

Wild Cards: see page 144.

Programming the Specified Cassette Selection Feature

1. **Function** **6** **0** **2** **2** **2** **2**

7 **6**

DEST. 6 on the opposite display shows that there are 6 RTIs/CSIs programmed so far. In a new machine, you will see DEST. 0.

- ☐ At this time, you can print a Specified Cassette Selection List by pressing **→** **Start** .

CST SELECT	SELECT	→
DEST. 6	PRI NT LI ST	→
1. RTI PROG 2. RTI	NO	TO CANCEL

2. Either:

- ☐ Store some RTIs/CSIs: **1** .
Go to step 3.

CST SELECT	ENTER RTI / CSI
	NO TO CANCEL
ABC	

- ☐ View the RTIs/CSIs that you have stored so far: **2** . Go to step 6.
DEST. 1 / 6 means that there are 6 RTIs/CSIs programmed so far, and the first in the list is now displayed.

CST SELECT	NO TO CANCEL
DEST. 1 / 6	CLR: CLR
XYZ. CO.	↓

3. Type in an RTI or CSI, then press **Yes** .



Label input and editing: see page 7.

CST SELECT	STORE AS W LD CARD?	YES	NO
XYZ. CO.			

4. Either:

- ☐ Store this RTI as a wild card: **Yes**
☐ Otherwise: **No**

CST SELECT	ENTER RTI / CSI
	NO TO CANCEL
ABC	

5. Either:
 - ☐ Enter another RTI or CSI: Go to step 3.
 - ☐ Finish: **No** . Go to step 2.
6. Scroll through the stored RTIs/CSIs on the screen with **↓** .
 - ☐ It is not possible to edit previously stored RTIs/CSIs; if you wish to do so, you must delete the incorrect label and store a new one.
 - ☐ To delete the displayed RTI/CSI: **Clear**
 - ☐ When you have finished: **No** . Go to step 2.

NOTE: Messages from senders that have RTI/CSIs that match those that were input using the above procedure will be printed using the first (upper) paper cassette.
 If there is no paper in the upper cassette, messages from the specified senders will be stored in the memory (substitute reception).
 If there is no paper in the lower cassette, messages from other senders will be stored in the memory.

Switching Specified Cassette Selection On/Off

Before you use this feature, you have to switch it on using Function 81.

1. **Function** **6** **0** **2** **2** **2** **2** **8** **1**

PSTN LINE TYPE	SELECT ← →
DP	TT ↑ ↓
	YES TO END

2. Scroll through the list of features with **↑** and **↓** until SPECIFIED CASSETTE SELECTION appears.
3. Change the on/off setting by pressing **←** or **→** .
4. Finish: **Yes** **Function**

Wild Cards

This feature greatly enhances the effectiveness of the following features:

- ☐ Authorized Reception
- ☐ Forwarding
- ☐ Specified Cassette Selection

In each of these features, you have to store the RTI or CSI of various terminals that you normally receive fax messages from. Then, when your machine detects an incoming call, it checks the RTI or CSI of the other terminal, and acts accordingly.

When you program RTIs for these features, you can program wild cards to greatly expand the number of terminals that you can receive from.

Example:

If you wish to accept messages from all 150 branches of XYZ Company (using Authorized Reception), print them on yellow paper (using Specified Cassette Selection), and forward them on to head office (using Forwarding), you don't have to store the RTI of each branch of XYZ Company. Program "XYZ" as a wild card for each of these functions. If the RTIs of all XYZ branches contain an "XYZ" somewhere in the RTI, messages coming in from them will be accepted, printed on yellow paper, and sent on to head office.

CAUTION

This feature cannot recognize spaces.

Example:

If you store MAN as a wild card, and a terminal with an RTI that includes MANCHESTER, HUMAN, or HUMANE calls you, your machine will recognize MAN as a wild card and accept and/or forward the message.

Cross-references


Authorized Reception: see page 132.

Forwarding: see page 134.

Specified Cassette Selection: see page 141.

RTI and CSI: see page 25.

Reverse Order Printing (Memory Card or Hard Disk Required)



Normally, the machine prints the pages of received messages in the order that they were received them.

However, with Reverse Order Printing, the machine will print the message from the last page first. This will make it easier to distribute the received fax messages, and more convenient for reading them.

Reverse Order Printing will not take place unless you switch it on beforehand.

To switch this feature on or off, do the following procedure. (See page 10 if you need more information about the User Parameter settings adjustment procedure).

1. **Function** **6** **0** **2** **2** **2** **2** **9** **1**

USER PARAMETER	PRI NT LI ST	→
DEFAULT:	01000000	↑
SW TCH00:	01000000	YES TO END ↓

ADVANCED
FEATURES

2. The settings for switch 00 are now shown on the bottom line of the display.

SWITCH00: 00000000

3. Press **↓** until the settings for switch 05 are shown.
The setting that you need to change is digit 1.

SWITCH05: 00000000


Digit 1
0: This feature is Off.
1: This feature is On.

4. If you wish to change the setting, press **1**.
5. Finish: **Yes** **Function**

Multi-sort Document Reception (Memory Card or Hard Disk Required)

Using this feature, more than one copy of each incoming fax message can be printed. This feature is useful if you need to reduce your photocopier's work load.

- ☐ You will only be able to print one copy if the Two in One feature is enabled. See page 151 for more about Two in One.



For example, if you switch this feature on overnight, you will not have to make distribution copies of the messages that came in during the night. However, the paper in the cassette will be used up much faster.

Cross-reference

Reverse Order Printing: see page 145.

Copying an Original: see page 181.

1. **Function** **6** **0** **2** **2** **2** **2** **7** **7**

MULTI COPY RX ENTER 1 - 9 COPY
ENTER # COPY: **1** COPY(S)
YES TO END

2. Input the number of copies that you need, then press **Yes** .
Copies of incoming faxes will be collated.

NOTE: Maximum number of copies: 9

To use Multi-sort Document Reception, you must switched Reverse Order Printing on. see page 145 for how to do this.

Center Mark



If you switch this feature on, a mark is printed halfway down each received page on the left hand side. This makes it easy for you to position the hole puncher correctly when you file away the received fax messages.

The center mark is not printed when you use the machine for making copies.

To switch this feature on, do the following. (See page 10 if you need more information about the User Parameter settings adjustment procedure).

1. **Function** **6** **0** **2** **2** **2** **2** **9** **1**

USER PARAMETER	PRI NT LI ST	→
DEFAULT:	01000000	↑
SW TCH00:	01000000	YES TO END ↓

2. The settings for switch 00 are now shown on the bottom line of the display.

SWITCH00: 00000000

3. Press **↓** until the settings for switch 01 are shown.
The setting that you need to change is digit 1.

SWITCH01: 00000000


Digit 1

0: The center mark will not be printed
1: The center mark will be printed

4. If you wish to change the setting, press **1**.

5. Finish: **Yes** **Function**

Checkered Mark



The machine prints a checkered mark in the top left corner of the first page of received messages. Using this mark, you can find the first page easily. This makes it easier for you to separate the messages that are lying in the copy tray.

To switch this feature on or off, do the following. (See page 10 if you need more information about the User Parameter settings adjustment procedure).

1. **Function** **6** **0** **2** **2** **2** **2** **9** **1**

USER PARAMETER	PRI NT LI ST	→
DEFAULT:	01000000	↑
SW TCH00:	01000000	YES TO END ↓

2. The settings for switch 00 are now shown on the bottom line of the display.

SWITCH00: 00000000

3. Press **↓** until the settings for switch 01 are shown.

The setting that you need to change is digit 4.

SWITCH01: 00000000

Digit 4
0: The checkered mark will not be printed.
1: The checkered mark will be printed.

4. If you wish to change the setting, press **4**.

5. Finish: **Yes** **Function**

Reception Time



When you receive a message, the time is printed at the top of the page. However, this is the time at the transmitting end. To check the local time, you have to print the TCR.

However, if you switch on Reception Time, the local time is also printed on each page that you receive. The time is taken from your machine's internal clock, and is the same as the time that will be printed on the TCR. Switch this feature on if you often receive fax messages from other countries.

Cross-references

TCR: see page 185.

Date and Time: see page 24.

To switch this feature on, do the following. (See page 10 if you need more information about the User Parameter settings adjustment procedure).

1. **Function** **6** **0** **2** **2** **2** **2** **9** **1**
2. The settings for switch 00 are now shown on the bottom line of the display.
3. Press **↓** until the settings for switch 01 are shown.
The setting that you need to change is digit 2.
4. If you wish to change the setting, press **2** .
5. Finish: **Yes** **Function**

USER PARAMETER

PRI NT LI ST

DEFAULT: 01000000

SW TCH00: 01000000

YES TO END

SWITCH00: 00000000

SWITCH01: 00000000

Digit 2
0: The reception time will not be printed.
1: The reception time will be printed.

ADVANCED
FEATURES

Note: If the message is in the memory for a while (for example confidential reception, memory lock or substitute reception), the printing time is printed at the top of the page.

Length Reduction

If the machine receives a page that is longer than the paper in the cassette, the machine reduces the length of the received image so that it will fit on one page, if the image length is within the following limits.


Paper size in the cassette	Maximum reducible incoming page length	
	Without Optional 400dpi Page Memory	With Optional 400dpi Page Memory
Letter (11")	14.4"	14.4"
Legal (14")	15.1"	15.1"

If the received image is longer than the above limits, there is no reduction and the image is split up and printed on two sheets of paper. Normally, the last 0.4 inch of the received image will be repeated at the beginning of the next page.

However, if you wish, the second page can continue from where the first page ended.

Contact your service representative if you require any adjustments to this feature.

Two in One



This feature helps you conserve paper. If the size of the incoming page is half the size of the paper in the cassette, the machine will print out two pages on one sheet of paper.

In the example shown above, somebody is sending your machine two sheets of half-letter sized paper and your machine is printing them out on one letter sized sheet.

- Note:**
- ☐ The effectiveness of this feature depends on the sizes of paper stocked in your machine's cassettes.
 - ☐ If your machine currently has two sizes of paper installed, the machine will try to print the incoming message on the smaller size.
 - ☐ If Two in One is switched on, you will not be able to print out more than one copy of an incoming fax message using Multi-sort Document Reception.

To switch this feature on, do the following. (See page 10 if you need more information about the User Parameter settings adjustment procedure).

1. **Function** **6** **0** **2** **2** **2** **2** **9** **1**

USER PARAMETER	PRI NT LI ST	→
DEFAULT:	01000000	↑
SW TCH00:	01000000	YES TO END ↓

2. The settings for switch 00 are now shown on the bottom line of the display.

SWITCH00: 00000000

3. Press **↓** until the settings for switch 05 are shown.
The setting that you need to change is digit 2.


SWITCH05: 00000000

Digit 2
0: Two in One is disabled.
1: Two in One is enabled.

4. If you wish to change the setting, press **2**.

5. Finish: **Yes** **Function**

Closed Network (Reception)



This feature may help you to prevent reception of excessive junk fax mail.

The ID Codes of the communicating machines are checked. If they are not the same, the communication is stopped.

Note: This feature may not be reliable if you are communicating with a terminal produced by a different manufacturer.

Cross-references

ID Codes: see page 85.


ID Transmission: see page 65.

OTHER

Polling

Overview

Polling means "picking up" a document that has been left for you at a remote fax terminal. You can also leave a document in your machine's memory for other machines to poll from you.



- ☐ With polling, telephone line costs are charged to the person receiving the message (the polling terminal).
- ☐ Polling can only be used when both machines have the Polling feature.

Polling Transmission

Use Polling Transmission when you wish to leave a document in the memory for others to pick up.

You cannot specify the telephone number of the polling terminal (the terminal that you wish to poll your document), but using the ID Code there are ways to make sure that the message does not go to the wrong place, as explained below.

There are three types of Polling Transmission.

Free Polling: Anybody can poll the message from the polled machine's memory.

Secured Polling: The message will only be sent out if the ID Code of the polling machine is the same as the ID Code stored in the polled machine.

Stored ID Override: There are two ways to use this feature:

- ☐ If your ID Code is different from that of the other terminal, you can use the other terminal's ID Code just for this transmission (ask the other terminal's operator what their ID Code is). Your machine's stored ID Code will be ignored.
- ☐ For extra security, both parties can specify an ID Code just for this communication. The ID Codes of both machines will be ignored. All communicating parties need to coordinate their ID Codes in this case.

Only one document can be stored in the memory for Free Polling, and only one can be stored for Secured Polling. However, with Stored ID Override, you can store more than one file, but you must use a different ID for each file.

Secured Polling and Stored ID Override can only be used between terminals produced by the same manufacturer.

Cross-reference

ID Code: see page 85.

Free Polling

1. Place your document in the feeder.

- ☐ If you only wish to scan a part of the document, use the Specified Image Area feature. See page 118 for details.

2. **Function** **1** **4**



See page 157 for the options that are available with Polling Transmission.

FREE POLLING	OPTI ONS
PRESS START	

3. **Start**

- ☐ Your fax message is stored and held on polling standby.

Note: If you see FILE EXISTS CLEAR? PRESS **YES** · **NO** , you already have a message on Free Polling Standby.

- ☐ To keep the old message: **No** . Remove the document from the feeder.
- ☐ To erase the old message: **Yes**

Secured Polling



1. Place your document in the feeder.

- ☐ If you only wish to scan a part of the document, use the Specified Image Area feature. See page 118 for details.

2. Either:

- ☐ **Function** **1** **3**

- ☐ If you have programmed one of the User Function Keys to activate this feature, press that key and go to step 3.

POLLING TRANS.	OPTI ONS
PRESS	START

NOTE

If you have not yet stored an ID Code using Function 61, you will be asked to enter an ID Code. Proceed in the same way as for step 4 in "Stored ID Override" on the next page.



See page 157 for the options that are available with polling.

3. **Start**

- ☐ Your fax message is stored and held on polling standby.

Note: If you see SAME ID FILE EXISTS CLEAR? PRESS **YES** · **NO** , you already have a message on Secured Polling Standby.

- ☐ To erase the old message: **Yes** . The old message is erased and your new one is stored.
- ☐ To keep the old message: **No** . Input an ID Code in the same way as for step 4 in "Stored ID Override" below.

Stored ID Override


This procedure will override the ID Code stored in your machine. The override is only effective for this one transmission.


1. Place your document in the feeder.

- ☐ If you only wish to scan a part of the document, use the Specified Image Area feature. See page 118 for details.


2. Either:

- ☐ **Function** **1** **3**

- ☐  If you have programmed one of the User Function Keys to activate this feature, press that key and go to step 3.


POLLING TRANS.	OPTI ONS 
PRESS	START

3.  **0** **6**

ID CODE	ENTER ID CODE
	NO TO END

4. Enter the ID code that you wish to use for this message.

Example: **2** **5** **6** **7** **Yes**

POLLING TRANS.	OPTI ONS 
PRESS	START

Note: If you see SAME ID FILE EXISTS CLEAR? PRESS **YES** · **NO** , you already have a message on Secured Polling Standby.

- ☐ To erase the old message: **Yes** . The old message is erased and your new one is stored.
- ☐ To keep the old message: **No** . Input another ID Code .

5. **Start**

- ☐ Your fax message is stored and held on polling standby.

NOTE: If you need to cancel a polling transmission operation, use Function 23 (see page 161).

Options for Polling Transmission

When you store a document in memory for Polling Transmission, you also have the following options:

- ☐ Auto Reduce On/Off: This is the same as for normal transmission (see page 63).
- ☐ TTI On/Off: This is the same as for normal transmission (see page 64).
- ☐ Polling Standby Duration: There are two options.
 - ONCE: The message will be automatically erased from memory after it has been polled once.
 - KEEP: The message will be kept in memory until you erase it yourself using Function 23; see page 161. While the message is in the memory, it can be polled at any time by as many terminals that need it.

The options are only available if the following can be seen in the top right corner of the display:

OPTI ONS 



1.   


OPTI ON	SELECT				TO END
AUTO REDUCE				OFF	
				TTI	


2. Scroll through the options using the  and  arrows of the scroll key.

The list of available options is as follows:

- ☐ Automatic Reduction
- ☐ TTI
- ☐ Polling Standby Duration (KEEP: The message is kept in memory until you erase it yourself, ONCE: The message is erased from memory after it has been polled once)

If you wish to switch something on or off, use the  and  arrows of the scroll key until the displayed setting is correct.

3.  when you have finished.

Polling Reception

Use this feature when you wish to poll a message from another terminal.

You can poll documents from many terminals with only one operation (use Groups and Keystroke Programs to make the most out of this feature).

You have three options: Free Polling, Secured Polling, and Stored ID Override, as described for Polling Transmission (see page 154).

The maximum number of terminals that you can poll in one operation is 200.

Cross-references

ID Code: see page 85.

Groups: see page 30.

Keystroke Programs: see page 99.

Operating Procedure

1. Either:

☐ **Function** **1** **5**

☐ If you have programmed one of the User Function Keys to activate this feature press that key and go to step 2.

2. Dial one or more numbers.

3. **Start**

POLLING RECV.	OPTI ONS
ENTER FAX NUMBER	
<div style="background-color: black; height: 15px; width: 100%;"></div>	




POLLING RECV.	OPTI ONS
ENTER NO. OR START	DEST: 2
<div style="background-color: black; height: 15px; width: 100%;"></div>	

Stored ID Override Option

This procedure overrides the ID Code that is stored in your machine. The override is effective for this operation only.




If OPTI ONS  is displayed:

1.   


I D CODE	ENTER I D CODE
	
	 TO END

2. Enter the password that you wish to use for this operation.

Example:     

POLL I NG RECV.	OPTI ONS 
ENTER NO. OR 	DEST: 2
	

3. Dial and press  .

 For how to use other options, such as Send Later for delayed polling, see page 59 and the pages following that.

NOTE: In theory, you can poll up to 200 different destinations using the above procedure. However, this number depends on how many numbers are currently waiting in memory to be dialed. See the table on page 43 for more information concerning the limitations to this feature.

ADVANCED
FEATURES

Continuous Polling Reception

If you wish to poll a number of destinations in a continuous cycle, switch this feature on. After the machine has polled all the specified destinations, it will start again from the first destination.

To switch on continuous polling reception, contact a service technician.

File Management

Every time you store a fax message in your machine's memory, a new file is created. Each file is given a number. To see which files are currently in the memory, print a File List.

Note: A new file is created for each Polling Transmission, Substitute Reception, and Confidential Reception also.

Cross-reference

File List: see page 191.

File Retention Time and File Retransmission



Normally, a fax message is erased from the machine's memory after it has been transmitted successfully. However, this machine has a setting known as the File Retention Time, which allows you to keep transmitted fax messages in the memory for a while longer.

You can select the File Retention Time, or switch File Retention off, using Function 81.

1. **Function** **6** **0** **2** **2** **2** **2** **8** **1**

PSTN LINE TYPE	SELECT	←	→
DP	TT	↑	↓
	YES	TO END	

2. Scroll through the list of features with **↑** and **↓** until FILE RETENTION TIME appears.
3. Change the setting by pressing **←** or **→** .
☐ You can select 24 hrs, 72 hrs, or Off.
4. Finish: **Yes** **Function**

File Retransmission

This feature allows you to transmit a fax message again, as long as the File Retention Time has not yet expired. Use this feature when you wish to retransmit a fax message that is still stored in a file in the memory. Note that you cannot change, add, or delete any destinations, and you cannot alter the Send Later time.

1. **Function** **2** **4**

RETRANSMIT FILE	SCROLL	↓
FILE NO. : XXXXXXXXXX	PRINT LIST	→
LAST FILE : 0015	NO TO CANCEL	

2. Either:

- ☐ Print a list of files: **→** **Start**
- ☐ Scroll through the files on the display: **↓** until the required file appears.
- ☐ If you know the file number, input it directly: **0** **0** **0** **2**

RETRANSMIT FILE	SCROLL ↑ ↓
NO. 0002	STANDBY PRESS YES
XYZ COMPANY NEWYORK	

The second line of the display shows the current status of the file.

STANDBY: The file is waiting to be transmitted.

IN USE: The file is currently being transmitted.

3. **Yes**

RETRANSMIT FILE	
NO. 0002	
RESEND FILE?	YES . NO

4. Retransmit the displayed file number: **Yes**

RETRANSMIT FILE	
NO. 0002	
READY TO TRANSMIT	

The message will be retransmitted as soon as the machine is free.

Erasing a File from Memory

You can delete any of the memory files (except Confidential Reception files). This is useful if the memory is getting full and you need to make some space for an important job.

☐ You cannot erase files that were received using Confidential Reception.

1. ☐ Fax message file (Memory Transmission):
 - ☐ Instruction file (Polling Reception):
 - ☐ Fax message file (Polling Transmission):
- (Example: Using Function 21)

Function	2	1
Function	2	2
Function	2	3

CLEAR TRANS. FILE	SCROLL ↓
FILE NO. : 0002	PRINT LIST →
LAST FILE : 0015	NO TO CANCEL

2. Either:

- ☐ Print a list of files: **→** **Start**
- ☐ Scroll through the files on the display: **↓** until the required file appears.
Then press **Yes**.
- ☐ If you know the file number, input it directly: **0** **0** **0** **2** **Yes**

CLEAR TRANS. FILE	
NO. 0002	
CLEAR FILE?	YES . NO

3. Either:

- ☐ Erase the file: **Yes**
- ☐ Keep the file: **No** . Go to step 2.

Printing a File

If you need to see the contents of any of the files, use this feature.

☐ It does not work for Confidential Reception files.

1. ☐ Fax message file (Memory Transmission):

Function **5** **1**

☐ Fax message file (Polling Transmission):

Function **5** **2**

(Example: Using Function 51)

PRI NT TRANS. FI LE	SCROLL	↓
FI LE NO. : 	PRI NT LI ST	→
LAST FI LE : 0015	NO	TO CANCEL

2. Either:

- ☐ Print a list of files: → **Start**
- ☐ Scroll through the files on the display: ↓ until the required file appears.
Then press **Yes** .
- ☐ If you know the file number, input it directly: **0** **0** **0** **2** **Yes**

PRI NT TRANS. FI LE
NO. 0002 NO TO CANCEL
PRESS START

3. **Start**


Note: If you do not have the 40MB Hard Disk Option, files in memory are erased when the power is turned off for more than an hour.

User Function Keys

There are five Function keys (F1 to F5) on the operation panel.

You can program each of these keys with a feature that you wish to use frequently. There are two ways to do this.

- ☐ Store a User Function Code in the User Function Key.
- ☐ Store a Function Program in the User Function Key.



User Function Codes

You can program each of the User Function Keys with one of the following functions. In a new machine, the User Function Keys F1 to F4 have already been programmed, as shown in the table below in boldface.

Code	Function	Code	Function
01	Use the Direct Fax Number Entry feature. [F1]	11	Print the TCR [F3]
02	Dial a group	12	Print a File List
03	Input a Personal Code [F4]	13	Switch Memory Storage Report On/Off
04	Use Economy Transmission [F2]	14	Switch Forwarding On/Off *
05	Switch TTI On or Off	15	Send Tonal Signals
06	Do a Confidential Transmission	16	Input a Subaddress (G4 mode only) **
07	Print a received confidential message*	17	Not used
08	Do a Transfer Request	18	Use Secure Transmission
09	Do a Polling Reception	19	Batch Transmission
10	Polling Transmission: Use Secured Polling or Stored ID Override	20	Specified Image Area Setup

*: Memory Card or Hard Disk required

** : ISDN G4 Kit required

To store a User Function Code, do the following procedure.

1. **Function** **3** **5**

USER FUNCTI ON	PRESS F1 TO F5
F <input type="text"/>	PRI NT LI ST <input type="button" value="→"/>
<input type="button" value="NO"/>	TO CANCEL

- ☐ At this time, you can print a User Function List if you press **Start** .

2. Press one of the User Function Keys.

Example : Press **F4** **Yes** .

If this key is already used, the currently stored code is displayed. Either:

- ☐ Press **Yes** to keep it as it is.
- ☐ Press **No** to erase the old code.

USER FUNCTI ON	ENTER CODE
F 4 CODE: <input type="text"/>	<input type="button" value="NO"/>
	TO CANCEL

3. Enter the two-digit code for the function that you wish to store.

Example: Group Dial, press **0** **2** .

USER FUNCTI ON	<input type="button" value="YES"/> OR <input type="button" value="NO"/>
F 4 CODE: 02	
GROUP	

4. **Yes**

USER FUNCTI ON	PRESS F1 TO F5
F <input type="text"/>	PRI NT LI ST <input type="button" value="→"/>
<input type="button" value="NO"/>	TO CANCEL

5. Either:

- ☐ Program another key: Go to step 2.
- ☐ Finish: **Function**

Function Programs

If the feature that you wish to store as a User Function Key does not have a User Function Code, you can store it as a Function Program.

Example:

If you often use Function 32 (Programming Speed Dial), store it as a Function Program in one of the User Function Keys. Then, when you want to store a Speed Dial, just press that User Function Key instead of pressing Function, 3, 2, and Yes.

Storing a Function Program

For example, store Function 32 (Programming Speed Dial) into Function Key F4.

1. **Function** **3** **2**

SPEED DI AL	ENTER SPEED CODE
<input checked="" type="checkbox"/> <input type="text"/>	PRI NT LI ST <input type="button" value="→"/>
<input type="button" value="NO"/>	TO CANCEL

2. **F4**

- ☐ If you cannot select this Function Key, it is already being used for something. Select another Function Key.

PROGRAM? YES OR NO

3. **Yes** **Function**Using a Function Program1. **F4**

SPEED DI AL	ENTER SPEED CODE
<input checked="" type="checkbox"/> —	PRI NT LI ST →
	NO TO CANCEL

2. Use the function as normal.

Deleting a Function Program1. **Function** **3** **5**

USER FUNCTI ON	PRESS F1 TO F5
F —	PRI NT LI ST →
	NO TO CANCEL

2. Press the key that you wish to erase.

Example: **F4**

USER FUNCTI ON	YES OR NO
F 4 CODE:	
FUNCTI ON PROGRAMMED	

3. **Yes** **No** **Function**

OMR Sheets

Introduction

Instead of inputting instructions at the operation panel, you can mark up a special form, called an OMR Sheet (OMR means Optical Mark Reader), and scan your instructions into the machine. Your fax machine will read the marks on the form and carry out your instructions. Your machine can accept five types of OMR Sheets.

- ☐ User Parameter Program Sheet - use this to change the user parameter settings
- ☐ Quick/Speed Dial Program Sheet - use this to store a number as a Quick Dial or Speed Dial
- ☐ Group Program Sheet - use this to store numbers into a Group
- ☐ Transmission Program Sheet - use this to transmit a fax message
- ☐ Transfer Request Program Sheet - use this to make a Transfer Request

This section of the manual first describes the OMR Sheets and how to use them, and finally gives the procedures that you need to use an OMR Sheet.

Using an OMR Sheet

The general procedure for using an OMR Sheet is as follows.

1. Print the OMR Sheet that you need, using Function 54 (see page 174).
2. Mark your instructions on the sheet. This will be explained in the following pages.
3. Place the OMR Sheet into the feeder, then press **Start** then **Yes** .

When you are using an OMR Sheet to send a fax message or make a transfer request, the OMR Sheet must be the first page that is scanned.

CAUTION:

- ☐ OMR Sheets should not be used more than 3 times. If they get dirty, incorrect data may be scanned.
- ☐ Do not try to correct mistakes on an OMR sheet with an opaque white correcting fluid.
- ☐ OMR Sheets must be marked with a felt tip or ball point pen as shown on page 167 and subsequent pages.
- ☐ Store OMR Sheets in a cool dry place in an airtight bag.
- ☐ Do not use cut off portions of OMR Sheets, photocopies of OMR Sheets, or OMR Sheets with paper or adhesive tape attached to them.

Completing an OMR Sheet


Each OMR Sheet contains a number of boxes or fields.

- ☐ Boxes are for marking user parameter settings, the contrast setting, and so on.
- ☐ Fields are for inputting telephone numbers and names.

Marking Up Boxes

The correct way to mark up a box is shown below. Make sure that you follow this rule, or you may get some strange results when you scan the OMR Sheet.


Note: Use a black felt tip or ball point pen. Do not use a pencil.



If you need to mark up a consecutive row of boxes, observe the following rules.

- ☐ Each individual box must be completely filled.
- ☐ Do not leave a box only partly filled.
- ☐ Gaps between boxes must be kept clear.

See below for examples of correct and incorrect marking of a row of boxes.



Marking Up Fields


There are two types of field.

- ☐ **Number Fields:** These are for inputting telephone numbers, personal codes, the number of pages in the fax message (Page Count), and the transmission start time (when using Send Later or TRD).
- ☐ **Name Fields:** These are for any names and labels that you need to input.

Number Fields

Each digit in a number field consists of a 3 x 3 rectangular array of dots. You can only write down the characters shown in the following diagram.

Caution: You must write each character exactly as shown below, clearly, carefully, and unambiguously. Otherwise, the machine may store the wrong data or dial the wrong telephone number. The machine cannot always detect errors in the data.



- Note:**
- ☐ If you wish to send Tonal Signals after a telephone number, use ' • ' to indicate the start of the tonal signal. See page 115 for more details on Tonal Signals.
 - ☐ If you wish to input a pause in the telephone number, use a ' - ' to indicate a pause.


Name Fields

In a name field, each letter, symbol, or punctuation mark is represented by two digits. The characters that you can use with this machine are shown below, with the character codes for each one.

Code	Character	Code	Character	Code	Character	Code	Character
20	Space	30	0	40	@	50	P
21	!	31	1	41	A	51	Q
22	"	32	2	42	B	52	R
23	#	33	3	43	C	53	S
24	\$	34	4	44	D	54	T
25	%	35	5	45	E	55	U
26	&	36	6	46	F	56	V
27	'	37	7	47	G	57	W
28	(38	8	48	H	58	X
29)	39	9	49	I	59	Y
2A	*	3A	:	4A	J	5A	Z
2B	+	3B	;	4B	K	5B	[
2C	,	3C	<	4C	L	5C	¥
2D	-	3D	=	4D	M	5D]
2E	.	3E	>	4E	N	5E	^
2F	/	3F	?	4F	O	5F	_

For example: SMITH

S = code 53, M = code 4D, I = code 49, T = code 54, and H = code 48



Note: The method of writing digits 0 to 9 and letters A to F is the same as explained above for Number Fields. However, if you wish to input a ' * ', ' # ', ' • ', or ' - ' into a Name Field, do not use the method described in the explanation of Number Fields on the previous page; input the two-digit code from the above table.

The Five Types of OMR Sheets

This section describes each of the five types of OMR Sheet and how to mark them. (Using Function 54, print a sample of each OMR Sheet for your reference while you are studying this section.)

❑ Procedures for use are on page 174 and the pages following that.

User Parameter Program Sheet

You can use this sheet to change the settings of the User Parameters. Each parameter is listed, along with each possible setting.

❑ An asterisk next to a setting indicates that this is the factory setting.

❑ To see the current settings, print the User Parameter List (Function 91, page 193).

To use the User Parameter Program Sheet, mark each setting that you wish to make. For example, to switch Restricted Access on, first look for Restricted Access on the sheet, then black out the box above "ON".

	<input checked="" type="checkbox"/>	<input type="checkbox"/>
<u>Restricted access</u>	ON	OFF

You might find this sheet more easy to understand than the eight-digit User Parameter Switches described on page 10 and the pages following that.

Quick/Speed Dial Program Sheet

You can use this sheet to program Quick Dial and Speed Dial numbers. However, you can only program one telephone number with each OMR Sheet.

1. At the top of the sheet, mark up either QUICK or SPEED.
2. Mark up the Quick or Speed Dial number that you wish to store. You must mark a Hundreds Digit, a Tens Digit, and a Units Digit.
Example: To program Speed Dial Code 25, mark up the first few lines of the OMR Sheet as follows.

Quick/Speed Dial Program Sheet											
<input type="checkbox"/>	<input checked="" type="checkbox"/>										
Quick	Speed										
		<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Hundreds Digit		0	1	2	3	4	5	6	7	8	9
		<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Tens Digit		0	1	2	3	4	5	6	7	8	9
		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Units Digit		0	1	2	3	4	5	6	7	8	9

CAUTION: If you mark a Quick or Speed Dial that already contains a number, the machine will replace the old number without giving you any warning.

3. In the "FAX No." field, write the telephone number that you wish to store in the Quick/Speed Dial number that you just marked in steps 1 and 2.
 - ☐ See "Number Fields" on page 168 for how to do this.
4. In the "FAX label" field, write the name that you wish to store with this telephone number.
 - ☐ See "Name Fields" on page 169 for how to do this.
5. For Label Insertion, mark either the ON or the OFF box.

Group Program Sheet

You can use this sheet to program Groups. You can program one Group with each OMR Sheet. However, using this method, you can only store one full telephone number in the Group; the others must all be Speed Dials or Quick Dials. If you wish to store more full numbers in the Group, store them with Function 33 (see page 38) after you have scanned the OMR Sheet.

1. At the top of the sheet, mark the Group number that you wish to program.

CAUTION: If you mark a Group number that already contains fax numbers, the machine will replace the old numbers without giving you any warning.

2. In the "Group Label" field, write in a name for the Group.
 - ☐ See "Name Fields" on page 169 for how to do this.
3. If you wish to include a full telephone number in the Group, write it in the "FAX No." field.
 - ☐ See "Number Fields" on page 168 for how to do this.

Continued on the next page.

4. Mark up the Quick and Speed Dials that you wish to place in this Group. Each Quick and Speed Dial has one box above it.

Example: Store Quick Dials 01, 02, 06, 10, and 27, and Speed Dials 00, 01, 05, 16, 24, and 39 into the Group.

Quick																			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
0	0	0	0	0	0	0	0	1	1	1	1	1	1	1	1	2	2	2	2
1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
4	4	4	4	4	4	4	4	5	5	5	5	5	5	5	5	6	6	6	6
1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9	0
Speed																			
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
0	0	0	0	0	0	0	0	1	1	1	1	1	1	1	1	2	2	2	2
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
4	4	4	4	4	4	4	4	5	5	5	5	5	5	5	5	6	6	6	6
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
8	8	8	8	8	8	8	8	9	9	9	9	9	9	9	9	9	9	9	9
0	1	2	3	4	5	6	7	8	9	0	1	2	3	4	5	6	7	8	9

Transmission Program Sheet

You can use this sheet to send a fax message. Using this sheet, you can send your fax message to more than one destination, and you can select a range of transmission options. However, you can only dial one full telephone number; all the others must be Quick Dials, Speed Dials, or Groups.

1. At the top of the sheet, next to Trans. Mode, mark up either the box above "Memory" or the box above "Immediate".
2. Mark up the required contrast, resolution, and halftone type. Also, indicate whether the marker should be ON or OFF, and whether your transmission is in Group 3 or Group 4 mode.
3. If you wish to input one of the destinations as a full telephone number, write it down in the "Address (Fax No.)" field.
☐ See "Number Fields" on page 168 for how to do this.
4. Mark each Quick Dial, Speed Dial, and Group that you wish to be the destinations for this fax message.
 For example, if you wish to use Quick Dial 01 as a destination, mark the box above 01 in the "Address (Quick Dial)" area.
5. If you wish to use Send Later (shown as DIAL AT on the OMR sheet), TRD, Personal Code, or Page Count, fill the appropriate fields.
☐ See "Number Fields" on page 168 for how to do this.

6. Mark either the ON or the OFF box for Voice Request, Economy Transmission, Secure Transmission, Auto Reduction, TTI, and ID Transmission.

Transfer Request Program Sheet

You can use this sheet when you make a Transfer Request.

1. At the top of the sheet, next to Trans. Mode, mark up either the box above "Memory" or the box above "Immediate".
2. Mark up the required contrast, resolution, and halftone type. Also, indicate whether the marker should be ON or OFF, and whether your transmission is in Group 3 or Group 4 mode.
3. Input the number of the Transfer Broadcasting Station. To do this, either:
 - ☐ Write the full telephone number of the Transfer Broadcasting Station in the "Transfer Station (Full No.)" field. See "Number Fields" on page 168 for how to write numbers on OMR Sheets.
 - ☐ Mark one of the Quick Dials in the "Transfer Station (Quick Dial)" row of boxes.
 - ☐ Mark one of the Speed Dials in the "Transfer Station (Speed Dial)" row of boxes.

NOTE: You can only enter one Transfer Broadcasting Station on the OMR Sheet.
Refer to page 87 and the pages following for all conditions required to perform a Transfer Request.

4. Mark the end receivers.
 - ☐ You must mark the end receivers as Speed Dials, Quick Dials, and Groups that are stored in the Transfer Broadcasting Station. Do not input any of your own stored Quick Dials, Speed Dials, or Groups here.
 - ☐ Confer with the operator of the Transfer Broadcasting Station if you need their latest list of stored telephone numbers.



Example: If one of the end receivers is stored in the Transfer Broadcasting Station as Speed Dial 10, mark the box above 10 in the "Receiver (Speed Dials in Transfer Station)" area.

Procedures


To Print an OMR Sheet

Note: You must have Letter, Legal, or A4-size paper in the cassette before you print an OMR Sheet.

1. **Function** **5** **4**

OMR SHEET
CODE: [REDACTED]
☐ NO TO CANCEL SCROLL  

2. Select the OMR Sheet that you wish to print.

- ❑ Use the  key to scroll through the possible selections until the correct one is displayed on the screen.

OMR SHEET NO TO CANCEL

CODE: 1 USER PARAMETER ↑


PRESS START ↓

- 3.
- Start**

Using an OMR Sheet to Send a Fax Message

After marking up the OMR Sheet, do the following:

1. Make sure that the machine is in standby mode (see page 49).
2. Place the OMR sheet face up at the top of your fax message and put everything into the feeder face down.

MEMORY TRANS	OPTI ONS	
ENTER FAX NUMBER		
<div style="background-color: black; height: 20px;"></div>		

Note: The OMR Sheet must be the page that is scanned first.

- 3.
- Start**

<h2 style="margin: 0;">SCAN PROGRAM SHEET</h2>	
<input type="checkbox"/> YES	OR <input type="checkbox"/> NO

4. **Yes**

The machine scans the OMR Sheet, then scans and sends the fax message in accordance with the instructions on the OMR Sheet. Then, the machine returns to standby mode.

Using an OMR Sheet to Program the Machine

After marking up the OMR Sheet, do the following.

1. Place the OMR Sheet in the feeder face down.

MEMORY TRANS.	OPTI ONS	↓
ENTER FAX NUMBER		

2. **Start**

SCAN PROGRAM SHEET		
<input type="checkbox"/> YES	OR	<input type="checkbox"/> NO

3. **Yes**

The machine scans the OMR Sheet and programs itself in accordance with the instructions marked on the OMR Sheet. Then it returns to standby mode.

Errors

If the machine finds an error, it stops scanning the OMR Sheet and displays an error message that shows you where the problem is. No data is stored and no fax message is sent. Correct the error and scan the OMR Sheet again.


Power Saver



Overview

Laser printing requires the application of heat to bond toner to the printer paper. For incoming messages to be output quickly, a heating element inside the machine must be kept hot. This may cause your electricity bills to rise.

The Power Saver feature lets you program timers to switch this heating element on and off. This will help you to reduce overnight electricity costs. It also means that anyone wandering through the office after working hours will not be able to casually read your incoming fax messages, because incoming messages are not printed while the heating element is switched off.



- ☐ If a fax message comes in while the heating element is switched off, the message is stored in the memory. When the heating element switches back on, the message is automatically printed.
- ☐ While the heating element is disabled, all incoming calls are refused when the memory fills up.
- ☐ If you wish to print a fax message while the heating element is off, you can temporarily override the timer and print the message. The timer will activate again automatically a few minutes after you have printed your message.

As a typical example, you could program the heating element inside the printer to stay off at night and over the weekend. (You can program different settings for every day of the week.)

To use Power Saver, you must:

- ☐ Program the timers for each day of the week.
- ☐ Switch the Power Saver feature on.

Programming Procedure

Example: For Tuesday, set the heater to switch on at 9 am and switch off at 6 pm.

1. **Function** **6** **0** **2** **2** **2** **2**

7 **4** **Yes**

POWER SAVER	DAY OF WK.	↑ ↓
(SUN)	ON = 12:00AM	ON = 12:00AM
		← → YES TO END

2. Use the ↑ and ↓ keys to scroll through the days of the week.

Example: Press ↓ twice to go to Tuesday.

POWER SAVER	DAY OF WK.	↑ ↓
(TUE)	ON = 12:00AM	ON = 12:00AM
		← → YES TO END

3. Program the first timer for Tuesday:

- ☐ Both timers for each day have an ON/OFF setting. "ON" means that the heater will switch on at the time indicated. "OFF" means that the heater will switch off at the time indicated. To change the ON to OFF, or the other way round, press * .
When the ON/OFF display is correct: →

POWER SAVER	DAY OF WK.	↑ ↓
(TUE)	ON = 12:00AM	ON = 12:00AM
		← → YES TO END

- ☐ Input the time: **0** **9** **0** **0**

Repeat step 3 for the second timer.

- ☐ Input **0** **6** **0** **0** for the timer value .

To change AM to PM and the other way around, press # .

POWER SAVER	DAY OF WK.	↑ ↓
(TUE)	ON = 09:00AM	OFF = 06:00 PM
		← → YES TO END

KEEPING THE HEATER ON ALL DAY: Set both timers to ON = 12:00AM.
KEEPING THE HEATER OFF ALL DAY: Set both timers to OFF = 12:00AM.

4. Either:

- ☐ Program the timer for another day: Go back to step 2.
☐ Finish: **Yes** **Function**

NOTE: To print the received messages while the heater is off, press any key. After all the messages have been printed, the heater will stay on for 5 minutes before switching off again. Because of this, the Power Saver does not give you complete security for received documents. For this type of security, use the Memory Lock feature; see page 129.

Switching the Power Saver On or Off

The Power Saver feature must be switched on using Function 81. If it is switched off, the heating elements will stay on all the time.

1. **Function** **6** **0** **2** **2** **2** **2** **8** **1**

PSTN LI NE TYPE	SELECT	←	→
DP	TT	↑	↓
	YES	TO END	

2. Scroll through the list of features with **↑** and **↓** until POWER SAVER appears.
3. Change the on/off setting by pressing **←** or **→** .
4. Finish: **Yes** **Function**

Counters

These counters will help you if you wish to keep a regular check on how many pages your machine has sent, received, and copied.

The machine has the following counters:

- ☐ **Tx (Transmit) Counter:** The number of pages that your machine has sent
- ☐ **Rx (Receive) Counter:** The number of pages that your machine has received
- ☐ **Scan Counter:** The number of pages that your machine has scanned (includes copy mode)
- ☐ **Print Counter:** The number of pages that your machine has printed (includes copy mode and report/list printing)

1. **Function** **6** **0** **2** **2** **2** **2** **9** **5**

COUNTERS		YES TO END
TX: 003256	SCN: 003287	
RX: 002648	PRT: 002703	

2. When you have finished: **Yes**

Communication Result Display

You can call up an on-screen display of the results of the previous few communications. This is useful if you wish to know whether your transmission was successful, but do not wish to print a TCR.


Cross-reference	TCR: see page 185.
-----------------	--------------------

1. **Function** **4** **1** **→**

PERS. CODE 7346	NO TO CANCEL
OCT. 10 08:23 AM RX OK 10 PAGES	↑
2125551234	↓

2. Scroll through the past communications on the screen using **↑** and **↓** .
- ☐ To print the TCR: **No** **Start** .

Entering PC Printer Mode (Printer Interface Required)



Using PC Printer Mode, you can connect your fax machine to an IBM or compatible personal computer and use it as a printer. Documents printed from your computer will be sent to your fax machine as text (ASCII characters) or graphics (vector or dot image), depending on the application that you are using. They will not be sent in the same way as fax messages, which are always dot images.

You must obtain the optional Printer Interface Type 90 and the optional Paper Feed Unit before you can use PC Printer Mode. Then, you must do the following procedure if you wish to enter printer mode. For full details about the printer interface kit, see the operation manual for the printer interface kit.

1. **Function** **3** **7**

SET PRINTER MODE **YES** TO END

READY: P3 / P/ Si

You can now operate the printer.

Selecting the Paper Feed Cassette for Printer Mode (Printer Interface and Paper Feed Unit Required)

Use the following procedure to select which cassette the machine will use for printouts from your computer.

1. **Function** **6** **0** **2** **2** **2** **2** **8** **1**

then press **↓** until the screen appears as shown on the right.

CASSETTE FOR PRINTER SELECT **←** **→**

1ST 2ND 3RD 4TH 5TH **↑**

YES TO END **↓**

2. Use the **←** and **→** arrows on the scroll key to select the cassette that you would like to use for printer outputs.
3. To store your setting: **Yes**

Copying

If you need to make a copy of something, and there is no copier available, use your fax machine. Just place your original in the feeder, and press the Copy key.

Copying an original is a good way to test contrast and resolution before sending a document, if you are not sure that the settings that you have chosen are appropriate. The copy made by your printer shows you how the message would look when received at the other end. If it does not look good, change the settings and try again.



Cross-references

Contrast, Resolution, and Halftone: see page 54.

1. Press **Copy** .

COPY MODE	NO. OF COPIES:	1
SET DOCUMENT		
PAPER	8.5x11	8.5x14 ← →

Note: To cancel copy mode, press Copy again.

2. Use the  and  arrows on the scroll key to select the required copy paper size. The number of choices that you have depends on how many paper feed units you have installed.

Example: Press 

COPY MODE	NO. OF COPIES:	1
SET DOCUMENT		
PAPER	8.5x11	8.5x14 ← →

3. Place your original in the feeder.

COPY MODE	NO. OF COPIES:	1
PRESS START		
PAPER	8.5x11	8.5x14 ← →

4. Input the number of copies that you need.

Example: 3 copies, press **3** .

NOTE: Maximum number of copies: 99

COPY MODE	NO. OF COPIES:	3
PRESS START		
PAPER	8.5x11	8.5x14 ← →

5. **Start**

Note:

- ☐ If you make a single copy, the original will be reproduced at 400 x 400 dpi, even if the 400 dpi memory option has not been installed.
- ☐ If you wish to prevent the machine from being used as a copier, call your service representative. If Copying has been disabled, you will see COPY MODE IS NOT AVAILABLE if you press **Copy**.

Dual Access

Dual Access means that even if the machine is already carrying out a task, you may be able to operate the machine.

For instance, if your machine is currently receiving a long fax message, but you want to send a message and go back to your desk without having to wait by the machine, you can place your message in the feeder, select the required transmission features (such as Confidential Transmission), dial the number, and press Start. Your message will be scanned and stored to memory while the machine is still receiving. This means that you can take your fax back to your desk before it is actually sent. However, to be sure whether your transmission was successful or not, keep an eye open for Error Reports (or check the TCR).

The following table shows which features can operate simultaneously on your machine.

	Job that you wish to carry out at the same time								
	1.	2.	3.	4.	5.	6.	7.	8.	9.
Job Currently in Progress									
1. Storing to Memory		✓	✗	✓	✗	✓	✓	✓	✗
2. Printing from Memory	✓		✗	✗	✓	✓	✗	✓	✗
3. Copying	✗	✗		✗	✗	✓	✗	✓	✗
4. Printing an Automatic Report	✓	✗	✗		✓	✓	✗	✓	✗
5. Immediate Transmission	✗	✓	✗	✗		✗	✗	✗	✗
6. Memory Transmission	✓	✓	✓	✓	✗		✗	✗	✓
7. Receiving and Printing a Fax	✓	✗	✗	✗	✗	✗		✗	✗
8. Receiving a Fax to Memory	✓	✓	✓	✓	✗	✗	✗		✓
9. Printing a Fax Message or a Report Manually	✗	✗	✗	✗	✗	✓	✗	✓	

✓: Possible, ✗: Impossible

Inch-to-millimeter Conversion


This machine is designed for use on digital data networks using Group 4. As a result, the hardware of this machine is set up to scan on a dot-per-inch basis. However, Group 3 fax machines are set up to scan and print on a dot-per-millimeter basis. This means that, if a dot-per-inch based machine like this one transmits to a dot-per-millimeter based machine, the data will be distorted slightly as it is printed at the other end (the data is shortened by about 1% across the page and expanded by about 1% down the page).

If you wish, you may ask a service technician to switch this conversion on or off. If you switch it on, the machine will correct for the distortion.

RDS (Remote Diagnostic System)



Overview



If your machine has a problem, a service technician can perform various diagnostic tasks over the telephone line from the service station to try to find out what is wrong with your machine. The service technician can also use RDS to change some of your machine's settings if you request it.

For RDS to work, you must switch it on before the service technician starts the RDS operation on your machine.

For some RDS operations, it may be necessary to you to stay near the machine.

ADVANCED
FEATURES

Switching RDS On/Off

Before your machine can accept incoming calls from an RDS, you have to switch RDS on using Function 81. If it is switched off, the machine will not accept treatment from an RDS.

1. **Function** **6** **0** **2** **2** **2** **2** **8** **1**

PSTN LI NE TYPE	SELECT	←	→
DP	TT	↑	↓
	YES	TO END	

2. Scroll through the list of features with **↑** and **↓** until RDS appears.
3. Change the on/off setting by pressing **←** or **→**.
4. Finish: **Yes** **Function**

Short Preamble

Short Preamble slightly reduces communication costs between machines produced by the same manufacturer. This feature reduces the length of signals exchanged between the machines during communication.

If you are interested in this feature, contact a service technician to have it switched on.

Note: Short Preamble may cause problems with long distance and international calls. If you suspect that such problems are occurring, store the number as a Quick Dial or Speed Dial. Then call a service technician and discuss the matter. Tell the technician the Speed Dial/Quick Dial that you stored the telephone number in.

Cross-references

Quick Dial and Speed Dial: see page 29.

AI Short Protocol

This feature employs Artificial Intelligence (AI) to learn the communication characteristics of the machines programmed as Speed Dials or Quick Dials. AI Short Protocol helps you to reduce communication costs between machines produced by the same manufacturer. AI Short Protocol only works if you dial using Quick Dial, Speed Dial, or AI Redial; also, the machine at the other end must have the AI Short Protocol feature.

When you send a fax message, the two machines carry out a handshaking procedure, during which they establish the best way to communicate with each other. Using AI Short Protocol, this handshaking procedure only takes place in full the first time you dial a particular number. Your machine remembers the optimum communication parameters for calling that number. The next time you dial that number, the machine will remember these parameters and the preliminary handshaking will be significantly reduced, saving communication costs.

If you are interested in this feature, contact a service technician to have it switched on.

Note: AI Short Protocol may cause problems with long distance and international calls. If you suspect that such problems are occurring, store the number as a Quick Dial or Speed Dial. Then call a service technician and discuss the matter. Tell the technician the Speed Dial/Quick Dial that you stored the telephone number in.

Cross-references

Quick Dial and Speed Dial: see page 29.

REPORTS

AUTOMATICALLY PRINTED REPORTS

The following reports are automatically printed out at the appropriate time.

Descriptions of the Available Reports

TCR (Transmission Confirmation Report)



This report gives detail on each communication made by your terminal. It is automatically output after a certain number of communications.

Transmission Result Report



This report is printed out after every transmission. It shows whether each transmission was successful or not. If you have switched this report off, a Communication Failure Report will be printed when a communication fails.

Error Report

This report is printed after each unsuccessful communication (compare with the Communication Failure Report below, which is printed after an operation has been completed). So while doing a broadcast, the machine may print a number of error reports, and at the end, it prints a Communication Failure Report (or Transmission Result Report if it is switched on).

Check the report and retransmit any pages that were not sent. Keep any error reports that are printed, as they may be useful for a service technician if a particular problem continues or gets worse.

Communication Failure Report

This report is printed after executing an operation, whether it be a single transmission or a broadcast from memory, if a transmission failure occurred during that operation. It is only printed if the Transmission Result Report is switched off.

Memory Storage Report



If you switch this report on, it is printed immediately after you store a document in memory for Memory Transmission or Polling Transmission. It gives the file number, the time that it was stored, and the destinations (including any Group numbers that were selected).

Power Failure Report

This report is printed if the machine's power was off for long enough to erase the memory. The report gives details of the files that were lost. With this information, you may store messages for transmission again, and contact the senders of any received messages that were lost.

Transfer Result Report

After the end of a transfer request, the transfer broadcasting station sends you this report. The report lists the telephone numbers of the broadcasting stations and the end receivers, and indicates whether each transmission was successful or not. With this information, you may retransmit any pages that were not sent, either directly, or using another transfer request operation.

If your machine is the broadcasting terminal, it will print the report if it cannot send the report to the transfer requesting terminal (for example, due to a busy line). The report asks you to send the report manually, and gives the telephone number.

Polling Reserve Report

If you switch this report on, it is printed automatically after you program the machine for polling reception (immediate or send later). It gives the file number, time of polling, and destinations (including any Group numbers that you selected).

Polling Result Report

This report is printed after your machine polls a message from another machine.

Polling Clear Report

This report is printed after a polling file has been erased from memory.

Confidential File Report (Memory Card or Hard Disk Required)

This report informs you when a confidential message has been received.

If the sender of the message used Confidential ID Override, and specified an ID that is the same as one of the Confidential IDs stored with a Personal Code in your machine, the name stored with that Personal Code will be printed on the Confidential File Report.

Transmission Deadline Report/Polling Confirmation List

If you selected the TRD (Transmission Deadline) option, this report will be printed when the deadline passes. The report will tell you whether the transmission was completed before the deadline or not. If you selected TRD with Polling, the Polling Confirmation List will be printed instead.

Switching Reports On/Off

Some of these reports can be switched on or off.

To switch a report on or off, do the following. (See page 10 if you need more information about the User Parameter settings adjustment procedure).

1. **Function** **6** **0** **2** **2** **2** **2** **9** **1**

USER PARAMETER	PRI NT LI ST	→
DEFAULT:	01000000	↑
SW TCH00:	01000000	YES TO END ↓

2. The settings for switch 00 are now shown on the bottom line of the display.

SWITCH00: 00000000

3. Press **↓** until the settings for switch 02 are shown.

Each digit from 0 to 7 controls one of the reports, except digit 1, as follows.

SWITCH02: 00000000

7 6 5 4 3 2 0

Digit	Purpose
0	Transmission result report (memory transmission) 0: Off 1: On Default Setting: On
1	Do not change this setting.
2	Memory storage report 0: Off 1: On Default Setting: Off
3	Polling reserve report 0: Off 1: On Default Setting: Off
4	Polling result report (polling reception) 0: Off 1: On Default Setting: On
5	Transmission result report (immediate transmission) 0: Off 1: On Default Setting: On
6	Polling clear report 0: Off 1: On Default Setting: On
7	TCR 0: Off 1: On Default Setting: On


REPORTS

4. If you wish to change a setting, press the appropriate key on the keypad. For example, to change digit 2, press **2**.

5. Finish: **Yes** **Function**

Note: ☐ To switch the Confidential File Report on or off, use Function 81 (see page 128).

☐ To switch the Error Report on or off, contact a service technician.

☐  You may program one of the User Function Keys to switch the Memory Storage Report on/off. Use Function 35; see page 163 to see how to do this.

Printing a Sample of Data on the Reports



For reference purposes, the machine prints the first few inches of the fax message on the following reports.

- ☐ Transmission Result Report
- ☐ Memory Storage Report
- ☐ Polling Clear Report
- ☐ Communication Failure Report
- ☐ Transfer Result Report
- ☐ Transmission Deadline Report
- ☐ Polling Confirmation List


The procedure to switch this feature on or off is as follows. (See page 10 if you need more information about the User Parameter settings adjustment procedure).

1. **Function** **6** **0** **2** **2** **2** **2** **9** **1**

USER PARAMETER	PRI NT LI ST	→
DEFAULT:	01000000	↑
SW TCH00:	01000000	YES TO END ↓

2. The settings for switch 00 are now shown on the bottom line of the display.

SWITCH00: 00000000

3. Press  until the settings for switch 03 are shown.
The setting you need to use is digit 0.

SWITCH03: 00000000

Digit 0
0: This feature is Off.
1: This feature is On.

4. If you wish to change the setting, press **0** .

5. Finish: **Yes** **Function**

Report Formats

Example 1. Error Report

The following report means that the machine sent four pages but there were errors during the first two pages.

*** Error Report (Apr 28 1992 12:09PM) ***						
		TTI		XYZ COMPANY		
File	Pers. Code	Address	Mode	Time	Page	Result
0087	JOHNSON	XYZ CO. NEW YORK	G3TES	0'29"	P. 4	E
		Page not sent				
		P. 1				
		P. 2				

Personal Code
of the Sender

Example 2. TCR

*** TCR (Apr 28 1992 11:40AM) ***									
						TTI	XYZ COMPANY		
<TX>									
Date	Time	Address	Mode	Time	Page	Result	Pers.	Code	File

Apr 28	9:48AM	XYZ NEW YORK	G4TES	1'11"	P. 5	OK	YAMAMOTO		0005
	9:54AM	XYZ LONDON	G3TES	0'27"	P. 1	OK	FENSTERWALD		0007
	9:56AM	2125551234	G3TES	0'28"	P. 1	OK	MCTAGGART		0009
	10:01AM	XYZ BERLIN	G3TES	0'24"	P. 1	OK	JONES		0010
<RX>									
Date	Time	Address	Mode	Time	Page	Result	Pers.	Code	File

Apr 28	9:51AM	DR J ALVAREZ	G4RS	0'24"	P. 1	OK			0006
	9:58AM	2015551234	G3RES	0"27"	P. 1	OK			0008
	10:56AM	XYZ PARIS	G3RES	0'28"	P. 1	OK			0011
	11:01AM	M. JONES	G3RES	0"24"	P. 1	OK			0012

REPORTS

The following pages explain the symbols that appear in certain columns of the reports.

The Mode Column

See the bottom of the TCR for a full listing of the symbols that are used on the TCR. On other reports such as the File List, a code is given, informing the type of communication. These codes are explained below.

SAF_TX	Memory Transmission	SUB_RX	Substitute Reception
IMM_TX	Immediate Transmission	FWD_TX	Forwarding
CNF_TX	Confidential Transmission	IMM_RX	Normal Reception
TONER	Transmission of Toner Order Form	LCK_RX	Reception with Memory Lock
POL_TX	Polling Transmission	TRN_TX	Transfer Request
POL_RX	Polling Reception	TRN_RX	Reception of document from Transfer Requester prior to broadcasting
CNF_RX	Confidential Reception	RPT_RX	Reception of Transfer Result Report
AUTO_D	Auto Document		

Also, in the Address and Group Name column of the File List, for a Transfer Request operation, you may see the following codes.

TRN_ST	Indicates that the number to the right is a transfer broadcasting station.
REC_ST	Indicates that the number to the right is an end receiver in the transfer broadcasting operation.
TRN_1	Indicates that the number to the right is the first transfer station in a two-step transfer operation.
TRN_2	Indicates that the number to the right is the second transfer station in a two-step transfer operation.
TRN_RQ	Indicates that the number on the right is the station that requested the transfer request for this file, using your machine as a transfer broadcasting terminal.

The Results Column

OK: Successful Communication
E: An error occurred
Standby: Ready to transmit

The Footnote on the TCR

TX counter: Total number of transmitted pages
RX counter: Total number of received pages

Counters listed on the User Parameter List

OPU counter: Total number of pages printed so far with the current master unit.
SCN: Total number of pages scanned
PRN: Total number of pages printed

In the Result column, some reports may have an "E" followed by a code, and there may be a message printed at the bottom of the report. This code and message indicate that a problem occurred. The codes are explained below.

CODE	MESSAGE	EXPLANATION
1	HANG UP OR LINE FAIL	The other party either a) hung up, b) had no message on polling standby, c) cannot do confidential reception or transfer request, or d) had an ID Code that did not match the one in your machine. Alternatively, there could have been a problem with the telephone line.
2	BUSY	The machine at the other end was busy.
3	NO ANSWER	The line is dead (no dial tone was detected).
4	NO FACSIMILE CONNECTION	The machine at the other end did not answer.

USER-INITIATED REPORTS

These reports can be printed at any time by executing a procedure on the operation panel.

Descriptions of Available Reports

TCR



In addition to the automatic output of this report, you can print the TCR at any time.

Press **Function** **4** **1** **Start**



If you have programmed User Function Keys to print the TCR or the File List, just press that key then **Start** .

File List



This is a list of memory transmission, memory reception, and polling files still in the memory. It gives information about each stored operation, such as the fax numbers, start time, status, and type of operation.

Press **Function** **4** **2** **Start**



If you have programmed User Function Keys to print the TCR or the File List, just press that key then **Start** .

Quick Dial List

This is a list of the telephone numbers and other items that you have stored in the machine's Quick Dial Keys.

Press **Function** **4** **3** **Start**

Speed Dial List

This is a list of the telephone numbers that you have stored as Speed Dial Codes.

Press **Function** **4** **4** **Start**

Group Dial List

This is a list of all the groups that you have programmed, and the telephone numbers in these groups.

Press **Function** **4** **5** **Start**

Program List

This gives details on the Keystroke Programs that you have stored in the machine.

Press **Function** **4** **6** **Start**

User Function List

This shows how the User Function Keys are currently programmed.

Press **Function** **4** **7** **Start**

Personal Code List

This is a list of the Personal Codes that you have stored, along with the names and Confidential IDs.

Press **Function** **6** **0** **2** **2** **2** **2** **7** **1** **→** **Start**

Authorized Reception List

This is a list of all terminal names that you have specified for Authorized Reception. It includes Wild Cards.

Press **Function** **6** **0** **2** **2** **2** **2** **7** **2** **→** **Start**

Forwarding List

This list shows details of how you have programmed the Forwarding feature. It also includes the Wild Cards.

Press **Function** **6** **0** **2** **2** **2** **2** **7** **5** **→** **Start**

Specified Cassette Selection List

This is a list of all terminal names that you have specified for Specified Cassette Selection. It includes Wild Cards.

Press **Function** **6** **0** **2** **2** **2** **2** **7** **6** **→** **Start**

User Parameter List

This shows the current settings of the User Parameters.

Press **Function** **6** **0** **2** **2** **2** **2** **9** **1** **→** **Start**



Cross-references

Immediate Transmission: see page 47.
Memory Transmission: see page 48.
Confidential Transmission: see page 104.
Confidential Reception: see page 126.
Keystroke Programs: see page 99.
Personal Codes: see page 110.
Authorized Reception: see page 132.
Specified Cassette Selection: see page 141.
User Function List: see page 163.

Quick Dial: see page 29.
Transfer Request: see page 87.
Polling: see page 153.
Groups: see page 30.
Speed Dial: see page 29.
TRD: see page 61
Forwarding: see page 134.
User Parameters: see page 10.

LOOKING AFTER THE MACHINE

REPLACING PAPER

- ❑ When the Add Paper indicator () on the operation panel is lit, the upper cassette is empty.
- ❑ When the Add Paper indicator () on one of the lower cassettes is lit, that cassette is empty (only when the lower cassette is installed).


To refill either cassette:

1. Slide the cassette all the way out, and place it on a large flat surface.


CAUTION

To avoid dropping the cassette, hold it by the front and side while pulling it out.

If there is a paper feed problem in the lower cassette entrance, please slide out the cassettes one by one, from the top cassette down, before removing the paper.




2. Bend the new stack of paper a few times.



3. Load the paper into the cassette.



- NOTE:**
- ❑ True up the edges of the stack.
 - ❑ Do not fill up the cassette past the load limit marker.

Load Limit



4. Replace the cassette carefully.


REPLACING THE TONER CASSETTE

- ❑ When the Add Toner indicator () starts to blink, the toner cassette is almost empty. You will be able to make 100 more copies before you have to change the toner cassette.
- ❑ When the Add Toner indicator () remains lit, it is time to install a new toner cassette.


Replacement Procedure

1. Take off the tray and document table.

Note: Do not switch off the machine.




2. Open the front cover. (Push up the lever on the cover.)



LOOKING AFTER
THE MACHINE

3. Slide out the old toner cassette holding the green tabs, and discard it properly.



Note: Do not shake the cassette, or toner may spill out.



WARNING

Do not incinerate waste toner. Toner dust may cause flashback when exposed to an open flame.


4. On the new toner cassette, remove the two green plastic stoppers.




5. Slide the new toner cassette into the machine along the rails until it stops.

CAUTION


- ☐ Do not touch the cleaning blade [A].
- ☐ Do not touch the gear [B].



6. Close the front cover.



7. Put the tray and document table back.



Ordering Toner



When you run out of toner, you can dial your dealer, and input the amount of toner needed. The machine will generate an order form and send it to your dealer.

To use this feature, you must do the following in advance:

- ☐ Switch this feature on (see below).
- ☐ Store the fax number of your dealer in Quick Dial Key 64. See page 31 for how to store a number in a Quick Dial Key.

If you wish to use Quick Dial 64 for other purposes, you must switch Ordering Toner off.

Switching the Ordering Toner Feature On/Off

To switch this feature on or off, do the following. (See page 10 for more information about the User Parameter settings adjustment procedure).

1. **Function** **6** **0** **2** **2** **2** **2** **9** **1**

USER PARAMETER	PRI NT LI ST	→
DEFAULT:	01000000	↑
SW TCH00:	01000000	YES TO END ↓

2. The settings for switch 00 are now shown on the bottom line of the display.

SWITCH00: 00000000

3. Press **↓** until the settings for switch 04 are shown.

The setting you need to use is digit 7.

SWITCH04: 00000000

Digit 7
0: This feature is Disabled.
1: This feature is Enabled.

4. If you wish to change the setting, press **7**.

5. Finish: **Yes** **Function**

Ordering Toner Procedure

You can automatically fax an order for new toner whenever you need to. Each carton contains four toner cartridges.

When you need to order, do the following.

1. **64**

ORDER NEW TONER	
PRESS	START
1	: AMOUNT

2. Input the number of toner cartridges that you wish to order (the maximum order is 9).

Example: **5**

ORDER NEW TONER	
PRESS	START
5	: AMOUNT


3. **Start**

- ☐ Your order is transmitted to your dealer. If the transmission was successful, your machine prints out a report.


REPLACING THE STAMP

When the stamp made by the stamp becomes pale, replace the stamp as described below.


1. Remove the document tray.



2. Open the scanner cover.



3. Replace the stamp.
If tweezers are not available, you may press the point of a pencil down vertically into the stamp and remove it by lifting straight up.



4. Close the cover and put back the document guide.

CHANGING THE PAPER SIZE OF THE CASSETTE

When you want to use a different size of paper in the cassette, do the following.


NOTE: You need a #2 Philips screwdriver for this procedure.

Upper Cassette


1. Remove the upper cassette.

CAUTION:


To avoid dropping the cassette hold it by the front and side while pulling it out.



2. Push the white lever [A] in the direction shown in the diagram below.
3. Change the position of the bracket [B] in accordance with the paper size which you wish to install.



4. Change the position of the two side fences [C] to match the new paper size.
5. Change the paper size actuator [D] to the appropriate one.
6. Push down the bottom plate [E].
7. Add paper and put back the cassette.




Lower Cassette(s)


1. Remove the lower cassette.

CAUTION:

To avoid dropping the cassette, hold it by the front and side while pulling it out.



2. Remove the side fences [F].
3. Change the position of the bracket [G].
NOTE: If necessary, hold up the bottom plate [H].
4. Install the two side fences in the appropriate position.
5. Change the paper size actuator [I] to the appropriate one.
6. Add paper and put back the cassette.



USER MAINTENANCE PROCEDURES

To ensure that your fax continues to operate smoothly, some simple maintenance is required. This entails cleaning a few components. User maintenance should be done once every 6 months.

User Maintenance Table

The following table shows what items you need to look after from time to time. Letters after component names in the Item column refer to the labels used in the diagrams on the following pages.


Area	Item	What to Use	Possible Problems if Not Maintained
Scanner	Separation Roller [E]	Soft damp cloth	Document non-feed or multifeed
	Pick-up Roller [J]	Soft damp cloth	Document non-feed or jam
	Feed Roller [J]	Soft damp cloth	
	White Strip [F]	Soft damp cloth	Poor copy quality (dirty background on copies and transmitted faxes)
	R1 Roller [H]	Soft damp cloth	Document skew, or dirt on the document
	R2 Roller [H]	Soft damp cloth	
	Exposure Glass [I]	Soft damp cloth	Vertical black lines on copies and transmitted faxes
Main Body	Paper Feed Rollers [N]	Soft damp cloth	Copy paper skew or jam
	Registration Rollers [L]	Soft damp cloth	Copy paper skew or jam, or leading edge of printouts missing
	Corona Wire [T]	Corona wire cleaner	Vertical black lines on copies and received faxes
Lower Paper Feed Units (if installed)	Paper Feed Rollers [U], [W]	Soft damp cloth	Copy paper non-feed or jam

LOOKING AFTER
THE MACHINE

Caution: A soft damp cloth is needed. The cloth must be wrung out tightly before use. Use water only. Do not use a detergent or a solvent such as alcohol.

User Maintenance Procedure

Scanner




1. Prepare a soft damp cloth.
2. Turn off the main power switch.


Note for machines that do not have the optional hard disk unit

Before turning off the main switch, make sure that the remaining memory capacity is 100%. If the machine is switched off for more than an hour, any fax messages in the memory may be lost.


3. Remove the document table [A] and copy tray [B].




4. Remove the document tray [C].



5. Open the ADF cover [D].




6. Clean the separation roller [E] with the soft damp cloth, while rotating the roller. This roller is near the ① decal inside the machine.




7. Clean the white strip [F] with the soft damp cloth.

CAUTION:


Do not damage the sensor actuator [G] (black plastic) below the white strip.




8. Clean the R1 and R2 rollers [H] with the soft damp cloth. To rotate the rollers, gently hold the cloth down on the rollers and turn the main power switch on. The rollers will rotate once. These rollers are near the ③ decal inside the machine.




9. Turn the main power switch off.
10. Clean the exposure glass [I] with the soft damp cloth.




11. Clean the pick-up and feed rollers [J] with the soft damp cloth, while rotating the rollers in the direction shown in the diagram. These rollers are near the ② decal inside the machine.



12. Close the ADF cover.




Main Body



1. Remove the upper cassette [K].

CAUTION:


To avoid dropping the cassette, hold it by the front and side while pulling it out.



2. Clean the three registration rollers [L] with the soft damp cloth, while rotating them in the direction shown in the diagram.


CAUTION:

Do not damage the sensor actuator [M] (black plastic).




LOOKING AFTER
THE MACHINE

3. Clean the white paper feed rollers [N] in the cassette, while rotating them.



4. Put back the cassette.
5. Open the front cover [O].




6. Remove the toner cassette [P].

CAUTION:

To prevent your table from getting dirty, lay a sheet of paper on it before removing the toner cassette.


Do not touch parts [Q] and [R].



7. Lay a sheet of paper on top of the master belt [S] (dark green plastic belt), to avoid damage to the master belt.

CAUTION:


Do not touch the master belt.



8. Slide the blue plastic corona wire cleaner [T] from its home position all the way across to the right side of the machine. Then move it back to the home position; you will hear a click when the cleaner reaches home position.


CAUTION:

Printout quality may deteriorate if the cleaner is not at the home position.



9. Remove the sheet of paper from the master belt, and put back the toner cassette.

10. Close the front cover.




Lower Paper Feed Unit(s) (If one or more are installed)

1. Remove the lower cassette.

CAUTION


To avoid dropping the cassette, hold it by the front and side while pulling it out.




2. Clean the paper feed roller [U] with the soft damp cloth, while rotating it in the direction shown in the diagram.

CAUTION

Do not damage the sensor actuator [V] (black plastic).



3. Clean the paper feed rollers [W] in the cassette with the soft damp cloth, while rotating them as shown in the diagram.





4. Put back the lower cassette.
5. Put back the document tray, document table and copy tray.
6. Turn the main switch back on.

SOLVING PROBLEMS

Caution: Do not attempt to make any repairs other than those described in this manual. Removing covers may expose you to dangerous voltages and other risks. Refer all servicing to qualified personnel.

CHECK THE INDICATORS AND DISPLAY PANEL


Check the indicators on the operation panel to check if there are any problems. See page 19 for information about the indicators.

Also, if you see "PROBLEM  " in the top right hand corner of the screen, press  to see what the problem is.

DOCUMENT JAMS

Clearing a Document Jam

If the Clear Original indicator () blinks:



- ☐ There is a document jammed in the feeder. Remove the jammed document and repeat the transmission procedure.
- ☐ The document may be longer than the maximum limit (see Recommended Types of Document, page 45).


1. Pull up the scanner release and open the scanner.
2. Carefully take out the jammed original. Do not leave any pieces inside. Then close the scanner.

A defective or unrecommended document type may cause a jam. See pages 45 and 46.

Adjusting the Document Feeder

If you normally scan thin or thick sheets of paper you can adjust the auto document feeder mechanism. Also, this is useful when you have document multifeed or non-feed problems.

If you open the scanner cover you can find the adjustment knob (blue color) and scale easily. Numbers 1 through 5 are printed beside the scale. Rotate the knob until the arrow points to the number which you want to select.



1. Setting in accordance with the document type

Document type	Setting
Thin Document	Use 1 or 2
Thick Document	Use 4 or 5

2. Setting if problems happen frequently

Problem		Setting
Multifeed	Thin Document	Use 1 or 2
	Thick Document	Use 4 or 5
Non Feed		Use 4 or 5
Document Jam		Use 1 or 2

Note: In a new machine the setting is 3.

COPY JAMS


If the Clear Copy Indicator () blinks, there is a copy jam.

There are four possible locations:


- ☐ Cassette entrance
- ☐ Inside the machine
- ☐ Copy feed-out area
- ☐ Lower cassette entrance (for machines with one or more lower paper feed units)

Cassette Entrance

1. Pull open the cassette.




2. Gently pull out the misfed paper.
Do not leave any pieces inside.




3. Replace the cassette.

Inside the Machine

1. Remove the trays, and pull open the cassette.




2. Open the front cover.



3. Pull out the jammed paper carefully by the leading or trailing edge, or by the center if both edges are jammed.

CAUTIONS:


- ☐ Do not touch the fusing unit (the parts inside the machine colored orange). It may be hot.
- ☐ Do not touch the master belt.
- ☐ Any toner on the paper will not be fixed to the paper. Be careful not to get your hands or clothing dirty.




4. Close the front cover.

Copy Feed-out Area


1. Remove the document table and copy tray, and pull open the cassette.



2. Open the copy feed out cover.



3. Gently pull out the misfed paper.
Do not leave any pieces inside.




4. Close the copy feed out cover.
Put back the document table and copy tray.

Lower Cassette Entrance


CAUTION

If there is a paper feed problem in the lower cassette entrance, please slide out the cassettes one by one, from the top cassette down, before removing the paper.

1. Pull open the lower cassette.




2. Gently pull out the misfed paper.
Do not leave any pieces inside.



3. Replace the cassette.

COMMUNICATION PROBLEMS

If the Line Fail indicator () blinks:

Wait for the Communicating indicator to go out. Then press **Stop** .

- ☐ A poor line caused the communication to fail.
- ☐ The line is busy or noisy. Try to retransmit.
- ☐ The other machine is out of order.
- ☐ Ask the other party to check their machine.

OPERATING DIFFICULTIES

Problem	Required Action
STANDBY MODE	
Nothing happens when the switch is turned on.	<p>Check the power cord. Is it properly plugged into the outlet?</p> <p>➤ Plug it in firmly</p>
SET DOCUMENT is not displayed.	<p>Switch the power on.</p> <p>➤ If the Power indicator does not light, check that the power cord is plugged in.</p>
The display does not show the Ready condition, or the machine stops during an operation.	<p>Is the Clear Original or Clear Copy indicator on?</p> <p>➤ Clear the misfed paper. See pages 213 and 215.</p>
	<p>Is the Load Paper indicator on?</p> <p>➤ Load paper into the paper tray. See page 194.</p>
	<p>Is the Close Cover indicator blinking?</p> <p>➤ Close all covers indicated on the display.</p>
	<p>Is the Add Toner indicator on?</p> <p>➤ Load a new toner cartridge. See page 195.</p>
	<p>Is the Call Service indicator on?</p> <p>➤ Call your service representative, and report the message on the display.</p>
TRANSMISSION	
The original is not pulled into the auto document feeder.	<p>You did not feed the document far enough into the feeder.</p> <p>➤ Insert the document into the feeder until it stops. Retransmit.</p>
	<p>Do user maintenance, especially rollers [E] and [J] (see page 203).</p> <p>➤ If the same problem still exists after user maintenance, adjust the auto document feeder mechanism (see page 214).</p>
The machine cannot dial out.	<p>The telephone line is disconnected.</p> <p>➤ Check that the line is connected properly.</p>
	<p>The telephone line type setting is incorrect.</p> <p>➤ Check the telephone line type setting (see page 28).</p>
The machine cannot dial out from behind a PBX.	<p>The dialed number does not contain an access code or a pause.</p> <p>➤ Include the access number and a pause before the telephone number.</p>
	<p>The dialed number did not have enough pauses between the access number and the telephone number.</p> <p>➤ Try adding more pauses after the access code.</p>

Problem	Required Action
Frequent original misfeeds	Multifeeds
	Incorrect positioning of originals ➤ Put the document in the feeder correctly. See page 49.
	Incorrect alignment of originals ➤ Align the edges of the document. See page 49.
	Curled pages ➤ Flatten the document. See page 46.
	Incorrect document type ➤ Use a proper document type. See page 46.
	Mixed document types ➤ The pages must all be of the same type.
	Static electricity on the originals ➤ Shuffle the document. See page 49.
	User maintenance is needed ➤ Do user maintenance, especially roller [E]. See page 203.
	The document feeder is not adjusted correctly. ➤ Adjust the auto document feeder. See page 214.
	Non-feeds
	Copier silicone oil on the originals ➤ Wait a few minutes, then try again.
	Incorrect alignment of originals ➤ Align the edges of the document. See page 49.
	Curled pages ➤ Flatten the document. See page 46.
	Incorrect document type ➤ Use a proper document type. See page 46.
	More than 50 pages in the feeder ➤ Do not place more than 50 pages in the automatic document feeder at once.
	User maintenance is needed ➤ Do user maintenance, especially rollers [E] and [J]. See page 203.
	The document feeder is not adjusted correctly. ➤ Adjust the auto document feeder. See page 214.

Problem	Required Action
Transmission cannot take place; the Clear Original indicator blinks.	The document is jammed in the feeder. ➤ Remove the jammed document (see page 213) and repeat the transmission procedure.
	The document may be longer than the maximum limit (see page 45). ➤ Make sure that none of your originals exceed this limit.
	Do user maintenance, especially rollers [J] and [H] (see page 203). ➤ If the same problem still exists after user maintenance, adjust the auto document feeder mechanism (see page 214).
Transmission cannot take place; the Line Fail indicator blinks. Note: Before taking action, wait until the Communicating indicator goes out, then press the Stop key.	The other machine is out of order. ➤ Check the error report. ➤ Ask the other party to check their machine and correct the fault.
	The line is busy or noisy. ➤ Check that the dial tone is sent out. Try to retransmit.
Consistent difficulty in communicating with a particular terminal	There are some bad lines between you and that other terminal. ➤ Store that terminal's number as a Quick Dial Key or Speed Dial Code. Then call a service technician. Inform the nature of the problem and give the Quick Dial Key or Speed Dial Code that you stored the number in.
Consistent poor image quality when communicating with a particular terminal	
RECEPTION	
The telephone keeps ringing and no fax is printed.	You are in Manual Receive mode. ➤ Change to Auto Receive mode (see page 74).
	Power is switched off. ➤ Switch the power on.
RECEPTION/COPYING	
No printout; the Add Paper indicator is lit.	The cassettes are empty. ➤ Add paper (see page 194).
No printout; the Clear Copy indicator blinks.	The printer has jammed. ➤ Clear the jam (see page 215).
	Do user maintenance, especially rollers [N], [L], and [U] (if the lower cassette is installed). See page 203.
Copies appear dirty.	Does the original have a gray or colored background? ➤ Select the Lighten contrast setting.
Copies are too light.	Does the original have a low contrast image? ➤ Select the Darken contrast setting.
Copies are blank.	The original must be placed face down in the document feeder ➤ Position the original correctly. See page 49.

Problem	Required Action
Copy paper misfeeds occur frequently.	Is the proper paper in the paper tray? ➤ Paper size and weight must be within the standards set for this machine.
	Is folded, wrinkled, damp, or curled paper in the paper tray? ➤ Always use dry, undamaged paper.
	Is the paper set properly in the paper tray? ➤ Always load paper correctly. See page 194. Make sure that there is not too much paper in the trays; do not fill them up over the load limit mark.
	Are there any pieces of misfed paper or other foreign objects in the machine? ➤ Make sure that the paper path is completely clear of paper and other material after a misfeed.
	Are you copying onto recycled paper? ➤ Fan the stack of recycled paper and load it in the paper tray.
Stripes on copies.	The exposure glass is dirty. ➤ Clean the exposure glass (see page 207).
	Do user maintenance, especially glass [I] and wire [T] (see page 203).
TELEPHONING	
You can't receive phone calls; the unit only rings once then goes into receive mode.	You are in Auto Receive mode. ➤ Change to Manual Receive mode (see page 74).
You can't receive phone calls; the unit does not ring.	The telephone line is not connected. ➤ Connect the modular cord (see page 22).
POLLING	
Dialing took place, but polling could not.	ID Codes do not match. ➤ Contact the person at the other end and make sure that the ID Codes are the same before trying the communication again.

DISPLAYED ERROR MESSAGES

The following messages may appear while you are operating or programming the machine.

CHECK AUTO- DI ALI NG	You cannot use the auto-dialer at the moment. Use the ten-key pad or the handset.
NO BOOKI NG FOR POLLI NG RECV	No polling reception operations have been programmed.
NO TRANS FI LES EXI ST	There are no messages in memory waiting for transmission.
NO POLLI NG DOCUMENTS EXI ST	There are no messages in memory waiting to be polled.
THI S FI LE DOES NOT EXI ST	Incorrect file number. Check the file number and try again.
TOO MANY DEST	The memory cannot hold any more telephone numbers. Either: Delete some numbers then try again. Or: Wait until some of the Send Later or other delayed transmissions waiting in memory have been carried out, then try again.
DOCUMENT I N USE	This message is now being sent. You cannot print it now.
USED AS GROUP	This Quick Dial Key has a Group stored in it.
USED AS PROGRAM	This Quick Dial Key has a Keystroke Program stored in it.
USED AS QUI CK DI AL	This Quick Dial Key has a telephone number stored in it.
NOT ADDED	The telephone number was not stored, because either: You cannot add any more numbers to this Group. The digit, pause, or other symbol that you just attempted to input was rejected because it is inappropriate.
NOT ADDED!	The telephone number was not stored, because you cannot store any more full telephone numbers at the moment. Either: Delete some numbers from the machine to make room, then try again. Or: Store this number as a Quick or Speed Dial before trying to use it. Or: Wait until some of the Send Later or other delayed transmissions waiting in memory have been carried out, then try again.
OVERFLOW	There is no room in the machine's memory for any more telephone numbers. Either: Delete some numbers from the machine to make room, then try again. Or: Wait until some of the Send Later or other delayed transmissions waiting in memory have been carried out, then try again.
NOT PROGRAMMED	Either: This Quick Dial Key or Speed Dial Code does not contain a number. This Quick Dial Key does not contain a Keystroke Program.
FAX NO NOT PROGRAMMED	There are no fax numbers stored in this Group.
NO DATA PROGRAMMED	The Group that you tried to erase does not contain any fax numbers.
ALREADY PROGRAMMED	Either: This number is already included in this Group. This RTI/CSI has already been stored for use with this feature.

OVER NO OF PROG RTI / CSI	You cannot store any RTIs or CSIs for use with this feature; the limit has already been reached.
RTI / CSI IS NOT PROGRAMMED	No RTIs or CSIs have been stored for this feature.
NO PAUSE	You must add a pause after your area code when you input your fax terminal's own telephone number.
SW TCH OFF AFTER PRI NT OUT	You cannot switch Memory Lock off while there is a received fax message in the memory. You must input the Memory Lock ID and print the message first before switching Memory Lock off.
NOT CHANGEABLE	You cannot change the setting of this feature.
(FORWARDI NG)	If displayed under SET DOCUMENT in standby mode, this indicates that Forwarding is now switched on.
(MEMORY LOCK)	If displayed under SET DOCUMENT in standby mode, this indicates that Memory Lock is now switched on.
(RDS)	If displayed under SET DOCUMENT in standby mode, this indicates that RDS is now switched on.
(POWER SAVER)	If displayed under SET DOCUMENT in standby mode, this indicates that the Power Saver is now switched on.
ADD TONER	The toner cartridge is empty. Install a new cartridge.
ADD PAPER I N CASSETTE NO. _	The indicated cassette is now empty.
CHECK I D	The ID that you entered is not correct. Try again.
COMMUNI CATI ON FAI L	There was an error during a transmission or reception. Check the error report.
CLEAR ORI GI NAL	A document is jammed in the feeder.
CLEAR COPY	Paper is jammed in the printer.
CLOSE COVER	A cover is not closed properly. Check that all covers are closed.
UNABLE TO PRI NT I N COMM.	You cannot print a report or make a copy while the machine is sending or receiving a fax message.
UNABLE TO PROGRAM	This Quick Dial Key already contains a number. Try another Quick Dial Key.

ERROR CODES

Fax machines use a telephone line. The same types of problems you experience while making phone calls (such as noisy lines, crosstalk, disconnection during conversation, weak signals) also occur with faxing. Telephone callers can deal with the problems themselves (for example, by speaking a bit louder), but fax machines cannot. Therefore some errors and line fails are to be expected.

When an error occurs, an error report is printed. This report includes an error code. The following table lists common error codes and a few of the possible causes. If any of these or any other error codes are persistent and the machine does not work properly, contact a service technician.

Note: When an error occurs, it does not mean that you are doing anything wrong or that your machine needs service. Only if the problem persists should you call your service representative.

Code	Possible Cause
0-01	Printer empty or jammed at the other end
0-04	Faulty machine at the other end Poor line condition
0-05	Poor line condition
0-06	Incompatible or faulty terminal at the other end Poor line condition
0-07	The facsimile machine that you were sending to disconnected during the call, either due to noisy phone lines, a paper jam or because it ran out of paper. Resend the page.
0-08	The machine at the other end received the page that you sent but it had errors on the page. You may want to resend the page in question. The other party's memory could also be full. Contact the other party and ask them to make room in their memory for your message.
0-14	Same as for code 0-06
0-15	The other party does not have the confidential or transfer function. The other party's memory may be full.
0-16	Same as for code 0-04
0-20	Poor line condition
0-21	Same as for code 0-04
0-22	You have just received a fax message, but there were problems because of poor line condition. Ask the other party to resend.
0-23	Same as for code 0-22
0-24	The memory may be full, and there may be a problem with your printer, such as a jam or running out of paper or toner. Wait for some space to appear in the memory, then solve the problem with your printer. If the memory was not full, substitute reception may have been disabled; switch substitute reception on using digit 0 of user parameter switch 05.
0-70	There is a problem with the network or with the machine at the other end.
1-00	Document jam Improperly inserted document
1-01	Document length exceeded the maximum limit Same as for code 1-00

Code	Possible Cause
2-xx	Possible fault in your machine
4-00	The page took too long to send. Send again at a lower resolution, or without halftone. The line may be bad.
4-01	There is a bad line. The telephone line at the rear of the machine may be disconnected.
4-02	The received page was too long.
4-10	ID codes did not match. Co-ordinate ID codes with the other party.
5-20 5-21	Insufficient memory to receive the message. When the pages in memory have been printed, ask the other party to resend.
5-25	Your machine has a problem.
6-01 6-02	Poor line condition or a problem with your machine
6-05	Poor line condition, a problem with the machine at the other end, or a problem with your machine
6-06	A problem with the machine at the other end, or a problem with your machine
6-08	A problem with the machine at the other end
6-09 6-10	A problem with the machine at the other end, or a problem with your machine
9-07	Copy jam at the cassette entrance (first, or top, paper feed station)
9-08	Copy jam inside the machine (first, or top, paper feed station)
9-09	Copy jam at the feed-out area
9-17 9-20 9-22 9-23 9-24	There is a problem with your printer.
9-50	Copy jam at the cassette entrance (second paper feed station)
9-51	Copy jam inside the machine (second paper feed station)
9-52	Copy jam at the cassette entrance (third paper feed station)
9-53	Copy jam inside the machine (third paper feed station)
9-54	Copy jam at the cassette entrance (fourth paper feed station)
9-55	Copy jam inside the machine (fourth paper feed station)
9-56	Copy jam at the cassette entrance (fifth paper feed station)
9-57	Copy jam inside the machine (fifth paper feed station)

CALLING THE SERVICE STATION



The machine has a feature called Service Report Transmission. Use this feature when your machine is having problems. The machine will transmit information about the condition of your machine to your service representative. A technician will then be able to find out what the problem is before making a visit.

To use this feature, you must do the following in advance:

- ❑ Switch this feature on (see below).
- ❑ Store the fax number of your service station in Quick Dial Key 63. See page 31 for how to store a number in a Quick Dial Key.

If you wish to use Quick Dial 63 for other purposes, you must switch Service Report Transmission off.

Switching Service Report Transmission On/Off

To switch this feature on or off, do the following. (See page 10 if you need more information about the User Parameter settings adjustment procedure).

1. **Function** **6** **0** **2** **2** **2** **2** **9** **1**

USER PARAMETER	PRI NT LI ST	→
DEFAULT:	01000000	↑
SW TCH00:	01000000	YES TO END ↓

2. The settings for switch 00 are now shown on the bottom line of the display.

SWITCH00: 00000000

3. Press **↓** until the settings for switch 04 are shown.
The setting you need to use is digit 6.

SWITCH04: 00000000

Digit 6
0: This feature is Disabled.
1: This feature is Enabled.

4. If you wish to change the setting, press **6** .
5. Finish: **Yes** **Function**

SOLVING PROBLEMS

Sending a Service Report

When you need to send a service report, do the following.

1. **63**

SERVICE REPORT TX
PRESS **START**

2. **Start**

If the transmission was not successful, the machine will not redial. You must repeat the operation.

DEDICATED TRANSMISSION PARAMETERS

If you often encounter problems when transmitting to a certain address, program that address into a Quick Dial Key or Speed Dial Code.

Then contact a service technician, describe the problem, and tell them which Speed Dial or Quick Dial you have stored the number in.

The technician can instruct the machine to use different transmission parameters whenever you select that Speed Dial/Quick Dial.

If you reprogram the Speed/Quick Dial, be sure to inform your service technician.

Cross-references

Quick Dial and Speed Dial: see page 29.

SPECIFICATIONS

Dimensions:	20.3" x 18.7" x 12.1" (W x D x H) Excluding trays, handset, cassettes, and optional kits.
Weight:	48.5 lbs Excluding the master unit and printer paper.
Power Supply:	115 ± 20 Vac, 60 Hz; single phase
Maximum Power Consumption:	Standby: 35 W Transmission: 40 W Reception: 180 W (excluding optional kits) Copying: 310 W
Acceptable Document Dimensions:	Width: 5.8" to 12.0" (11.7" maximum scanning width) Length: 4.1" to 47.2" (328" max limit is available) Thickness: 2 to 8 mils (20 lb bond paper)
ADF Capacity:	50 letter-size sheets (using 20 lb paper)
Cassette Capacity:	Upper Cassette: 250 sheets Lower Cassettes: 500 sheets per cassette Maximum Total: 2250 sheets
Memory Capacity:	Base machine: 56 pages With 1 Mbyte memory: 112 pages With 2 Mbyte memory: 168 pages With hard disk: 1,200 pages Measured using a CCITT #1 chart (Slerexe letter) at standard resolution
Resolution:	Standard: 200 x 100 dpi Detail: 200 x 200 dpi Fine: 200 x 400 dpi Super Fine: 400 x 400 dpi (400 dpi option required)
Transmission Speed:	6 seconds at 14,400 bps (G3 ECM) for a CCITT #1 test document (Slerexe letter) using standard resolution
Compatibility:	G3 (G4 kit available)
Paper Size:	Letter, Legal
Maximum Printout Width:	8.3"

APPENDIX A. PAPER FEED UNIT

WARNING: Do not attempt any maintenance or troubleshooting other than that mentioned in this manual.

Operation

Up to four additional paper feed units can be installed. Each paper feed unit can hold up to 500 sheets of paper, which means that you can add an extra 2,000 sheets of copy paper capacity to your fax machine.

If you have the same size of paper in more than one cassette, the paper in the uppermost cassette will be used.

Maintenance

Replacing Paper: See the section entitled REPLACING PAPER on page 194.

Copy Jams

When a paper jam occurs in the machine, and you have one or more optional paper feed units installed:

- ☐ If the jam is at the top cassette entrance, substitute reception will take place. Remove the jammed paper (see the section entitled COPY JAMS on page 215).
- ☐ If the jam is at the entrance to one of the lower cassettes, printing will resume from the top cassette, or from one of the lower cassettes that is not affected by the jam. However, if there is no available cassette with the same paper size as the one that was originally selected for printing, substitute reception will take place.

APPENDIX B. FAX MEMORY TYPE 90 40 MB HD

WARNING: Do not attempt any maintenance or troubleshooting other than that mentioned in this manual.

General

You can upgrade the memory capacity of the facsimile machine with this hard disk unit.

Neither the standard memory nor the optional 1 Mbyte or 2 Mbyte memory card can be used if you install the hard disk unit.

This manual contains information about using the hard disk.

CAUTION

Do not knock, shake, or move the hard disk unit while the hard disk is working.

Note: The hard disk read/write head automatically moves to the shipping position in standby mode.

Operation

The operating procedures are the same as those already described in this manual.

The memory features of the hard disk are the same as the features of the standard memory or the optional 1 Mbyte/2 Mbyte memory card, except for the following items.

1. The data will remain on the hard disk even if you switch off the power to the machine.
2. The hard disk can store up to 1,200 pages (based on the CCITT number 1 test chart). The memory capacity is 40 Mbytes.

Note: Do not knock, shake, or move the hard disk unit while the hard disk is working.

APPENDIX C. ISDN G4 OPTION TYPE 90

Introduction

The ISDN G4 Option Type 90 allows you to send and receive fax messages on high-speed high-quality digital networks. It will allow you to connect the machine to an ISDN (Integrated Services Digital Network) for either Group 4 or Group 3 fax communication.

A few of the features described earlier in this manual cannot be used over an ISDN. These are as follows.

- ☐ Manual reception
- ☐ Telephone line type (DTMF/Pulse dial) selection
- ☐ Manual dialing with the handset
- ☐ Voice Request
- ☐ On Hook Dial
- ☐ RTI, TTI, CSI (these identifiers can only be used with Group 3 communication. In Group 4 mode, another identifier called the Terminal ID is used instead; this is programmed by a service technician at installation. The Terminal ID is explained on page 240)

However, Group 4 has the following major advantages over Group 3:

- ☐ If your organization sends large volumes of material by fax, using Group 4 will greatly reduce your communication costs as a result of the high speed of data transmission.
- ☐ Normal analog networks tend to be noisy, affecting the quality of received data. However, communications over digital networks are of a high quality.
- ☐ The Group 4 interface will greatly enhance other features, especially broadcasting, transfer request, and other networking features, allowing complex distribution of documents with just a few keystrokes. The types of network that you can set up are described in the Networking section of this manual (see page 81).

Note: Your sales or service representative will be able to help program all the necessary group and transfer station numbers in the various broadcasting terminals throughout your proposed network. Please coordinate with your sales representative to obtain correct programming at the time of installation.

Batch Transmission

The use of Batch Transmission is critical to making your Group 4 ISDN kit a cost effective alternative to Group 3. Set up a batch for each of your major fax message destinations. To do this, decide on separate times of execution for each of your batch files. Then, if you wish to send a message to one of these destinations, use Send Later to delay the transmission until the time that you decided for that destination. See page 124 for a description of the Batch Transmission feature.

Setting up the Group 4 Interface

Before you start sending faxes using the Group 4 interface, there are a few items that you have to store in your machine. These are as follows.

- ☐ Subaddress Key
- ☐ Own ISDN G4 Number
- ☐ Own ISDN G3 Number
- ☐ Next Transfer Station

Subaddress Key

Group 4 fax machines may be connected to a multiplexer or similar device. Inputting the subaddress of a destination fax machine will allow you to reach it directly if it is connected behind a multiplexer or similar device. The subaddress can be thought of as similar to the extension number of a telephone connected behind a PBX.

You must program one of the User Function Keys (F1 to F5) to input a subaddress (see page 163 for how to program a User Function Key). When you need to input a subaddress (during dialing, or when inputting your own ISDN G3 or G4 number), press that User Function Key (a backslash will appear), then input the subaddress.

Own ISDN-G4 Number

This is your machine's own telephone number for Group 4 communications over the ISDN.

1. **Function** **6** **0** **2** **2** **2** **2**
6 **1** then **↓** until the screen is as shown opposite.

OWN ISDN- G4 NUMBER	
<input type="button" value="YES"/> TO SET	PREVIOUS <input type="button" value="↑"/>
<input type="button" value="NO"/> TO CANCEL	NEXT <input type="button" value="↓"/>

2. **Yes**

OWN ISDN- G4 NUMBER	
<input type="text" value=""/>	<input type="button" value="YES"/> TO END

3. Input your ISDN number for Group 4 communications.

The format of the number must be as follows: International Dial Prefix, Your Country Code, Your Area Code, **then you must input a Pause**, followed by your telephone number. After that, if your ISDN G4 number contains a subaddress, type a slash followed by the subaddress number.

Check the International Dialing Prefix and the Country Code with your local telecommunications operator. The example shown below is for the USA; the codes to add are 011 and 1.

- ☐ Use the **Pause** key to add a pause.

- ☐ To type the backslash, you must have programmed one of the User Function Keys to input a subaddress (see page 163 for how to program a User Function Key). Press that User Function Key to input the slash, then input the subaddress.

OWN I SDN- G4 NUMBER

OR

0111212- 5551234/ 2468

4.

Own ISDN-G3 Number

You can also make Group 3 communications over the ISDN. This procedure is for storing your machine's own telephone number for Group 3 communications over the ISDN.

1.
- then until the screen is as shown opposite.

OWN I SDN- G3 NUMBER

TO SET PREVIOUS

TO CANCEL NEXT

2.

OWN I SDN- G3 NUMBER

TO END

3. Input your ISDN number for Group 3 communications.

The format of the number must be as follows: International Dial Prefix, Your Country Code, Your Area Code, **then you must input a Pause**, followed by your telephone number. After that, if your ISDN G3 number contains a subaddress, type a slash followed by the subaddress number. Check the International Dial Prefix and your Country Code with your local telecommunications operator. The example shown below is for the USA; the codes to add are 011 and 1.

- ☐ Use the key to add a pause.
- ☐ To type the backslash, you must have programmed one of the User Function Keys to input a subaddress (see page 163 for how to program a User Function Key). Press that User Function Key to input the slash, then input the subaddress.

OWN I SDN- G3 NUMBER

OR


0111212- 5551234/ 2468

4.

Next Transfer Station

The Next Transfer Station allows your fax machine to be a transfer station in a two-step transfer operation using a digital network. An example is given in the section entitled Networking (see page 81); refer to this for details of how to use this feature.


Cross reference
Two-step Transfer: see page 91.

1. **Function** **6** **0** **2** **2** **2** **2**
 6 **1** then  until the screen is as
 shown opposite.
2. **Yes**
3. Input the number of the Next Transfer
 Station.
4. **Yes** **Function**

NEXT TRANSF.


YES

 TO SET

PREVI OUS 

NO

 TO CANCEL

NEXT 

NEXT TRANSF. ENTER FAX NUMBER

NO

 TO CANCEL

NEXT TRANSF.

YES

 OR

CLR

 .

NO

201 - 5553 456

Operation

Dialing and Storing Telephone Numbers

Overview

After installing the ISDN G4 Option Type 90, you must be careful to select the correct signaling type (Group 3 or Group 4) when dialing, or when storing a telephone number as a Speed Dial or Quick Dial.

The G4/G3 Selector key on the operation panel allows you to select whether the telephone number is to be dialed using Group 3 (G3) or Group 4 (G4). An indicator above the key will light to show which has been selected.

To change the setting, press the key until the required indicator is lit. In most cases, <G3> (Group 3) or <G4> (Group 4) will appear on the display as a reference while you are entering a telephone number.

Caution: When you dial a number using a Quick Dial or Speed Dial, or using AI Redial, check the two indicator lamps above the G4/G3 selector key to make sure that the correct mode is selected. If it is not correct, press the G4/G3 selector key until the correct indicator is lit.

- Notes:**
- ☐ Your machine is set up to send to Group 3 fax machines over the regular telephone network (the PSTN, the Public Switched Telephone Network). If you wish to send to Group 3 machines over the ISDN, contact your service representative.
 - ☐ When dialing a fax machine or telephone over an ISDN, the destination could have a subaddress number. This number can be thought of as similar to an extension number on a PBX. If the destination telephone or fax machine has a subaddress number, input this number when dialing. You can get this number from your contact at that location.



To enter a subaddress, you must use a User Function Key. See page 163 for how to program a User Function Key using Function 35.

Transmission Procedure

The following example shows how to dial (assuming that the ISDN G4 Option Type 90 has been installed). The differences between this procedure and the procedure for the base machine (refer to page 49) are as follows:

- ☐ You have to select G3 or G4 before you dial a number.
- ☐ You may have to input a subaddress for a G4 number if the destination has one.

1. Make sure that the machine is in standby mode (see page 49).

MEMORY TRANS.	APR. 4. 12:25 PM
SET DOCUMENT	
MEMORY 100%	

2. Carefully place the document into the auto document feeder.

MEMORY TRANS.	OPTI ONS	↓
ENTER FAX NUMBER		
< G3 >		

3. Change the line type (G3/G4) to the correct setting by pressing the G4/G3 Selector key on the operation panel.

MEMORY TRANS.	OPTI ONS	↓
ENTER FAX NUMBER		
< G4 >		

4. Dial.



See page 51 for how to dial.
You may use Speed Dial, Quick Dial, Group Dial, or the ten-key pad.

MEMORY TRANS.	OPTI ONS	↓
PRESS [YES] OR [CLR] · [NO]		
7005551234		

G3 numbers - If your machine is behind a PBX, include the PBX access code and a pause before the number. For an international number, place a pause after the country code.
G4 numbers - If you wish to enter a subaddress, press the User Function Key that you have already programmed as the subaddress key. Then enter the subaddress.



To enter a subaddress, you must use a User Function Key. See page 163 for how to program a User Function Key using Function 35.

5. **Yes**

MEMORY TRANS.	OPTI ONS	↓
ENTER NO. OR [START] DEST: 2		

6. Either:

- ☐ Dial more numbers: go to step 4.
- ☐ Start the transmission: **Start**

Note: If the other party has not had a G4 Terminal ID programmed, you will see "—" on the screen during transmission, instead of their ID.

Storing a Telephone Number

The following example shows how to store a Quick Dial if the ISDN G4 Option Type 90 has been installed. The differences between this procedure and the procedure for the base machine (refer to page 31) are as follows:

- ❑ You have to select G3 or G4 before you input a Quick Dial or Speed Dial
- ❑ You may have to input a subaddress for a G4 number if the destination has one.

1. **Function** **3** **1**

- ❑ At this time, you can print a Quick Dial List if you press **→** **Start** .

QUI CK DI AL	CHOOSE KEY
<input checked="" type="checkbox"/> —	PRI NT LI ST →
	NO TO CANCEL

2. Press the Quick Dial Key that you wish to program.

Example: **01** **Yes**

QUI CK DI AL	ENTER FAX NUMBER
<input checked="" type="checkbox"/> 01 <G3>	NO TO CANCEL
—	

3. Change the line type (G3/G4) to the correct setting by pressing the G4/G3 Selector key on the operation panel.

QUI CK DI AL	ENTER FAX NUMBER
<input checked="" type="checkbox"/> 01 <G4>	NO TO CANCEL
—	

4. Enter the telephone number at the operation panel's ten key pad.

QUI CK DI AL	YES OR CLR . NO
<input checked="" type="checkbox"/> 01 <G4>	
7005551234	

G3 numbers - If your machine is behind a PBX, include the PBX access code and a pause before the number. For an international number, place a pause after the country code.
 G4 numbers - If you wish to enter a subaddress, press the User Function Key that you have already programmed as the subaddress key. Then enter the subaddress.



To enter a subaddress, you must use a User Function Key. See page 163 for how to program a User Function Key using Function 35.

5. **Yes**

QUI CK DI AL	ENTER LABEL
<input checked="" type="checkbox"/> 01	<input type="text" value="ABC"/>

6. Either:

- ☐ Program a label for this number: go to step 7.
- ☐ Do not program a label: **Yes** . Go to step 8.

7. Input a label using the Quick Dial keys.
Then press **Yes** .

QUI CK DI AL	OPTI ON SETTI NG
LABEL I NSERTI ON	ON OFF
SELECT	<input type="button" value="←"/> <input type="button" value="→"/> YES TO END

8. Switch Label Insertion on or off.

Use the and arrows on the scroll key to select the required setting.
Then press **Yes** .

QUI CK DI AL	CHOOSE KEY
<input checked="" type="checkbox"/> <input type="text" value=""/>	PRI NT LI ST <input type="button" value="→"/>
	<input type="button" value="NO"/> TO CANCEL

9. Either

- ☐ Program another Quick Dial: go to step 2.
- ☐ Finish: **Function** .

Note

The procedure for storing a Speed Dial using Function 32 is exactly similar to that shown above; it is the same as the procedure for the base machine except that you have to select G3 or G4 and you may need to input a subaddress.

Automatic Fallback from Group 4 Mode to Group 3 Mode

If your machine cannot communicate with the other party using Group 4 mode, it will try using Group 3 mode. This will allow your machine to send the message even if you selected Group 4 mode instead of Group 3 mode by mistake.


Terminal ID

Instead of the TTI, a Group 4 communication will transmit a variety of information, including an identifier known as the Terminal ID, which identifies the other party in the same way as a TTI.


The contents of the Terminal ID are programmed by a service technician.

The make-up of the Group 3 TTI and the Group 4 Terminal ID is as shown below.

Group 3



Group 4




- ☐ Date, TTI, Page No., and Label Insertion are transmitted in the data signal, superimposed on the image.
- ☐ Receiver (Rx) Terminal ID, Transmitter (Tx) Terminal ID, Date (Group 4), Page No. (Group 4), are transmitted in the Group 4 handshake signals.
- ☐ The Receiver and Transmitter Terminal IDs have up to 24 characters. The Date (Group 4) is in the YY-MM-DD-HH:MM format. The Page No. (Group 4) has up to 7 characters.

Explanation of the Items in the Group 4 Identifier

Transmitter and Receiver Terminal IDs

The following example shows what happens when the two communicating terminals are connected to two different ISDNs. Each ISDN has its own country code.



At the top of the received page, the following will be seen.

1 - 201558310 = N.J./44 - 818905566 = LDN/(Date)/(Page No.)

The zero in the London area code and the other pauses in the phone numbers are not represented on the printout.

The country code and terminal ID are programmed by the service technician at installation.

Date and Time

The date and time in the receiving machine are printed.

Page Number

001-001 (File number followed by page number)

Example: Batch Transmission

Receiving a three-page file and a two-page file

First page: 001-001	Fourth page: 002-001
Second page: 001-002	Fifth page: 002-002
Third page: 001-003	

Switching the Command Information Line On/Off



This is similar to the TTI On/Off switching option for Group 3 Transmission (see page 64).

The Command Information Line consists of the Receiver and Transmitter Terminal IDs, the Date and Time, and the Page Number. Normally, this line is printed at the top of each of the pages you transmit when they are received at the other end. The top of the image will be overprinted if there is no margin at the top of the transmitted page.

In some cases, you may wish the other party to receive an unmarked copy of your original. In this case, you can switch the Command Information Line off.

Note: If you switch the Command Information Line off, make sure that Label In - section is also off if you want the image received at the other end to be un - marked.

To switch this feature on or off, do the following. (See page 10 if you need more information about the User Parameter settings adjustment procedure).

1. **Function** **6** **0** **2** **2** **2** **2** **9** **1**

USER PARAMETER	PRI NT LI ST	→
DEFAULT:	01000000	↑
SW TCH00:	01000000	YES TO END ↓

2. The settings for switch 00 are now shown on the bottom line of the display.

SWITCH00: 00000000

3. Press **↓** until the settings for switch 01 are shown.
The setting you need to use is digit 5.

SWITCH01: 00000000

Digit 5
0: This feature is Off.
1: This feature is On.

4. If you wish to change the setting, press **5** .

5. Finish: **Yes** **Function**

Terminal ID Verification

This feature helps you to make sure that your communications do not go to the wrong place. However, like Protection Against Wrong Connections, it will not help you if you dial the wrong number.

If the Terminal ID of the other party does not match the label stored with the Quick Dial or Speed Dial that you used to dial the other party with, the communication will be stopped.

For this function to work:

- ☐ You must store the destination as a Quick or Speed Dial.
- ☐ You must make sure that the labels that you program in the Quick/Speed Dials exactly match the Terminal IDs that are actually stored in the destination fax machines.

Cross-reference

Terminal ID: see page 240.
Quick Dial: see page 31.

Speed Dial: see page 34.

Troubleshooting

Call Progress Signals (CPS)

Sometimes, a Call Progress Signal and an error message will appear on the display panel. Possible messages are as follows.

DI ALI NG	The machine is dialing; do not press Stop.
REMOTE TERMI NAL BUSY	Try again later.
WRONG NUMBER	Check the number, and check that G3 or G4 was correctly selected. Then redial.
LI NE NOT AVAI LABLE	Try again later.
FAX NUMBER CHANGED	Find out the new fax number.
REMOTE FAX REJECTED	Contact the user at the other end.
UNABLE TO CONNECT	Try again.
NO RESPONSE	Try again.
NETWORK BUSY	Try again later.
CLASS I NCOMPATI BLE	The other terminal's signaling mode is not compatible with yours, and the message cannot be sent.
CHECK I NTERFACE	Check that the ISDN line cord is connected properly. Then try again.

To remove the message from the display, make sure that the Communicating indicator is not lit, then press **Stop** .

GLOSSARY

ADF (Automatic Document Feeder):

A device which feeds the pages of a multipage document one at a time, in the order that you arranged the pages in the stack.

Batch Numbering (Page Count):

This is a way of numbering pages that allows you to check whether you received all pages, and if not, which ones are missing. For example, if you receive two pages with p1/3 printed on one and p2/3 on the other, you have just received a three-page document but page 3 didn't make it.

BPS (Bits Per Second):

This is the data communication rate. In G3 mode, your fax terminal digitizes documents, transforming them into 'bits' - binary digits - (an average page will produce about 200,000 of them), and then sends them out at a top speed of 9,600 to 14,400 bps, depending on the model.

Broadcasting:

In G3 fax communication terminology, broadcasting is the transmission of a document to more than one address in sequence, not simultaneously.

CCITT

Consultative Committee for International Telephone and Telegraph. This committee sets international standards for communication.

Communication:

Transmission or reception.

Copy:

When used as a noun, this refers to a printout, either in copy mode or receive mode

Country Code:

In international dialing, this is the code that directs the call to the country where the terminal that you wish to send to is located.


CSI:

Called Subscriber Identification.  page 25.

Default Setting:

See "Factory Setting".

Dial Pulses:

These are dialing signals that your terminal sends out if it uses pulse dialing ( page 28).

Document:

This is the original page or set of pages that you wish to send.

DPI (Dots Per Inch), or l/mm (Lines Per Millimeter):

This is the unit of resolution. The scanner scans your document according to the selected resolution. An 8-1/2" x 11" page is broken down into about 1,728,000 dots if standard resolution is used. (Digital compression techniques for G3 convert these into about 200,000 bits.)

ECM (Error Correction Mode): This is signaling method that is designed to eliminate transmission errors on even the noisiest of telephone lines. See page .

EFC:

This is a proprietary digital data compression technique. It shortens the time for sending a page.

Factory Setting:

The factory setting of a function is the state into which it was programmed at the factory; this will also be the state of that function in a new machine. It can also referred to as "Default Setting".

File:

☞ Memory File, Polling File.

Group 3:

This is an internationally-agreed signaling and data transfer method used for facsimile communication (approved by CCITT). It is also known as G3.

Handset:

This is the telephone that is connected to the jack marked "TEL 1 or TEL 2".

Home Position:

Some of your machine's features can be adjusted. The home position is the setting to which the machine always returns at the end of an operation.

International Dialing Code:

This is the code that must be dialed at the beginning of the number if the destination is outside your country.

Memory File:

This is a document stored in the SAF memory (see the next page) and the instructions (destinations, time of transmission) for sending that document.

Modem:

Acronym for modulator/demodulator. A device that transforms a digital signal into a form suitable for transmission over the telephone network.

Original:

Same as "Document".

Page Retransmission:

If the terminal you are sending to indicates that it did not properly receive the page you just sent, your terminal will resend that page from memory. This only works if you used Memory Mode and if you are not using ECM. (ECM is a more effective data retransmission method.)

Polling File:

This is a set of instructions (destinations to be polled, time of polling) for polling reception.

Pulse Dialing:

This method of dialing uses a string of pulses to represent each dialed digit.

Reception:

The act of receiving a document.

Reduction:

If your document is wider than the paper available in the other terminal, your terminal will automatically reduce it so that it will fit.

Remote Terminal:

The facsimile terminal that you are sending to or receiving from.

RTI:

Remote Terminal Identification. ➡ page 25.

Sending:

Same as "Transmission", see below.

Standby Mode:

The terminal is said to be in standby mode when it is idle.

Terminal:

A facsimile terminal, such as your machine.

Tone Dialing:

This method of dialing uses a tone to represent each dialed digit.

Transmission:

The act of sending a document.

TTI:

Transmit Terminal Identification. ➡ page 25.

INDEX

A

Add Paper Indicator	194
Add Toner Indicator	195 - 198
AI Redial	20
Making a telephone call	78
Sending a fax	73
AI Short Protocol	184
Area Code Prefix	84
Authorized Reception	132
Authorized Reception List	133, 192
On/Off switch	134
Auto Document	106
Auto Receive Mode	75
Auto Reduce	63
Automatic Group 4 to Group 3 Fallback	240

B

Batch Transmission	124
Broadcasting	51
Using an OMR Sheet	172
Buzzer	
Alarm	53
Volume Control	80

C

Call Progress Signals (CPS)	243
Center Mark, on/off	147
Chain Dialing	116
Checkered Mark, on/off	148
Clear Copy Indicator	215 - 217
Clear Original indicator	53, 213
Clock	24
Closed Network	
Reception	152
Transmission	121
Command Information Line (CIL), on/off	242
Communication Failure Report	185
Communication Result Display	179
Confidential File Indicator	127
Confidential File Report	128, 186
On/Off Switch	128
Confidential ID	127
Confidential ID Override Option	105
Confidential Reception	126
Confidential Transmission	104
Continuous Polling Reception	159
Contrast	55
Copy Jam	215 - 217
Copy Mode: Multi-copy	181
Copy paper	16
Changing the size	200
Copy Paper Replacement	194

Correcting Mistakes

Dialing	8, 52 - 53
Erasing a file from memory	161
Input	8
Wrong Function Number	8
Counters	179
Listed on reports	190
Country Code	83
CPS (Call Progress Signals)	243
CSI (Called Subscriber Identification)	27

D

Date and Time	24
Daylight Saving Time	24
Dedicated Transmission Parameters	228
Destination Check	52
Dialing	50, 51
Direct Fax Number Entry	68
Document Feeder	
Acceptable originals	45 - 46
Adjustment knob (blue)	214
Document Jam	213 - 214
Document size, allowable	45
Document types, allowable	46
Dual Access	182

E

ECM (Error Correction Mode)	123
Economy Transmission	66
Economy Transmission Time	67
Erasing a Memory File	161
Error Codes	225 - 226
Error Report	185, 189, 225 - 226

F

Faxing, basic procedure	49
File List	190 - 191
File Retention Time	
0 hr/24 hr/72 hr selection switch	160
File Retransmission	160
Forwarding	134, 224
Forwarding List	136, 193
Forwarding Mark, on/off	140
On/Off switch	140
Function Programs	164

G

Grounding	14
Group Dial List	192
Group Transfer Station	86
How to use	92 - 93
Programming	41

Groups	30
Programming	38
Programming by OMR Sheet	171
Using a Group	51, 86

H

Halftone	55
Halftone Type Selection	56
Handset	22, 78
Installation	22, 28

I

ID Codes	
Confidential ID	104, 127
ID Code	85
ID Code, use with ID Transmission	65
ID Code, use with Polling Reception	159
ID Code, used with Secure Polling	155
ID Code, used with Stored ID Override	156
ID Code, used with Transfer Request	87
Memory Lock ID	129 - 130
ID Transmission	65
Immediate Transmission	47, 69
Inch-to-millimeter conversion	182
Indicators	19
Add Paper	194
Add Toner	195 - 198
Clear Copy	215 - 217
Clear Original	53, 213
Confidential File	127
Line Fail	53, 218
Receive File	75
Installation	21
International dialing	31, 50

K

Keystroke Programs	99
--------------------	----

L

Label Insertion	120
Language Selection	23
Length Reduction	150
Lightning protection	14 - 15
Line Fail Indicator	53, 218, 221

M

Manual Receive Mode	74
Memory % Display	6
Memory Lock	19, 129 - 130, 140, 224
Memory Lock ID	129
On/Off switch	130

Memory Storage Report	185
On/Off switch	187
Memory Transmission	48, 69
Multi-sort Document Reception	146
Multi-step Transfer	82, 93
Multicopy Mode	181

N

Next Transfer Station	
How to use	91
Programming	235

O

OMR Sheets	166
On Hook Dial	77, 79
On/Off Switches	9
Authorized Reception	134
Auto Reduce	64
Center Mark	147
Checkered Mark	148
Command Information Line (CIL)	242
Confidential File Report	128
File Retention Time	160
Forwarding	140
Forwarding Mark	140
Image sample on reports	188
Memory Lock	130
Memory Storage Report	187
Ordering Toner	197
Polling Clear Report	187
Polling Reserve Report	187
Polling Result Report	187
Power Saver	178
RDS	183
Reception Time	149
Rejection of Messages from	
Unidentified Senders	131
Restricted Access	113
Reverse Order Printing	145
Service Report Transmission	227
Specified Cassette Selection	143
Substitute Reception	76
TCR (Transaction Confirmation Report)	187
Transfer Request by Tonal Signals	95
Transmission Result Report	187
Two-in-one	151
Ordering Toner	197
Ozone	17, 21

P

Page Count	62
Page Retransmission	123
PBX, dialing from behind	31, 50
PC Printer Mode	180
Personal Code List	111, 192
Personal Codes	59, 110
Programming	110
Use with Label Insertion	120
Use with Restricted Access	113
Use with Transmission	59
Polling	153
Canceling a Polling Operation	161
Continuous Polling Reception	159
Polling Reception	158
Polling Standby Duration	157
Polling Transmission	154
Secured Polling	155
Stored ID Override (Polling Reception)	159
Stored ID Override (Polling Transmission)	156
Polling Clear Report	186
On/Off switch	187
Polling Confirmation List	187
Polling Reserve Report	186
On/Off switch	187
Polling Result Report	186
On/Off switch	187
Power Failure Report	186
Power Saver	176
On/Off switch	178
Power supply	14
Printing a file from memory	162
Program List	101, 192
Programming	
Area Code Prefix	84
Authorized Reception	133
Confidential ID	127
Country Code	83
CSI (Called Subscriber Identification)	27
Date and Time	24
Daylight Saving Time	24
Economy Transmission Time	67
Forwarding	134
Function Programs	164
Group Dial	38
Group Transfer Station	41
ID Code	85
Language Selection	23
Memory Lock ID	129
Multi-sort Document Reception	146

Next Transfer Station	235
On/Off Switches	9
Personal Codes	110
Power Saver	177
Quick Dial	31
Quick Dial (ISDN)	238
RTI (Remote Terminal Identification)	26
Speaker and Buzzer Volume	80
Specified Cassette Selection	141
Speed Dial	34
Speed Dial (ISDN)	238
Telephone Directory	34
Telephone Line Type	28
TTI (Transmit Terminal Identification)	26
User Function Keys	163
User Parameters	10
Using an OMR Sheet	170 - 171, 175
Your Machine's ISDN Group 3 Number	234
Your Machine's ISDN Group 4 Number	233
Your Machine's Telephone Number	84
Protection against wrong connections	122

Q

Quick Dial	29
Programming	31, 238
Programming by OMR Sheet	170
Using a Quick Dial number	50 - 51
Quick Dial Keys	20
Quick Dial List	31, 192

R

RDS (Remote Diagnostic System)	183, 224
Receive File Indicator	75
Reception	
Auto Receive Mode	75
Confidential Reception	126
Manual Receive Mode	74
Mode Selection	74
Substitute Reception	75
Reception Time, on/off	149
Redialing	20, 72
Reduction	
Auto Reduce	63
Length Reduction	150
Replacing Copy Paper	194
Replacing the Stamp	199
Replacing the Toner Cassette	195 - 198

Reports

Authorized Reception List	133, 192
Communication Failure Report	185
Confidential File Report	186
Error Report	185, 189, 225 - 226
File List	190 - 191
Forwarding List	136, 193
Group Dial List	192
Memory Storage Report	185
Memory Storage Report, on/off	187
Personal Code List	111, 192
Polling Clear Report	186
Polling Clear Report, on/off	187
Polling Confirmation List	187
Polling Reserve Report	186
Polling Reserve Report, on/off	187
Polling Result Report	186
Polling Result Report, on/off	187
Power Failure Report	186
Program List	101, 192
Quick Dial List	31, 192
Service Report	227
Specified Cassette Selection List	142, 193
Speed Dial List	34, 192
TCR (Transaction Confirmation Report)	185, 189, 191
TCR, on/off	187
Transfer Result Report	186
Transmission Deadline Report	187
Transmission Result Report	185
Transmission Result Report, on/off	187
User Function List	164, 192
User Parameter List	190, 193
Resolution	55
Default setting	57
Restricted Access	110
On/off switch	113
Reverse Order Printing	145
RTI (Remote Terminal Identification)	26

S

Secure Transmission	117
Send Later	60
Sending a Fax	49
Service Report Transmission	227
Shift Key	8
Short Preamble	184
Speaker Volume	80
Specified Cassette Selection	141
On/Off switch	143

List	142, 193
Specified Image Area	118
Speed Dial	29
Programming	34, 238
Programming by OMR Sheet	170
Using a Speed Dial number	50 - 51
Speed Dial List	34, 192
Stamp	19, 71
Use during transmission	71
Replacement	199
Standby Mode	6
Subaddress	233
Substitute Reception	75
On/Off switch	76

T

TCR (Transaction Confirmation Report)	185, 189, 191
On/Off Switch	187
Telephone Directory	
How to use	58
Programming	34
Telephone Line Type	10, 28
Telephoning	
Making a Telephone Call	77
Phoning and faxing on the same call	79
Receiving a call	79
Using On Hook Dial	77, 79
Using the Handset	78
Terminal ID	240
Terminal ID Verification	243
Tonal Signals	115
Toner cartridges	16
Toner Cassette Replacement	195 - 198
Transfer	
Multi-step	93
Two-step	91
Transfer Request	82, 87, 186
Using an OMR Sheet	173
Transfer Result Report	186
Transfer Station	81, 87
Your machine as	94
Transmission	
Basic Procedure	49
Broadcasting	51
Chain Dialing	116
Direct Fax Number Entry	68
Immediate	47, 69
Immediate Transmission	69
ISDN	237
Memory	48, 69
Secure Transmission	117
Tonal Signals	115
Using AI Redial	73
Using an OMR Sheet	172, 174

Transmission Deadline (TRD)	61
Transmission Deadline Report	187
Transmission mode	
Default setting	70
Transmission Result Report	185
On/Off Switch	187
TTI (Transmit Terminal Identification)	
	26
TTI On/Off	64
Two-in-one	151
Two-step Transfer	82, 91

U

User Function Keys	20, 163
User Function List	164, 192
User Maintenance Procedures	203 - 212
User Parameter List	190, 193
User Parameters	10
Programming by OMR Sheet	170

V

Voice Request	67, 80
Volume Control, Speaker & Buzzer	80

W

Well Log Transmission	125
Wild Cards	144

Y

Your Machine's ISDN Group 3 Number	234
Your Machine's ISDN Group 4 Number	233
Your Machine's Telephone Number	84

OFFICIAL NOTICE TO USERS

USA

FCC Requirements

1. This equipment complies with Part 68 of the FCC rules. On the cover of this equipment is a label that contains, among other information, the FCC registration number and ringer equivalence number (REN) for this equipment. If requested, this information must be provided to the telephone company.
2. This equipment uses the following USOC jack: RJ11C
3. The REN is used to determine the quantity of devices which may be connected to the telephone line. Excessive REN's on the telephone line may result in the devices not ringing in response to an incoming call. In most, but not all areas, the sum of the REN's should not exceed five (5.0). Contact the telephone company to determine the maximum REN for the calling area.
4. If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. If advance notice is not practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.
5. The telephone company may make changes in its facilities, equipment, operations, or procedures that could affect the operation of the equipment. If this happens, the telephone company will provide advance notice in order for you to make necessary modifications in order to maintain uninterrupted service.
6. In the event of operation problems (document jam, copy jam, communication error indication), refer to the solving problems section in this manual.
7. If you cannot correct the problem, please contact the RICOH CORP. CUSTOMER SUPPORT DEPT. at 1-800-FASTFIX for repair and warranty information. If it is causing harm to the telephone network, the telephone company may request you to disconnect the equipment from the network until the problem is resolved.
8. This equipment cannot be used on telephone company-provided coin service. Connection to Party Line Service is subject to state tariffs.

WHEN PROGRAMMING EMERGENCY NUMBERS AND/OR MAKING TEST CALLS TO EMERGENCY NUMBERS:

1. Remain on the line and briefly explain to the dispatcher the reason for the call before hanging up.
2. Perform such activities in the off-peak hours, such as early morning hours or late evenings.

CANADA

The Canadian Department of Communications label identifies certified equipment. This certification means that the equipment meets certain telecommunications network protective, operational, and safety requirements. The department does not guarantee that the equipment will operate to the user's satisfaction. Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier.

Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment. Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines, and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

Caution: Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as appropriate.

The standard connecting arrangement code for this equipment is CA11A or CB-1D.

The Load Number (LN) assigned to each terminal device denotes the percentage of the total load to be connected to a telephone loop which is used by the device to prevent overloading. The termination of a loop may consist of any combination of devices subject only to the requirement that the sum of the load numbers of all the devices does not exceed 100.


FUNCTION LIST

NO.	FUNCTION	PAGE
11	Confidential Transmission	104
12	Transfer Request	87
13	Secured Polling Transmission	155, 156
14	Free Polling Transmission	154
15	Polling Reception	158
16	Direct Fax Number Entry	68
21	Erasing Memory Files	161
22	Erasing Polling Reception Files	161
23	Erasing Polling Transmission Files	161
24	Retransmitting a Fax Message from Memory	160
31	Programming Quick Dial/Printing the Quick Dial List	31
32	Programming Speed Dial/Printing the Speed Dial List	34
33	Programming Groups/Printing the Group Dial List	38
34	Keystroke Programs and Function Programs: Labeling and Erasing	101, 103
35	Programming User Function Keys/Printing the User Function Key List	163
36	Auto Documents: Labeling and Erasing	107, 109
37	Entering Printer Mode****	180
41	Printing the TCR/On-screen Communication Result Display	179, 191
42	Printing the File List	191
43	Printing the Quick Dial List	192
44	Printing the Speed Dial List	192
45	Printing the Group Dial List	192
46	Printing the Program List	192
47	Printing the User Function List	192
51	Printing the Contents of a Memory File	162
52	Printing the Contents of a Polling File	162
53	Printing an Auto Document	108
54	Printing Blank OMR Sheets	174
55	Printing a Confidential Message*	127
56	Printing from Memory Lock*	130
Functions 60 and above can only be used after a password has been entered.		
61	System Set-up: Your Country Code, Your Fax Terminal's Telephone Number, ISDN G4 and G3 Telephone Numbers**, Your Inter-city Access Code (Area Code Prefix), Next Transfer Station **, ID Code, Confidential ID*, Memory Lock ID*, Remote ID, RTI, TTI, CSI	83, 84, 233, 234, 84, 235, 85, 127, 129, 95, 26, 26, 27
71	Programming Personal Codes/Printing the Personal Code List	110, 192
72	Programming Authorized Reception/Printing the Authorized Reception List	132, 192
74	Programming the Economy Transmission Time and the Power Saver	67, 176
75	Programming Forwarding/Printing the Forwarding List*	134, 193
76	Programming Specified Cassette Selection/Printing the Specified Cassette Selection List****	141, 193
77	Programming the Number for Multi-sort Document Reception*	146
81	On/Off Switches	9
91	Programming the User Parameters/Printing the User Parameter List	10, 193
92	Programming the Date and Time	24
93	Adjusting the Speaker and Buzzer Volume	80
94	Selecting the Language on the Display and Reports	23
95	Checking the Counters	179
96	Specified Image Area	118

*: Memory card or hard disk required, **: Group 4 kit required

: At least one optional extra paper feed unit required, *: Printer interface kit required

CERTIFICATION LABEL



Certification Label

RICOH UNITECHNO CO., LTD.

713
TSURUGASONE YASHIO-SHI
SAITAMA-KEN JAPAN.

Complies with FDA radiation performance
standards, 21 CFR Subchapter J.

MANUFACTURED:



PPC2100S HS

SUPPLIES

CAUTION: Ricoh shall not be responsible for any damage or expense that may result from the use of parts other than recommended parts.

TONER CASSETTES

☐ TONER CASSETTE TYPE 30 is recommended for the best performance.

STAMP

☐ MARKER TYPE 30 is recommended for the best performance.

RICOH

Headquarters: Ricoh Corporation, 5 Dedrick Place, West Caldwell, NJ 07006. 201-882-2000
U.S. Government Marketing: Ricoh Corporation, 1700 N. Moore Street, Suite 1200, Arlington, VA 22209. 703-525-3234
Rico Company Ltd., 15-5, Minami-Aoyama 1-Chome, Minato-ku, Tokyo 107, Japan



Part No. H5134302 Printed in Japan