

Model U-P1
(Machine Code: G071)

SERVICE MANUAL

IMPORTANT SAFETY NOTICES

PREVENTION OF PHYSICAL INJURY

1. Before disassembling or assembling parts of the printer and peripherals, make sure that the printer power cord is unplugged.
2. The wall outlet should be near the printer and easily accessible.
3. If any adjustment or operation check has to be made with exterior covers off or open while the main switch is turned on, keep hands away from electrified or mechanically driven components.
4. The printer drives some of its components when it completes the warm-up period. Be careful to keep hands away from the mechanical and electrical components as the printer starts operation.
5. The inside and the metal parts of the fusing unit become extremely hot while the printer is operating. Be careful to avoid touching those components with your bare hands.

HEALTH SAFETY CONDITIONS

Toner and developer are non-toxic, but if you get either of them in your eyes by accident, it may cause temporary eye discomfort. Try to remove with eye drops or flush with water as first aid. If unsuccessful, get medical attention.

OBSERVANCE OF ELECTRICAL SAFETY STANDARDS

1. The printer and its peripherals must be serviced by a customer service representative who has completed the training course on those models.
2. The NVRAM module (option) installed on the controller has a lithium battery which can explode if replaced incorrectly. Replace the NVRAM only with an identical one. The manufacturer recommends replacing the entire NVRAM. Do not recharge or burn this battery. Used NVRAM must be handled in accordance with local regulations.

SAFETY AND ECOLOGICAL NOTES FOR DISPOSAL

1. Do not incinerate toner bottles or used toner. Toner dust may ignite suddenly when exposed to an open flame.
2. Dispose of used toner, the maintenance unit which includes developer or the organic photoconductor in accordance with local regulations. (These are non-toxic supplies.)
3. Dispose of replaced parts in accordance with local regulations.
When keeping used lithium batteries in order to dispose of them later, do not put more than 100 batteries per sealed box. Storing larger numbers or not sealing them apart may lead to chemical reactions and heat build-up.
4. When keeping used lithium batteries in order to dispose of them later, do not put more than 100 batteries per sealed box. Storing larger numbers or not sealing them apart may lead to chemical reactions and heat build-up.

LASER SAFETY

The Center for Devices and Radiological Health (CDRH) prohibits the repair of laser-based optical units in the field. The optical housing unit can only be repaired in a factory or at a location with the requisite equipment. The laser subsystem is replaceable in the field by a qualified Customer Engineer. The laser chassis is not repairable in the field. Customer engineers are therefore directed to return all chassis and laser subsystems to the factory or service depot when replacement of the optical subsystem is required.


WARNING

Use of controls, or adjustment, or performance of procedures other than those specified in this manual may result in hazardous radiation exposure.

WARNING

WARNING: Turn off the main switch before attempting any of the procedures in the Laser Optics Housing Unit section. Laser beams can seriously damage your eyes.

CAUTION MARKING:



Trademarks

Microsoft®, Windows®, and MS-DOS® are registered trademarks of Microsoft Corporation in the United States and /or other countries.

PostScript® is a registered trademark of Adobe Systems, Incorporated.

PCL® is a registered trademark of Hewlett-Packard Company.

Ethernet® is a registered trademark of Xerox Corporation.


PowerPC® is a registered trademark of International Business Machines Corporation.

Other product names used herein are for identification purposes only and may be trademarks of their respective companies. We disclaim any and all rights involved with those marks.


Conventions in this Manual

This manual uses several symbols.

Symbol	What it means
	Refer to section number
	See Core Tech Manual for details
	Screw
	Connector
	Clip ring
	E-ring



Lengthwise, SEF (Short Edge Feed)



Sideways, LEF (Long Edge Feed)

TABLE OF CONTENTS

1. INSTALLATION.....	1-1
1.1 INSTALLATION REQUIREMENTS.....	1-1
1.1.1 ENVIRONMENT	1-1
1.1.2 MACHINE LEVEL	1-1
1.1.3 SPACE REQUIREMENTS.....	1-2
1.1.4 POWER REQUIREMENTS.....	1-2
1.2 MACHINE INSTALLATION.....	1-3
1.3 OPTIONS.....	1-4
1.4 REMARKS FOR INSTALLATION	1-5
2. PREVENTIVE MAINTENANCE	2-1
2.1 OVERVIEW	2-1
Users Do the User PM Procedures	2-1
All PM Done by Technicians	2-1
Counters	2-1
2.2 USER MAINTENANCE.....	2-1
Main Unit.....	2-1
Optional Paper Tray Unit.....	2-2
2.3 SERVICE MAINTENANCE	2-2
Main Unit.....	2-2
Optional Units.....	2-3
3. REPLACEMENT AND ADJUSTMENT.....	3-1
3.1 SPECIAL TOOLS.....	3-1
3.2 EXTERIOR COVERS	3-2
3.2.1 REAR COVER	3-2
3.2.2 LOWER LEFT COVER	3-3
3.2.3 UPPER COVER, OPERATION PANEL	3-3
3.3 ELECTRICAL COMPONENTS.....	3-4
3.3.1 PRINTER CONTROLLER.....	3-4
3.3.2 CONTROLLER BOX.....	3-4
3.3.3 BCU BOARD.....	3-4
3.3.4 I/O BOARD	3-5
3.3.5 PSU	3-5
3.3.6 HIGH VOLTAGE SUPPLY BOARD	3-6
3.4 DRIVE UNITS	3-7
3.4.1 DEVELOPMENT CLUTCHES.....	3-7
K/Y Development Units	3-7
C/M Development Units	3-7
3.4.2 DEVELOPMENT MOTOR.....	3-8
3.4.3 MAIN MOTOR.....	3-8
3.4.4 PCU GEAR BOX AND OPC BELT CLEANING CLUTCH.....	3-9
3.4.5 FUSING UNIT MOTOR.....	3-9
3.4.6 PAPER FEED MOTOR.....	3-10

3.4.7	PAPER FEED CLUTCH.....	3-10
3.4.8	REGISTRATION CLUTCH.....	3-10
3.5	LASER OPTICS SECTION.....	3-11
3.5.1	CAUTION DECAL LOCATION.....	3-11
3.5.2	LASER OPTICS HOUSING UNIT.....	3-12
	Adjusting for Image Skew	3-14
	Laser Beam Pitch Adjustment	3-15
3.5.3	POLYGONAL MIRROR MOTOR AND LSD.....	3-16
3.6	DEVELOPMENT UNIT	3-17
3.7	PHOTOCONDUCTOR UNIT (PCU).....	3-19
3.7.1	MAIN UNIT.....	3-19
3.7.2	WASTE TONER BOTTLES	3-20
3.7.3	CHARGE CORONA WIRE.....	3-21
3.7.4	CHARGE CORONA WIRE CLEANER MOTOR	3-22
3.7.5	OPC BELT CLEANING UNIT.....	3-22
3.7.6	IMAGE TRANSFER BELT CLEANING UNIT.....	3-22
3.8	PAPER TRANSFER UNIT	3-23
3.8.1	VERTICAL TRANSPORT UNIT	3-23
3.8.2	TRANSFER ROLLER	3-23
	Cleaning the Paper Dust Mylar	3-24
3.9	FUSING/PAPER EXIT	3-25
3.9.1	FUSING UNIT	3-25
3.9.2	OIL SUPPLY UNIT.....	3-25
3.9.3	LAMPS.....	3-26
3.9.4	FUSING INNER UNIT	3-27
3.9.5	PRESSURE ROLLER THERMOFUSE.....	3-27
3.9.6	FUSING BELT UNIT AND PRESSURE ROLLER UNIT	3-27
3.9.7	PRESSURE ROLLER THERMISTOR	3-28
3.9.8	HOT ROLLER STRIPPERS.....	3-28
3.9.9	PRESSURE ROLLER.....	3-29
3.9.10	OIL ABSORBERS.....	3-30
3.9.11	PAPER EXIT UNIT AND PAPER EXIT/ OVERFLOW SENSOR	3-31
3.10	PAPER FEED AND TRANSPORT.....	3-32
3.10.1	FEED ROLLER AND FRICTION PAD	3-32
3.10.2	REGISTRATION SENSOR.....	3-33
3.10.3	PAPER FEED SENSOR.....	3-35
3.10.4	PAPER NEAR-END SENSOR.....	3-35
3.10.5	PAPER END SENSOR	3-35
3.11	BYPASS TRAY.....	3-36
3.11.1	PICKUP/FEED ROLLER.....	3-36
3.11.2	PAPER FEED CLUTCH.....	3-37
3.11.3	REVERSE ROLLER	3-37
4.	TROUBLESHOOTING.....	4-1
4.1	SERVICE CALL.....	4-1
4.1.1	SERVICE CALL CONDITIONS.....	4-1
4.1.2	SC TABLE.....	4-2

4.2	CONTROLLER ERROR TABLE	4-9
4.3	BLOWN FUSE CONDITIONS.....	4-12
4.4	CHECK POINTS FOR IMAGE PROBLEMS AT REGULAR INTERVALS.....	4-12
5.	SERVICE TABLES.....	5-1
5.1	SERVICE PROGRAM MODE.....	5-1
5.1.1	OPERATION PANEL KEYS.....	5-1
5.1.2	STARTING SERVICE PROGRAM MODE	5-2
	Procedure 1.....	5-2
	Procedure 2.....	5-2
5.1.3	MAIN MENU	5-2
5.1.4	SPECIFYING A VALUE OR SETTING	5-3
5.1.5	LEAVING SERVICE MODE	5-3
5.2	SP MODE TABLES.....	5-4
5.2.1	SERVICE (CONTROLLER SERVICE MODES).....	5-4
	Bit Switch Settings	5-6
	Gamma Adjustment	5-8
5.2.2	ENGINE SERVICE MODES	5-11
	SP1-XXX: (Feed)	5-11
	SP2-XXX: (Drum).....	5-15
	SP3-XXX: (Process).....	5-27
	SP5-XXX: (Mode).....	5-30
	SP7-XXX: (Data Log)	5-38
	Input Check Table	5-46
	Table 1: Tray 1 Paper Size	5-49
	Table 2: 1st/2nd Bank Paper Size.....	5-49
	Table 3: 1st/2nd Bank Near End	5-49
	Output Check Table	5-50
5.3	CONTROLLER SELF-DIAGNOSTICS.....	5-52
5.3.1	OVERVIEW.....	5-52
5.3.2	DETAILED SELF-DIAGNOSTICS.....	5-53
5.4	USER PROGRAM MODE.....	5-54
5.5	UPGRADING SOFTWARE.....	5-55
5.5.1	OVERVIEW.....	5-55
5.5.2	UPGRADING	5-56
	Procedure.....	5-56
	Error Recovery	5-57
5.6	DIP SWITCHES.....	5-58
	Controller Board	5-58
	BCU Board.....	5-58
5.7	PRINTING A TEST PATTERN	5-59
6.	DETAILED SECTION DESCRIPTIONS.....	6-1
6.1	OVERVIEW	6-1
6.1.1	MAJOR COMPONENTS.....	6-1
6.1.2	PAPER PATH	6-2
6.1.3	DRIVE COMPONENTS	6-3

6.1.4	ELECTRICAL COMPONENTS	6-4
	Image Transfer.....	6-4
	Development Units.....	6-5
	Paper Path	6-6
	Drive Components	6-7
	Circuit Boards.....	6-8
6.2	PRINTING PROCESS OVERVIEW	6-9
6.3	PROCESS CONTROL.....	6-11
6.3.1	OVERVIEW.....	6-11
6.3.2	PROCESS CONTROL STEPS	6-12
	Six Steps.....	6-12
	When is Process Control Done?	6-12
6.4	PHOTOCONDUCTOR UNIT (PCU).....	6-13
6.4.1	OVERVIEW.....	6-13
6.4.2	NEW PHOTOCONDUCTOR UNIT DETECTION.....	6-14
	New PCU Sensor.....	6-14
	Mechanism.....	6-14
	PCU Counter.....	6-14
6.4.3	CHARGE CORONA UNIT.....	6-15
	Power Supply	6-15
	Wire Cleaning.....	6-15
	Cleaning Interval	6-15
	Quenching.....	6-16
6.4.4	OPC BELT DRIVE	6-16
6.4.5	OPC BELT CLEANING UNIT.....	6-17
	Toner Collection Augers.....	6-17
	Counter Blade + Brush.....	6-17
	Waste Toner Bottle Sensors	6-17
	Drive.....	6-18
6.4.6	IMAGE TRANSFER BELT UNIT.....	6-19
	Drive.....	6-19
	Belt Mark Sensor.....	6-19
	Bias Roller.....	6-20
6.4.7	TRANSFER BELT CLEANING UNIT	6-21
	Bias Brush.....	6-21
	Bias Roller and Cleaning Blade.....	6-21
	Collecting Coil	6-21
	Waste Toner Bottle Sensors	6-21
	Contact Mechanism	6-22
	Power Supply	6-23
	Drive.....	6-23
6.5	LASER EXPOSURE	6-24
6.5.1	OVERVIEW.....	6-24
	Dust Shield Glass Cleaning	6-25
	LD Unit Adjustment	6-25
	Polygonal Mirror	6-25
	Laser Diode Power Control	6-25
	Maintenance Adjustment.....	6-25
6.5.2	LD SAFETY SWITCH	6-26

Operation Panel Message and Switch Mechanism	6-27
6.6 DEVELOPMENT	6-28
6.6.1 OVERVIEW.....	6-28
6.6.2 DEVELOPMENT UNIT	6-29
Rollers and Agitators.....	6-29
Replacing Units.....	6-29
Memory Chip.....	6-29
6.6.3 TONER SUPPLY MECHANISM	6-30
Toner Cartridge Agitators.....	6-30
Drive Power Path	6-30
Development Unit Agitator	6-30
Toner Supply Roller and Doctor Roller.....	6-30
Shutter	6-30
6.6.4 TONER END DETECTION	6-31
Mechanism.....	6-31
Toner Near-End Detection	6-31
Toner End Detection	6-32
Toner End Recovery	6-32
6.6.5 DEVELOPMENT UNIT CONTACT MECHANISM	6-33
Mechanism.....	6-33
Reverse Rotation	6-33
6.6.6 POWER SOURCE	6-34
Development, Toner Supply, and Doctor Rollers	6-34
Doctor Roller	6-34
6.7 PAPER FEED	6-35
6.7.1 OVERVIEW.....	6-35
Transport Speed	6-36
Friction Pad.....	6-36
6.7.2 STANDARD TRAY DRIVE.....	6-36
Feed and Vertical Transport Rollers.....	6-36
Registration Roller.....	6-36
6.7.3 STANDARD TRAY – BOTTOM PLATE LIFT.....	6-37
Lift Mechanism	6-37
Paper Near End Detection	6-37
Paper End Detection	6-37
6.7.4 STANDARD TRAY - PAPER SIZE DETECTION.....	6-38
Mechanism.....	6-38
Switch Pattern.....	6-38
6.7.5 BYPASS TRAY	6-39
Paper Feed Mechanism	6-39
Bypass Tray Drive Power Path	6-39
Pick-up Solenoid	6-39
Paper End Sensor.....	6-39
6.8 PAPER TRANSFER AND SEPARATION.....	6-40
6.8.1 OVERVIEW.....	6-40
Jammed Paper Release.....	6-40
Image Transfer and Paper Separation.....	6-40
6.8.2 MECHANISM.....	6-41
Timing	6-41

Mechanism.....	6-41
6.8.3 POWER SUPPLY	6-42
Electric Power Path.....	6-42
Transfer Roller Bias	6-42
Discharge Plate.....	6-42
Temperature/Humidity Control	6-42
Roller Cleaning.....	6-43
6.9 FUSING UNIT AND OIL SUPPLY UNIT	6-44
6.9.1 OVERVIEW.....	6-44
6.9.2 FUSING UNIT CONFIGURATION.....	6-45
Fusing Belt	6-45
Oil Supply.....	6-45
Heating Roller Lamp	6-45
Pressure Roller Lamp	6-45
Pressure Roller Pawls.....	6-45
Fusing Bias	6-46
Fusing Unit SCs	6-46
6.9.3 TEMPERATURE CONTROL	6-47
6.9.4 OIL SUPPLY AND CLEANING	6-48
Oil Supply.....	6-48
Oil Path	6-48
Oil Recycling	6-48
Belt Cleaning.....	6-48
Oil End Detection	6-49
Fusing unit switch.....	6-49
6.9.5 DRIVE.....	6-49
Drive Power Path (Fusing Unit and Oil Supply Roller)	6-49
Drive Power Path (Pressure Roller)	6-49
6.9.6 ENERGY SAVER MODE.....	6-50
Level 1 Energy Saver Mode (default: off).....	6-50
Level 2 Energy Saver Mode	6-50
Ready Mode.....	6-50
6.9.7 PAPER EXIT.....	6-51
Drive Power Path	6-51
Paper Jam Detection.....	6-51
6.9.8 OVERFLOW DETECTION.....	6-51
6.10 PRINTED CIRCUIT BOARDS	6-52
6.10.1 PRINTER CONTROLLER.....	6-52
Function	6-52
Memory	6-52
Interfaces	6-52
Slots	6-53
Options.....	6-53
DIP Switch.....	6-53
LED Indicators.....	6-53
6.10.2 BASE ENGINE CONTROL UNIT (BCU).....	6-54
Function	6-54
Upgrading.....	6-54
Nonvolatile Random Access Memory (NVRAM)	6-54

DIP Switch.....	6-54
6.10.3 INPUT/OUTPUT (I/O) BOARD.....	6-55
6.10.4 POWER SUPPLY UNIT (PSU)	6-55
6.10.5 HIGH VOLTAGE SUPPLY	6-55
6.11 CONTROLLER	6-56
6.11.1 OVERVIEW.....	6-56
6.11.2 BOARD LAYOUT	6-58
6.11.3 PRINT DATA PROCESSING.....	6-59
RPCS Driver.....	6-59
PCL5c Driver.....	6-59
PS3 Driver.....	6-60
CMS (Color Management System)	6-60
Gray Correction.....	6-60
BG/UCR (Black Generation/Under Color Removal)	6-60
Gamma Correction.....	6-60
Toner Limitation	6-61
Dither Processing and ROP/RIP	6-61
6.11.4 CONTROLLER FUNCTIONS.....	6-62
Sample Print.....	6-62
Locked Print	6-62
Paper Source Selection	6-63
Auto Continue	6-64
Paper Output Tray.....	6-65
Stapling	6-66
6.12 IEEE1394 INTERFACE	6-67
6.12.1 SPECIFICATIONS	6-67
Hardware Specification	6-67
System Requirements.....	6-67
6.12.2 IEEE1394.....	6-67
6.12.3 BLOCK DIAGRAM	6-68
6.12.4 PIN ASSIGNMENT	6-68
6.12.5 REMARKS ABOUT THIS INTERFACE KIT	6-69
6.12.6 TROUBLESHOOTING NOTES.....	6-69
6.12.7 IP OVER IEEE 1394	6-70
6.13 IEEE 802.11B (WIRELESS LAN)	6-71
6.13.1 SPECIFICATIONS	6-71
6.13.2 BLOCK DIAGRAM.....	6-71
6.13.3 TRANSMISSION MODE	6-72
Ad hoc Mode.....	6-72
Infrastructure Mode	6-72
6.13.4 SECURITY FEATURES.....	6-73
Using the SSID in Ad hoc mode.....	6-73
6.13.5 TROUBLESHOOTING NOTES.....	6-74
Communication Status	6-74
Channel Settings.....	6-74
Troubleshooting Steps	6-75
6.14 USB	6-76
6.14.1 SPECIFICATIONS	6-76
6.14.2 USB 1.1/2.0.....	6-76

6.14.3 USB CONNECTORS	6-77
6.14.4 PIN ASSIGNMENT	6-77
6.14.5 REMARKS	6-78
Related SP Mode	6-78

PERIPHERALS

PAPER TRAY UNIT (G313)

1. REPLACEMENT AND ADJUSTMENT	G313-1
1.1 REAR COVER	G313-1
1.2 PAPER FEED CLUTCH.....	G313-1
1.3 LIFT MOTOR	G313-2
1.4 PAPER FEED MOTOR.....	G313-2
1.5 CONTROLLER BOARD.....	G313-2
1.6 PICK-UP/FEED/SEPARATION ROLLERS	G313-3
2. DETAILED DESCRIPTIONS	G313-4
2.1 MECHANICAL COMPONENT LAYOUT	G313-4
Feed and Reverse Roller (FRR).....	G313-4
Drive Path	G313-4
Paper End Feeler Method	G313-4
2.2 ELECTRICAL COMPONENT LAYOUT	G313-5
2.3 DRIVE LAYOUT	G313-6
2.4 PAPER SIZE DETECTION	G313-7
2.5 PAPER LIFT	G313-8
2.6 PAPER HEIGHT AND END DETECTION	G313-9
Paper Height Detection	G313-9
Paper End Detection	G313-9

INTERCHANGE UNIT (G305)

1. REPLACEMENT AND ADJUSTMENT	G305-1
1.1 EXTERIOR COVER AND PAPER EXIT SENSOR	G305-1
1.2 CONTROL BOARD.....	G305-1
2. DETAILED DESCRIPTIONS	G305-2
2.1 ELECTRICAL COMPONENTS	G305-2
2.2 DRIVE.....	G305-2
2.3 MECHANISM.....	G305-3

DUPLEX UNIT (G303)

1. REPLACEMENT AND ADJUSTMENT	G303-1
1.1 EXTERIOR COVER.....	G303-1
1.2 ENTRANCE/EXIT SENSORS.....	G303-1

1.3	INVERTER MOTOR	G303-2
1.4	CONTROLLER BOARD.....	G303-2
1.5	TRANSPORT MOTOR	G303-2
2.	DETAILED DESCRIPTIONS	G303-3
2.1	OVERVIEW	G303-3
2.2	ELECTRICAL COMPONENT LAYOUT	G303-4
2.3	DRIVE LAYOUT	G303-5
2.4	DUPLEX PAPER FEED ORDER.....	G303-6
2.4.1	LONGER THAN A4/LT LEF	G303-6
2.4.2	UP TO A4/LT LEF	G303-7
2.5	REVERSE MECHANISM.....	G303-8

500-SHEET FINISHER (G314)

1.	REPLACEMENT AND ADJUSTMENT.....	G314-1
1.1	EXTERIOR COVERS	G314-1
	Front Cover	G314-1
	Rear Cover.....	G314-1
	Lower Guide.....	G314-2
	Upper Cover.....	G314-3
	Right Cover	G314-3
1.2	ENTRANCE UPPER GUIDE AND PAPER EXIT UNIT.....	G314-4
1.3	MOTORS	G314-5
1.3.1	MAIN MOTOR.....	G314-5
1.3.2	JOGGER MOTOR	G314-5
1.4	STAPLER	G314-6
1.5	PADDLE ROLLER SOLENOID.....	G314-6
1.6	MAIN CONTROL PCB.....	G314-7
1.7	OUTPUT TRAY UNIT	G314-8
2.	DETAILED DESCRIPTIONS	G314-10
2.1	OVERALL MACHINE INFORMATION.....	G314-10
2.1.1	COMPONENT LAYOUT	G314-10
2.1.2	DRIVE LAYOUT.....	G314-11
2.1.3	ELECTRICAL COMPONENTS	G314-12
2.2	DETAILED SECTION DESCRIPTIONS.....	G314-14
2.2.1	OUTPUT TRAY.....	G314-14
	Stack Height Detection.....	G314-14
	Output Tray Up/Down Mechanism	G314-15
2.2.2	PAPER FEED	G314-16
	Overview	G314-16
	Straight Feed-out Mode	G314-16
	Shift Sorting Mode.....	G314-17
	Stapling Mode	G314-19
2.2.3	JAM CONDITIONS	G314-20
2.2.4	ERROR DETECTION	G314-20

FOUR-BIN MAILBOX (G312)

1. REPLACEMENT AND ADJUSTMENT	G312-1
1.1 EXTERIOR COVER.....	G312-1
1.2 MAIN MOTOR AND CONTROLLER BOARD.....	G312-1
1.3 VERTICAL TRANSPORT AND PAPER OVERFLOW SENSORS.....	G312-2
2. DETAILED DESCRIPTIONS	G312-3
2.1 OVERVIEW	G312-3
2.2 DRIVE.....	G312-4
Drive Path	G312-4
2.3 ELECTRICAL COMPONENT LAYOUT	G312-5
2.4 PAPER DISTRIBUTION	G312-6
Mechanism.....	G312-6
Paper Overflow Sensor	G312-6
2.5 BASIC OPERATION.....	G312-7
2.6 PAPER MISFEED DETECTION TIMING.....	G312-7

SPECIFICATIONS

SPECIFICATIONS.....	Spec-1
1. GENERAL SPECIFICATIONS.....	Spec-1
1.1 MAIN UNIT.....	Spec-1
2. SUPPORTED PAPER SIZES	Spec-4
2.1 MAIN TRAY, BYPASS TRAY, AND DUPLEX UNIT	Spec-4
2.2 FINISHER, MAIL BOX, AND PAPER TRAY UNIT	Spec-5
3. SOFTWARE ACCESSORIES.....	Spec-6
3.1 PRINTER DRIVERS	Spec-6
3.2 UTILITY SOFTWARE	Spec-6
4. MACHINE CONFIGURATION	Spec-7
4.1 SYSTEM COMPONENTS.....	Spec-7
Exterior.....	Spec-7
Interior.....	Spec-8
Maintenance Kits.....	Spec-8
4.2 OPTIONAL EQUIPMENT	Spec-9
Paper Tray Unit.....	Spec-9
Finisher	Spec-9
Mail Box	Spec-10
Duplex Unit.....	Spec-10
Interchange Unit.....	Spec-10

1. INSTALLATION

1.1 INSTALLATION REQUIREMENTS


1.1.1 ENVIRONMENT

1. Temperature Range: 10°C to 32°C (50°F to 89°F)
2. Humidity Range: 20% to 80% RH
3. Ambient Illumination: Less than 2,000 lux (keep the machine out of direct sunlight.)
4. Ventilation: 3 times/hr/person or more
5. Avoid exposing the machine to sudden temperature changes, which include:
 - 1) Direct cool air from an air conditioner
 - 2) Direct heat from a heater
6. Avoid installing the machine in areas that may be exposed to corrosive gas.
7. Install the machine at a location lower than 2,500 m (8,200 ft.) above sea level.
8. Install the machine on a strong, level base. (☛ 1.1.2)
9. Avoid installing the machine in areas that may be subjected to strong vibration.

1.1.2 MACHINE LEVEL

- Front to back: Within 5 mm (0.2") of level
- Right to left: Within 5 mm (0.2") of level

1.1.3 SPACE REQUIREMENTS



- A: Over 100 mm (4")
- B: Over 100 mm (4")
- C: Over 550 mm (22")
- D: Over 750 mm (30")

G0701001.WMF

1.1.4 POWER REQUIREMENTS

<p>⚠ CAUTION</p> <ol style="list-style-type: none"> 1. Insert the plug firmly in the outlet. 2. Avoid using an outlet extension plug or cord. 3. Ground the machine.
--

1. Input voltage level:
 - 120 V, 60 Hz, More than 11 A
 - 220 to 240 V, 50/60 Hz, More than 7 A
2. Permissible voltage fluctuation: $\pm 10\%$
3. Do not put or place anything on the power cord.

1.2 MACHINE INSTALLATION

Refer to the Operating Instructions for details.

If the customer has a service contract, change the settings of the following SP modes depending on the contract type.

Item	SP No.	Function	Default
Meter charge	SP5-930-1 (Meter_Charge)	Specifies whether the meter charge mode is enabled or disabled. If the user is doing the user PM procedures, set meter charge to 'Off'. If the technician is doing all the PM, set meter charge to 'On'. Meter charge mode enabled: <ul style="list-style-type: none"> The Counter menu appears immediately after the Menu key is pressed. The counter type selected by the counting method (SP5-045-1, Counter Method) can be displayed with the Counter menu. The counter values can also be printed with the Counter menu. The selected counter starts from a negative number. Meter charge mode disabled: <ul style="list-style-type: none"> The Counter menu is not displayed. The total counter starts from 0. 	Off
Counting method	SP5-045-1 (Counter Method)	Specifies whether the counting method used in meter charge mode is based on developments or prints. Important: This SP can only be done before the negative counters are reset with SP7-825-001 (Counter Reset)	Developments
A3/11" x 17" double counting	SP5-104-1 (Double Count)	Specifies whether the counter is doubled for A3/11" x 17" paper.	No: Single counting
PM warning display 1	SP5-931-1 (PM_Display – Charger)	Specifies whether the PM warning for the charge corona unit is displayed when the replacement time arrives. 1: Displayed 0: Not displayed	1
PM warning display 2	SP5-931-2 (PM_Display – PCU)	Specifies whether the PM warning for the PCU is displayed. 1: Displayed 0: Not displayed	1



Item	SP No.	Function	Default
PM warning display 3	SP5-931-3 (PM_Display - Bank_Feed)	Specifies whether the PM warning for the feed rollers in the optional paper feed unit is displayed. 1: Displayed 0: Not displayed	0
Fax No. setting	SP5-812-2 (FAX TEL No.)	Programs the service station fax number. The number is printed on the counter list when the meter charge mode is selected, so that the user can fax the counter data to the service station.	
Counter reset	SP7-825-1 (Counter Reset)	Resets the counters to 0. Important: This must be done at installation after all the above settings have been finished. The negative counters used in meter charge mode will be reset to zero.	

NOTE: 1) The default setting for this machine is meter-charge mode off.
2) The meter-charge counter cannot be reset.

1.3 OPTIONS

Refer to the Option Setup Guide for details.

No.	Optional Unit	Alternative	Requirements
1	500-sheet finisher	No. 2	<ul style="list-style-type: none"> No. 3 Hard disk or memory (extra 64 MB or more) for sort mode
2	4-bin mailbox	No. 1	<ul style="list-style-type: none"> No. 3
3	Interchange unit		
4	Duplex unit		<ul style="list-style-type: none"> No. 3
5	Paper tray unit		
6	Printer hard disk		
7	DIMM memory (64, 128, or 256 MB modules available)		
8	IEEE1394 interface unit		<ul style="list-style-type: none"> Extra 64 MB (or more) optional SDRAM module
9	User account enhancement unit		
10	IEEE802.11b (Wireless LAN)		

NOTE: 1) You cannot install the finisher and mailbox on the same machine.
2) You can install either 1 or 2 paper tray units.

1.4 REMARKS FOR INSTALLATION

In case you install this printer or you instruct customers to install, please note the following remark for development unit installation and replacement:

After installation or replacement of the development unit, print out the development unit check sheet by user mode (User Mode – Maintenance – Development Unit Check).

NOTE: For details please refer to the Quick Installation Guide.

2. PREVENTIVE MAINTENANCE

2.1 OVERVIEW

Users Do the User PM Procedures

The user does PM for the items in section 2.2. The technician does PM for the items in section 2.3. Meter-charge mode must be set to “off” (SP5-930 [Meter_Charge], ⚙ 5.2).

Preventive Maintenance

All PM Done by Technicians

The technician does PM for the items in sections 2.2 and 2.3. Meter-charge mode must be set to “on” (SP5-930, [Meter_Charge], ⚙ 5.2).

Counters

When a maintenance counter for a unit has reached the limit, the corresponding message is displayed on the operation panel. After completing the maintenance procedure for that item, reset the counter (SP7-804, [PM_Clear], ⚙ 5.2).

2.2 USER MAINTENANCE

Abbreviations:

Clean, **I**nspect, **L**ubricate, **R**eplace, **KP**rints, **KD**evelopments, **W**henever**N**ecessary

Main Unit

Item	KD		KP		Detection	Reset	Machine stops
	50	120	30	120			
T/B waste toner bottle		R*			Waste toner sensors	Auto-reset (sensor)	Yes
O/B waste toner bottle	R*				Waste toner sensors	Auto-reset (sensor)	Yes
Oil supply unit			R**		Oil end sensor/Oil supply unit counter	Manual reset	Yes
Fusing unit with paper feed roller				R	Exit sheet counter	Manual reset	Yes

* : Replacement period calculated for a 50% color ratio (the actual waste toner bottle condition is detected with the sensors)

** : Standard replacement period (the actual oil amount is detected with the sensor)

Item	KD			Detection	Reset	Machine stops
	60	120	240			
Black development unit		R		Dev. Bk counter*	Auto-reset (memory chip)	Yes
Color development unit	R			Dev. color counter*	Auto-reset (memory chip)	Yes
PCU (includes charge corona unit & dust filters)		R		PCU counter*	Auto-reset (new PCU sensor)	No

*Displayed with SP7-906 (PMCounter-PREV)

Item	WN	Detection	Reset	Machine stops	Remarks
Registration roller	C	None	None	No	① damp cloth and ② dry cloth
Dust shield glass (LD unit)	C	None	None	No	Built-in cleaning brush
Bottom plate pad	C	None	None	No	① damp cloth and ② dry cloth

Optional Paper Tray Unit

Item	150KP	Detection	Reset	Machine stops	Remarks
Feed, pick-up, and separation rollers	R	None	None	No	① damp cloth and ② dry cloth

2.3 SERVICE MAINTENANCE

Abbreviations:

Clean, Inspect, Lubricate, Replace, KiloPrints, KiloDevelopments, WheneverNecessary

Main Unit

Bypass Tray

Item	WN	Remarks
Feed Roller	C	① damp cloth and ② dry cloth
Pick-up Roller	C	① damp cloth and ② dry cloth
Separation Roller	C	① damp cloth and ② dry cloth

Optional Units***Paper Tray Unit***

Item	WN	Remarks
Relay Roller	C	① damp cloth and ② dry cloth
Bottom Plate Pad	C	① damp cloth and ② dry cloth

Finisher

Item	WN	Remarks
Rollers	C	① damp cloth and ② dry cloth
Sensors	C	Blower blush or dry cloth
Anti-Static Brush	C	Blower blush or dry cloth
Bushings	L	Launa oil when abnormal noise occurs
Stapler	R	Every 200K staples (estimated replacement period)

Mail Box

Item	WN	Remarks
Rollers	C	① damp cloth and ② dry cloth
Tray Paper Sensors	C	Blower blush or dry cloth

Duplex Unit

Item	WN	Remarks
Rollers	C	① damp cloth and ② dry cloth
Feed/exit sensors	C	Blower blush or dry cloth

Interchange Unit

Item	WN	Remarks
Paper Exit Sensor	C	Blower blush or dry cloth

3. REPLACEMENT AND ADJUSTMENT

CAUTION

Turn off the main power switch and unplug the machine before beginning any of the procedures in this section.

NOTE: This manual uses the following symbols.

 : See or Refer to
  : Screws
  : Connector
  : Clip ring
 : E-ring

3.1 SPECIAL TOOLS


Part Number	Part Name
N8036701	Flash Memory Card - 4MB
G0219350	Loop-back connector - Parallel

Replacement
Adjustment

3.2 EXTERIOR COVERS


3.2.1 REAR COVER

1. Duct cover [A] (4 hooks)
2. Ozone filter [B]
3. Printer controller [C] (⚙ x 2)



G070R702.WMF


4. Rear cover [D] (⚙ x 2)



G070R703.WMF

3.2.2 LOWER LEFT COVER

1. Lower left cover [A] (⚙️ x 3)




G070R704.WMF

Replacement
Adjustment

3.2.3 UPPER COVER, OPERATION PANEL

1. Open the right cover [A].
2. Upper right cover [B]
3. Paper exit cover [C] (⚙️ x 1)
4. Open the front cover [D].
5. Upper cover [E] (⚙️ x 4)
6. Operation panel [F] (4 hooks, ⚙️ x 2, ⚙️ x 1)

NOTE: Insert a screwdriver between the upper cover and the main unit and unhook the panel.



G070R701.WMF

3.3 ELECTRICAL COMPONENTS

3.3.1 PRINTER CONTROLLER


☛ 3.2.1

NOTE: Remove the NVRAM from the old controller board, and install it on the new one.

If the controller NVRAM is defective, reset the total counter to 0 after changing the NVRAM, if meter charge mode is enabled.

3.3.2 CONTROLLER BOX


1. Rear cover (☛ 3.2.1)
2. Cooling fan [A] (☛ x 2)
NOTE: When reassembling, install the fan with the label facing the inside.
3. Controller box [B] (☛ x 11)
NOTE: 1) Do not remove the BCU board base with the controller box.
2) When putting back the controller box, take care not to pinch the cable from the I/O board.



3.3.3 BCU BOARD


1. Controller box (☛ 3.3.2)
2. All ☛ (12)
3. 1 flat cable
4. BCU board base [A] (☛ x 5)
5. BCU board [B] (☛ x 5)

NOTE: Remove the NVRAM from the old BCU board, and install it on the new one.



3.3.4 I/O BOARD

1. Controller box (☛ 3.3.2)
2. All  (33)
3. I/O board [A] ( x 4)




G070R707.WMF

Replacement
Adjustment

3.3.5 PSU


1. Controller box (☛ 3.3.2)
2. Flywheel ( x 3) (☛ 3.4.1)
3. Duct [A] ( x 1,  x 1)
NOTE: When removing and reassembling the fan, install it with the label facing the outside.
4. PSU protector [B] ( x 1)
5. Unlink the main switch [C].
6. PSU base ( x 8,  x 4)
NOTE: 1) Remove the PSU [D] with the PSU base.
2) When reassembling, check that the main switch is linked to the PSU.



G070R717.WMF


3.3.6 HIGH VOLTAGE SUPPLY BOARD

1. Photoconductor unit (☞ 3.7)
2. Right inner cover (☞ 3.10.2)
3. Photoconductor unit rail [A] (🔩 x 2)



G070R719.WMF

4. 📏 [B] x 1
5. Bushing [C] x 1
6. High voltage supply board [D] (📏 x 17,
🔩 x 6)



G070R720.WMF


3.4 DRIVE UNITS

3.4.1 DEVELOPMENT CLUTCHES

1. Controller box (☛ 3.3.2)

K/Y Development Units


1. Unhook the lock [A] and pull out the clutch [B] (☛ x 1).



Replacement Adjustment


C/M Development Units

1. Flywheel [A] (☛ x 3)
2. Unhook the lock [B] and pull out the clutch [C] (☛ x 1).



3.4.2 DEVELOPMENT MOTOR


1. Controller box (☛ 3.3.2)
2. Development motor [A] (☛ x 1, ⚙ x 3)



G070R710.WMF

3.4.3 MAIN MOTOR


1. Controller box (☛ 3.3.2)
2. Flywheel [A] (⚙ x 3)
3. Main motor [B] (☛ x 1, ⚙ x 3)



G070R711.WMF

3.4.4 PCU GEAR BOX AND OPC BELT CLEANING CLUTCH


1. I/O board (☛ 3.3.4)
2. Main motor (☛ 3.4.3)
3. C/M development unit clutch (☛ 3.4.1)
4. Bracket [A] (🔩 x 2)
5. Tension spring [B]
6. 📏 x 1 [C]
7. Gear box and clutch assembly [D] (🔩 x 5)



G070R712.WMF

3.4.5 FUSING UNIT MOTOR


1. Rear cover (☛ 3.2.1)
2. Fusing unit motor (📏 x 1, 🔩 x 3) [A]



G070R713.WMF

3.4.6 PAPER FEED MOTOR


1. Rear cover (☛ 3.2.1)
2. Pull out the handle [A].
3. Paper feed motor [B] (☛ x 1,
⚙ x 3)



G070R714.WMF

3.4.7 PAPER FEED CLUTCH


1. Rear cover (☛ 3.2.1)
2. Pull out the handle [A].
3. Connector bracket [B] (☛ x 6,
⚙ x 2)
4. Paper feed clutch [C] (☛ x 1,
⚙ x 2)



G070R716.WMF

3.4.8 REGISTRATION CLUTCH

1. Rear cover (☛ 3.2.1)
2. Unhook the lock [A] and pull the clutch out [B] (☛ x 1).



G070R715.WMF


3.5 LASER OPTICS SECTION

⚠ WARNING
Turn off the main switch and unplug the machine before beginning any of the procedures in this section. Laser beams can cause serious eye injury.

3.5.1 CAUTION DECAL LOCATION



LD_CAUTION.TIF




G070R208.WMF

Replacement
Adjustment

⚠ DANGER
Turn off the main switch and disconnect the power plug from the power outlet before beginning any disassembly or adjustment of the laser unit. This printer uses a class-1 laser beam with a wavelength of 650 nm and an output of 7 mW. The laser can cause serious eye injury.


3.5.2 LASER OPTICS HOUSING UNIT

1. Open the left cover [A].
2. ID chip connectors [B] (Ⓜ x 4)
3. Development units [C] x 4




G070R301.WMF

4. Rear cover (☛ 3.2.1)
5. Left cover [D]
6. Lower left cover [E] (Ⓜ x 3)



G070R201.WMF


7. Controller box (☛ 3.3.2)
8. Flat cable [F]
NOTE: When reassembling,
 connect the flat cable with
 the blue side up.
9. Ⓜ x 4 [G]
10. Harness clamps [H]



G070R202.WMF


- 11. Open the front cover.
- 12. Remove the dust shield glass cleaner lever [A] from the dust shield glass cleaner.

NOTE: The dust shield glass cleaner lever is the blue lever at the right side of the main switch.



G070R209.WMF

- 13. LD cover [B] (⚙ x 2)
- 14. Laser optics housing unit [C] (⚙ x 4)




G070R203.WMF

Replacement
Adjustment


Adjusting for Image Skew

1. Positioning pin [A] (🔩 x 1)
2. Loosen 🔩 (x 4) [B].
3. Adjust the position of the laser optics housing unit [👉 NOTE].
4. Fasten 🔩 (x 4) [B].

NOTE: After changing the position of the laser optics housing unit, do not reinstall the positioning pin. Keep the pin in a safe place.



NOTE: When the image skews as shown, move the unit 1 mm in the direction of the black arrow as shown in the **upper** diagram.



Laser Beam Pitch Adjustment

1. Select test pattern 15 with SP5-955-1 (Test Pattern – Pattern).
2. Check if vertical black stripes can be seen.
 - a) If stripes cannot be seen (Figure 2), laser beam pitch adjustment is not required.
 - b) If stripes can be seen (Figure 1), laser beam pitch adjustment is required. Go on to the next step.





Figure 1

Figure 2

G070R952.WMF

Replacement Adjustment

3. To adjust the laser beam pitch, tighten or loosen the screw [A] on the LD unit holder.
4. Set SP 2-917 (Test Pattern) to 'On'. Then send a one-page job to the printer, or print an SMC list (SP 5-990-6, SP Print mode – Non default).
5. Repeat steps 2 through 4 until the black stripes disappear (Figure 2).



G070R820.WMF


3.5.3 POLYGONAL MIRROR MOTOR AND LSD

⚠ WARNING
Do not touch any edges of the polygon mirror, spring, or bracket. These edges can cause serious injury.

1. Development units, LD cover (☛ 3.5.2)

2. Cover [A] (🔩 x 1)

NOTE: Before removing the cover, clean the cover to prevent toner from entering into the unit.



G070R204.WMF


3. Polygonal mirror motor [B]

(🔩 x 1, 🛠 x 4)

NOTE: Do not touch the surface of the polygonal motor.

4. Synch. detection board (LSD) [C]

(🔩 x 1, 🛠 x 1)



G070R205.WMF




3.6 DEVELOPMENT UNIT

⚠ CAUTION

Do not touch the development unit sleeves or ID chip terminals.

1. Open the left cover [A].
2. ID chip connector [B]
3. Lift up the development unit [C] slightly, and pull it out of the machine.


NOTE: Remove the units in the order K, Y, C, M. For example, before removing the M unit, remove the K, Y, and C units first.



G070R301.WMF

Replacement
Adjustment


4. Peel off the toner cartridge seal [D].
5. Reinstall the toner cartridge in the development unit.



G070R901.WMF

6. Keep the development unit level and shake the development unit about 10 times from side to side.

NOTE: 1) Do not touch the development roller or the development roller gear.
2) Use caution not to drop the cartridge or to damage it.
3) If the cartridge has not been shaken well, the machine takes a longer time to initialize the development unit, or an error message or SC350 is displayed. When either of them is displayed, turn the main switch off and on.




G070R902.WMF

7. Install the development unit in the machine.

8. After installing the development unit, print out the "development unit check" sheet to confirm the correct installation of the development unit (Menu — Maintenance — Devp.UnitCheck).

NOTE: A white line or band may appear on one end of the paper if a development is incorrectly installed. To correct this, pull out the development unit partially (about 30 mm) [E] and slowly reinstall it.



G070R457.WMF

3.7 PHOTOCONDUCTOR UNIT (PCU)

3.7.1 MAIN UNIT



NOTE: 1) Before replacing any of the parts or consumables in this section, cover the floor with cloth or some sheets of paper.




2) Never tilt the unit. The toner may come out of the unit.

3) When handling the unit, grasp the brown (front) and green (top) grips. Never touch the OPC (left) or transfer (right) belts.



4) After removing the photoconductor unit, cover it with a light-proof sheet. Keep it in a dark place.




Replacement
Adjustment

G070R308.WMF

1. Open the front cover [A].
2. Open the right cover [B].
3. x 4
4. Pull the OPC unit [C] out of the machine.
5. Grasp the brown and green grips.
6. Lift the unit and remove it.


3.7.2 WASTE TONER BOTTLES

1. O/B waste toner bottle [A]



G070R302.WMF


2. T/B waste toner bottle [B]



G070R303.WMF

3.7.3 CHARGE CORONA WIRE


1. Modular cable [A]
2. Loosen  (x 1) [B]
3. Charge corona unit [C]



G070R304.WMF


Replacement Adjustment

4. Front bracket ( x 1) [D]
5. Grid [E]
6. Rear bracket [F]



G070R305.WMF


7. Front wire cover [G]
8. Rear wire cover [H]
9. Wire cleaner [I]
10. Unhook the corona wire [J].



G070R259.WMF

3.7.4 CHARGE CORONA WIRE CLEANER MOTOR

1. Charge corona unit (☛ 3.7.3)
2. Front motor cover [A] (🔩 x 3)
3. Motor [B]




G070R306.WMF

3.7.5 OPC BELT CLEANING UNIT

1. Photoconductor unit (☛ 3.7.1)
2. Charge corona unit (☛ 3.7.3)
3. Drive gear [A] (🔩 x 1)
4. Rear brace [B] (🔩 x 1)
5. Front brace [C] (🔩 x 1)
6. OPC belt cleaning unit [D] (🔩 x 2)


NOTE: Hold up the photoconductor unit while removing the OPC belt cleaning unit.



G070R315.WMF

3.7.6 IMAGE TRANSFER BELT CLEANING UNIT

1. Photoconductor unit (☛ 3.7.1)
2. Bracket [A] (🔩 x 2)
3. Image transfer belt cleaning unit [B]




G070R309.WMF

3.8 PAPER TRANSFER UNIT

3.8.1 VERTICAL TRANSPORT UNIT

1. Open the right lower cover [A].
2. Right cover [B] (⚙ x 1)




G070R451.WMF

Replacement
Adjustment

3.8.2 TRANSFER ROLLER

1. Brace [A] (⚙ x 1)
2. Guide [B]
- NOTE:** To remove the screws, turn the roller unit on its pivot.
3. Transfer roller [C]
(Ⓢ x 2, Bushing x 2, Bearing x 2)




G070R453.WMF

Cleaning the Paper Dust Mylar

–Quick Method–


1. Cover [A]
2. Sweep away paper dust with a blower brush [B].



G070R562.WMF

–When the paper dust has to be removed completely–

1. Bracket [C] (⚙ x 2)
2. Plate spring [D]
3. Metal roller [E]
4. Bearing [F][G]
5. Spring [H][I]
6. Clean the mylar [J] with a dry cloth.



G070R561.WMF


3.9 FUSING/PAPER EXIT

⚠ CAUTION

Turn off the main switch and wait until the fusing unit cools down before beginning any of the procedures in this section. The fusing unit can cause serious burns.

3.9.1 FUSING UNIT

1. Loosen the knob screw [A].
2. Pull the unit out of the machine.
3. Unhook the bottom stopper [B].
4. Grasp the rear end (marked with a green label) [C].
5. Release the unit [D] from the base plate [E].




G070R501.WMF

Replacement
Adjustment

3.9.2 OIL SUPPLY UNIT

NOTE: When removing either of the lamps (☛ 3.9.3), remove the knob screw (☛ 3.9.1) before removing the oil supply unit.

1. Fusing unit (☛ 3.9.1)
2. Put the fusing unit on a level place.
3. Oil supply unit [A]




G070R502.WMF

NOTE: 1) Do not touch the oiling felt.
2) When reassembling, push the top of the oil supply unit so that the front and rear hinges are correctly set.


3.9.3 LAMPS

1. Oil supply unit (☞ 0)
2. Gear bracket [A] (☞ x 2)
3. Upper cover [B] (☞ x 2, shoulder screw x 1)



G070R503.WMF


4. Terminals [C], [D] (☞ x 5)
NOTE: [C]: Pressure roller lamp terminals
 [D]: Heating roller lamp terminals



G070R504.WMF

5. Pull out the lamp (350 W) [E].
6. Pull out the lamp (770 W) [F].


NOTE: “350 W” and “770 W” are etched on the respective terminals.



G070R510.WMF

3.9.4 FUSING INNER UNIT


1. Lamps (☛ 3.9.3)
2. Drive gear [A]
3. Knob screw [B] (☞ x 1)
4. Heating roller lamp harness terminal [C] (☛ x 1)
5. Fusing inner unit [D] (☛ x 2, ☞ x 3)



Replacement Adjustment


3.9.5 PRESSURE ROLLER THERMOFUSE

1. Fusing inner unit (☛ 3.9.4)
2. Pressure roller thermofuse [A] (☛ x 2)




3.9.6 FUSING BELT UNIT AND PRESSURE ROLLER UNIT

1. Fusing inner unit (☛ 3.9.4)
2. Springs [A] [B]
3. Separate the fusing belt unit [C] and pressure roller unit [D].



3.9.7 PRESSURE ROLLER THERMISTOR

1. Pressure roller unit (☛ 3.9.6)
2. Pressure roller lower stay [A] (⚙ x 2)
3. Pressure roller thermistor holder [B] (⚙ x 1)
4. Pressure roller thermistor [C]




G070R509.WMF

3.9.8 HOT ROLLER STRIPPERS

1. Oil supply unit (☛ 3.9.2)
2. Fusing lamps (☛ 3.9.3)
3. Fusing inner unit (☛ 3.9.4)
4. Gear [A]

NOTE: Remove the gear before removing the stripper pawl assembly; otherwise, the gear may be damaged.

5. Hot roller stripper pawl assembly [B] (Spring x 1, ⚙ x 2)
6. Hot roller stripper pawl [C]




G070R552.WMF

Reassembling

1. Put the spring [D] on the pawl.
2. Put the left end of the pawl in the square opening [E].
3. Put the front and rear ends of the pawl in the holder [F].
4. Confirm that the pawl moves correctly.

3.9.9 PRESSURE ROLLER




G070R900.WMF

**Replacement
Adjustment**

1. Pressure roller unit (➔ 3.9.6)
2. Gear [A]
3. Hot roller stripper assembly [B] (🔧 x 2)
4. Front bracket [C] (🔧 x 1)
5. Bearing [D]
6. Pressure roller [E]

3.9.10 OIL ABSORBERS



G070R825.WMF

1. Fusing inner unit (☛ 3.9.4)
2. Absorber 1 [A]
3. Pressure roller unit (☛ 3.9.6)
4. Absorber holder [B] (🔩 x 1)
5. Absorber 2 [C]
6. Spring [D]
7. Absorber holder [E] (🔩 x 1)
8. Absorber 3 [F]
9. Spring [G]
10. Base bracket [H] (🔩 x 2)
11. Absorber holder [I] (🔩 x 1)
12. Absorber 4 [J]
13. Absorber 5 [K]
14. Absorber 6 [L]

3.9.11 PAPER EXIT UNIT AND PAPER EXIT/OVERFLOW SENSOR


⚠ CAUTION

Turn off the main switch and wait until the paper exit unit cools down before beginning any of the procedures in this section. The paper exit unit can cause serious burns.

1. Paper exit cover (☛ 3.2.3)
2. Paper exit unit [A] (☛ x 3,
🔧 x 1)

NOTE: Remove 2 connectors before removing the unit. To remove the last connector, remove the unit and turn it. The connector is on the bottom side.

3. Paper exit sensor [B]
4. Paper overflow sensor [C]




Replacement
Adjustment

G070R601.WMF

3.10 PAPER FEED AND TRANSPORT


3.10.1 FEED ROLLER AND FRICTION PAD

1. Paper tray [A]



G070R101.WMF


2.  x 1 [B]
3. Slide the shaft [C].
4. Feed roller [D] (1 hook)
5. Friction pad [E]



G070R102.WMF

3.10.2 REGISTRATION SENSOR


1. Front cover [A] (L-shaped-pin x 2)
2. Rear cover (☛ 3.2.1)
3. Upper cover (☛ 3.2.3)
4. Lower left cover (☛ 3.5.2)



G070R103.WMF

Replacement
Adjustment

5. Dust shield glass cleaning lever [B] (☛ 3.5.2)
6. Charge corona unit (☛ 3.7.3)
7. Right cover (☛ 3.8.1)
8. Left inner cover door [C]
9. Left inner cover [D] (☛ x 2)
10. Right inner cover [E] (☛ x 3)




G070R653.WMF

11. Terminal [A] (🔩 x 1)

NOTE: You have to remove the terminal to lift the transport stay (👁️ step 14).

12. Transport guide [B] (🔩 x 1)




G070R104.WMF

13. Drive gear [C] (1 hook)

14. Lift the transport stay [D] (🔩 x 2) and release the wire [E].

NOTE: You can see the wire clip from the rear of the machine.


15. Registration sensor [F] (🔩 x 1, 📏 x 1)



G070R105.WMF

3.10.3 PAPER FEED SENSOR


1. Lift the transport stay [A] (☛ 3.10.2)
2. Paper feed sensor [B] (☛ x 1)
NOTE: Unhook the rear two pawls first, move the feeler, and unhook the front pawl.



Replacement Adjustment


3.10.4 PAPER NEAR-END SENSOR

1. Lift the transport stay [A] (☛ 3.10.2)
2. Feeler [B]
3. Sensor bracket [C] (☛ x 1)
4. Paper near-end sensor [D] (☛ x 1)



3.10.5 PAPER END SENSOR


1. Lift the transport stay [A] (☛ 3.10.2)
2. Feeler [B]
3. Sensor bracket [C] (☛ x 2)
4. Paper end sensor [D] (☛ x 1)



3.11 BYPASS TRAY


3.11.1 PICKUP/FEED ROLLER

1. Bypass tray (🔩 x 3)
2. Upper cover [A] (🔩 x 3)



G070R151.WMF


3. Lift the paper end sensor feeler [B].
4. Pick-up roller [C] (1 hook)
5. Paper feed roller [D] (🔩 x 1)



G070R152.WMF


3.11.2 PAPER FEED CLUTCH

1. Upper cover (☛ 3.11.1)
2. Rear cover [A] (🔩 x 1)
3. Gear holder [B] (🔩 x 3)
4. Gears [C][D]




Replacement
Adjustment

5. Clutch [E] (🔩 x 1)



3.11.3 REVERSE ROLLER

1. Bypass tray (☛ 3.11.1)
2. Turn the unit upside down.
3. Bottom cover [A] (🔩 x 3)
4. Reverse roller [B] (🔩 x 1)



4. TROUBLESHOOTING

4.1 SERVICE CALL

4.1.1 SERVICE CALL CONDITIONS

Level	Definition	Reset Procedure
A	Fusing unit SCs displayed on the operation panel. The machine is disabled. The user cannot reset the SC.	Turn the main switch off then on before entering SP mode. Reset the SC (set SP5-810 [SC_Reset] to 1), then turn the main switch off then on again.
B	SCs that disable only the features that use the defective item. Although these SCs are not shown to the user under normal conditions, they are displayed on the operation panel only when the defective feature is selected.	Turn the main power switch off and on.
C	SCs that are not shown on the operation panel. They are internally logged.	Logging only
D	Turning the operation switch or main power switch off then on resets the SC. The SC is displayed on the operation panel. It is redisplayed if it occurs after the main power switch is turned on again.	Turn the main power switch off and on.

Trouble-
shooting

- NOTE:** 1) All SCs are logged.
 2) When an electrical circuit board has a problem, check the connections before replacing the PCBs.
 3) When a motor has a problem, check the mechanical load before replacing the motor or sensor.

4.1.2 SC TABLE

No. Definition		Symptom	Possible Cause
201	D	Polygon motor error	<ul style="list-style-type: none"> Defective polygon motor Defective harness
		<ul style="list-style-type: none"> The polygon motor starts operating. → The lock signal is not detected within 20 seconds. The polygon motor starts operating. → The lock signal is detected within 20 seconds. → After a 3-second waiting time, no lock signal is detected within 20 seconds. The polygon motor stops operating. → The lock signal is not detected within 20 seconds. The polygon motor is operating. → The lock signal remains undetected for 0.5 seconds. 	
220	D	1st beam synchronization error	<ul style="list-style-type: none"> Disconnected synchronization detector board Defective LD unit Defective BCU
		A polygon motor lock is detected; the LD door is closed; the LD remains on. → The LD error (1st beam synchronization error) continues for 0.5 seconds.	
221	D	2nd beam synchronization error	<ul style="list-style-type: none"> Disconnected synchronization detector board Defective LD unit Defective BCU
		A polygon motor lock is detected; the LD door is closed; the LD remains on. → The LD error (2nd beam synchronization error) continues for 0.5 seconds.	
230	D	FGATE on error	<ul style="list-style-type: none"> Defective BCU
		A transfer belt mark is detected. → No FGATE on signal is detected within 175+50 milliseconds.	
231	D	FGATE off error	<ul style="list-style-type: none"> Defective BCU
		A FGATE assert signal is detected. → The FGATE negate signal is not detected within 30 seconds.	
241	D	LD error	<ul style="list-style-type: none"> Defective LD unit
		An LD error continues for 0.5 seconds. (After an LD error is detected, an LD error release is written to the GAVD chip during monitoring.)	
280	D	Image transfer belt mark detection error	<ul style="list-style-type: none"> Defective BCU Poor electrical connection Noise
		<ul style="list-style-type: none"> An imaging process starts. → No belt mark is detected in 1 revolution. A color imaging process starts. → A mono color image is transferred. → FGATE becomes active. → No belt mark is detected in 1 revolution. Thick paper or OHP film is used. → The belt slows down. → No belt mark is detected in 1 revolution. 	
281	D	GAPCI communication error	<ul style="list-style-type: none"> Defective BCU
		Data is transferred. → The CPU does not detect the communication ACK signal from GAPCI.	
282	D	GAVD communication error	<ul style="list-style-type: none"> Defective BCU
		Data is transferred. → The CPU does not detect the communication ACK signal from GAVD.	

No. Definition		Symptom	Possible Cause
300	D	Charge corona unit electrical leak	<ul style="list-style-type: none"> • Short circuit in the charge corona unit • Defective high voltage supply board • Defective harness (BCU - high voltage supply board)
		The charge corona unit keeps outputting; the unit is operating at the minimum PWM duty value. → 4.5 Volt (or more) is returning for 60 milliseconds.	
301	D	Charge corona unit disconnection	<ul style="list-style-type: none"> • Defective PCU installation • Defective high voltage supply board • Defective harness (BCU - high voltage supply board)
		The charge corona unit keeps outputting. → The unit is operating at the maximum PWM duty value for 60 milliseconds.	
302	D	Charge grid electrical leak	<ul style="list-style-type: none"> • Short circuit in the charge grid • Defective high voltage supply board • Defective harness (BCU - high voltage supply board)
		The charge grid keeps outputting. → The returning voltage exceeds the target by 0.5 Volt or more for 120 milliseconds.	
305	D	Charge corona unit cleaner error	<ul style="list-style-type: none"> • Defective cleaner
		<ul style="list-style-type: none"> • Cleaning starts. → The lock signal is not detected within 30 seconds. • Cleaning starts. → The cleaner turns. → The lock signal is detected within 6 seconds. • The lock signal is detected while the unit is moving away from the HP. → The next lock signal is detected within 6 seconds after the unit has turned toward the HP. 	
350	D	Development error 1 (K/Y)	<ul style="list-style-type: none"> • Short circuit in the development unit • Defective high voltage supply board • Defective harness (BCU - high voltage supply board)
		A development process starts. → The returning voltage exceeds the target by 0.5 Volt or more for 60 milliseconds.	
351	D	Development error 2 (C/M)	<ul style="list-style-type: none"> • Short circuit in the development unit • Defective high voltage supply board • Defective harness (BCU - high voltage supply board)
		A development process starts. → The returning voltage exceeds the target by 0.5 Volt or more for 60 milliseconds.	
352	D	Development motor error	<ul style="list-style-type: none"> • Defective development motor
		<ul style="list-style-type: none"> • The development motor starts or changes speed. → The motor does not detect a 1-second lock signal within 3 seconds. • The development motor starts. → The lock signal is detected during normal operation. → The lock signal is interrupted for 1 second or more. 	

Trouble-shooting

No. Definition		Symptom	Possible Cause
400	D	1st transfer (image transfer) electric leakage (+)	<ul style="list-style-type: none"> • Short circuit in the image transfer unit • Defective image transfer belt • Defective high voltage supply board • Defective harness (BCU - high voltage supply board)
		Image transfer starts. → The process operates at the minimum PWM duty value. The returned current exceeds 1.8 V for 180 milliseconds.	
401	D	1st transfer (image transfer) electric leakage (-)	<ul style="list-style-type: none"> • Short circuit in the image transfer belt • Defective high voltage supply board • Defective harness (BCU - high voltage supply board)
		Image transfer starts. → The negative (-) output is at the maximum PWM duty value for 60 milliseconds.	
410	D	2nd transfer (paper transfer) electric leakage (+)	<ul style="list-style-type: none"> • Short circuit in the paper transfer unit • Defective high voltage supply board • Defective harness (BCU - high voltage supply board)
		Paper transfer starts. → The positive (+) output is at the minimum PWM duty value. → The returning voltage stays at 2.7 V or more for 60 milliseconds.	
411	D	2nd transfer (paper transfer) electric leakage (-)	<ul style="list-style-type: none"> • Short circuit in the paper transfer unit • Defective high voltage supply board • Defective harness (BCU - high voltage supply board)
		Paper transfer starts. → The negative (-) output is at the minimum PWM duty value. → The returning voltage stays at 4.5 V or more for 60 milliseconds.	
412	D	2nd transfer (paper transfer) disconnection (+)	<ul style="list-style-type: none"> • Right cover not closed • Defective transfer roller contact mechanism • Defective high voltage supply board • Defective harness (BCU - high voltage supply board)
		Paper transfer starts. → The positive (+) output is at the maximum PWM duty value for 60 milliseconds.	
413	D	2nd transfer (paper transfer) disconnection (-)	<ul style="list-style-type: none"> • Right cover not closed • Defective transfer roller contact mechanism • Defective high voltage supply board • Defective harness (BCU - high voltage supply board)
		Paper transfer starts. → The negative (-) output is at the maximum PWM duty value for 60 milliseconds.	

No. Definition		Symptom	Possible Cause
420	D	Discharge error (fusing bias)	<ul style="list-style-type: none"> Discharge pin short circuit Defective high voltage supply board Defective harness (BCU - high voltage supply board) Scratched fusing belt
		The discharge circuit is operating at the maximum PWM duty value for 60 milliseconds.	
421	D	Discharge plate error	<ul style="list-style-type: none"> Short circuit in the discharge plate Defective high voltage supply board Defective harness (BCU - high voltage supply board)
		During discharging, the leakage detection signal is low for 60 milliseconds.	
430	D	Transfer belt cleaning error	<ul style="list-style-type: none"> Short circuit in the transfer belt cleaning unit Defective high voltage supply board Defective harness (BCU - high voltage supply board)
		Cleaning is operating at the maximum PWM duty value for 60 milliseconds.	
440	D	Main motor error	<ul style="list-style-type: none"> Defective main motor
		<ul style="list-style-type: none"> The main motor starts or changes speed. → The lock signal does not continue for 1 second within 3 seconds. The main motor starts. → The lock signal is detected and operation proceeds normally. → The lock signal is interrupted for 1 second. 	
460	D	Temperature sensor error	<ul style="list-style-type: none"> Short circuit in the temperature sensor Defective circuit Defective connector
		The output is 4.5 V (or higher) or 0.3 V (or lower) for 12 seconds.	
461	D	Humidity sensor error	<ul style="list-style-type: none"> Short circuit in the humidity sensor Defective circuit Defective connector
		The output is 4.5 V (or higher) or 0.3 V (or lower) for 12 seconds.	
480	D	ID sensor error	<ul style="list-style-type: none"> Defective ID sensor Defective connector
		The ID sensor is being calibrated (process control, step 1) → While the LED is off, the output voltage is 0.5 V or lower.	
481	D	Transfer belt mark detection error	<ul style="list-style-type: none"> Defective main motor Image transfer belt out of position Belt mark blurred or absent
		The main motor is operating; and the lock signal is detected. → The belt mark sensor signal does not change for 120 milliseconds.	
502	B	2nd tray error	<ul style="list-style-type: none"> Defective paper height sensor Defective tray lift motor
		<ul style="list-style-type: none"> The tray lift motor turns on. → The top of the paper stack is not detected for 13 seconds. The tray is set. → The top of the paper stack is detected. → The bottom plate is lowered. → The stack detection is not cleared within 5 seconds. → These steps are repeated 4 times. 	

No. Definition		Symptom	Possible Cause
503	B	3rd tray error	<ul style="list-style-type: none"> Defective paper height sensor Defective tray lift motor
		<ul style="list-style-type: none"> The tray lift motor turns on. → The top of the paper stack is not detected for 13 seconds. The tray is set. → The top of the paper stack is detected. → The bottom plate is lowered. → The stack detection is not cleared within 5 seconds. → These steps are repeated 4 times. 	
515	D	Duplex unit communication error	<ul style="list-style-type: none"> Defective duplex unit board Defective BCU Defective IOB Defective connection (Main unit - Duplex unit)
		<ul style="list-style-type: none"> A connection error occurs. The signal is sent from the printer to the duplex unit every 3 seconds while paper is not transported by the unit. However, the duplex unit does not respond within 5 seconds. 	
520	D	Paper feed motor error	<ul style="list-style-type: none"> Defective paper feed motor
		<ul style="list-style-type: none"> The motor starts or changes speed. → The lock signal does not continue for 1 second within a 3-second interval. The motor starts. → The lock signal is detected and operation proceeds normally. → The lock signal is interrupted for 1 second. 	
541	A	Thermistor disconnection (heating roller)	<ul style="list-style-type: none"> Defective thermistor Thermistor loose connection Defective connector
		The fusing unit starts warm up to the print ready temperature. → The temperature does not reach 7°C for 10 seconds.	
542	A	Fusing warm-up timeout (heating roller)	<ul style="list-style-type: none"> Defective lamp (loose connection, thermostat failure, PSU, thermostat) Incorrect detection (loose thermistor connection, fusing - drawer loose connection)
		The main switch is turned on or a cover is closed. → The heating roller does not reach the warm-up temperature within 50 seconds.	
543	A	Overheat error (heating roller)	<ul style="list-style-type: none"> Short circuit Defective BCU board Defective PSU
		The heating roller thermistor detects 220°C for 5 seconds.	
544	A	Low temperature error (heating roller)	<ul style="list-style-type: none"> Defective lamp (loose connection, thermostat failure, PSU, thermostat) Incorrect detection (loose thermistor connection, fusing - drawer loose connection)
		During standby or operation, the heating roller thermistor detects 100 °C or less for 5 seconds.	
545	A	Full power error (heating roller)	<ul style="list-style-type: none"> Thermistor loose connection Fusing - drawer loose connection
		Fusing unit warm-up is complete. → The heating roller stops turning. → The heating roller lamp keeps outputting the maximum power for 30 seconds.	

No. Definition		Symptom	Possible Cause
546	A	Unstable temperature (heating roller)	<ul style="list-style-type: none"> • Thermistor loose connection • Fusing - drawer loose connection
		<ul style="list-style-type: none"> • The heating roller thermistor detects unstable temperature increases or decreases within 60 seconds. 	
551	A	Thermistor disconnection (pressure roller)	<ul style="list-style-type: none"> • Thermistor loose connection • Defective harness • Defective connector
		The pressure roller thermistor detects 7°C or lower for 30 seconds.	
552	A	Warm-up time over (pressure roller)	<ul style="list-style-type: none"> • Defective lamp (loose connection, thermostat failure, PSU, thermostat) • Incorrect detection (thermistor loose connection, fusing - drawer loose connection)
		The main switch is turned on or a cover is closed. → The fusing pressure roller does not reach the ready temperature within 200 seconds.	
553	A	Overheat error (pressure roller)	<ul style="list-style-type: none"> • Loose connection • Defective BCU board • Defective PSU
		The pressure roller thermistor detects 220°C for 5 seconds.	
554	A	Low temperature error (pressure roller)	<ul style="list-style-type: none"> • Defective lamp (loose connection, thermostat failure, PSU, thermostat) • Incorrect detection (thermistor loose connection, fusing - drawer loose connection)
		During standby or operation, the pressure roller thermistor detects 80°C or less for 5 seconds.	
555	A	Full power error (pressure roller)	<ul style="list-style-type: none"> • Thermistor loose connection • Fusing - drawer loose connection
		Fusing unit warm-up is complete. → The fusing pressure roller stops turning. → The pressure roller lamp keeps outputting the maximum power for 200 seconds.	
556	A	Unstable temperature (pressure roller)	<ul style="list-style-type: none"> • Thermistor loose connection • Fusing - drawer loose connection
		<ul style="list-style-type: none"> • The pressure roller thermistor detects unstable temperature increases or decreases within 60 seconds. 	
560	D	Zero cross error	<ul style="list-style-type: none"> • Defective relay circuit • Defective PSU • Incorrect power supply
		The main switch is turned on; the fusing relay turns on. → 50 Hz or 60 Hz is not detected within 5 seconds.	
670	D	No response from BCU at power on	<ul style="list-style-type: none"> • Loose connection • Defective controller • Defective BCU
680	D	EEPROM error	<ul style="list-style-type: none"> • Incorrect EEPROM connection
		The main switch is turned on. → EEPROM is not connected.	



Trouble-shooting



No. Definition		Symptom	Possible Cause
687	D	PER command error	<ul style="list-style-type: none"> Poor connection between BCU and controller Defective BCU Defective controller
		<ul style="list-style-type: none"> Some image data is transferred. → The controller does not report the necessary memory address. The PES command is issued. → The controller does not issue the necessary memory report (PER) command within 6 seconds.. 	
730	D	Four-bin mail box communication error	<ul style="list-style-type: none"> Defective mail box control board Defective BCU Defective IOB Incorrect installation
		<ul style="list-style-type: none"> A connection error occurs. The UART reports a communication error. In other cases than paper transport, after an every-3-second command is sent, the mail box does not respond within 5 seconds. 	
740	D	Finisher communication error	<ul style="list-style-type: none"> Defective finisher control board Defective board Defective BCU Defective IOB Incorrect installation
		<ul style="list-style-type: none"> A connection error occurs. The UART reports a communication error. In other cases than paper transport, after an every-3-second command is sent, the finisher does not respond within 5 seconds. 	
741	D	Finisher jogger motor error	<ul style="list-style-type: none"> Defective jogger motor Defective jogger home position sensor
		The jogger home position sensor (on/off) is not detected in a given time.	
742	D	Finisher stapler unit error	<ul style="list-style-type: none"> Defective stapler unit
		<ul style="list-style-type: none"> The stapler does not return to home position within 1 second. 	
743	D	Finisher output tray motor error	
		The stack height and lever sensors do not detect paper.	
744	D	Finisher output tray motor lock	<ul style="list-style-type: none"> Defective motor
		The tray is locked for 10 seconds.	
745	D	Finisher paper detection error	
		The stack height and lever sensors do not correctly detect paper.	
750	D	1st paper tray unit communication error	<ul style="list-style-type: none"> Defective paper tray unit control board Defective BCU Defective IOB Defective connection (Paper tray - main unit)
		<ul style="list-style-type: none"> A connection error occurs. The UART reports a communication error. In other cases than paper transport, after an every-3-second command is sent, the paper tray unit does not respond within 5 seconds. 	
751	D	2nd paper tray unit communication error	<ul style="list-style-type: none"> Defective paper tray unit control board Defective connection (1st - 2nd paper tray)
		<ul style="list-style-type: none"> After the 1st paper tray has recognized the 2nd paper tray, the trays cannot communicate with each other. After the 1st paper tray has recognized the 2nd paper tray, an ATM (CPU reset) is sent from the 2nd paper tray. 	

4.2 CONTROLLER ERROR TABLE

The table lists the controller error codes. If an error occurs, the code is displayed when the main switch is turned on or after the startup self-diagnostics.

NOTE: For the startup self-diagnostics, see section 5.3.

Code	Description	Required Action
640	BCU – Controller communication error (no response)	Turn the main switch off and on. Replace the controller. Replace the BCU.
641	BCU – Controller communication error (no response)	Turn the main switch off and on. Check the connection between BCU and controller. Replace the controller. Replace the BCU.
800	Video output error (K)	Data transfer starts to the BCU, but the transfer completion command does not return to the controller within the required time. Defective controller board
801	Video output error (Y)	
802	Video output error (M)	
803	Video output error (C)	
818	Watchdog error	Turn the main switch off and on. Replace the controller. See NOTE at the end of this table
819	Fatal error	Turn the main switch off and on. Check and/or replace the RAM DIMM. Check and/or replace the ROM DIMM. Replace the controller. See NOTE at the end of this table
820	Self-diagnostics error: CPU [XXXX]: Detailed error code	Turn the main switch off and on. Reinstall the controller system firmware. Replace the controller.
821	Self-diagnostics error: ASIC	Turn the main switch off and on. Reinstall the controller system firmware. Replace the RAM DIMM. Replace the controller board.
822	Self-diagnostics error: HDD (Hard Disk Drive) [XXXX]: Detailed error code	Turn the main switch off and on. Check that the HDD is properly connected to the controller. Replace the HDD. Replace the controller.
823	Self-diagnostics error: NIB [XXXX]: Detailed error code	Turn the main switch off and on. Replace the controller.
824	Self-diagnostics error: Standard NVRAM	Turn the main switch off and on. Check that the standard NVRAM is firmly inserted into the socket. Replace the NVRAM. Replace the controller.
827	Self-diagnostics error: Standard SRAM DIMM [XXXX]: Detailed error code	Turn the main switch off and on. Replace the SRAM DIMM. Replace the controller.

Code	Description	Required Action
828	Self-diagnostics error : ROM [XXXX]: Detailed error code	Turn the main switch on and off. Replace the ROM DIMM Replace the controller.
829	Self-diagnostics error: optional RAM [XXXX]: Detailed error code	Turn the main switch off and on. Replace the RAM DIMM. Replace the controller board.
835	Self-diagnostics error: Centronics interface [XXXX]: Detailed error code	Turn the main switch off and on. Check the connection between the Centronics connector and loop-back connector. Reconnect the loop-back connector. Replace the controller.
836	Self-diagnostics error: Font ROM (standard)	Turn the main switch off and on. Replace the standard ROM-DIMM.
838	Self-diagnostics error: Font ROM (clock generator)	Replace the controller.
850	Network interface error	Turn the main switch off and on. Replace the controller.
851	IEEE1394 interface error	Turn the main switch off and on. Replace the IEEE1394 interface board. Replace the controller.
853	IEEE802.11b error - card not detected (power-on)	Check the wireless LAN card connection. Replace the wireless LAN card.
854	IEEE802.11b error - card not detected (during operation)	Check the wireless LAN card connection. Replace the wireless LAN card.
855	IEEE802.11b error	Check the wireless LAN card connection. Replace the wireless LAN card.
856	IEEE802.11b interface board error	Check the wireless LAN interface board connection. Replace the interface board.
857	USB interface error detected.	Check the USB connections, make sure that they are securely connected. Replace the controller board.
860	HDD: Error detected at power up (partition error, unformatted disk, incorrect disk type)	Turn the main switch off and on. Reformat the HDD (SP 5-832-1 [HDD Init]). Replace the HDD.
861	HDD: Reboot error	Turn the main switch off and on. Check the connection between HDD and controller. Check and replace the cables. Replace the HDD. Replace the controller.
862	Defective sector management maximum	Replace the HDD.
863	HDD: Read error	Turn the main switch off and on. Replace the HDD. Replace the controller.
864	HDD: CRC error	Turn the main switch off and on. Replace the HDD.
865	HDD: Access error	Turn the main switch off and on. Replace the HDD.



Code	Description	Required Action
900	Electrical counter error	Turn the main switch off and on. Check the connection between NVRAM and controller. Replace the NVRAM. Replace the controller.
990	Software performance error	Turn the main switch off and on. Reinstall the controller and/or engine main firmware. See NOTE at the end of this table.
991	Unexpected software error	The machine does not stop and the SC code is not displayed. The machine automatically recovers. However, the SC code is logged in the engine summary sheet (SMC).
998	Application start error	Turn the main switch off and on. Check that the RAM DIMM and ROM DIMM are properly connected. Reinstall the controller system firmware. Replace the controller.
999	Program installation error	Controller DIP SW1 setting incorrect. Defective software on IC card. Controller software download error. Replace the controller.

NOTE: If a problem always occurs in a specific situation (for example, same printer driver settings, same image file), the problem may be caused by a software error. In this case, send the following data and information to your product specialist.

- Symptom/Possible causes/Action taken
- Summary sheet (SP mode '1 Service', [Print Summary])
- SMC All (SP5-990-2, SP print mode - All)
- Logged data (SP5-990-4, SP print mode - Logging)
- Printer driver settings used when the problem occurs
- All data displayed on the screen (SC code, error code, and program address where the problem is logged.)
- Image file which causes the problem, if possible

4.3 BLOWN FUSE CONDITIONS


Fuse	Rating		Symptom when turning on the main switch
	115V	220 ~ 240V	
Power Supply Board			
FU1 (N.A.)/ CB1 (Eur./Asia)	15A/125V	8A/250V	No response
FU2	6.3A/250V	3.15A/250V	No response
FU3	4A/125V	4A/125V	"Tray 2 Hardware Problem" is displayed. The optional tray does not operate.* ¹
FU4	4A/125V	4A/125V	"Ready" is displayed. The interchange unit (and the finisher and/or the 4-bin mail box and/or duplex) does not operate.* ²

*¹: Vaa (+24V) for the optional tray is cut.

*²: Vaa (+24V) for the interchange unit is cut.

4.4 CHECK POINTS FOR IMAGE PROBLEMS AT REGULAR INTERVALS

Symptoms for image problems at regular intervals depend on the circumference of certain components. The following diagram shows the possible symptoms (black or white dots at regular intervals).



G070T801.WMF

Color spots at 54-mm intervals: Development roller in the development unit

Abnormal image at 68-mm intervals: Transfer roller

Abnormal image at 188-mm intervals: Fusing belt in the fusing unit


Abnormal image at 125-mm intervals: Pressure roller in the fusing unit

5. SERVICE TABLES

5.1 SERVICE PROGRAM MODE

⚠ CAUTION
Before starting a service program, check that no data is coming into the printer. If data is coming in, wait until the data is completely processed.

5.1.1 OPERATION PANEL KEYS



Service
Tables

- | | |
|---------------|-----------------|
| [A]: Online | [E]: Down arrow |
| [B]: Menu | [F]: Enter |
| [C]: Escape | [G]: Form feed |
| [D]: Up arrow | [H]: Reset |

5.1.2 STARTING SERVICE PROGRAM MODE

You can enter service mode with either of the following procedures.

Procedure 1

1. Turn the main switch off.
2. Press the online key and the escape key at the same time, and hold them.
3. Turn the main switch on.
4. Wait until "SYSTEM ver V.x.xx. 1. Service" is displayed.
NOTE: "ver V.x.xx." indicates the machine's firmware version.

Procedure 2

1. Press the up arrow key and the down arrow key at the same time, and hold them for about 5 seconds.
NOTE: At this moment, the display does not change.
2. Press the enter key. "SYSTEM ver V.x.xx. 1. Service" is displayed.
NOTE: "ver V.x.xx." indicates the machine's firmware version.

5.1.3 MAIN MENU

1. The main menu has three sub menus (see below). Press the up arrow key or the down arrow key to scroll through these sub menus.
 - 1) Service: Goes to the controller service modes
 - 2) Engine: Goes to the engine service modes
 - 3) End: Exits from the main menu
2. Press the enter key.
3. Press the up arrow key or the down arrow key to scroll through the items in the selected sub menu.
4. To exit from the sub menu, press the escape key.

5.1.4 SPECIFYING A VALUE OR SETTING

1. Select the required item from the sub menu. The current setting is displayed.
2. Use the up arrow key or down arrow key to specify a new setting.
3. Press the enter key.
NOTE: If you do not press the enter key, the previous setting remains valid.
4. To exit from the sub menu item, press the escape key.

5.1.5 LEAVING SERVICE MODE

1. Select "3. End."
2. Press the enter key.

NOTE: You cannot exit from the main menu by pressing the escape key.

5.2 SP MODE TABLES

NOTE: In the Function/[Setting] column:

- The related pop-up screen name and function name (if any) appear in parenthesis following the function description.
- Comments are in *italics*.
- The setting range is enclosed in brackets, with the default setting written in **bold**.
- An asterisk (*) after the mode number means that this mode's value is stored in the NVRAM. If you do a RAM reset, all these SP modes will be returned to their factory settings.
- **DFU** stands for **Design/Factory Use** only. Values marked **DFU** should not be changed.

5.2.1 SERVICE (CONTROLLER SERVICE MODES)

Mode No. (Class 1 and 2)		Function / [Setting]
Bit Switch		
1	Bit Switch 1	(See "Bit switch Settings".) For use in Japan only.
2	Bit Switch 2	
3	Bit Switch 3	
4	Bit Switch 4	
Clear Setting		
1	Clear Setting	Initializes the settings in the "System" menu of the user tools.
Print Summary		
1	Print Summary	Prints the service summary sheet (a summary of all the controller settings).
DispVersion		
1	Disp Version	Displays the version of the controller firmware.
ToneCtlSet		
1	Tone (Factory)	Recalls the gamma settings. Select the factory, previous, or current setting.
2	Tone (Prev.)	
3	Tone (Current)	
ToneCtlSet		
1	*600 x 600 x 2 Photo	Selects the printing mode (resolution) for the printer gamma adjustment. When selecting a print mode, an asterisk (*) is displayed in the front of the mode.
2	600 x 600 x 2 Graph	
3	600 x 600 Text	
4	600 x 600 x 2 Text	
5	600 x 600 Photo	
PrnColorSheet		
1	ToneCtlSheet	Prints the test page to check the color balance before and after the gamma adjustment.
2	ColorChart	

Mode No. (Class 1 and 2)		Function / [Setting]
TonerCtlValue		
1	Black/Cyan/Magenta/Yellow 1	Adjusts the printer gamma for the mode selected with the "Tone Ctl Set" setting. [0 to 255 / 16 / 1/step]
2	Black/Cyan/Magenta/Yellow 2	[0 to 255 / 32 / 1/step]
3	Black/Cyan/Magenta/Yellow 3	[0 to 255 / 48 / 1/step]
4	Black/Cyan/Magenta/Yellow 4	[0 to 255 / 64 / 1/step]
5	Black/Cyan/Magenta/Yellow 5	[0 to 255 / 80 / 1/step]
6	Black/Cyan/Magenta/Yellow 6	[0 to 255 / 96 / 1/step]
7	Black/Cyan/Magenta/Yellow 7	[0 to 255 / 112 / 1/step]
8	Black/Cyan/Magenta/Yellow 8	[0 to 255 / 128 / 1/step]
9	Black/Cyan/Magenta/Yellow 9	[0 to 255 / 144 / 1/step]
10	Black/Cyan/Magenta/Yellow 10	[0 to 255 / 160 / 1/step]
11	Black/Cyan/Magenta/Yellow 11	[0 to 255 / 176 / 1/step]
12	Black/Cyan/Magenta/Yellow 12	[0 to 255 / 192 / 1/step]
13	Black/Cyan/Magenta/Yellow 13	[0 to 255 / 208 / 1/step]
14	Black/Cyan/Magenta/Yellow 14	[0 to 255 / 224 / 1/step]
15	Black/Cyan/Magenta/Yellow 15	[0 to 255 / 240 / 1/step]
ToneCtlSave		
1	ToneCtlSave	Stores the print gamma adjusted with the "Toner Ctl Value" menu item as the current setting. Before the machine stores the new "current setting", it moves the data currently stored as the "current setting" to the "previous setting" memory storage location.
Toner Limit		
1	TonerLimitPhot	Adjusts the maximum toner amount for image development. [100 to 400 / 260 / 1%/step]
2	TonerLimitText	[100 to 400 / 260 / 1%/step]

Bit Switch Settings

NOTE: These bit switches are all for use in Japan only.

How to Change Bit Switch Settings

1. Select "1. Service".
NOTE: "ver V.x.xx." indicates the machine's firmware version.
2. Press the enter key 2 times.
3. Press the up arrow key or down arrow key to display bit switches 1 through 4.
4. Press the enter key.
5. Press the up arrow key or down arrow key to select a column.
6. Press the enter key. The current value appears in the column.
7. Press the up arrow key or down arrow key to change the value.
8. Press the enter key. The changed value is stored.
9. Press the escape key 3 times.
10. Select "3. End".

```
SYSTEMver V.X.xx
1.Service
```

G070S501.WMF

```
<Bit Switch>
Bit Switch 1
```

G070S502.WMF

```
Bit Switch>
Bit Switch 4
```

G070S503.WMF

```
Sw#4    00000000
bit0    _
```

G070S504.WMF

```
Sw#4    00000000
bit0    _
```

G070S505.WMF

```
Sw#4    00000000
bit0    0
```

G070S506.WMF

```
Sw#4    00001000
bit0
```

G070S507.WMF

```
Sw#4    00000000
bit0
```

G070S508.WMF

```
SYSTEMver V.0.24
1.Service
```

G070S509.WMF

```
SYSTEMver V.0.24
3.End
```

G070S510.WMF

Bit Switch 1

Bit	Function	Default
0	Key protect [0: Not activated, 1: Activated] DFU	0
1	(Not used.) DFU	0
2	(Not used.) DFU	0
3	(Not used.) DFU	0
4	(Not used.) DFU	0
5	(Not used.) DFU	0
6	(Not used.) DFU	0
7	Emulation print area (RPCS only). [0: Not printed, 1: Printed] DFU	0

Bit Switch 2

Bit	Function	Default
1	Overlap job mode (njob) [0: Not activated, 1: Activated] DFU	1
4	"Letterhead mode" display in UP mode (*NOTE) [0: Not activated, 1: Activated]	0

NOTE: In addition to 2-4 Bit Switch setting, press the following keys to enter the hidden menu display mode.

#Enter → Escape → Menu

The hidden indication "Letterhead mode" appears at the bottom of "system" menu. You can select the letterhead mode in this menu.

Bit Switch 3

Not used

Bit Switch 4

Bit	Function	Default
0	Background areas of simple graphics (RPDL, R16, R55, R98) [0: Not painted, 1: Painted] DFU	0
1	Unknown 2-byte characters (R98) [0: Cleared, 1: Not cleared] DFU	0
2	Specifies portrait/landscape reset (R16) [0: Reset by the reset command, 1: Not reset by the reset command] DFU	0
3	Changes line thickness adjustment mode [0: Mode 1, 1: Mode 2] DFU	0
4	Displays or not displays error messages No. 84 through DF (RPDL, R16, R55, R98, GL/GL2). [0: Displays, 1: Not displays] DFU	0
5	Displays or not displays error messages No. E1 and higher (RPDL, R16, R55, R98, GL/GL2). [0: Displays, 1: Not displays] DFU	0
6	Changes the tray setting (GL/GL2). [0: LP, 1: MFP] DFU	0
7	Changes the default tray. [0: LP (Tray 1), 1: MFP (System default)] DFU	0

Gamma Adjustment


NOTE: To solve color quality problems, clean and/or replace related parts first. If adjustments are required, follow the procedure in this section.

Summary

To adjust the printer gamma:

- Select the print mode that needs calibrating
- Print a color calibration test sheet
- Make the gradation scales on the printout smooth from the lowest to the highest density. Adjust the CMY gradation scale at the top of the chart by balancing the density of the C, M, and Y gradation scales – the CMY gray scale should change smoothly from minimum to maximum, and there should be no coloration.

The color adjustment sheet is as follows.



G070S013.PCX

For each color, you can adjust 15 points (example [A]) between 0 (lowest density) [B] and 255 (highest density) [C]. For each point, you can adjust the density within 0 and 255.

The gradation scales marked 'Default' are printed according to the default gamma settings in the flash ROM in the controller. The gamma adjustment changes the densities at the adjustable points in the gradation scale. The gradation scale marked "Current" shows the current settings.

During the adjustment procedure, compare the "Current" gradation scale with the 'Default'. Select the density for each of the 15 adjustable points, excluding points 0 and 255, from the 'Default' gradation scale.

The NVRAM holds three sets of controller gamma settings:

- Those saved this time: ToneCtlSet - Tone (Current)
- Those saved in the previous adjustment: ToneCtlSet - Tone (Prev)
- The factory settings: ToneCtlSet - Tone (Factory).

Adjustment Procedure

1. Enter the controller service mode.
2. Use the down arrow key to select "ToneCtlSet" (the second of the two) and press the Enter key.
3. Use the up/down key to select the mode that requires calibrating, then press the Escape key until you get back to the controller service mode menu.
4. Use the down arrow key to select "PrnColorSheet" and press the Enter key.
5. Use the up/down key to select "ToneCtlSheet" (normally this is displayed by default) and press the Enter key.
6. When "Execute?" is displayed, press the Enter key to print out the "color calibration test sheet".
7. When "Execute OK" is displayed, press the Escape key 2 times to exit from the menu. (You return to "PrnColorSheet" in the controller service menu.)
8. Use the down arrow key to select "ToneCtlValue" and press the enter key.

9. Use the up/down arrow key to select the setting you are adjusting, then press the enter key. The three digits in the display (example '016') indicate a position on the color calibration test sheet.

Operation Panel Display	Color Calibration Test Sheet
Set Black 1	Default Value 16
Set Black 2	Default Value 32
Set Black 3	Default Value 48
⋮	⋮
Set Black 13	Default Value 208
Set Black 14	Default Value 224
Set Black 15	Default Value 240
Set Cyan 1 ~ 15	See Set Black 1 ~ 15
Set Magenta 1 ~ 15	See Set Black 1 ~ 15
Set Yellow 1 ~ 15	See Set Black 1 ~ 15

Adjust the color density at each of the 15 points for each of the four colors.

- NOTE:**
- 1) To decide what density value to input, do the following.
 - 2) Look at the color adjustment sheet.
 - 3) For the color you are adjusting, look at the gradation scale entitled 'Default'.
 - 4) Go along the scale until you reach the density that you wish to input.
 - 5) Read off the value on the scale and store it in the machine.
 - a) Use the up/down key to move the cursor along the three-digit display, then press the Enter key.
 - b) Use the up/down key to change the digit at the cursor, then press the Enter key.
 - c) Press the Escape key to exit from the menu.
 - 6) Do the same for all 15 points.

10. When the density setting is complete for all colors, print out a color adjustment sheet again and make sure that the gradation scale for each printed color is smooth and that the CMY gradation scale is gray. Repeat the adjustment if there is an anomaly (normally, repeat this procedure 3 to 5 times).
11. When the adjustment results are satisfactory, do the following:
 - 1) Use "ToneCtlSave" in the controller service menu, to store the new settings in the controller.
 - 2) Reset the controller (press the **[Reset]** key when the machine is off line") to use the new settings.

NOTE: The new settings will not be saved in the controller NVRAM unless you reset the controller.

5.2.2 ENGINE SERVICE MODES

The SP numbers do not appear on the screen, but they may appear on reports.

NOTE: The Service Program Mode is for use by service representatives only, so that they can properly maintain product quality. If this mode is used by anyone other than service representatives for any reason, data might be deleted or settings might be changed. In such case, product quality cannot be guaranteed any more.

SP1-XXX: (Feed)

1	Mode No. (Class 1, 2, and 3)	Function / [Setting]
001*	Lead_Edge_Reg.	
	1	Tray: Plain
	2	Tray: Thick
	3	Tray: OHP
	4	Bank1
	5	Bank2
	6	By-pass: Plain
	7	By-pass: Thick
	8	By-pass: OHP
002*	S-to-S_Reg.	
	1	By-pass
	2	Tray1
	3	Bank1
	4	Bank2
	5	Duplex
	Adjusts the side-to-side registration by changing the laser main scan start position for each mode. [-4.0 ~ 4.0 / 0.0 / 0.1 mm/step]	
	• <i>The user mode cannot adjust the settings for thick paper or OHP sheets.</i>	
	003*	Paper_Buckle
1		Tray: Plain
2		Tray: Thick
3		Tray: OHP
4		Tray: SmallSize
6		By-pass: Plain
7		By-pass: Thick
8		By-pass: OHP
9		Duplex
105*	Fusing_Temp.	
	1	H: Pre
	2	H: _Ready
Sets the temperature at which the heating roller starts idling. [100 ~ 180 / 145 / 1°C/step]		
Sets the temperature at which the heating roller enters the print ready condition. [100 ~ 180 / 165 / 1°C/step]		

1	Mode No. (Class 1, 2, and 3)		Function / [Setting]
105*	3	H: _Standby	Sets the heating roller temperature for the ready (standby) condition. After the main switch has been turned on, the machine enters this condition when the heating roller temperature reaches the temperature specified in this SP mode. When the machine is recovering from energy saver or auto off mode, the machine becomes ready when both heat and pressure roller temperatures reach the specified temperature. Pressure roller: SP1-105-16 [100 ~ 180 / 175 / 1°C/step]
	4	H: Plain/1C	Sets the heating roller temperature for plain paper in single-color mode. [120 ~ 190 / 160 / 1°C/step]
	5	H: Plain/FC	Sets the heating roller temperature for plain paper in full-color mode. [120 ~ 190 / 170 / 1°C/step]
	6	H: M-Thick/1C	Sets the heating roller temperature for medium thickness paper in single-color mode. [120 ~ 190 / 170 / 1°C/step]
	7	H: M-Thick/FC	Sets the heating roller temperature for medium thickness paper in full-color mode. [120 ~ 190 / 180 / 1°C/step]
	8	H: Thick/1C	Sets the heating roller temperature for thick paper in single-color mode. [120 ~ 190 / 170 / 1°C/step]
	9	H: Thick/FC	Sets the heating roller temperature for thick paper in full-color mode. [120 ~ 190 / 175 / 1°C/step]
	10	H:OHP/1C	Sets the heating roller temperature for OHP sheets in single-color mode. [120 ~ 190 / 170 / 1°C/step]
	11	H: OHP/FC	Sets the heating roller temperature for the OHP sheets in full-color mode. [120 ~ 190 / 180 / 1°C/step]
	12	H: Duplex/1C	Sets the heating roller temperature for duplex printing (both sides) in single-color mode. [120 ~ 190 / 155 / 1°C/step]
	13	H: Duplex/FC	Sets the heating roller temperature for duplex printing (both sides) in full-color mode. [120 ~ 190 / 165 / 1°C/step]
	14	P: Pre	Sets the temperature at which the pressure roller starts idling. [30 ~ 100 / 30 / 1°C/step]
	15	P: _Ready	Sets the temperature at which the pressure roller becomes ready for printing. [60 ~ 150 / 80 / 1°C/step]

1	Mode No. (Class 1, 2, and 3)		Function / [Setting]
105*	16	P: _Standby	Sets the pressure roller temperature for the ready (standby) condition. After the main switch has been turned on, the machine enters this condition when the pressure roller temperature reaches the temperature specified in this SP mode. When the machine is recovering from energy saver or auto off mode, the machine becomes ready when both heat and pressure roller temperatures reach the specified temperature. Heating roller: SP1-105-3 [60 ~ 150 / 120 / 1°C/step]
	27	H: OFFSET+	Sets the heating roller temperature correction for when room temperature is 15°C or lower. [0 ~ 20 / 5 / 1°C/step]
	28	P: OFFSET+	Sets the pressure roller temperature correction for when room temperature is 15°C or lower. [0 ~ 20 / 0 / 1°C/step]
	29	H: OFFSET-	Sets the heating roller temperature correction for when room temperature is 30°C or higher. [0 ~ 20 / 5 / 1°C/step]
	30	P: OFFSET-	Sets the pressure roller temperature correction for when room temperature is 30°C or higher. [0 ~ 20 / 0 / 1°C/step]
106	Temp_ Display		Displays the current temperature of the heating or pressure roller. [0 ~ 255 / 0 / 1/step]
	1	H_Roller	
	2	P_Roller	
109	Fusing_Nip		Checks the fusing nip width using an OHP sheet. [0 ~ 1 / 0 / 1/step] <ul style="list-style-type: none"> • <i>The OHP sheet stops in the fusing unit for the specified time (☛ SP1-109-2).</i> • <i>The nip width should be 9 ± 0.5 mm at front and rear. If this requirement is not met, change the fusing unit.</i>
	1	ExecuteMode	
	2	Stop_Duration	Adjusts the stoppage time for the OHP sheet in the fusing unit (☛ SP1-109-1). [0 ~ 100 / 10 / 1 s/step]
902*	PaperSize		Specifies how the machine interprets the paper size sensor output for the main unit tray. [0 ~ 1 / 0 / 1/step] <ul style="list-style-type: none"> • For Europe: 0: B4 SEF, 1: LG SEF • For N. America: 0: LG SEF, 1: B4 SEF
	1	B4/LG	
	2	A3/DLT	Specifies how the machine interprets the paper size sensor output for the main unit tray. [0 ~ 1 / 0 / 1/step] <ul style="list-style-type: none"> • For Europe: 0: A3 SEF, 1: DLT SEF • For N. America: 0: DLT SEF, 1: A3 SEF

1	Mode No. (Class 1, 2, and 3)		Function / [Setting]
902*	3	A4/LT	Specifies how the machine interprets the paper size sensor output for the main unit tray. [0 ~ 1 / 0 / 1/step] <ul style="list-style-type: none"> • For Europe: 0: A4 SEF, 1: LT SEF • For N. America: 0: LT SEF, 1: A4 SEF
	4	B5/Executive	Specifies how the machine interprets the paper size sensor output for the main unit tray. [0 ~ 1 / 0 / 1/step] <ul style="list-style-type: none"> • For Europe: 0: B5 SEF, 1: Executive (10.5" x 7.25") SEF • For N. America: 0: B5 SEF, 1: Executive (10.5" x 7.25") SEF
910	EmptyRev		Specifies the settings for when fusing idling is done after printing on A4/LT LEF or smaller paper sizes. [0 ~ 2 / 0 / 1/step] <ul style="list-style-type: none"> • <i>After printing on small-width paper (A4 LEF/LT LEF or smaller), fusing idling evens the oil thickness on the roller surface.</i> • 0 (Int): Enables printing during fusing idling. • 1 (NoRev): Disables this type of fusing idling. • 2 (NoInt): Disables printing during fusing idling.



SP2-XXX: (Drum)

2	Mode No. (Class 1, 2, and 3)		Function / [Setting]
001*	Charge_Bias		
	1	[M]	Adjusts the charge corona unit grid voltage. [300 ~ 800 / 500 / 1 Volt/step] Only effective is SP3-003 (Lub_Interval) is set to 0.
	2	[C]	
	3	[Y]	
	4	[K]	
	5	NoImageArea	
6	ChargerCurrent	Adjusts the charge corona unit current. [400 ~ 800 / 500 / 1 µA/step]	
100*	Mag. Adjust		
	1	MainDirection	Adjusts the magnification in the main scan direction. [-12.8 ~ 12.7 / 0.0 / 0.1%/step]
101*	Mag. Adjust		
	1	SubDirection	Adjusts the magnification in the sub scan direction. [-12.8 ~ 12.7 / 0.2 / 0.1%/step]
201*	DevelopBiasAdj		
	1	[M]	Adjusts the development bias. [0 ~ 500 / 220 / 1 Volt/step] Only effective is SP3-003 (Lub_Interval) is set to 0.
	2	[C]	
	3	[Y]	
	4	[K]	
208	Forced_Toner		
	1	[K]	Forces toner to be supplied to the development unit. [0 ~ 1 / 0 / 1/step]
	2	[C]	
	3	[M]	
	4	[Y]	
	5	AllColor	
301	TransBeltBias		
	1	1C/1st/1	Adjusts the transfer belt current. [3.0 ~ 14.0 / 8.0 / 0.1 µA/step] <i>The front side image of 1-color duplex printing</i>
	2	1C/2nd/2	[3.0 ~ 14.0 / 8.0 / 0.1 µA/step] <i>The rear side image of 1-color duplex printing</i>
	3	2C/--/1	[3.0 ~ 14.0 / 13.0 / 0.1 µA/step] <i>The first color toner image of 2-color printing</i>
	4	3C/--/1	[3.0 ~ 14.0 / 13.0 / 0.1 µA/step] <i>The first color toner image of 3-color printing</i>
	5	4C/--/1	[3.0 ~ 14.0 / 7.5 / 0.1 µA/step] <i>The first color toner image of 4-color printing</i>
	6	2C/--/2	[3.0 ~ 14.0 / 13.0 / 0.1 µA/step] <i>The second color toner image of 2-color printing</i>
	7	3C/--/2	[3.0 ~ 14.0 / 13.0 / 0.1 µA/step] <i>The second color toner image of 3-color printing</i>
	8	4C/--/2	[3.0 ~ 14.0 / 13.0 / 0.1 µA/step] <i>The second color toner image of 4-color printing</i>
	9	3C/--/3	[3.0 ~ 14.0 / 13.0 / 0.1 µA/step] <i>The third color toner image of 3-color printing</i>
	10	4C/--/3	[3.0 ~ 14.0 / 13.0 / 0.1 µA/step] <i>The third color toner image of 4-color printing</i>
11	4C/--/4	[3.0 ~ 14.0 / 13.0 / 0.1 µA/step] <i>The fourth color toner image of 4-color printing</i>	

2	Mode No. (Class 1, 2, and 3)		Function / [Setting]
301	12	--/--/1	[3.0 ~ 14.0 / 7.0 / 0.1 μ A/step] <i>After the first color toner image</i>
	13	--/--/2	[3.0 ~ 14.0 / 7.0 / 0.1 μ A/step] <i>After the second color toner image</i>
	14	--/--/3	[3.0 ~ 14.0 / 7.0 / 0.1 μ A/step] <i>After the third color toner image</i>
	15	--/--/last	[3.0 ~ 14.0 / 7.0 / 0.1 μ A/step] <i>After the final color toner image</i>
	16	DevStart	[3.0 ~ 14.0 / 7.0 / 0.1 μ A/step] <i>Development start</i>
	17	DevEnd	[3.0 ~ 14.0 / 7.0 / 0.1 μ A/step] <i>Development end</i>
	18	1C/1st/--	[3.0 ~ 14.0 / 7.0 / 0.1 μ A/step] <i>Waiting for thick paper or OHP before creating the front side image for 1-color printing</i>
	19	1C/2nd/--	[3.0 ~ 14.0 / 7.0 / 0.1 μ A/step] <i>Waiting for thick paper or OHP before creating the rear side image for 1-color duplex printing</i>
	20	2C/--/--	[3.0 ~ 14.0 / 7.0 / 0.1 μ A/step] <i>Waiting for thick paper or OHP before creating an image for 2-color printing</i>
	21	3C/--/--	[3.0 ~ 14.0 / 7.0 / 0.1 μ A/step] <i>Waiting for thick paper or OHP before creating an image for 3-color printing</i>
	22	4C/--/--	[3.0 ~ 14.0 / 7.0 / 0.1 μ A/step] <i>Waiting for the thick paper or OHP before creating an image for 4-color printing</i>
	23	PowerOnRecovery	[3.0 ~ 14.0 / 7.0 / 0.1 μ A/step] <i>Machine start and jam recovery</i>
303*	TransBeltEnv		
	1	1	Adjusts the environmental threshold for the transfer belt. [0 ~ 100.0 / 3.5 / 0.1 g/m ³ /step] DFU
	2	2	[0 ~ 100.0 / 19.0 / 0.1 g/m ³ /step] DFU
305*	TransBeltStart		
	1	BiasOnOff	Sets the bias for the image transfer start to on or off. [0 ~ 1 / 1 / 1/step] DFU <ul style="list-style-type: none"> • 0: Bias off • 1: Bias on
306	TransBeltFirst		
	1	1C	This value is added to the transfer current for the first page to improve insufficient transfer of solid images. [3.0 ~ 14.0 / 9.0 / 0.1 μ A/step]
	2	2C-4C	[3.0 ~ 14.0 / 13.0 / 0.1 μ A/step]

2	Mode No. (Class 1, 2, and 3)	Function / [Setting]																																																																																																
310*	PaperTrans_LL1 (Paper Transfer LL1) The display indicates: Paper Weight/Side 1 or 2/Paper Width (mm)	<table border="1"> <tr> <td data-bbox="308 353 379 613">1</td> <td data-bbox="379 353 684 613">Nrml/1st/-297</td> <td data-bbox="684 353 1385 613"> Sets the paper transfer current when absolute humidity AH (g/m^3) is in the following range: $0 < \text{AH} \leq 3.5$ (this is the 'LL1' humidity range) Adjust only if there are problems with insufficient transfer in the image area of the copy for a particular paper type or mode, or in response to field problems as directed by technical support staff. [0 ~ 70.0 / 32.0 / 0.2 $\mu\text{A}/\text{step}$] </td> </tr> <tr><td>2</td><td>Nrml/1st/257-296</td><td>[0 ~ 70.0 / 34.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>3</td><td>Nrml/1st/210-256</td><td>[0 ~ 70.0 / 36.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>4</td><td>Nrml/1st/129-209</td><td>[0 ~ 70.0 / 39.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>5</td><td>Nrml/1st/-128</td><td>[0 ~ 70.0 / 42.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>6</td><td>Mid/1st/-297</td><td>[0 ~ 70.0 / 33.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>7</td><td>Mid/1st/257-296</td><td>[0 ~ 70.0 / 35.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>8</td><td>Mid/1st/210-256</td><td>[0 ~ 70.0 / 37.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>9</td><td>Mid/1st/129-209</td><td>[0 ~ 70.0 / 40.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>10</td><td>Mid/1st/-128</td><td>[0 ~ 70.0 / 43.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>11</td><td>Thk/1st/-297</td><td>[0 ~ 70.0 / 16.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>12</td><td>Thk/1st/257-296</td><td>[0 ~ 70.0 / 19.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>13</td><td>Thk/1st/210-256</td><td>[0 ~ 70.0 / 21.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>14</td><td>Thk/1st/129-209</td><td>[0 ~ 70.0 / 24.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>15</td><td>Thk/1st/-128</td><td>[0 ~ 70.0 / 27.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>16</td><td>Nrml/2nd/-297</td><td>[0 ~ 70.0 / 38.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>17</td><td>Nrml/2nd/257-296</td><td>[0 ~ 70.0 / 40.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>18</td><td>Nrml/2nd/210-256</td><td>[0 ~ 70.0 / 42.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>19</td><td>Nrml/2nd/129-209</td><td>[0 ~ 70.0 / 43.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>20</td><td>Nrml/2nd/-128</td><td>[0 ~ 70.0 / 44.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>21</td><td>Mid/2nd/-297</td><td>[0 ~ 70.0 / 39.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>22</td><td>Mid/2nd/257-296</td><td>[0 ~ 70.0 / 41.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>23</td><td>Mid/2nd/210-256</td><td>[0 ~ 70.0 / 43.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>24</td><td>Mid/2nd/129-209</td><td>[0 ~ 70.0 / 44.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>25</td><td>Mid/2nd/-128</td><td>[0 ~ 70.0 / 45.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>26</td><td>Thk/2nd/-297</td><td>[0 ~ 70.0 / 16.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>27</td><td>Thk/2nd/257-296</td><td>[0 ~ 70.0 / 19.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>28</td><td>Thk/2nd/210-256</td><td>[0 ~ 70.0 / 21.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>29</td><td>Thk/2nd/129-209</td><td>[0 ~ 70.0 / 24.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>30</td><td>Thk/2nd/-128</td><td>[0 ~ 70.0 / 26.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>31</td><td>OHP/297</td><td>[0 ~ 70.0 / 16.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> <tr><td>32</td><td>OHP/210</td><td>[0 ~ 70.0 / 22.0 / 0.2 $\mu\text{A}/\text{step}$]</td></tr> </table>	1	Nrml/1st/-297	Sets the paper transfer current when absolute humidity AH (g/m^3) is in the following range: $0 < \text{AH} \leq 3.5$ (this is the 'LL1' humidity range) Adjust only if there are problems with insufficient transfer in the image area of the copy for a particular paper type or mode, or in response to field problems as directed by technical support staff. [0 ~ 70.0 / 32.0 / 0.2 $\mu\text{A}/\text{step}$]	2	Nrml/1st/257-296	[0 ~ 70.0 / 34.0 / 0.2 $\mu\text{A}/\text{step}$]	3	Nrml/1st/210-256	[0 ~ 70.0 / 36.0 / 0.2 $\mu\text{A}/\text{step}$]	4	Nrml/1st/129-209	[0 ~ 70.0 / 39.0 / 0.2 $\mu\text{A}/\text{step}$]	5	Nrml/1st/-128	[0 ~ 70.0 / 42.0 / 0.2 $\mu\text{A}/\text{step}$]	6	Mid/1st/-297	[0 ~ 70.0 / 33.0 / 0.2 $\mu\text{A}/\text{step}$]	7	Mid/1st/257-296	[0 ~ 70.0 / 35.0 / 0.2 $\mu\text{A}/\text{step}$]	8	Mid/1st/210-256	[0 ~ 70.0 / 37.0 / 0.2 $\mu\text{A}/\text{step}$]	9	Mid/1st/129-209	[0 ~ 70.0 / 40.0 / 0.2 $\mu\text{A}/\text{step}$]	10	Mid/1st/-128	[0 ~ 70.0 / 43.0 / 0.2 $\mu\text{A}/\text{step}$]	11	Thk/1st/-297	[0 ~ 70.0 / 16.0 / 0.2 $\mu\text{A}/\text{step}$]	12	Thk/1st/257-296	[0 ~ 70.0 / 19.0 / 0.2 $\mu\text{A}/\text{step}$]	13	Thk/1st/210-256	[0 ~ 70.0 / 21.0 / 0.2 $\mu\text{A}/\text{step}$]	14	Thk/1st/129-209	[0 ~ 70.0 / 24.0 / 0.2 $\mu\text{A}/\text{step}$]	15	Thk/1st/-128	[0 ~ 70.0 / 27.0 / 0.2 $\mu\text{A}/\text{step}$]	16	Nrml/2nd/-297	[0 ~ 70.0 / 38.0 / 0.2 $\mu\text{A}/\text{step}$]	17	Nrml/2nd/257-296	[0 ~ 70.0 / 40.0 / 0.2 $\mu\text{A}/\text{step}$]	18	Nrml/2nd/210-256	[0 ~ 70.0 / 42.0 / 0.2 $\mu\text{A}/\text{step}$]	19	Nrml/2nd/129-209	[0 ~ 70.0 / 43.0 / 0.2 $\mu\text{A}/\text{step}$]	20	Nrml/2nd/-128	[0 ~ 70.0 / 44.0 / 0.2 $\mu\text{A}/\text{step}$]	21	Mid/2nd/-297	[0 ~ 70.0 / 39.0 / 0.2 $\mu\text{A}/\text{step}$]	22	Mid/2nd/257-296	[0 ~ 70.0 / 41.0 / 0.2 $\mu\text{A}/\text{step}$]	23	Mid/2nd/210-256	[0 ~ 70.0 / 43.0 / 0.2 $\mu\text{A}/\text{step}$]	24	Mid/2nd/129-209	[0 ~ 70.0 / 44.0 / 0.2 $\mu\text{A}/\text{step}$]	25	Mid/2nd/-128	[0 ~ 70.0 / 45.0 / 0.2 $\mu\text{A}/\text{step}$]	26	Thk/2nd/-297	[0 ~ 70.0 / 16.0 / 0.2 $\mu\text{A}/\text{step}$]	27	Thk/2nd/257-296	[0 ~ 70.0 / 19.0 / 0.2 $\mu\text{A}/\text{step}$]	28	Thk/2nd/210-256	[0 ~ 70.0 / 21.0 / 0.2 $\mu\text{A}/\text{step}$]	29	Thk/2nd/129-209	[0 ~ 70.0 / 24.0 / 0.2 $\mu\text{A}/\text{step}$]	30	Thk/2nd/-128	[0 ~ 70.0 / 26.0 / 0.2 $\mu\text{A}/\text{step}$]	31	OHP/297	[0 ~ 70.0 / 16.0 / 0.2 $\mu\text{A}/\text{step}$]	32	OHP/210	[0 ~ 70.0 / 22.0 / 0.2 $\mu\text{A}/\text{step}$]
1	Nrml/1st/-297	Sets the paper transfer current when absolute humidity AH (g/m^3) is in the following range: $0 < \text{AH} \leq 3.5$ (this is the 'LL1' humidity range) Adjust only if there are problems with insufficient transfer in the image area of the copy for a particular paper type or mode, or in response to field problems as directed by technical support staff. [0 ~ 70.0 / 32.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
2	Nrml/1st/257-296	[0 ~ 70.0 / 34.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
3	Nrml/1st/210-256	[0 ~ 70.0 / 36.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
4	Nrml/1st/129-209	[0 ~ 70.0 / 39.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
5	Nrml/1st/-128	[0 ~ 70.0 / 42.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
6	Mid/1st/-297	[0 ~ 70.0 / 33.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
7	Mid/1st/257-296	[0 ~ 70.0 / 35.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
8	Mid/1st/210-256	[0 ~ 70.0 / 37.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
9	Mid/1st/129-209	[0 ~ 70.0 / 40.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
10	Mid/1st/-128	[0 ~ 70.0 / 43.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
11	Thk/1st/-297	[0 ~ 70.0 / 16.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
12	Thk/1st/257-296	[0 ~ 70.0 / 19.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
13	Thk/1st/210-256	[0 ~ 70.0 / 21.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
14	Thk/1st/129-209	[0 ~ 70.0 / 24.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
15	Thk/1st/-128	[0 ~ 70.0 / 27.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
16	Nrml/2nd/-297	[0 ~ 70.0 / 38.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
17	Nrml/2nd/257-296	[0 ~ 70.0 / 40.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
18	Nrml/2nd/210-256	[0 ~ 70.0 / 42.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
19	Nrml/2nd/129-209	[0 ~ 70.0 / 43.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
20	Nrml/2nd/-128	[0 ~ 70.0 / 44.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
21	Mid/2nd/-297	[0 ~ 70.0 / 39.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
22	Mid/2nd/257-296	[0 ~ 70.0 / 41.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
23	Mid/2nd/210-256	[0 ~ 70.0 / 43.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
24	Mid/2nd/129-209	[0 ~ 70.0 / 44.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
25	Mid/2nd/-128	[0 ~ 70.0 / 45.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
26	Thk/2nd/-297	[0 ~ 70.0 / 16.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
27	Thk/2nd/257-296	[0 ~ 70.0 / 19.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
28	Thk/2nd/210-256	[0 ~ 70.0 / 21.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
29	Thk/2nd/129-209	[0 ~ 70.0 / 24.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
30	Thk/2nd/-128	[0 ~ 70.0 / 26.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
31	OHP/297	[0 ~ 70.0 / 16.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
32	OHP/210	[0 ~ 70.0 / 22.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																
311*	PaperTrans_LL2 (Paper Transfer LL2) The display indicates: Paper Weight/Side 1 or 2/Paper Width (mm)	<table border="1"> <tr> <td data-bbox="308 1809 379 1977">1</td> <td data-bbox="379 1809 684 1977">Nrml/1st/-297</td> <td data-bbox="684 1809 1385 1977"> Sets the paper transfer current when absolute humidity AH (g/m^3) is in the following range: $3.5 < \text{AH} \leq 8.0$ (this is the 'LL2' humidity range) See SP2-310 for comments. [0 ~ 70.0 / 36.0 / 0.2 $\mu\text{A}/\text{step}$] </td> </tr> </table>	1	Nrml/1st/-297	Sets the paper transfer current when absolute humidity AH (g/m^3) is in the following range: $3.5 < \text{AH} \leq 8.0$ (this is the 'LL2' humidity range) See SP2-310 for comments. [0 ~ 70.0 / 36.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																													
1	Nrml/1st/-297	Sets the paper transfer current when absolute humidity AH (g/m^3) is in the following range: $3.5 < \text{AH} \leq 8.0$ (this is the 'LL2' humidity range) See SP2-310 for comments. [0 ~ 70.0 / 36.0 / 0.2 $\mu\text{A}/\text{step}$]																																																																																																

2	Mode No. (Class 1, 2, and 3)	Function / [Setting]
311*	2	Nrml/1st/257-296 [0 ~ 70.0 / 38.0 / 0.2 μ A/step]
	3	Nrml/1st/210-256 [0 ~ 70.0 / 40.0 / 0.2 μ A/step]
	4	Nrml/1st/129-209 [0 ~ 70.0 / 43.0 / 0.2 μ A/step]
	5	Nrml/1st/-128 [0 ~ 70.0 / 46.0 / 0.2 μ A/step]
	6	Mid/1st/-297 [0 ~ 70.0 / 37.0 / 0.2 μ A/step]
	7	Mid/1st/257-296 [0 ~ 70.0 / 39.0 / 0.2 μ A/step]
	8	Mid/1st/210-256 [0 ~ 70.0 / 41.0 / 0.2 μ A/step]
	9	Mid/1st/129-209 [0 ~ 70.0 / 44.0 / 0.2 μ A/step]
	10	Mid/1st/-128 [0 ~ 70.0 / 47.0 / 0.2 μ A/step]
	11	Thk/1st/-297 [0 ~ 70.0 / 20.0 / 0.2 μ A/step]
	12	Thk/1st/257-296 [0 ~ 70.0 / 21.0 / 0.2 μ A/step]
	13	Thk/1st/210-256 [0 ~ 70.0 / 23.0 / 0.2 μ A/step]
	14	Thk/1st/129-209 [0 ~ 70.0 / 24.0 / 0.2 μ A/step]
	15	Thk/1st/-128 [0 ~ 70.0 / 26.0 / 0.2 μ A/step]
	16	Nrml/2nd/-297 [0 ~ 70.0 / 40.0 / 0.2 μ A/step]
	17	Nrml/2nd/257-296 [0 ~ 70.0 / 43.0 / 0.2 μ A/step]
	18	Nrml/2nd/210-256 [0 ~ 70.0 / 45.0 / 0.2 μ A/step]
	19	Nrml/2nd/129-209 [0 ~ 70.0 / 47.0 / 0.2 μ A/step]
	20	Nrml/2nd/-128 [0 ~ 70.0 / 50.0 / 0.2 μ A/step]
	21	Mid/2nd/-297 [0 ~ 70.0 / 41.0 / 0.2 μ A/step]
	22	Mid/2nd/257-296 [0 ~ 70.0 / 44.0 / 0.2 μ A/step]
	23	Mid/2nd/210-256 [0 ~ 70.0 / 46.0 / 0.2 μ A/step]
	24	Mid/2nd/129-209 [0 ~ 70.0 / 48.0 / 0.2 μ A/step]
	25	Mid/2nd/-128 [0 ~ 70.0 / 51.0 / 0.2 μ A/step]
	26	Thk/2nd/-297 [0 ~ 70.0 / 20.0 / 0.2 μ A/step]
	27	Thk/2nd/257-296 [0 ~ 70.0 / 24.0 / 0.2 μ A/step]
	28	Thk/2nd/210-256 [0 ~ 70.0 / 27.0 / 0.2 μ A/step]
	29	Thk/2nd/129-209 [0 ~ 70.0 / 31.0 / 0.2 μ A/step]
	30	Thk/2nd/-128 [0 ~ 70.0 / 34.0 / 0.2 μ A/step]
	31	OHP/297 [0 ~ 70.0 / 19.0 / 0.2 μ A/step]
	32	OHP/210 [0 ~ 70.0 / 26.0 / 0.2 μ A/step]
	312*	PaperTrans_NN1 (Paper Transfer NN1) The display indicates: Paper Weight/Side 1 or 2/Paper Width (mm)
1		Nrml/1st/-297 Sets the paper transfer current when absolute humidity AH (g/m^3) is in the following range: 80 < AH \leq 14 (this is the 'NN1' humidity range) See SP2-310 for comments. [0 ~ 70.0 / 40.0 / 0.2 μ A/step]
2		Nrml/1st/257-296 [0 ~ 70.0 / 42.0 / 0.2 μ A/step]
3		Nrml/1st/210-256 [0 ~ 70.0 / 44.0 / 0.2 μ A/step]
4		Nrml/1st/129-209 [0 ~ 70.0 / 47.0 / 0.2 μ A/step]
5		Nrml/1st/-128 [0 ~ 70.0 / 50.0 / 0.2 μ A/step]
6		Mid/1st/-297 [0 ~ 70.0 / 41.0 / 0.2 μ A/step]
7		Mid/1st/257-296 [0 ~ 70.0 / 43.0 / 0.2 μ A/step]
8		Mid/1st/210-256 [0 ~ 70.0 / 45.0 / 0.2 μ A/step]
9		Mid/1st/129-209 [0 ~ 70.0 / 47.0 / 0.2 μ A/step]
10		Mid/1st/-128 [0 ~ 70.0 / 51.0 / 0.2 μ A/step]



2	Mode No. (Class 1, 2, and 3)	Function / [Setting]	
312*	11	Thk/1st/-297 [0 ~ 70.0 / 23.0 / 0.2 μ A/step]	
	12	Thk/1st/257-296 [0 ~ 70.0 / 23.0 / 0.2 μ A/step]	
	13	Thk/1st/210-256 [0 ~ 70.0 / 24.0 / 0.2 μ A/step]	
	14	Thk/1st/129-209 [0 ~ 70.0 / 24.0 / 0.2 μ A/step]	
	15	Thk/1st/-128 [0 ~ 70.0 / 24.0 / 0.2 μ A/step]	
	16	Nrml/2nd/-297 [0 ~ 70.0 / 42.0 / 0.2 μ A/step]	
	17	Nrml/2nd/257-296 [0 ~ 70.0 / 45.0 / 0.2 μ A/step]	
	18	Nrml/2nd/210-256 [0 ~ 70.0 / 48.0 / 0.2 μ A/step]	
	19	Nrml/2nd/129-209 [0 ~ 70.0 / 51.0 / 0.2 μ A/step]	
	20	Nrml/2nd/-128 [0 ~ 70.0 / 55.0 / 0.2 μ A/step]	
	21	Mid/2nd/-297 [0 ~ 70.0 / 43.0 / 0.2 μ A/step]	
	22	Mid/2nd/257-296 [0 ~ 70.0 / 46.0 / 0.2 μ A/step]	
	23	Mid/2nd/210-256 [0 ~ 70.0 / 49.0 / 0.2 μ A/step]	
	24	Mid/2nd/129-209 [0 ~ 70.0 / 52.0 / 0.2 μ A/step]	
	25	Mid/2nd/-128 [0 ~ 70.0 / 56.0 / 0.2 μ A/step]	
	26	Thk/2nd/-297 [0 ~ 70.0 / 23.0 / 0.2 μ A/step]	
	27	Thk/2nd/257-296 [0 ~ 70.0 / 28.0 / 0.2 μ A/step]	
	28	Thk/2nd/210-256 [0 ~ 70.0 / 32.0 / 0.2 μ A/step]	
	29	Thk/2nd/129-209 [0 ~ 70.0 / 37.0 / 0.2 μ A/step]	
	30	Thk/2nd/-128 [0 ~ 70.0 / 42.0 / 0.2 μ A/step]	
	31	OHP/297 [0 ~ 70.0 / 22.0 / 0.2 μ A/step]	
	32	OHP/210 [0 ~ 70.0 / 30.0 / 0.2 μ A/step]	
	313*	PaperTrans_NN2 (Paper Transfer NN2) The display indicates: Paper Weight/Side 1 or 2/Paper Width (mm)	
		1	Nrml/1st/-297 Sets the paper transfer current when absolute humidity AH (g/m^3) is in the following range: 14 < AH \leq 19 (this is the 'NN2' humidity range) See SP2-310 for comments. [0 ~ 70.0 / 36.0 / 0.2 μ A/step]
		2	Nrml/1st/257-296 [0 ~ 70.0 / 38.0 / 0.2 μ A/step]
		3	Nrml/1st/210-256 [0 ~ 70.0 / 39.0 / 0.2 μ A/step]
		4	Nrml/1st/129-209 [0 ~ 70.0 / 40.0 / 0.2 μ A/step]
		5	Nrml/1st/-128 [0 ~ 70.0 / 42.0 / 0.2 μ A/step]
		6	Mid/1st/-297 [0 ~ 70.0 / 37.0 / 0.2 μ A/step]
		7	Mid/1st/257-296 [0 ~ 70.0 / 39.0 / 0.2 μ A/step]
		8	Mid/1st/210-256 [0 ~ 70.0 / 40.0 / 0.2 μ A/step]
		9	Mid/1st/129-209 [0 ~ 70.0 / 41.0 / 0.2 μ A/step]
10		Mid/1st/-128 [0 ~ 70.0 / 43.0 / 0.2 μ A/step]	
11		Thk/1st/-297 [0 ~ 70.0 / 25.0 / 0.2 μ A/step]	
12		Thk/1st/257-296 [0 ~ 70.0 / 25.0 / 0.2 μ A/step]	
13		Thk/1st/210-256 [0 ~ 70.0 / 24.0 / 0.2 μ A/step]	
14		Thk/1st/129-209 [0 ~ 70.0 / 24.0 / 0.2 μ A/step]	
15		Thk/1st/-128 [0 ~ 70.0 / 24.0 / 0.2 μ A/step]	
16		Nrml/2nd/-297 [0 ~ 70.0 / 43.0 / 0.2 μ A/step]	
17		Nrml/2nd/257-296 [0 ~ 70.0 / 45.0 / 0.2 μ A/step]	
18		Nrml/2nd/210-256 [0 ~ 70.0 / 46.0 / 0.2 μ A/step]	
19		Nrml/2nd/129-209 [0 ~ 70.0 / 48.0 / 0.2 μ A/step]	

2	Mode No. (Class 1, 2, and 3)	Function / [Setting]
313*	20	Nrml/2nd/-128 [0 ~ 70.0 / 50.0 / 0.2 μ A/step]
	21	Mid/2nd/-297 [0 ~ 70.0 / 44.0 / 0.2 μ A/step]
	22	Mid/2nd/257-296 [0 ~ 70.0 / 46.0 / 0.2 μ A/step]
	23	Mid/2nd/210-256 [0 ~ 70.0 / 47.0 / 0.2 μ A/step]
	24	Mid/2nd/129-209 [0 ~ 70.0 / 49.0 / 0.2 μ A/step]
	25	Mid/2nd/-128 [0 ~ 70.0 / 51.0 / 0.2 μ A/step]
	26	Thk/2nd/-297 [0 ~ 70.0 / 28.0 / 0.2 μ A/step]
	27	Thk/2nd/257-296 [0 ~ 70.0 / 32.0 / 0.2 μ A/step]
	28	Thk/2nd/210-256 [0 ~ 70.0 / 36.0 / 0.2 μ A/step]
	29	Thk/2nd/129-209 [0 ~ 70.0 / 41.0 / 0.2 μ A/step]
	30	Thk/2nd/-128 [0 ~ 70.0 / 45.0 / 0.2 μ A/step]
	31	OHP/297 [0 ~ 70.0 / 23.0 / 0.2 μ A/step]
	32	OHP/210 [0 ~ 70.0 / 33.0 / 0.2 μ A/step]
314*	PaperTrans_HH (Paper Transfer HH). The display indicates: Paper Weight/Side 1 or 2/Paper Width (mm)	
	1	Nrml/1st/-297 Sets the paper transfer current when absolute humidity AH (g/m^3) is in the following range: 19 < AH (this is the 'HH' humidity range) See SP2-310 for comments. [0 ~ 70.0 / 32.0 / 0.2 μ A/step]
	2	Nrml/1st/257-296 [0 ~ 70.0 / 33.0 / 0.2 μ A/step]
	3	Nrml/1st/210-256 [0 ~ 70.0 / 33.0 / 0.2 μ A/step]
	4	Nrml/1st/129-209 [0 ~ 70.0 / 34.0 / 0.2 μ A/step]
	5	Nrml/1st/-128 [0 ~ 70.0 / 34.0 / 0.2 μ A/step]
	6	Mid/1st/-297 [0 ~ 70.0 / 33.0 / 0.2 μ A/step]
	7	Mid/1st/257-296 [0 ~ 70.0 / 34.0 / 0.2 μ A/step]
	8	Mid/1st/210-256 [0 ~ 70.0 / 34.0 / 0.2 μ A/step]
	9	Mid/1st/129-209 [0 ~ 70.0 / 35.0 / 0.2 μ A/step]
	10	Mid/1st/-128 [0 ~ 70.0 / 35.0 / 0.2 μ A/step]
	11	Thk/1st/-297 [0 ~ 70.0 / 26.0 / 0.2 μ A/step]
	12	Thk/1st/257-296 [0 ~ 70.0 / 25.0 / 0.2 μ A/step]
	13	Thk/1st/210-256 [0 ~ 70.0 / 25.0 / 0.2 μ A/step]
	14	Thk/1st/129-209 [0 ~ 70.0 / 24.0 / 0.2 μ A/step]
	15	Thk/1st/-128 [0 ~ 70.0 / 24.0 / 0.2 μ A/step]
	16	Nrml/2nd/-297 [0 ~ 70.0 / 44.0 / 0.2 μ A/step]
	17	Nrml/2nd/257-296 [0 ~ 70.0 / 44.0 / 0.2 μ A/step]
	18	Nrml/2nd/210-256 [0 ~ 70.0 / 44.0 / 0.2 μ A/step]
	19	Nrml/2nd/129-209 [0 ~ 70.0 / 44.0 / 0.2 μ A/step]
	20	Nrml/2nd/-128 [0 ~ 70.0 / 44.0 / 0.2 μ A/step]
	21	Mid/2nd/-297 [0 ~ 70.0 / 45.0 / 0.2 μ A/step]
	22	Mid/2nd/257-296 [0 ~ 70.0 / 45.0 / 0.2 μ A/step]
	23	Mid/2nd/210-256 [0 ~ 70.0 / 45.0 / 0.2 μ A/step]
	24	Mid/2nd/129-209 [0 ~ 70.0 / 45.0 / 0.2 μ A/step]
	25	Mid/2nd/-128 [0 ~ 70.0 / 45.0 / 0.2 μ A/step]
	26	Thk/2nd/-297 [0 ~ 70.0 / 28.0 / 0.2 μ A/step]
	27	Thk/2nd/257-296 [0 ~ 70.0 / 32.0 / 0.2 μ A/step]
28	Thk/2nd/210-256 [0 ~ 70.0 / 36.0 / 0.2 μ A/step]	



2	Mode No. (Class 1, 2, and 3)		Function / [Setting]
314*	29	Thk/2nd/129-209	[0 ~ 70.0 / 40.0 / 0.2 μ A/step]
	30	Thk/2nd/-128	[0 ~ 70.0 / 44.0 / 0.2 μ A/step]
	31	OHP/297	[0 ~ 70.0 / 24.0 / 0.2 μ A/step]
	32	OHP/210	[0 ~ 70.0 / 36.0 / 0.2 μ A/step]
320*	PaperTrans_Col (Paper Transfer Correction) The display indicates: Paper Type/Side 1 or 2/Printing mode		
	1	Nrml/1st/1C	Corrects the electric current for paper transfer. DFU [0 ~ 100 / 45 / 1%/step]
	2	Nrml/1st/2C	[0 ~ 100 / 90 / 1%/step]
	3	Nrml/1st/3C	[0 ~ 100 / 100 / 1%/step]
	4	Nrml/2nd/1C	[0 ~ 100 / 45 / 1%/step]
	5	Nrml/2nd/2C	[0 ~ 100 / 90 / 1%/step]
	6	Nrml/2nd/3C	[0 ~ 100 / 100 / 1%/step]
	7	Thick/1st/1C	[0 ~ 100 / 45 / 1%/step]
	8	Thick/1st/2C	[0 ~ 100 / 90 / 1%/step]
	9	Thick/1st/3C	[0 ~ 100 / 100 / 1%/step]
	10	Thick/2nd/1C	[0 ~ 100 / 45 / 1%/step]
	11	Thick/2nd/2C	[0 ~ 100 / 90 / 1%/step]
	12	Thick/2nd/3C	[0 ~ 100 / 100 / 1%/step]
	13	OHP/1C	[0 ~ 100 / 60 / 1%/step]
	14	OHP/2C	[0 ~ 100 / 90 / 1%/step]
15	OHP/3C	[0 ~ 100 / 100 / 1%/step]	
400*	ClnBiasLL1		
	1	1C	Adjusts the transfer belt cleaning bias voltage when absolute humidity AH (g/m^3) is in the following range: 0 < AH \leq 3.5 (this is the 'LL1' humidity range) DFU [0 ~ 2000 / 1200 / 10 Volt/step]
	2	2C-4C	[0 ~ 2000 / 1200 / 10 Volt/step]
	3	HalfSpeed/1C	[0 ~ 2000 / 1200 / 10 Volt/step]
	4	HalfSpeed/2C-4C	[0 ~ 2000 / 1200 / 10 Volt/step]
	5	Ppattern	[0 ~ 2000 / 1600 / 10 Volt/step]
	6	NolmageArea	[0 ~ 2000 / 1400 / 10 Volt/step]
7	JamRecovery	[0 ~ 2000 / 1600 / 10 Volt/step]	
401*	ClnBiasLL2		
	1	1C	Adjusts the transfer belt cleaning bias voltage when absolute humidity AH (g/m^3) is in the following range: 3.5 < AH \leq 8.0 (this is the 'LL2' humidity range) DFU [0 ~ 2000 / 1600 / 10 Volt/step]
	2	2C-4C	[0 ~ 2000 / 1600 / 10 Volt/step]
	3	HalfSpeed/1C	[0 ~ 2000 / 1600 / 10 Volt/step]
	4	HalfSpeed/2C-4C	[0 ~ 2000 / 1600 / 10 Volt/step]
	5	Ppattern	[0 ~ 2000 / 1600 / 10 Volt/step]
	6	NolmageArea	[0 ~ 2000 / 1400 / 10 Volt/step]
7	JamRecovery	[0 ~ 2000 / 1600 / 10 Volt/step]	
402*	ClnBiasNN1		
1	1C	Adjusts the transfer belt cleaning bias voltage when absolute humidity AH (g/m^3) is in the following range: 8.0 < AH \leq 14 (this is the 'NN1' humidity range) DFU [0 ~ 2000 / 1700 / 10 Volt/step]	

2	Mode No. (Class 1, 2, and 3)		Function / [Setting]
402*	2	2C-4C	[0 ~ 2000 / 1700 / 10 Volt/step]
	3	HalfSpeed/1C	[0 ~ 2000 / 1700 / 10 Volt/step]
	4	HalfSpeed/2C-4C	[0 ~ 2000 / 1700 / 10 Volt/step]
	5	Ppattern	[0 ~ 2000 / 1600 / 10 Volt/step]
	6	NoImageArea	[0 ~ 2000 / 1400 / 10 Volt/step]
	7	JamRecovery	[0 ~ 2000 / 1600 / 10 Volt/step]
	403*	ClnBiasNN2	
1		1C	Adjusts the transfer belt cleaning bias voltage when absolute humidity AH (g/m ³) is in the following range: 14 < AH ≤ 19 (this is the 'NN2' humidity range) DFU [0 ~ 2000 / 1700 / 10 Volt/step]
2		2C-4C	[0 ~ 2000 / 1700 / 10 Volt/step]
3		HalfSpeed/1C	[0 ~ 2000 / 1700 / 10 Volt/step]
4		HalfSpeed/2C-4C	[0 ~ 2000 / 1700 / 10 Volt/step]
5		Ppattern	[0 ~ 2000 / 1600 / 10 Volt/step]
6		NoImageArea	[0 ~ 2000 / 1400 / 10 Volt/step]
7		JamRecovery	[0 ~ 2000 / 1600 / 10 Volt/step]
404*	ClnBiasHH		
	1	1C	Adjusts the transfer belt cleaning bias voltage when absolute humidity AH (g/m ³) is in the following range: 19 < AH (this is the 'HH' humidity range) DFU [0 ~ 2000 / 1700 / 10 Volt/step]
	2	2C-4C	[0 ~ 2000 / 1700 / 10 Volt/step]
	3	HalfSpeed/1C	[0 ~ 2000 / 1700 / 10 Volt/step]
	4	HalfSpeed/2C-4C	[0 ~ 2000 / 1700 / 10 Volt/step]
	5	Ppattern	[0 ~ 2000 / 1600 / 10 Volt/step]
	6	NoImageArea	[0 ~ 2000 / 1400 / 10 Volt/step]
	7	JamRecovery	[0 ~ 2000 / 1600 / 10 Volt/step]
500*	FusingBias (Discharge pin)		
	1	Nrml/1C/1st	Adjusts the discharge pin voltage (paper separation) and fusing bias voltage. DFU [4000 ~ 1000 / 3000 / 100 Volt/step] • Same bias voltage is applied to the fusing unit and the discharge pin.
500*	2	Nrml/1C/2nd	[4000 ~ 1000 / 3000 / 100 Volt/step]
	3	Nrml/FC/1st	[4000 ~ 1000 / 2500 / 100 Volt/step]
	4	Nrml/FC/2nd	[4000 ~ 1000 / 2500 / 100 Volt/step]
	5	Thk/1C/1st	[4000 ~ 1000 / 3000 / 100 Volt/step]
	6	Thk/1C/2nd	[4000 ~ 1000 / 3000 / 100 Volt/step]
	7	Thk/FC/1st	[4000 ~ 1000 / 2500 / 100 Volt/step]
	8	Thk/FC/2nd	[4000 ~ 1000 / 2500 / 100 Volt/step]
	510*	Fu_Bias_SW	
1		Fu_Bias_SW	Switches the fusing and discharge pin bias control on or off. [0 ~ 1 / 1 / 1/step] DFU • 0: Control off • 1: Control on
801*	ChrgClnIntval		
	1	ChrgClnIntval	Sets the charge corona unit cleaning interval. [0 ~ 5000 / 600 / 100 counts/step] Refer to section 6 for details.

2	Mode No. (Class 1, 2, and 3)		Function / [Setting]
802	ChargerCln		
	1	Charger Cln	Executes a forced charge corona unit cleaning. Set to 1 to start cleaning. [0 ~ 1 / 0 / 1/step]
901*	EnvControl		
	1	EnvControl	Switches environment control on or off. [0 ~ 1 / 1 / 1/step] DFU <ul style="list-style-type: none"> • 0: Control off (The paper transfer and cleaning bias environments are set to NN1. The image transfer bias environment is set to MM.) • 1: Control on
903	PaperTrans_Low		
	1	LL1/Nrml	Adjusts the paper transfer current applied when the machine is at low temperature. [0.0 ~ 70.0 / 8.0 / 0.1 μ A/step] The specified value is subtracted from the value specified by SP2-310 (PaperTrans_LL1) under the following conditions: <ul style="list-style-type: none"> • The machine is in the LL1 environment. • 400 images or less are created after the machine starts
904	1CBiasAdj		
	1	[M]	Adjusts the development bias applied during the mono-color mode. DFU [0 ~ 100 / 50 / 1 V/step]
	2	[C]	[0 ~ 100 / 0 / 1 V/step]
	3	[Y]	[0 ~ 100 / 0 / 1 V/step]
	4	[K]	[0 ~ 100 / 0 / 1 V/step]
912	Temp_HumDisp		
	1	Temp	Displays the temperature measured by the temperature sensor inside the machine. [-127 ~ 127 / 0 / 1°C/step]
	2	Humidity_1	Displays the humidity measured by the humidity sensor inside the machine. [0 ~ 255 / 0 / 1%/step]
	3	Humidity_2	Displays the absolute humidity calculated from the temperature/humidity sensor readings. [0 ~ 65535 / 0 / 0.1 g/m ³ /step]
912	4	EnvLevel	Displays the current humidity level calculated from the absolute humidity. [0 ~ 1 / 0 / 1/step] <ul style="list-style-type: none"> • LL1: 0 < AH \leq 3.5 • LL2: 3.5 < AH \leq 8.0 • NN1: 8.0 < AH \leq 14 • NN2: 14 < AH \leq 19 • HH: 19 < AH * AH = absolute humidity

2	Mode No. (Class 1, 2, and 3)		Function / [Setting]
917	Test Pattern		
	1	Test Pattern	Allows you to print out the test pattern. [0 ~ 1 / 0 / 1/step] • 1: Print out the test patterns listed in SP5-955 (Test Pattern – Pattern). To print the selected chart, change the setting from 0 to 1, then print out the demo sheet (user tool) or send a print job from a PC.
930*	TrimAdjust		
	1	Front	Adjusts the white margin on printouts. [0 ~ 65535 / 0 / 1/step]
	2	Back	[0 ~ 65535 / 0 / 1/step]
	3	Lead	[0 ~ 65535 / 20 / 1/step]
4	Trail	[0 ~ 65535 / 20 / /step]	
939	OPC_Lub_Int		
	1	OPC_Lub_Int	Executes/does not execute OPC lubrication by interrupting the job. DFU [0 ~ 1 / 0 / 1/step] • 0: Off • 1: On SP2-942-1 (OPC_Lub_Intrvl) specifies the lubrication interval.
940	OPC_Lub_Mode		
	1	OPC_Lub_Mode	Executes a forced OPC lubrication to reduce the friction on the OPC belt. DFU [0 ~ 1 / 0 / 1/step] • The OPC belt and the lubricant brush operate for 2 minutes.
941	OPC_Lub_Time		
	1	job end	Determines how long the OPC belt is lubricated for after the end of every job. [0 ~ 30 / 20 / 1 s/step]
	2	OPC_Lub_Int	Determines how long the OPC belt is lubricated at the forced lubrication [0 ~ 60 / 10 / 1 s/step]
942	OPC_Lub_Intrvl		
	1	OPC_Lub_Intrvl	[10 ~ 200 / 50 / 10/step] DFU When SP2-939 (OPC_Lub_Int) is set to on, the machine lubricates the OPC belt and image transfer belt at the interval (number of prints) set with this SP. Incoming print jobs do not interrupt the lubrication.
943	DischargeTslid (Discharge Threshold)		
	1	DischargeTslid	Adjusts the threshold of discharge. DFU [13.0 ~ 22.0 / 17.0 / 1.0 g/m ³ /step]

2	Mode No. (Class 1, 2, and 3)		Function / [Setting]
944	OPCLub:LrgArea		
	1	Int	<p>Enables/disables OPC lubrication after a certain amount of images are printed. The lubrication timing depends on SP2-944-2 to -5.</p> <p>When high coverage images are continuously printed, cleaning of the OPC may not be enough. To correct this, OPC lubrication is carried out during printing (lubrication time: around 34 seconds).</p> <ul style="list-style-type: none"> • On • Off <p>When "on" is set, OPC lubrication is executed under either of the following conditions:</p> <p>Condition 1. The number of printouts since the previous lubrication reaches the value in SP2-944-4; and the average pixel coverage of those printouts exceeds the value in SP2-944-2.</p> <p>Conditions 2. The number of printouts since the previous lubrication reaches the value in SP2-944-5; and the average pixel coverage of those printouts exceeds the value in SP2-944-3.</p>
	2	ImgAreaValue1	Adjusts the average pixel. [50 ~ 800 / 500 / 10 /step]
	3	ImgAreaValue2	[50 ~ 800 / 350 / 10 /step]
	4	Sheets1	[10 ~ 80 / 20 / 1 /step]
	5	Sheets2	[10 ~ 80 / 40 / 1 /step]
950	S_Reg._Adj.		
	1	M(2:P1b)	<p>Colour registration adjustment: adjusts the start timing of imaging for each color. DFU</p> <p>[-3 ~ 3 / -1 / 2 line/step]</p> <ul style="list-style-type: none"> • 2 lines = 0.047566 ms (about 85 μm) • +: Delays the start timing. • -: Advances the start timing. • The start timing is adjusted only in plain paper mode, and when one of the following conditions is satisfied: <ol style="list-style-type: none"> 1) Between the two images on the transfer belt (when two images are developed on the OPC at the same time (☛ 6.2)) 2) B4 SEF or larger (multi-print job)
	2	C(2:P1b)	[-3 ~ 3 / 0 / 2 line/step]
	3	Y(2:P1b)	[-3 ~ 3 / 0 / 2 line/step]
	4	K(2:P1b)	[-3 ~ 3 / 0 / 2 line/step]
	5	M(1:P1b)	[-3 ~ 3 / -1 / 2 line/step]
	6	C(1:P1b)	[-3 ~ 3 / 0 / 2 line/step]
	7	Y(1:P1b)	[-3 ~ 3 / 0 / 2 line/step]
	8	K(1:P1b)	[-3 ~ 3 / 0 / 2 line/step]
	9	M(P1a)	For use in Japan only.
	10	C(P1a)	[-3 ~ 3 / 0 / 2 line/step]
	11	Y(P1a)	
	12	K(P1a)	

2	Mode No. (Class 1, 2, and 3)		Function / [Setting]
960 *	Tray_Heater		
	1	Tray_Heater	Optional tray heaters installed or not [0 ~ 1 / 0 / 1/step] 0: No, 1: Yes
970	OilClearMode		
	1	Mode	Enables/disables the settings of SP2-970-2 through 4. [0 ~ 1 / 1 / 1/step] <ul style="list-style-type: none"> • 0: Does not clear • 1: Clears Oil on duplex copies gets on the transfer belt, and this can cause uneven image density. To remove this oil, printing stops, the PCU turns, and the cleaning unit removes the oil.
	2	Print_Int	Enables/disables interruption of the oil removal process. [0 ~ 1 / 0 / 1/step] <ul style="list-style-type: none"> • 0: Users cannot interrupt • 1: Users can interrupt If interruption is enabled, the user does not need to wait until the oil removal process ends, but the output image may be poor.
	3	Repetition_Num	Specifies how many times the oil removal process is repeated. [1 ~ 20 / 5 / 1/step] The more times the oil removal is repeated, the better the output images are; but the longer it takes
	4	Dup_Sheets	Specifies how often the oil removal process is done. The unit is the number of duplex prints. The counter counts down once every narrow (A4 SEF or less) duplex sheet, and counts back up 1 for every other type of sheet. [1 ~ 50 / 10 / 1/step]



SP3-XXX: (Process)

3	Mode No. (Class 1, 2, and 3)	Function / [Setting]
001	ProcessCtrl	
	1	ProcessCtrl Does a forced process control, and displays the result as one of the following codes. [0 ~ 1 / 0 / 1/step] <ul style="list-style-type: none"> • 0: Normal termination • 103: Error (ID sensor inactive → Defective ID sensor, Defective circuit, Defective BCU board) • 104: Error (ID sensor unable to receive light → Defective OPC belt, Dirty OPC belt, Defective ID sensor, Defective circuit, Defective BCU board) • 105: Error (ID sensor unable to receive reflection from OPC → Same as "104") • 254: Execution impossible (Executed while not in the ready status) • 255: Execution aborted (due to an SC or a cover opened)
003*	Lub_Interval	
	1	Lub_Interval Sets the process control interval. [0 ~ 1000 / 200 / 10 sheet/step] <ul style="list-style-type: none"> • 0: Disables automatic process control
004*	EnvChange	
	1	Temp Sets the temperature/humidity change that triggers process control (process control is done if temperature or humidity has changed by this amount since the previous process control). [0 ~ 255 / 15 / 1°C/step]
	2	Humidity [0 ~ 65535 / 15.0 / 1.0 g/m ³ /step]
005*	ProconPreRound	
	1	ProconPreRound PCU and development unit idling is done before process control. This value determines the amount of idling rotation. [1 ~ 5 / 1 / 1 turn/step] <ul style="list-style-type: none"> • 1 turn: A3 length
006*	DensityAdjust	
	1	M/A AdjustLevel
	2	Vh_ AdjustLevel Select the toner density compensation level for process control. [0 ~ 3 / 0 / 1/step] <ul style="list-style-type: none"> • 0: None • 1: Weak • 2: Medium • 3: Strong <i>The higher the value, the darker the prints will be.</i>

3	Mode No. (Class 1, 2, and 3)	Function / [Setting]
910*	DoctorIntval	
	1	print(FC) Sets the doctor roller reverse rotation interval. [0 ~ 50 / 50 / 1 sheet/step] <ul style="list-style-type: none"> • The value indicates how many sheets are output before the doctor roller is reversed. (Sheet counts are converted into equivalent A4-LEF sheet counts.) • Reversing the roller removes toner blockages. • The sheet count is reset after reverse rotation. • Decrease the value when vertical white lines appear on prints.
	2	print(MC) [0 ~ 65535 / 50 / 1 sheet/step]
	3	job end [0 ~ 65535 / 20 / 1 sheet/step]
920*	Lub._CL_Time	
	1	Lub._CL_Time Sets the OPC belt lubrication period. DFU [0 ~ 100 / 100 / 10%/step] <ul style="list-style-type: none"> • When 100 is specified, the OPC belt cleaning clutch is always on whenever the OPC is turning, so the OPC gets lubricated. When 50 is specified, the clutch is only on half the time that the motor is on.
940	JobEnd_Int	
	1	JobEnd_Int The OPC belt is lubricated after the end of every job. This SP determines whether the lubrication is interrupted when a job arrives at the printer. [0 ~ 1 / 0 / 1/step] <ul style="list-style-type: none"> • 0: Interrupted • 1: Not interrupted
941	OPC_Ide_PwrOn	
	1	Idling_Time The image transfer belt tends to curl after a long period without rotation. To correct this, image transfer belt idling is done if the fusing temperature is not high enough to print <u>just after the main switch is turned on</u> . This SP determines how long the idling rotation is done. [3 ~ 5 / 3 / 1 minute/step]
	2	PrintingReady Select when the machine can accept a print job after the idling starts. <ul style="list-style-type: none"> • 0: Immediately • 1: After idling has been done for 1 minute • 2: After idling finishes. [0 ~ 2 / 0 / 1/step]
942	OPC_Ide_E_Svr	
	1	Idling_Time The image transfer belt has curl tendency after long period without rotation. The image transfer belt tends to curl after a long period without rotation. To correct this, image transfer belt idling is done if the fusing temperature is not high enough to print <u>when returning from energy saver mode</u> . This SP determines how long the idling rotation is done. [3 ~ 5 / 3 / 1 minute/step]

3	Mode No. (Class 1, 2, and 3)		Function / [Setting]
942	2	PrintingReady	Select when the machine can accept a print job after the idling starts. <ul style="list-style-type: none"> • 0: Immediately • 1: After idling has been done for 1 minute • 2: After idling finishes. [0 ~ 2 / 0 / 1/step]
970	ImgAreaRate		
	1	M	Specifies the minimum image area (expressed as a percentage of an A4 page) required to maintain optimum development unit condition (● Toner Revitalization: SP3-971 [AutoTnrConsume]). [0 ~ 10.0 / 2.0 / 0.1 %/step] <i>After 20 sheets over a number of small jobs (or after 50 sheets in one job), if the developed area is less than the value of this SP mode, toner is transferred to the image transfer belt and cleaned off. This is performed during the doctor roller reverse rotation.</i>
	2	C	[0.0 ~ 10.0 / 2.0 / 0.1 %/step]
	3	Y	[0.0 ~ 10.0 / 2.0 / 0.1 %/step]
971	AutoTnrConsume		
	1	AutoTnrConsume	Enables/disables the toner revitalization. [0 or 2 / 2 / 1 /step] <ul style="list-style-type: none"> • 0: Disables • 2: Enables <i>Continuous printing with a relatively low coverage ratio (CMYK less than 5% each) tends to reduce the charge potential of the toner, because the toner remains in the hopper for a long time. This can lead to spots on the copy. Toner revitalization removes this defective toner periodically.</i>
	EmptyRev(Bk)		
	1	EmptyRev(Bk)	Activates/deactivates 1-color idling after paper transfer. [0 ~ 1 / 0 / 1/step] <ul style="list-style-type: none"> • 0: Deactivates • 1: Activates <i>Set this to 1 if the user complains about diagonal lines in solid areas of prints that only use one toner color (M, C, or Y). It is especially noticeable in black areas.</i>

SP5-XXX: (Mode)

5	Mode No. (Class 1, 2, and 3)	Function / [Setting]
009*	Language	
	1	<p>Selects the language for the operation panel. After changing the setting, turn the main switch off and on for initialization. [2 ~ 16 / 2 / 1 /step]</p> <ul style="list-style-type: none"> • 2: <i>British</i> • 3: <i>American</i> • 4: <i>French</i> • 5: <i>German</i> • 6: <i>Italian</i> • 7: <i>Spanish</i> • 8: <i>Dutch</i> • 9: <i>Norwegian</i> • 10: <i>Danish</i> • 11: <i>Swedish</i> • 12: <i>Polish</i> • 13: <i>Portuguese</i> • 14: <i>Hungarian</i> • 15: <i>Czech</i> • 16: <i>Finnish</i>
024	mm/inch Display	
	1	<p>mm/inch Display</p> <p>Changes the unit on the display. [0 ~ 1 / 0 / 1/step]</p> <ul style="list-style-type: none"> • 0: <i>mm</i> • 1: <i>inch</i>
045*	Counter Method	
	1	<p>Counter Method</p> <p>Switches the counter display. The setting can only be changed once. [0 ~ 1 / 0 / 1/step]</p> <ul style="list-style-type: none"> • 0: <i>Developments</i> • 1: <i>Prints</i>
046*	RomUpdateDisp	
	1	<p>ROM Update</p> <p>Enables or disables the ROM Update utility. When enabled, this utility will be displayed in the user program mode. [0 ~ 1 / 1 / 1/step]</p> <ul style="list-style-type: none"> • 0: <i>Enabled</i> • 1: <i>Disabled</i>
101*	Energy Saver	
	3	<p>Level 1</p> <p>Sets the energy saver timers. [0 ~ 60 / 0 / 10 s/step]</p> <ul style="list-style-type: none"> • <i>To enable Energy Saver, use the user program mode. When Energy Saver Level 1 is enabled, the value is initialized to 30 seconds.</i> • 0: <i>Energy saver level 1 is disabled</i>
	4	<p>Level 2</p> <p>[0 ~ 3600 / 1800 / 60 s/step]</p> <ul style="list-style-type: none"> • <i>To enable Energy Saver, use the user program mode. When Energy Saver Level 2 is enabled, the value is initialized to 1,800 seconds.</i> • 0: <i>Energy saver level 2 is disabled</i>

5	Mode No. (Class 1, 2, and 3)	Function / [Setting]
104*	Double Count	
1	Double Count	The counters count double for A3/11" x 17". [0 ~ 1 / 0 / 1/step] <ul style="list-style-type: none"> • 0: Normal count • 1: Double count
305*	ES Level 2 set	
1	ES Level 2 set	Activates energy saver level 2. [0 ~ 1 / 0 / 1/step] <ul style="list-style-type: none"> • 0: Enables • 1: Disables
401*	UlimitAutoSet	
44	UlimitAutoSet	Activates the auto user code registration function (prints are counted and logged for each user code and the counts can be viewed with SmartNetMonitor). [0 ~ 1 / 1 / 1/step]0: Inactivated <ul style="list-style-type: none"> • 1: Activated
801	Memory Clear	
1	All	Clears the settings from the NVRAM and initializes the settings. <ul style="list-style-type: none"> • Enter key: Clears • Escape key: Does not clear
2	ENG_All	Clears the engine settings. <ul style="list-style-type: none"> • Enter key: Clears • Escape key: Does not clear
3	SCS (System Control Service)	Clears the system settings. <ul style="list-style-type: none"> • Enter key: Clears • Escape key: Does not clear
4	IMH (Image Memory Handler)	Clears IMH data. DFU <ul style="list-style-type: none"> • Enter key: Clears • Escape key: Does not clear
5	MCS (Memory Control Service)	Clears MCS data. DFU <ul style="list-style-type: none"> • Enter key: Clears • Escape key: Does not clear MCS is for network settings.
8	PRT	Clears the user tool settings. <ul style="list-style-type: none"> • Enter key: Clears • Escape key: Does not clear
11	NCS	Clears the network settings. <ul style="list-style-type: none"> • Enter key: Clears • Escape key: Does not clear
803	InputCheck (See section 5.3.2.)	
804	OutputCheck (See section 5.3.3.)	
810	SC_Reset	
1	SC_Reset	Resets a fusing-related SC. [0 ~ 1 / 0 / 1/step] Resets a type A service call condition. NOTE: Turn the main switch off and on after using this SP.
811	MachineSerial	

5	Mode No. (Class 1, 2, and 3)		Function / [Setting]
	2	Display	Displays the machine serial number. [0 ~ 1 / 0 / 1/step]
812*	FAX TEL No.		
	2	FAX TEL No.	Sets the fax or telephone number for a service representative by using the enter key and the down arrow key. [0 ~ 0 / 0 / 0/step] <ul style="list-style-type: none"> • Both numbers and alphabetic characters can be input.
813*	HV_SC_Sens		
	1	HV_SC_Sens	Activates/deactivates detection of SC conditions for the high voltage power supplies. [0 ~ 1 / 0 / 1/step] <ul style="list-style-type: none"> • 0: Activated • 1: Deactivated • The following SCs are affected: SC300, 301, 302, 350, 351, 400, 410, 411, 412, 413, 420, 421, 430
814*	Jam_OFF/ON		
	1	Jam_OFF/ON	Activates/deactivates jam detection. [0 ~ 1 / 0 / 1/step] <ul style="list-style-type: none"> • 0: Jam sensor activated • 1: Jam sensor deactivated
816*	RMS Setting		
	1	RMS Setting	Enables/disables the RMS function. DFU [0 ~ 1 / 0 / 1/step] <ul style="list-style-type: none"> • 0: Disable • 1: Enable
828	Network		
	66	HD job Clear	Clears/prints the jobs spooled on the HDD (before the main power was turned off) after initialization. [0 ~ 1 / 0 / 1 /step] <ul style="list-style-type: none"> • 0: Clears • 1: Prints
	67	JobSpool(LPR)	Spools/does not spool jobs. [0 ~ 1 / 0 / 1 /step] <ul style="list-style-type: none"> • 0: Does not spool • 1: Spools
	68	JopSpool(IPP)	Spools/does not spool jobs. [0 ~ 1 / 0 / 1 /step] <ul style="list-style-type: none"> • 0: Does not spool • 1: Spools
832	HDD Init		
	1	HDD Init.	Initializes the hard disk. [0 ~ 0 / 0 / 0 /step] <i>Use this SP mode only for hard disk error recovery.</i>
833*	JobLog ON/OFF		

5	Mode No. (Class 1, 2, and 3)		Function / [Setting]
	7	JobLog ON/OFF	Saves the results of jobs in the job log. [0 ~ 1 / 0 / 1 /step] <ul style="list-style-type: none"> • <i>If this mode is enabled, the result data is written on the HDD. If no HDD is installed, this feature is disabled even if this SP is set to "enabled".</i> • <i>0: Disabled</i> • <i>1: Enabled</i>
839	IEEE1394		
	4	Device Name	Displays the host name.
	7	Cycle Master	Activates/deactivates the cycle master function. [0 ~ 1 / 1 / 1 /step] <ul style="list-style-type: none"> • <i>0: Deactivates</i> • <i>1: Activates</i>
	8	BCR mode	Specifies the setting of the broadcast channel register (BCR). [0 ~ 3 / 3 / 1 /step] <ul style="list-style-type: none"> • <i>0: Does not operate until IRM writes data</i> • <i>1: Wait awhile; copies the BCR of IRM if IRM does not write data</i> • <i>2: (Reserved)</i> • <i>3: Always validates the BCR</i>
	9	IRM 1394a Check	Executes/does not execute the 1394a check of IRM (1 bit). [0 ~ 1 / 0 / 1 /step] <ul style="list-style-type: none"> • <i>0: Does not execute</i> • <i>1: Executes</i>
	10	Unique ID	Shows/does not show node unique IDs. [0 ~ 1 / 1 / 1 /step] <ul style="list-style-type: none"> • <i>0: Does not show</i> • <i>1: Shows</i>
	11	Logout	Specifies how the initiators are handled. [0 ~ 1 / 1 / 1 /step] <ul style="list-style-type: none"> • <i>0: Rejects the initiator if it tries to log in once again after having logged off</i> • <i>1: Rejects the initiator if it tries to log on once again after having logged off; then forcefully makes the initiator log in</i>
	12	Login	Validates/invalidates exclusive logon processing. [0 ~ 1 / 0 / 1 /step] <ul style="list-style-type: none"> • <i>0: Invalidates exclusive logon processing</i> • <i>1: Validates exclusive logon processing</i>
	13	Login MAX	Specifies the maximum number of initiators that are able to log on. [0 ~ 63 / 8 / 1 /step]
840	IEEE 802.11b		
	4	Current SSID	Displays the current SSID.
	6	Channel Max	Specifies the maximum number of channels. [0 ~ 14 / 0 / 1 /step]
	7	Channel Min	Specifies the minimum number of channels. [0 ~ 14 / 0 / 1 /step]
	11	WEP key number	Displays the WEP key number.
844	USB		

5	Mode No. (Class 1, 2, and 3)		Function / [Setting]
	1	TransferRate	Specifies the transfer rate. <ul style="list-style-type: none"> • HS/FS Auto • <i>FS Fixation</i>
	2	Vendor ID	Specifies the vendor ID. [0000 ~ FFFF / 05CA / 1 /step]
	3	Product ID	Specifies the vendor ID. [0000 ~ FFFF / 0403 / 1 /step]
	4	DevReleaseNum (Device Release Number)	Specifies the device release number. [0 ~ 9999 / 100 / 1 /step]
851	Bluetooth		
	1	Bluetooth	Selects the Bluetooth mode. DFU <ul style="list-style-type: none"> • Public • <i>Private</i>
907	Plug/Play		
	1	Plug/Play	Specifies the Plug and Play setting. [0 ~ 6 / 0 / 1 /step] <ul style="list-style-type: none"> • <i>0: Ricoh Asia & EU</i> • <i>1: Ricoh US</i> • <i>2: SAVIN</i> • <i>3: GES</i> • <i>4: NRG</i> • <i>5: Infotec</i> • <i>6: LANIER</i>
930*	Meter_Charge		
	1	Meter_Charge	Activates the meter charge function. [0 ~ 1 / 0 / 1 /step] <ul style="list-style-type: none"> • <i>0: Off</i> • <i>1: On</i>
931	PM_Display		



5	Mode No. (Class 1, 2, and 3)		Function / [Setting]
	1	Charger	Specifies whether the PM warning for the charge corona unit is displayed when the replacement time arrives. <ul style="list-style-type: none"> • 1: Displayed • 0: Not displayed
	2	PCU	Specifies whether the PM warning for the PCU is displayed when the replacement time arrives. <ul style="list-style-type: none"> • 1: Displayed • 0: Not displayed
	3	Bank_Feed	Specifies whether the PM warning for the feed rollers in the optional paper feed unit is displayed when the replacement time arrives. <ul style="list-style-type: none"> • 1: Displayed • 0: Not displayed
945*	MidThickPaper		Defines whether a tray contains 'normal' or 'middle thick' paper, when the user tool setting for the tray is set to 'plain'. [0 ~ 1 / 1 / 1 /step] <ul style="list-style-type: none"> • 0: Yes (>90g/m², 24lb) • 1: No (Normal) • <i>The user tool setting (Paper Input – Paper Type) defines whether each tray contains 'normal', thick, or OHP. SP5-945 defines what 'normal' means for each tray (either 'normal' or '>90g/m², 24lb').</i> • <i>Thick: Use this for paper heavier than 105 g/m² (28 lb)</i> NOTE: '>90g/m ² , 24lb' means 'greater than or equal to 90g/m ² , 24lb'.
	1	Tray1	
	2	Tray2	
	3	Tray3	
	6	Bypass Tray	
955*	Test Pattern		

Service Tables

5	Mode No. (Class 1, 2, and 3)		Function / [Setting]
	1	Pattern	<p>Selects the test pattern. ⇒ Enable with SP2-917 (Test Pattern), then send a job from a PC or print an SMC list. [0 ~ 255 / 0 / 1 /step]</p> <ul style="list-style-type: none"> • 0: Normal operation • 1: Vertical 1 dot & 1 line • 2: Horizontal 1 dot & 1 line • 3: Vertical 2 dots & 1 line • 4: Horizontal 2 dots & 1 line • 5: Grid – 1 dot & 1 line • 6: Grid – 1 dot & dual lines • 7: Independent dot pattern • 8: 2 independent dots pattern • 9: Black • 10: Belt pattern • 11: Trimmed area • 12: 2 dots & 1 trimmed area • 13: Slant grid • 14: 2 dots & a slant grid • 15: Horizontal (dots & a stitch pattern) • 16: Check Flag • 19: 4 independent dots • 20: Horizontal 1 dot & a line (LD 1/2 reversals) • 21: Grid – 1 dot & a line (LD 1/2 reversals) • 22: Grid – 1 dot & dual lines (LD 1/2 reversals) • 23: Independent 1 dot pattern (LD 1/2 reversals) • 24: 3 line gray scale • 25: Horizontal gray scale • 26: Vertical gray scale • 29: Horizontal gray scale extended • 30: Vertical gray scale extended • 31: Horizontal gray scale 600 dpi • 32: Vertical gray scale 600 dpi • 35: Horizontal gray scale with white spots • 36: Vertical gray scale with white spots • 38: Horizontal gray scale extended with white spots • 39: Vertical gray scale extended with white spots • 40: Horizontal gray scale 600 dpi with white spots • 41: Vertical gray scale 601 dpi with white spots • 43: White - for process evaluation • 50: Vertical stitch & dot pattern • 51: 2 beam density pattern • 52: Trimmed area & cross pattern • 53: Grid – 1 dot & 1 line (2) • 54: Grid – 1 dot & dual lines (2) • 55: Independent 2 dot pattern – 40 mm sub scan • 56: Independent 2 dot pattern – 102.5 mm sub scan • 57: Process control pattern <p>Reset to 0 after finishing the tests.</p>
	2	Density	<p>Adjusts the test pattern density [0 ~ 255 / 255 / 1 /step]</p>
970	DebugSerial		

5	Mode No. (Class 1, 2, and 3)		Function / [Setting]
	1	DebugSerial	[0 ~ 0xff / 0x00 / 0 /step] DFU
990*	SP print mode		
	1	SP all print	Prints SP setting data.
	2	All	[0 ~ 255 / 0 / 0 /step]
	4	Loging	<ul style="list-style-type: none"> • SP all print: All items printed out with SPs 5-990-2, -4, -6, and -7.
	6	Non-Default	<ul style="list-style-type: none"> • All: All SP mode settings
	7	NIB Summry	<ul style="list-style-type: none"> • Non-Default: SP settings that have been changed from the defaults
998	ColorAdjExe		
	1	ColorAdjExe	Executes charge corona wire cleaning and forced process control. [0 ~ 1 / 0 / 1 /step]

SP7-XXX: (Data Log)

7	Mode No. (Class 1, 2, and 3)	Function / [Setting]
003*	M/C Counter	
	1 P: Total	Displays the values of the color counters. [-3000 ~ 9999999 / 0 / 1/step]
	7 P: B&W	[0 ~ 9999999 / 0 / 1/step]
	8 P: Full Color	[0 ~ 9999999 / 0 / 1/step]
	10 D: Color	[-3000 ~ 9999999 / 0 / 1/step] <i>This SP mode is development counter for meter charge mode.</i>
	11 D: B&W	[-2000 ~ 9999999 / 0 / 1/step] <i>This SP mode is development counter for meter charge mode.</i>
	20 P: Full color	[-1000 ~ 9999999 / 0 / 1/step] <i>This SP mode is used for the Japanese market only.</i>
	21 P: B&W/Single	[-2000 ~ 9999999 / 0 / 1/step] <i>This SP mode is used for the Japanese market only.</i>
	22 P: Single	[-2000 ~ 9999999 / 0 / 1/step] <i>This SP mode is used for the Japanese market only.</i>
	23 P: B&W	[-2000 ~ 9999999 / 0 / 1/step] <i>This SP mode is used for the Japanese market only.</i>
	25 P: Full Color	[-1000 ~ 9999999 / 0 / 1/step] <i>This SP mode is used for the Japanese market only.</i>
	28 P: Color (except for B&W)	[-1000 ~ 9999999 / 0 / 1/step] <i>This SP mode is print counters for meter charge mode. This SP mode is used in all markets.</i>
	29 P: B&W	[-2000 ~ 9999999 / 0 / 1/step] <i>This SP mode is print counters for meter charge mode. This SP mode is used in all markets.</i>
	30 P: Color Total	[-1000 ~ 9999999 / 0 / 1/step] <i>This SP mode is print counters for meter charge mode. This SP mode is used in all markets.</i>
007*	Other Counter	
	1 Duplex	Displays counter values.
	2 A3/DLT/Over420	[0 ~ 9999999 / 0 / 0 sheet/step]
	3 Staple	
101*	Size Counter	
	4 A3	Displays the counter values for each paper size. [0 ~ 9999999 / 0 / 0 sheet/step]
	5 A4	
	6 A5	
	13 B4	
	14 B5	
	32 11" x 17"	
	36 8 1/2" x 14"	
	38 8 1/2" x 11"	
	44 5 1/2" x 8 1/2"	
	128 Other	
106*	WasteTnrFull	
	1 OPC	Displays the waste toner bottle counter. [0 ~ 65535 / 0 / 1 /step]
	2 Belt	[0 ~ 65535 / 0 / 1 /step]

7	Mode No. (Class 1, 2, and 3)	Function / [Setting]
107*	OilCounter	
	1	EndCounter
	2	NearEndCounter
Displays the oil supply unit counter. [0 ~ 65535 / 0 / 1 /step]		
204*	Feed Counter	
	1	Tray1
	2	Tray2
	3	Tray3
	5	By-pass
	6	Duplex
Displays the number of sheets fed from each paper feed station. [0 ~ 9999999 / 0 / 0 sheet/step]		
502*	Total Jam	
	1	Total Jam
Displays the total number of jams detected. [0 ~ 9999 / 0 / 0 /step]		
504*	Jam Location	
	3	Tray1:NonFeed
	4	Tray2:NonFeed
	5	Tray3:NonFeed
	6	Bypass:NonFeed
	8	VerticalTrans1
	9	VerticalTrans3
	12	Regist.1
	13	Regist.3
	14	Fusing_Unit1
	16	Exit1
	17	Relay1
	19	EntDuplex1
	20	EntDuplex:Rev1
	23	ExitDuplex1
	40	Ent.Fin.
	41	Exit_Fin.
	42	Base_Fin.
	52	Tray2: OFF
	53	Tray3: OFF
	58	VerticalTrans1
	59	VerticalTrans2
	60	VerticalTrans3
	63	Regist.2
	64	Regist.4
	66	Exit2
	67	Relay2
	69	EntDuplex2
	70	EntDuplex:Rev2
	73	ExitDuplex2
	100	Finisher entrance/Upper Mail box
	101	Finisher Exit/Lower Mail box
	102	Finisher Print removed
103	Finisher Base sensor	
104	Finisher Staple Error	
Displays the number of jams according to the location. where they were detected. [0 ~ 9999 / 0 / 0 /step]		

7	Mode No. (Class 1, 2, and 3)		Function / [Setting]
504*	105	Finisher Tray Shift Error	Displays the number of jams according to the location. where they were detected. [0 ~ 9999 / 0 / 0 /step]
	106	Finisher Tray Lift Error	
	133	Finisher Exit: off	
506*	Jam Paper Size		Displays the number of jams according to paper size. [0 ~ 9999 / 0 / 1 /step]
	4	A3	
	5	A4	
	13	B4	
	14	B5	
	32	11" x 17"	
	36	8 1/2" x 14"	
	38	8 1/2" x 11"	
	44	5 1/2" x 8 1/2"	
128	Other		
508*	Replace_Cnter		Displays how many times the parts/consumables have been replaced. [0 ~ 255 / 0 / 1 /step]
	1	PCU	
	2	Development: M	
	3	Development: C	
	4	Development: Y	
	5	Development: Bk	
	6	FusingUnit	
	7	Charger	
	8	Oil	
	9	WesteTnr: OPC	
508*	11	Tonner: M	Displays how many times the parts/consumables have been replaced. [0 ~ 255 / 0 / 1 /step]
	12	Tonner: C	
	13	Tonner: Y	
	14	Tonner: Bk	
	15	Bank1_Feed	
	16	Bank2_Feed	
509*	Proc_Cnt_Cnter		Displays the process control counter. [0 ~ 9999999 / 0 / 1 /step]
	1	Proc_Cnt_Cnter	
510*	Chgr_Cln_Cntr		Displays the charge corona unit cleaning counter. [0 ~ 9999999 / 0 / 1 /step]
	1	Chgr_Cln_Cntr	

7	Mode No. (Class 1, 2, and 3)	Function / [Setting]																				
603*	<table border="1"> <tr> <td colspan="2" data-bbox="308 293 676 322">Proc_ErrorLog</td> </tr> <tr> <td data-bbox="308 322 379 351">1</td> <td data-bbox="379 322 676 351">Log 1</td> </tr> <tr> <td data-bbox="308 351 379 380">2</td> <td data-bbox="379 351 676 380">Log 2</td> </tr> <tr> <td data-bbox="308 380 379 409">3</td> <td data-bbox="379 380 676 409">Log 3</td> </tr> </table>	Proc_ErrorLog		1	Log 1	2	Log 2	3	Log 3	<p>Displays the process control error log. [0 ~ 9999999 / 0 / 1 /step]</p> <ul style="list-style-type: none"> • 103: ID sensor unable to receive light Reasons: ID sensor failure or incorrect installation, BCU failure • 104: ID sensor unable to receive reflection Reasons: As for 103, plus: Uneven OPC belt surface, foreign material on OPC belt • 105: ID sensor unable to receive OPC reflection Reasons: As for 103, plus: Uneven OPC belt surface, foreign material on OPC belt • 110: ID sensor defective imaging – Cyan Reasons: Abnormal development bias, dirty bias terminal, development unit incorrectly installed, BCU failure • 111: ID sensor defective imaging – Magenta Reasons: As for 110 • 113: ID sensor defective imaging – Cyan Reasons: As for 110, plus: Laser writing failure, abnormal charge, loss of synchronization • 114: ID sensor defective imaging – Magenta Reasons: As for 110, plus: Laser writing failure, abnormal charge, loss of synchronization • 115: ID sensor defective imaging – Yellow Reasons: As for 110, plus: Laser writing failure, abnormal charge, loss of synchronization • 116: ID sensor defective imaging – Black Reasons: As for 110 • 118: Black not detected Reasons: As for 110 • 123: ID sensor defective imaging – Black Reasons: As for 110, plus: Laser writing failure, abnormal charge, loss of synchronization 												
Proc_ErrorLog																						
1	Log 1																					
2	Log 2																					
3	Log 3																					
803*	<table border="1"> <tr> <td colspan="2" data-bbox="308 1368 676 1397">PM_Counter</td> </tr> <tr> <td data-bbox="308 1397 379 1426">1</td> <td data-bbox="379 1397 676 1426">PCU</td> </tr> <tr> <td data-bbox="308 1426 379 1456">2</td> <td data-bbox="379 1426 676 1456">Development: M</td> </tr> <tr> <td data-bbox="308 1456 379 1485">3</td> <td data-bbox="379 1456 676 1485">Development: C</td> </tr> <tr> <td data-bbox="308 1485 379 1514">4</td> <td data-bbox="379 1485 676 1514">Development: Y</td> </tr> <tr> <td data-bbox="308 1514 379 1543">5</td> <td data-bbox="379 1514 676 1543">Development: Bk</td> </tr> <tr> <td data-bbox="308 1543 379 1572">6</td> <td data-bbox="379 1543 676 1572">FusingUnit</td> </tr> <tr> <td data-bbox="308 1572 379 1601">7</td> <td data-bbox="379 1572 676 1601">Charger</td> </tr> <tr> <td data-bbox="308 1601 379 1630">8</td> <td data-bbox="379 1601 676 1630">Bank1_Feed</td> </tr> <tr> <td data-bbox="308 1630 379 1659">9</td> <td data-bbox="379 1630 676 1659">Bank2_Feed</td> </tr> </table>	PM_Counter		1	PCU	2	Development: M	3	Development: C	4	Development: Y	5	Development: Bk	6	FusingUnit	7	Charger	8	Bank1_Feed	9	Bank2_Feed	<p>Displays the number of sheets printed for each current unit. [0 ~ 9999999 / 0 / 1 sheet/step]</p> <ul style="list-style-type: none"> • For clearing the counters, see SP7-804.
PM_Counter																						
1	PCU																					
2	Development: M																					
3	Development: C																					
4	Development: Y																					
5	Development: Bk																					
6	FusingUnit																					
7	Charger																					
8	Bank1_Feed																					
9	Bank2_Feed																					
804	<table border="1"> <tr> <td colspan="2" data-bbox="308 1715 676 1744">PM_Clear</td> </tr> <tr> <td data-bbox="308 1744 379 1774">6</td> <td data-bbox="379 1744 676 1774">FusingUnit</td> </tr> <tr> <td data-bbox="308 1774 379 1803">7</td> <td data-bbox="379 1774 676 1803">Charger</td> </tr> <tr> <td data-bbox="308 1803 379 1832">8</td> <td data-bbox="379 1803 676 1832">Bank1_Feed</td> </tr> <tr> <td data-bbox="308 1832 379 1861">9</td> <td data-bbox="379 1832 676 1861">Bank2_Feed</td> </tr> <tr> <td data-bbox="308 1861 379 1890">100</td> <td data-bbox="379 1861 676 1890">AllReset</td> </tr> </table>	PM_Clear		6	FusingUnit	7	Charger	8	Bank1_Feed	9	Bank2_Feed	100	AllReset	<p>Clears the PM counters. [0 ~ 1 / 0 / 1 /step]</p> <ul style="list-style-type: none"> • For displaying the counter, see SP7-803. 								
PM_Clear																						
6	FusingUnit																					
7	Charger																					
8	Bank1_Feed																					
9	Bank2_Feed																					
100	AllReset																					

Service Tables

7	Mode No. (Class 1, 2, and 3)		Function / [Setting]
807	SC/Jam Clear		Clears the counters related to SC codes and paper jams. [0 ~ 1 / 0 / 0 /step]
	1	SC/Jam Clear	
808	Counter Clear		Clears all counters except for SP7-003 and -007. [0 ~ 1 / 0 / 0 /step]
	1	Counter Clear	
816	Tray Clear		Clears the tray counters (SP7-204). [0 ~ 1 / 0 / 0 /step]
	1	Tray1	
	2	Tray2	
	3	Tray3	
	5	BypassTray	
	6	Duplex	
819	OilCntRst		Resets the oil counter values to "0." [0 ~ 1 / 0 / 0 /step] • 0: Does not clear • 1: Clears
	1	OilCntRst	
825	Counter Reset		Resets the total counter values to "0." [0 ~ 0 / 0 / 0 /step]
	1	Counter Reset	
832*	Diag. Result		Displays the result of the diagnostics. Refer to section 4.2 for the error codes. [0 ~ 0 / 0 / 0 /step]
	1	Diag. Result	
833	Coverage		Displays coverage ratios. [0.00 ~ 100.0 / 0.00 / 0.01 %step] <i>This SP mode displays the "coverage ratio" of the output, i.e. the ratio of the total pixel area of the image data to the total printable area on the paper.</i> <i>Do not use this counter for billing purposes. This is because this value is not directly proportional to the amount of toner consumed, although of course it is one factor that affects this amount. The other major factors involved include: the type, total image area and image density of the original, toner concentration and developer potential.</i> <i>Last: This is the coverage for the previous sheet.</i> <i>Average: This is the average coverage for each sheet.</i>
	1	Last:M	
	2	Last:C	
	3	Last:Y	
	4	Last:Bk	
	5	Average: M	
	6	Average: C	
	7	Average: Y	
	8	Average: Bk	
834	TnrConsume		Displays the coverage ratios, including toner revitalization mode. [0 ~ 9999999 / 0 / 1 /step] <i>This displays the average coverage ratio, including toner consumed during printing and toner consumed during toner revitalization mode (SP3-971).</i> <i>Do not use this counter for billing purposes</i>
	1	M	
	2	C	
	3	Y	
	4	Bk	



7	Mode No. (Class 1, 2, and 3)	Function / [Setting]
835	HighDutyCnt	
	1	M
	2	C
	3	Y
	4	Bk
Used for the toner revitalization process (SP3-971). Counts the number of developments made during the past 12 hours.		
836	Total Memory	
	1	Total Memory
Displays the memory capacity in the controller system.		
850	P/J	
	1	P/J(1)
	2	P/J(2)
	3	P/J(3)
	4	P/J(4)
	5	P/J(5)
	6	P/J(6-10)
	7	P/J(11-20)
	8	P/J(21-)
Print per job counters are displayed.		
901	Assert Info (Assert Information)	
	1	File Name
	2	# of Lines
	3	Location
Records the location where the last problem (SC990) was detected in the program. The data stored in this SP is used for problem analysis. [0 ~ 0 / 0 / 0 /step]		
906*	PMCounter-PREV	
	1	PCU
	2	Development: M
	3	Development: C
	4	Development: Y
	5	Development: Bk
	6	FusingUnit
	7	Charger
	8	Oil
	9	WasteTnr: OPC
	10	WasteTnr: Belt
	11	Toner: M
	12	Toner: C
	13	Toner: Y
	14	Toner: Bk
	15	Bank1_Feed
	16	Bank2_Feed
	17	Development: M
	18	Development: C
	19	Development: Y
	20	Development: Bk
	21	PCU
22	FusingUnit	
Displays the counters for the previous units. [0 ~ 9999999 / 0 / 1 /step]		
910	Firmware PN	
	1	System
	2	Engine
	7	Finisher
	9	Bank1
	11	Mail Box
Displays the part numbers. [0 ~ 0 / 0 / 0 /step]		

7	Mode No. (Class 1, 2, and 3)		Function / [Setting]
910	13	Duplex	Displays the part numbers. [0 ~ 0 / 0 / 0 /step]
	18	NIB	
	19	Bank2	
	150	RPCS	
	151	PS	
	152	RPDL	
	153	R98	
	154	R16	
	155	RPGL	
	156	R55	
	157	RTIFF	
	158	PCL	
	159	PCLXL	
	160	MSIS	
	161	MSIS(OPTION)	
	200	Factory	
	204	Printer	
209	Test		
210	MIB		
911*	Firmware Version		Displays the firmware versions. [0 ~ 0 / 0 / 0 /step]
	1	Controller	
	2	Engine	
	7	Finisher	
	9	Bank1	
	11	Mail Box	
	13	Duplex	
	18	NIB	
	19	Bank2	
	150	RPCS	
	151	PS	
	152	RPDL	
	153	R98	
	154	R16	
	155	RPGL	
	156	R55	
	157	RTIFF	
	158	PCL	
	159	PCLXL	
160	MSIS		
161	MSIS(OPTION)		
200	Factory		
204	Printer		
209	Test		
210	MIB		
920	PM Interval		Adjusts the PM interval for each unit. [60 ~ 120 / 120 / 5/step]
	1	Fusing Unit	
	3	Charger	
	4	PCU	
	5	Development (K)	
	6	Development (MCY)	

7	Mode No. (Class 1, 2, and 3)	Function / [Setting]
930	PM counter correction	
	1	Development:M
	2	Development:C
	3	Development:Y
	4	Development:Bk
	5	PCU
	A unit can be replaced before its PM counter reaches the predicted value (☛ 2.2). In this case the PM counter is automatically set to "0." When you want the PM counter to take over the previous value, the counter value of the old unit can be input. After inputting the value of this SP mode, turn the main switch off and on.	

Input Check Table

The SP numbers do not appear on the screen. Just scroll through the menu with the up/down arrow keys until the required item appears on the display.

SP5-803 -XXX		Description	Reading	
			0	1
1	Tray1	Tray set (standard tray)	Set	Not set
2	Tray1PaperEnd	Paper end sensor (standard tray)	End	Not end
3	Tray1NearEnd	Paper near-end sensor (standard tray)	Not near end	Near end
4	Tray1PaperSize	Paper size sensor (standard tray)	(See table 1.)	
5	RegistSensor	Registration sensor	Detected	Not detected
6	V Trans Sensor	Paper feed sensor	Detected	Not detected
7	ExitSensor	Exit sensor	Detected	Not detected
8	ExitFull	Paper overflow sensor	Full	Not full
9	ExitCover	Exit cover switch	Closed	Open
10	IntChngSensor	Interchange unit exit sensor	Detected	Not detected
11	By-passPaper	By-pass paper end sensor	Detected	Not detected
12	By-passSet	By-pass tray set	Not set	Set
13	FusingUSet	Fusing unit set	Set	Not set
14	OilEnd	Oil supply unit empty	End	Not end
17	TonerEnd: M	Toner end sensor: M	Not end	End
18	TonerEnd: C	Toner end sensor: C	Not end	End
19	TonerEnd: Y	Toner end sensor: Y	Not end	End
20	TonerEnd: K	Toner end sensor: K	Not end	End
21	TonerCart. M	Toner cartridge memory chip: M	Not set	Set
22	TonerCart. C	Toner cartridge memory chip: C	Not set	Set
23	TonerCart. Y	Toner cartridge memory chip: Y	Not set	Set
24	TonerCart. K	Toner cartridge memory chip: K	Not set	Set
27	WasteToner OPC	OPC belt waste toner sensor	Full	Not full
28	W.T.Bottle OPC	OPC belt waste toner bottle switch	Set	Not set
31	BeltMark	Belt mark sensor	Not detected	Detected
32	PCUNew	New PCU sensor	Not new	New
33	WasteToner Blt	Transfer belt waste toner sensor	Full	Not full
34	W.T.Bottle Blt	Transfer belt waste toner bottle switch	Set	Not set
35	LD5VCover	Interlock switch	Closed	Open
36	LeftCover	"Close Left Cover" status	Closed	Open
37	RightCover	Right cover	Closed	Open
38	FrontCover	Front cover	Closed	Open
39	Cover 24V	Interlock switch (24V)	Closed	Open
41	l'changeUnit	Interchange unit	Set	Not set

SP5-803 -XXX		Description	Reading	
			0	1
42	DevMotorLock	Development motor lock	Locked	Not locked
43	OpcMotorLock	Main motor lock	Locked	Not locked
44	PfdMotorLock	Paper feed motor lock	Locked	Not locked
45	PolyMotorLock	Polygon motor lock	Locked	Not locked
46	FusingSensor	Fusing exit	Detected	Not detected
55	DplxConnect	Duplex unit	Not connected	Connected
56	Bank1Connect	1st optional paper tray	Not connected	Connected
57	Bank2Connect	2nd optional paper tray	Not connected	Connected
58	ExitOptConnect	Exit Option Connection	Not connected	Connected
60	Fin.EntSensor	Finisher: Entrance sensor	Not detected	Detected
61	Fin.ExitSensor	Finisher: Exit sensor	Not detected	Detected
62	Fin.HPSensor	Finisher: Jogger HP sensor	Not positioned	Positioned
63	Fin.TopCover	Finisher: Top cover sensor	Closed	Open
64	Fin.PaperHgt.	Finisher: Stack height sensor	Lever is lowered	Lever is raised
65	Fin.Upper	Finisher: Tray upper limit sensor	Not uppermost	Uppermost
66	Fin.NearFull	Finisher: Stack near-limit sensor	Not near limit	Near limit
67	Fin.StplCover	Finisher: Stapler cover	Closed	Open
68	Fin.StplHP	Finisher: Stapler HP sensor	Not at HP	At HP
69	Fin.StplEmpty	Finisher: Staple end	Detected	Not detected
70	Fin.StplCtrg	Finisher: Staple cartridge	Not detected	Detected
71	Fin.StplLock	Finisher: Stapler unit lock	Not locked	Locked
72	Fin.BaseSensor	Finisher: Base sensor	Not detected	Detected
73	Fin.BaseCover	Finisher: Right cover switch	Closed	Open
74	Fin.PaperPress	Finisher: Lever sensor	Lever is raised	Lever is lowered
80	4binFeedSens1	Mailbox: Lower vertical transport sensor	Paper present	No paper
81	4binFeedSens2	Mailbox: Upper vertical transport sensor	Paper present	No paper
84	4binFullSens1	Mailbox: Tray 1 overflow	Not full	Full
85	4binFullSens2	Mailbox: Tray 2 overflow	Not full	Full
86	4binFullSens3	Mailbox: Tray 3 overflow	Not full	Full
87	4binFullSens4	Mailbox: Tray 4 overflow	Not full	Full
88	4binPaperSens1	Mailbox: Tray 1 paper	Detected	Not detected
89	4binPaperSens2	Mailbox: Tray 2 paper	Detected	Not detected
90	4binPaperSens3	Mailbox: Tray 3 paper	Detected	Not detected
91	4binPaperSens4	Mailbox: Tray 4 paper	Detected	Not detected
92	4binDoorSens	Mailbox: Door safety sw.	Open	Closed
100	BankFeedSens1	1st optional tray: Relay sensor	No paper	Paper present
101	BankFeedSens2	2nd optional tray: Relay sensor	No paper	Paper present

SP5-803 -XXX		Description	Reading	
			0	1
102	BankCover1	1st optional tray: Right cover (vertical guide switch)	Closed	Open
103	BankCover2	2nd optional tray: Right cover (vertical guide switch)	Closed	Open
104	Bank1Set	1st optional tray: Set	Not set	Set
105	Bank2Set	2nd optional tray: Set	Not set	Set
106	Bank1PaperEnd	1st optional tray: Paper end	Not end	End
107	Bank2PaperEnd	2nd optional tray: Paper end	Not end	End
108	Bank1PaperSize	1st optional tray: Paper size	(See table 2.)	
109	Bank2PaperSize	2nd optional tray: Paper size		
110	Bank1NearEnd	1st optional tray: Paper height	(See table 3.)	
111	Bank2NearEnd	2nd optional tray: Paper height		
120	DplxEntSens	Duplex: Entrance sensor	Not detected	Detected
121	DplxExitSens	Duplex: Exit sensor	Detected	Not detected
122	DplxOpen	Duplex unit open switch	Closed	Open
123	DplxCover	Duplex cover sensor	Open	Closed

Table 1: Tray 1 Paper Size

Switch	North America	Europe/Asia	Value
0000	LG SEF*	B4 SEF*	00000000
0001	DLT SEF**	A3 SEF**	00100000
0010	B5 LEF	B5 LEF	00010000
0011	B5 SEF****	B5 SEF****	00110000
0100	LT LEF***	A4 LEF***	00001000
0101	HLT LEF	A5 LEF	00101000
0110	A4 SEF	A4 SEF	00011000
0111	LT SEF	LT SEF	00111000

* : Selected with SP1-902-1 [PaperSize - B4/LG], (LG SEF/B4 SEF)

** : Selected with SP1-902-2 [PaperSize - A3/DLT], (DLT SEF/A3 SEF)

*** : Selected with SP1-902-3 [PaperSize - A4/LT], (LT LEF/A4 LEF)

**** : Selected with SP1-902-4 [PaperSize - B5/Executive], (B5 SEF/10.5" x 7.25" SEF)

0: pushed

1: not pushed

Table 2: 1st/2nd Bank Paper Size

The paper size is displayed in the ASAP paper size code. For example, 000001001 (0x05) is displayed for A4 LEF.

Size	North America	Europe/Asia	Code
A3 SEF	Detected	Detected	10000100
B4 SEF	None	Detected	10100100
A4 SEF	None	Detected	10100110
A4 LEF	Detected	Detected	00000101
B5 LEF	Detected	Detected	00001110
A5 LEF	None	Detected	00101100
DLT SEF	Detected	Detected	10100000
LG SEF	Detected	None	10100100
LT SEF	Detected	None	10100110
LT LEF	Detected	Detected	00100110
HLT LEF	Detected	None	00101100

Service
Tables

Table 3: 1st/2nd Bank Near End

Remaining paper	Paper height sensor 2	Paper height sensor 1	Code
Full	ON	ON	01100100
Nearly full	OFF	ON	00110010
Near end	OFF	OFF	00001010

Output Check Table

The SP numbers do not appear on the screen. Just scroll through the menu with the up/down arrow keys until the required item appears on the display.

SP5-804 -XXX		Description
1	PF Mtr:89mm/s	Paper feed motor: 89 mm/s
2	PF Mtr:178mm/s	Paper feed motor: 178 mm/s
3	PF Mtr:240mm/s	Paper feed motor: 240 mm/s
4	PF CL (1)	Paper feed clutch (standard tray)
6	FusingMtr	Fusing unit motor
7	FusingMtr: Half	Fusing unit motor: Half Speed
8	FusingFan: High	Fusing unit fan: High speed
9	FusingFan: Low	Fusing unit fan: Low speed
12	Regist CL	Registration clutch
13	I'changeSol1	Upper gate solenoid
14	I'changeSol2	Lower gate solenoid
15	By-pass CL	By-pass paper feed clutch
16	Pick-up SOL	By-pass pick-up solenoid
17	GAPCISleepMode	GAPCIS Sleep Mode Trigger Signal
18	QL/TonerEnd	QL/Toner End
19	DevCl: M	Development clutch: M
20	DevCl: C	Development clutch: C
21	DevCl: Y	Development clutch: Y
22	DevCl: K	Development clutch: K
23	DevMtr	Development motor
24	DevMtr: Half	Development motor: Half Speed
25	DevMtr: Rev	Development motor: Reverse
26	DevMtr: RevHalf	Development motor: Reverse Half Speed
27	Lub. Cl	OPC belt cleaning clutch
28	IDsensLED	ID sensor LED
29	OPCMtr	Main motor: Regular Speed
30	OPCMtr: Half	Main motor: Half Speed
31	OPCMtr: Rev	Main motor: Reverse
32	OPCMtr: RevHalf	Main motor: Reverse Half Speed
33	PolygonMtr	Polygon motor
34	LD	LD
35	PaperTransSol	Paper transfer solenoid
36	BeltClnCl	Transfer belt cleaning clutch
37	EngineReady	Engine Ready
39	GAVDReset	GAVD Reset
40	BeltClnSol	Transfer belt cleaning contact solenoid
45	PolyMtr+LD	Polygon Motor + LD
46	Forced Lub.	Forced Lubrication to OPC belt
47	OzonFan	Ozone Fan
48	Fan3	3rd Fan (Not Used)
49	TonerEnd	Toner End LED
50	Charger	Charge corona unit output
51	Dev.Bias: KY	Development bias: K

SP5-804 -XXX		Description
52	Dev.Bias: CM	Development bias: MCY
53	Trans. Belt	Image transfer power supply
54	PaperTrans.: P	Paper transfer: +
55	PaperTrans.: N	Paper transfer: –
56	BeltCln: P	Image transfer belt cleaning: +
57	FusingBias	Fusing bias
58	QuenchingBias: L	Discharge pin power supply: L
59	QuenchingBias: H	Discharge pin power supply: H
60	Fin.AllOff	Finisher All Off
61	Fin.FeedMtr	Finisher: Main motor
62	Fin.JoggerMtr	Finisher: Jogger motor
63	Fin.PdlSol1	Finisher: Paddle roller solenoid
64	Fin.PEUSol1	Finisher: Exit unit gear solenoid
65	Fin.LeverSol	Finisher: Stack height lever solenoid
66	Fin.TrayMtr	Finisher: Output tray motor
67	Fin.StplMtr	Finisher: Stapler motor
68	Fin.FreeRun	Finisher: Free run
80	4bin AllOff	Mailbox: All Off
81	4bin Motor	Mailbox: Main motor
82	4bin SOL1	Mailbox: Turn gate solenoid 1
83	4bin SOL2	Mailbox: Turn gate solenoid 2
84	4bin SOL3	Mailbox: Turn gate solenoid 3
85	4bin FreeRun	Mailbox: Free run
100	BankCl1	1st optional paper tray unit: Paper feed clutch
101	BankCl2	2nd optional paper tray unit: Paper feed clutch
102	Bank1Mtr	1st optional paper tray unit: Paper feed motor
103	Bank1Mtr: Half	1st optional paper tray unit: Paper feed motor - half speed
104	Bank1Mtr: High	1st optional paper tray unit: Paper feed motor - high speed
105	Bank2Mtr	2nd optional paper tray unit: Paper feed motor
106	Bank2Mtr: Half	2nd optional paper tray unit: Paper feed motor - half speed
107	Bank2Mtr: High	2nd optional paper tray unit: Paper feed motor - high speed
108	"Bank1,2Half"	1st and 2nd optional paper tray units: Half speed
109	"Bank1,2Mtr"	1st and 2nd optional paper tray units: Paper feed motor
120	DplxRevMtr	Duplex: Inverter motor
121	DplxRevMtrRev	Duplex: Inverter motor - reverse
122	DplxFeedMtr	Duplex: Transport motor
123	DplxFeedMtrRev	Duplex: Transport motor - reverse
124	DplxSol	Duplex: Inverter gate solenoid
125	DplxFreeRun	Duplex: Free run


5.3 CONTROLLER SELF-DIAGNOSTICS

5.3.1 OVERVIEW

There are three types of self-diagnostics for the controller.

- Power-on self-diagnostics: The machine automatically starts the self-diagnostics just after the power has been turned on.
- Detailed self-diagnostics: The machine does the detailed self-diagnostics by using a loop-back connector (P/N G0219350)
- SC detection: The machine automatically detects SC conditions at power-on or during operation.

The following shows the workflow of the power-on and detailed self-diagnostics.



5.3.2 DETAILED SELF-DIAGNOSTICS


This detailed self-diagnostic test requires a loop-back connector (P/N: G0219350).

1. Turn off the machine and attach the loop-back connector to the parallel interface.
2. Turn on the machine while pressing the “Online” key and “# Enter” key together.
3. The machine automatically starts the self-diagnostics and prints the diagnostic report after completing the test.
 - Refer to the diagnostics report for the detected errors. The errors detected during self-diagnostics can be checked with SP7-832-001 (Diag. Result).
 - Refer to section 4.2 for details about the error codes.

5.4 USER PROGRAM MODE

To activate the user program mode, press the menu key and use the up/down arrow keys to scroll through the menu. To go back to a higher level, press the escape key. After changing the settings, press the online key. The user menu list can be printed using 'menu list' in the "List/Test Print" user mode.

User Mode Tree



G070S517.WMF

5.5 UPGRADING SOFTWARE

CAUTION

1. Before upgrading the software, print out the system settings and check the current software versions.
2. Check that your IC card contains a later version of the software. Machine performance is not guaranteed if you install an older version.

NOTE: Open the front cover when upgrading the firmware. This is to prevent the printer from going in the process control session.

5.5.1 OVERVIEW


You can upgrade the following software modules:

- Engine software (BCU board software) – 1 card
- Controller system software (Controller board software) – 2 cards (no special order required)
- Network card system software – 1 card

5.5.2 UPGRADING

Procedure

1. Turn the main switch off.
2. IC card cover [A] (x 2)
3. Insert the IC card [B].




4. Open the front cover and turn the main switch on. The message on the right appears on the operation panel.



5. Press the enter key.




6. Press the down arrow key.



7. Press the enter key.



8. Wait until the message on the right appears on the operation panel.



9. Turn the main switch off.

10. Remove the IC card.

11. If upgrading two or more software modules, insert the next IC card and repeat the steps above.

12. Put back the IC card cover.

13. Turn the main switch on.

Error Recovery

Installation Error

If the software upgrade is unsuccessful, “NG!” or “ERR” appears on the operation panel. When either of the messages is output, do the following:

- 1) Turn the main switch off.
- 2) Check that the IC card is correctly inserted.
- 3) Turn the main switch on.
- 4) Start upgrading software from the beginning.

Power Failure

If the power supply is interrupted, an error code may appear on the operation panel. Then, do the following:

- 1) Turn the main switch off.
- 2) Failure during BCU firmware download: Turn DIP switch 1 on the BCU board to ON
Failure during controller, emulation, or network firmware download: Turn DIP switch 1 on the controller board to ON
- 3) Turn the main switch on.
- 4) Start upgrading software from the beginning.
- 5) Turn the DIP switch off again after finishing.

5.6 DIP SWITCHES

Controller Board

DIP SW No.	OFF	ON
1	Boot-up from machine	Boot-up from IC card
2 to 4	Factory Use Only: Keep these switches OFF.	

If a download attempt failed, you must boot the machine from the IC card. To do this, set DIP SW 1 on the controller board to ON.

BCU Board

DIP SW No.	OFF	ON
1	Boot-up from machine	Boot-up from IC card
2 to 4	Factory Use Only: Keep these switches OFF.	

If a download attempt failed, you must boot the machine from the IC card. To do this, set DIP SW 1 on the BCU board to ON.


5.7 PRINTING A TEST PATTERN

1. Use SP5-955-1 (Test Pattern – Pattern) to select the pattern that you wish to print.
2. Enable test pattern printing by setting SP2-917 (Test Pattern) to 'On'.
3. To print the test pattern, send a one-page job to the printer, or print an SMC list (try using SP5-990-6, SP Print mode – Non default).
4. After finishing the test patterns, return SP2-917 (Test Pattern) to 'Off', or switch the machine off/on

6. DETAILED SECTION DESCRIPTIONS

6.1 OVERVIEW

6.1.1 MAJOR COMPONENTS




G070V102.WMF

Detailed
Descriptions

- | | |
|---------------------|-------------------------|
| 1. Toner cartridge | 6. Transfer roller unit |
| 2. Development unit | 7. Paper tray |
| 3. Oil supply unit | 8. Transfer belt |
| 4. Paper exit unit | 9. OPC belt unit |
| 5. Fusing unit | 10. Laser optics unit |

6.1.2 PAPER PATH



G070V109.WMF


- | | |
|-----------------------------------|-------------------------------------|
| 1. Finisher exit sensor | 7. Registration sensor |
| 2. Finisher feed sensor | 8. Duplex unit exit sensor |
| 3. Exit sensor (main unit) | 9. Paper feed sensor |
| 4. Exit sensor (interchange unit) | 10. Bypass tray feed sensor |
| 5. Duplex unit feed sensor | 11. 1st paper tray unit feed sensor |
| 6. Fusing exit sensor | 12. 2nd paper tray unit feed sensor |

The illustration shows a machine with the following equipment:

- Two paper tray units
- Interchange unit
- Duplex unit
- 500-sheet finisher

6.1.3 DRIVE COMPONENTS

This is a rear view of the machine.




Motor name	Motor type	Drives ...
Development [G]	DC brushless	<ul style="list-style-type: none"> • Development units *1 • OPC belt cleaning unit [I] *2
Main [E]	DC brushless	<ul style="list-style-type: none"> • OPC belt [J] *3 • Transfer belt [K]
Fusing Unit [B]	DC brushless	<ul style="list-style-type: none"> • Fusing unit [Q] • Paper exit unit [A] • Transfer belt cleaning unit *4 • Registration roller *5 • Paper transfer roller • Transfer belt cleaning unit contact mechanism *6 • Paper transfer roller contact mechanism *7
Paper Feed [L]	Stepper	<ul style="list-style-type: none"> • Paper pick-up roller *8 • Vertical transport roller [N]

Detailed Descriptions

- *1: Drive delivered through the development clutches [F]
- *2: Drive delivered through the OPC belt cleaning clutch (not shown here).
- *3: Stabilized by the flywheel [H]
- *4: Drive delivered through the transfer belt cleaning clutch [C]
- *5: Drive delivered through the registration clutch [O]
- *6: Drive delivered through the belt cleaning contact solenoid [D]
- *7: Drive delivered through the paper transfer solenoid [P]
- *8: Drive delivered through the paper feed clutch [M]

6.1.4 ELECTRICAL COMPONENTS

Image Transfer




- | | |
|-------------------------------------|---------------------------------|
| 1. Charge corona wire cleaner motor | 10. Pressure roller thermofuse |
| 2. Quenching lamp | 11. Pressure roller thermistor |
| 3. ID sensor | 12. Heating roller thermistor |
| 4. New PCU sensor | 13. Pressure roller fusing lamp |
| 5. Belt mark sensor | 14. Heating roller fusing lamp |
| 6. T/B waste toner bottle switch | 15. Oil unit switch |
| 7. T/B waste toner sensor | 16. Heating roller thermostat |
| 8. O/B waste toner sensor | 17. Oil end sensor |
| 9. O/B waste toner bottle switch | |

T/B: Transfer belt

O/B: OPC belt

Development Units




G070V104.WMF

- | | |
|--------------------------------|--------------------|
| 1. Rear development board | 7. Memory chip I/F |
| 2. Laser sync. detection board | 8. Memory chip M |
| 3. Front development board | 9. Memory chip C |
| 4. Main switch | 10. Memory chip Y |
| 5. Polygonal mirror motor | 11. Memory chip K |
| 6. LD unit | |

Detailed
Descriptions


Paper Path



- | | |
|--------------------------|--|
| 1. Right cover switch | 10. Tray heater (option) |
| 2. Interlock switch | 11. Paper exit sensor |
| 3. Paper overflow sensor | 12. Main switch (See the Note after the table) |
| 4. Fusing exit sensor | 13. Front cover switch |
| 5. Registration sensor | 14. Operation panel |
| 6. Paper feed sensor | 15. By-pass paper end sensor |
| 7. Paper near-end sensor | 16. By-pass pick-up solenoid |
| 8. Paper end sensor | 17. By-pass paper feed clutch |
| 9. Exit cover switch | |

NOTE: Main Switch: The red switch at the front of the machine is connected to a switch on the PSU with a mechanical link (☛ 3.3.5).


Drive Components



- | | |
|--|------------------------------|
| 1. Fusing unit motor | 8. Development clutch - C |
| 2. Transfer belt cleaning clutch | 9. Paper size switch |
| 3. Transfer belt cleaning contact solenoid | 10. Development clutch - M |
| 4. Main motor | 11. OPC belt cleaning clutch |
| 5. Development clutch - K | 12. Paper feed motor |
| 6. Development clutch - Y | 13. Paper feed clutch |
| 7. Development motor | 14. Registration clutch |
| | 15. Paper transfer solenoid |


Detailed Descriptions

Circuit Boards



- | | |
|--------------------|--------------------------------|
| 1. Operation panel | 7. PSU |
| 2. Fusing unit fan | 8. Temperature-humidity sensor |
| 3. IOB | 9. Printer controller |
| 4. BCU | 10. High voltage supply board |
| 5. Controller fan | 11. USB 2.0 board |
| 6. Ozone fan | |

6.2 PRINTING PROCESS OVERVIEW



G070V101.WMF

- | | |
|--------------------------------|---------------------------|
| 1. Development unit | 5. Transfer roller unit |
| 2. OPC belt | 6. Quenching lamp |
| 3. Transfer belt cleaning unit | 7. OPC belt cleaning unit |
| 4. Transfer belt | 8. Polygonal mirror |

Detailed
Descriptions

1. Drum Charge

The corona wire gives the drum a negative charge.

2. Black (K) Image Creation**a) Laser Exposure**

The laser diode (LD) emits two laser beams. The laser beams create a latent image on the OPC surface.

b) Development

The development roller transfers negatively charged toner to the latent image. The OPC belt surface holds only one toner color at one time.

c) Image Transfer

The OPC belt transfers the single-color toner image to the image transfer belt.

d) Cleaning

The OPC belt cleaning unit cleans the image transfer belt.

3. Magenta (M) Image Creation

Same as 2 a) through 2 d) above.

4. Cyan (C) Image Creation

Same as 2 a) through 2 d) above.

5. Yellow (Y) Image Creation

Same as 2 a) through 2 d) above.

6. Paper Transfer

The paper transfer roller transfers the combined CMYK toner image to the paper.

The OPC belt and the transfer belt can hold two A4-size LEF images on their surfaces. When printing on A4 LEF or smaller paper, the OPC and transfer belts process two images in one cycle. At this time, two sheets of paper are consecutively output with little interval between them. This speeds up color print output.

7. Separation

The paper is separated from the transfer belt when the belt curves away from it. A discharge pin assists this process.

8. Fusing

The fusing unit rollers fuse the image to the paper.

9. Cleaning

The transfer belt cleaning unit cleans the belt.

10. Quenching

The quenching lamp erases any remaining charge on the OPC belt.

6.3 PROCESS CONTROL

6.3.1 OVERVIEW

The printer adjusts the following process control parameters:

- Development bias (VB)
- Charge corona grid voltage (VG)

These 2 parameters maintain a consistent gamma for the engine.

NOTE: This printer uses only the ID sensor. (There is no TD or potential sensor.)

6.3.2 PROCESS CONTROL STEPS

Six Steps

Depending on the machine's condition, some or all of the following steps may occur:

- ①: ID sensor calibration
- ②: Color development bias initialization (M, then C, then Y)
- ③: K development bias initialization
- ④: M, C, Y, and K bias fine adjustment
- ⑤: Charge grid bias voltage adjustment
- ⑥: Process control interval counter reset

If the main power is turned off (or the cover opened) during a process control session, the session is aborted. Turning the power on (or closing the cover) restarts the process control session.


When is Process Control Done?

When an event arises, the specified steps are performed.

Event	Condition	Steps
Forced process control	When forced process control is done (engine SP mode 3-001-1 [ProcessCtrl])	① → ⑥
Process control regular interval	When more than 200 sheets have been printed upon completion of a job. (The interval can be changed with engine SP3-003-1 [Lub_Interval].)	①, ④, ⑤, ⑥
Power on	When the fusing pressure roller temperature is 60°C or lower immediately after the power is turned on.	①, ④, ⑤, ⑥
Environmental change	When the change in the temperature/humidity sensor output since the previous process control exceeds a certain value. SP3-004 (EnvChange) can be used to change the threshold temperature and humidity values.	①, ④, ⑤, ⑥
K toner cartridge or K development unit replacement	This is done after clearing the K toner near-end state (i.e., when a new K development unit is added). The machine idles and when the development roller stops for 10 seconds, indicating that idling is over, process control occurs.	①, ③, ④, ⑤
Color development unit replacement	After the color toner end or near-end state is reset, the machine idles to transfer color toner to the development unit. After idling, process control occurs.	① → ⑥
Color toner cartridge replacement	After the color toner end or near-end state is reset, the machine idles to transfer color toner to the development unit. After idling, process control occurs.	①, ④, ⑤, ⑥
24 hours after previous process control	Same as 'power on' process control	①, ④, ⑤, ⑥
PCU replacement	After a new PCU is detected, it is lubricated (new OPC belt lubricant application mode). Then process control occurs.	① → ⑥

6.4.2 NEW PHOTOCONDUCTOR UNIT DETECTION

- [A]: New PCU sensor
- [B]: OPC belt
- [C]: Gear 1
- [D]: Gear 2



G070D321.WMF

New PCU Sensor

The new PCU sensor [A] detects when a new photoconductor unit is installed. The machine then executes process control (☛ 6.3.2).

Mechanism

When a new PCU is placed into the machine, the actuator on gear 2 [D] enters the new PCU sensor (new PCU detected). When the OPC belt starts rotating, gear 1 [C] also starts rotating. Gear 1 also turns gear 2, so the actuator moves down. Gear 2 disengages from gear 1 when the actuator reaches its lowest position, and the actuator never returns to the new PCU sensor.

PCU Counter


The photoconductor unit can be used for 120 kilo-developments (☛ 2.2). When the unit has been used for 120 kilo-developments, a message is displayed on the operation panel. To check the PCU counter, use SP7-803, PM_Counter (☛ 5.2.2).

6.4.3 CHARGE CORONA UNIT

Power Supply

High voltage supply [A] → Harness [C] → Charge corona unit [B] (negative charge)


- [A]: High voltage supply
- [B]: Charge corona unit
- [C]: Harness



Wire Cleaning

The motor [A] drives the bottom screw [B], which moves the wire cleaner [C] forward or backward, cleaning the corona wire.

- [A]: Motor
- [B]: Screw
- [C]: Wire cleaner



Detailed Descriptions

Cleaning Interval

The cleaning feature is activated after 600 development counts (default), at the end of the job. However, if 1000 counts is reached in the middle of a job, printing pauses while the wire is cleaned. The counter counts up as shown in the table.


	Black & White	Color
A4 (LT) LEF (or smaller)	1 count	4 counts
Others	2 counts	8 counts



To set the counter, use SP2-801, ChrgClnIntval (☛ 5.2.2).

Quenching

- [A]: Quenching lamp
(☛ **CT** Photocopying Processes – Quenching)
- [B]: Charge corona unit
(☛ **CT** Photocopying Processes – Charge – Corona Charge – Scorotron Method)




G070D309.WMF

6.4.4 OPC BELT DRIVE

Main motor [B] → Gear → Timing belt → Bottom shaft


- [A]: OPC belt
- [B]: Main motor



G070D308.WMF

6.4.5 OPC BELT CLEANING UNIT

- [A]: Lubricant bar
- [B]: Lubricant brush
- [C]: Counter blade
- [D]: Toner collection auger 1
- [E]: Toner collection auger 2
- [F]: Waste toner bottle switch
- [G]: Waste toner bottle sensor



G070D313.WMF

Toner Collection Augers

Toner collection auger 1 [D] collects waste toner; toner collection auger 2 [E] levels the toner in the waste toner bottle.

Counter Blade + Brush

The lubricant brush [B] applies lubricant to the OPC belt.

☛  Photocopying Processes – Cleaning – Counter Blade and Brush


Waste Toner Bottle Sensors

The waste toner bottle switch [F] and the waste toner bottle sensor [G] are at the back of the cleaning unit. The switch detects whether the toner bottle is installed correctly. The sensor detects when the bottle is full.

When the bottle becomes full, a message is displayed on the operation panel. After the message is displayed, the machine can output 100 prints, then further printing is disabled.

Drive

Development motor [A] → Gear → Timing belt → OPC belt cleaning clutch [B] → OPC belt cleaning unit (including the brush and toner collection coil)




While the development motor is operating, the OPC cleaning clutch is always on. The clutch cuts the drive to the cleaning unit when the development motor reverses (this is done at intervals to prevent toner blockages in the development unit).

6.4.6 IMAGE TRANSFER BELT UNIT

Drive

- [A]: Main motor
- [B]: Image transfer belt
- [C]: Bottom shaft (rubber coated)



G070D314.WMF


Main motor [A] → Gears & timing belt → Bottom shaft [C]

The bottom shaft drives the transfer belt by the friction between the belt [B] and the rubber coating on the shaft [C].

NOTE: The transfer belt and OPC belt contact each other. If you wish to inspect the transfer belt by turning it, you must also turn the OPC belt at the same time to avoid damaging the surfaces of the belts.

Belt Mark Sensor

- [A]: Belt mark sensor
- [B]: Mark



G070D315.WMF


The belt mark sensor is a reflective photosensor.

To exactly synchronize the four mono-color toner images on the image transfer belt, the belt mark sensor [A] monitors the belt speed. The sensor detects the light reflected by the marks [B] at the rear end of the belt (25 marks per rotation; mark frequency: 21 mm). The sensor output is used to control the belt speed.

Detailed Descriptions

Bias Roller

- [A]: Bias roller
- [B]: High voltage supply
- [C]: Terminal plates




G070D316.WMF

The transfer roller [A] attracts toner from the OPC belt to the image transfer belt by using a positive charge.

The terminal in the middle of the PCU contacts the terminal on the transfer roller shaft when the image transfer belt unit is installed in the PCU.

The current is adjusted based on environmental temperature and humidity.

6.4.7 TRANSFER BELT CLEANING UNIT



Bias Brush

The lubricant bar [A] lubricates the bias brush [B]. The brush applies this to the transfer belt surface. The bias brush is positively charged to attract residual toner from the belt surface.

Bias Roller and Cleaning Blade

The bias roller [C] removes toner from the bias brush. The cleaning blade [D] removes the residual toner off the bias roller.

Collecting Coil

The collecting coil [E] transports waste toner to the rear of the transfer belt cleaning unit. The waste toner bottle [F] collects the toner through its opening shutter.

Waste Toner Bottle Sensors

The waste toner bottle switch [G] and the waste toner bottle sensor [H] are at the back of the cleaning unit. The switch detects whether the toner bottle is installed correctly.


The toner bottle sensor detects when the bottle is full, and a message is displayed on the operation panel. After the message is displayed, 100 prints can be output then the machine stops and printing is disabled.

Contact Mechanism

During standby mode, the cleaning unit is away from the transfer belt.


When the toner images are being transferred from the OPC belt to the transfer belt, this mechanism holds the transfer belt cleaning unit away from the belt.

When the solenoid [A] activates, it transmits power from the fusing unit motor [B] to the gear and the cam [C]. The cam moves the bias brush roller into contact with the transfer belt.



G070D320.WMF

The transfer belt cleaning unit [D] has a lever [E] on its rear side. When the lever rests on the high point of the cam [F], the cleaning unit is away from the transfer belt; when the lever rests on the low point, the cleaning unit contacts the transfer belt.




G070D322.WMF

The transfer belt cleaning contact solenoid [H] operates a half-turn clutch [I] to control the contact mechanism.

Power Supply

- [A]: Cleaning brush
- [B]: Cleaning roller
- [C]: High voltage supply
- [D]: Contact spring
- [E]: Contact spring
- [F]: Contact spring




The cleaning roller [B] charges the cleaning brush, and attracts toner from it.

The high voltage supply [C] supplies positive charge to the cleaning roller via the harness and contact springs (leaf springs) [D, E, and F].

Drive

- [A]: Gear 1
- [B]: Image transfer belt cleaning clutch
- [C]: Fusing unit motor
- [D]: Drive gear
- [E]: Gear 2
- [F]: Toner path
- [G]: Image transfer belt
- [H]: Toner collection auger 1
- [I]: Toner collection auger 2
- [J]: Turning direction of the cleaning brush




Detailed Descriptions

Fusing unit motor [C] → drive gear [D] → gears [A] and [E] → cleaning brush [J] and toner collection augers [H and I]

The clutch [B] controls the on/off timing of the mechanism.

6.5 LASER EXPOSURE

6.5.1 OVERVIEW



- | | |
|--|---------------------------|
| 1. LD unit | 6. Polygonal mirror motor |
| 2. Laser synchronization detection board | 7. WT lens |
| 3. Synchronization detection mirror | 8. F theta lens |
| 4. Dust shield glass | 9. 1st mirror |
| 5. 3rd mirror | 10. 2nd mirror |
| | 11. Cylindrical lens |

1. The LD unit simultaneously emits two laser beams. This is true both in full-color mode and in single-color mode.
2. The polygonal mirror motor rotates at 21,024 rpm (both in the full-color mode and in the single-color mode).
3. Laser beam path: LD unit → Polygonal mirror → WTL lens → F theta lens → 1st mirror → 2nd mirror → Synchronization detection mirror
NOTE: The synchronization detection board simultaneously monitors both laser beams.

Dust Shield Glass Cleaning

The user cleans the dust shield glass by pushing and pulling the lever at the front of the cleaner.

LD Unit Adjustment

There are no field service adjustments for this LD unit.

Polygonal Mirror

☛  Digital Processes – Printing – Laser Printing – Optical Components


Laser Diode Power Control

☛  Digital Processes – Printing – Laser Printing – Laser Diode Power Control
Done by the LD control board

Maintenance Adjustment

The LD unit does not need adjustment when replaced.

6.5.2 LD SAFETY SWITCH



G070D999.WMF

The interlock switch is at the top of the front cover.

This switch is in series with the 5-V circuit leading to the LD unit.

When the front, left, or right cover is opened, the switch interrupts the power supply, preventing laser emission.

Operation Panel Message and Switch Mechanism

If the covers are all closed, all three switches are on.

If a cover is opened, the indication on the display panel depends on the combination of signals from the interlock switch and the two cover switches.

The interlock switch turns off when any of these three covers is opened.


“Close Front Cover”

Front cover switch	Off
Right cover switch	On
Interlock switch	Off

Front cover switch	Off
Right cover switch	Off
Interlock switch	Off

Front cover switch	Off
Right cover switch	On
Interlock switch	Off

Front cover switch	Off
Right cover switch	Off
Interlock switch	Off




[A]: Front cover switch
[B]: Right cover switch
[C]: Interlock switch

G070D701.WMF

“Close Right Cover”

Front cover switch	On
Right cover switch	Off
Interlock switch	Off


Front cover switch	On
Right cover switch	Off
Interlock switch	Off



G070D702.WMF

“Close Left Cover”

Front cover switch	On
Right cover switch	On
Interlock switch	Off




G070D703.WMF

Off: Switch open

Detailed Descriptions

6.6 DEVELOPMENT

6.6.1 OVERVIEW



G070D301.WMF

K: black, **Y:** yellow, **C:** cyan, **M:** magenta

- | | |
|------------------------------|------------------------|
| 1. Memory chip | 6. Toner supply roller |
| 2. Toner cartridge | 7. Development roller |
| 3. Toner cartridge agitators | 8. Doctor roller |
| 4. Development agitator | 9. OPC belt |
| 5. Development unit | |

 **CT**: Development – Mono-component Development – Double Development Roller Process

The development units operate in the following order: K → M → C → Y.

6.6.2 DEVELOPMENT UNIT

Rollers and Agitators

Each development unit has 3 rollers and 3 agitators (2 toner cartridge agitators and 1 development agitator):

Toner cartridge agitators:	Evenly mixes the toner in the cartridge, and sends it to the development unit
Development agitator:	Evenly mixes the toner in the development unit, and sends it to the toner supply roller
Toner supply roller:	Supplies the development roller with toner
Development roller:	Transfers the toner to the OPC
Doctor roller:	Regulates the amount of the toner on the development roller

Replacing Units

Near-end condition: “Replace Development Unit, xxxx-unit” is displayed when a development unit has made the ‘PM period’ number of prints (K: 120K, CMY: 60K). If more than one unit reaches PM period at the same time, the messages for each unit will be displayed one after the other.

End condition: When toner end is detected while the development unit is in a near-end condition, that unit enters the end condition. The machine cannot print. The end condition is cleared when that unit is replaced. There is no need to replace all 4 units. However, if each colour (C, M, Y) is used at the same rate, they will enter the end condition at about the same time.

The user can replace only the K unit, the color units (Y, C, and M), or all units (K, Y, C, and M) at the same time.

The color units are available for the user as a set, but can be replaced individually if required (individual units are available as spare parts).

Recovery: Each new development unit contains a starter toner cartridge. When the machine detects the memory chip on the new starter cartridge, it will clear the development unit end condition. The memory chip on a normal toner cartridge cannot clear the development unit end condition.


A starter toner cartridge has more paddles on the toner cartridge agitators than a normal toner cartridge does. This is to transport toner more quickly from the cartridge into the toner hopper.

When a development unit has to be replaced, use a starter toner cartridge in the development unit even if toner remains in the used normal toner cartridge. After the toner in the starter toner cartridge is all used up, the normal toner cartridge can be loaded into the development unit.

Memory Chip

Each toner cartridge contains a memory chip, which contains information on whether the cartridge is “new” or “not new”.

6.6.3 TONER SUPPLY MECHANISM



- | | |
|--------------------------------|--------------------------|
| [A]: Toner cartridge agitators | [E]: Toner supply roller |
| [B]: Development unit agitator | [F]: Development roller |
| [C]: Development clutch | [G]: Doctor roller |
| [D]: Lever | |

Toner Cartridge Agitators

Each toner cartridge contains two agitators [A]. They are equipped with several mylar sheets, which agitate the toner and send it to the development unit agitator [B].

Drive Power Path

Development motor → Development clutch [C] → Lever [D] → One-way clutch → Agitators

Development Unit Agitator

The development unit agitator [B] agitates the toner and sends it to the toner supply roller [E].

Toner Supply Roller and Doctor Roller

The toner supply roller [E] sends the toner to the development roller [F]. The doctor roller [G] controls the thickness of toner on the development roller, before the toner is transported to the OPC belt.

Shutter

Each toner cartridge has a shutter. The shutter is pushed open when the cartridge is installed in the development unit.


6.6.4 TONER END DETECTION

Mechanism

[A]: Optic fiber
 [B]: Light emission
 [C]: Gap

An optic fiber [A] in each development unit detects toner end. Light is emitted from the rear end [B] of the unit. There is a gap [C] in the optic fiber.

When the development unit is filled with toner, the toner breaks the light path through the gap. When the unit is running out of toner, the light path is not broken.



G070D306.WMF

Toner Near-End Detection

The machine uses two methods simultaneously: pixel count, and toner end sensor. If either of these methods detects near-end, the machine indicates near-end.

Near-End by Pixel Count

The machine counts how many pixels have been printed with each toner cartridge. When there are 1000 (starter toner) or 2000 (normal toner) prints remaining until the estimated toner end condition, toner near-end is indicated.

Near-End by Toner End Sensor

- If the toner end sensor output drops to toner end level, counter 1 is set to 1.
- If the above condition (counter 1 is 1) is detected twice accumulated 14 seconds while the development clutch is activated, counter 2 is set to 1.
- If the above condition (counter 2 is 1) is detected twice continuously, the machine enters the toner supply mode after the job.

The above detection is carried out while the development clutch is activated.

Toner supply mode after the job:

- The development unit with the almost-empty cartridge idles for 40 s.
- Then, it idles again for another 20 s.
- During this 20 s period, the toner end sensor is checked every 10 ms. If a low toner condition is not detected during this 20 s period, the machine returns to standby mode after idling all development units for 90 s.
- However, if a low toner condition was detected during that 20 s period, the machine indicates toner near-end.

Toner End Detection

When any one of the following conditions occurs, toner end is indicated.

1. If near-end was detected by pixel count:
The remaining pixel count reaches 0.
2. If near-end was detected by toner end sensor:
Either 100 developments or 100 prints at 5% coverage are made since near-end was detected.
3. If near-end was detected by pixel count, and later it was detected by toner end sensor again before toner end:
Either the remaining pixel count reaches 0, or 100 developments or 100 prints at 5% coverage are made since near-end by toner end sensor was detected.

Toner End Recovery

When the machine detects a new toner cartridge, it drives the development unit for that cartridge for about 3 minutes.

During this time, the development clutch is repeatedly activated for 10 s and deactivated for 1 s.

The machine checks the toner end condition every 20 s. The end and near-end conditions are cleared if the sensor detects sufficient toner. However, if the sensor does not detect sufficient toner after 5 minutes of development unit drive, the toner end condition remains and a new cartridge must be added.


6.6.5 DEVELOPMENT UNIT CONTACT MECHANISM

Mechanism

Each development unit has an independent clutch. When a development clutch turns on, a gear under the development unit moves the development unit into contact with the OPC belt. When the clutch turns off, two springs (one at the front and one at the rear) detach the development unit from the OPC belt.

☛ **CT** Color Processes – Color Development – Fixed Position Development Systems – Similar to Example 2: Model G033

[A]: OPC belt
[B]: Development clutch




G070D305.WMF

Reverse Rotation

The gears reverse at intervals to prevent toner from clumping.

Detailed
Descriptions

6.6.6 POWER SOURCE



Development, Toner Supply, and Doctor Rollers

When a development unit [A] comes into contact with the OPC belt, the bias terminal [D] comes into contact with the harness terminal [E]. Then, a negative charge is supplied to the unit.

The negative charge on the doctor roller is the same size as the charge on the development roller and toner supply roller.


Doctor Roller

The doctor roller [G] restricts the amount of toner on the development roller [C]. The high voltage supply [F] applies a charge to the doctor roller through the rear-side terminal cable [B]. This charge is the same as the charge applied to the development roller. However, the development roller charge is applied through a different terminal [E].

☛ **CT** Mono-component Development – Toner Metering Blade (similar principle)

6.7 PAPER FEED

6.7.1 OVERVIEW



- | | |
|----------------------------------|--------------------|
| 1. Registration roller | 6. Friction pad |
| 2. Path from duplex | 7. Feed roller |
| 3. Vertical transport roller | 8. Base plate |
| 4. Path from by-pass tray | 9. Paper end fence |
| 5. Path from optional paper tray | 10. Standard tray |

Detailed Descriptions

The printer comes with two paper feed stations. It can be equipped with up to four paper feed stations.

Tray	Number	Main/Optional
Standard tray	1	Main unit
Bypass tray	1	
Paper tray unit	1 or 2	Optional units

Transport Speed

Until the registration roller, the paper travels at 240 mm/s. This high initial speed ensures that the first output time is as short as possible.

From the registration roller to the exit, the paper travels at the following speeds:

- 178 mm/s (plain paper)
- 89 mm/s (thick paper or OHP films)

Friction Pad

☛  Handling Paper – Paper Feed – Paper Feed Methods – Friction Pad

NOTE: The roller and pad are packaged as a maintenance kit, with the fusing unit. Replace the roller and pad as a unit (not separately).

6.7.2 STANDARD TRAY DRIVE


Feed and Vertical Transport Rollers

Feed motor [A] → Feed clutch [C] → Feed roller [D]/vertical transport roller [E]

Registration Roller

Fusing unit motor [B] → Registration clutch [F] → Registration roller [G]

- [A]: Feed motor
- [B]: Fusing unit motor
- [C]: Feed clutch
- [D]: Feed roller
- [E]: Vertical transport roller
- [F]: Registration clutch
- [G]: Registration roller




6.7.3 STANDARD TRAY – BOTTOM PLATE LIFT

Lift Mechanism

The spring under the bottom plate [A] presses the plate upward. When you press the bottom plate as far down as possible, the hook on lever [C] holds the plate. The lever releases the bottom plate when it is pressed by the protruding part on the right tray rail; this happens when the tray [B] is completely pushed into the machine.

- [A]: Bottom plate
- [B]: Tray
- [C]: Lever



G070D103.WMF

Paper Near End Detection

The bottom plate gradually rises as paper is fed. The bottom plate position is checked with a feeler which is linked to the paper near-end sensor (☛ 6.1.4). The sensor is actuated when about 50 sheets are left in the tray, and the paper near end message appears on the operation panel.


Paper End Detection

When paper runs out, the paper end sensor (☛ 6.1.4) feeler drops through the opening in the bottom plate. Then, the paper end message appears on the operation panel.

6.7.4 STANDARD TRAY - PAPER SIZE DETECTION

Mechanism

The end fence [G] moves the lever [F], which moves a different set of notches on the actuator [E] into contact with the paper size switches [B]~[D]. When you put the tray in the main unit, the rear fence of the tray and the actuator activate the switches; from this the machine detects the presence of the tray, and the paper size.



G070D104.WMF

Switch Pattern

When the tray is pushed into the machine, the leftmost switch [A] is always activated by the rear fence of the tray; this switch detects the presence of the tray. The combination of the other 3 switches [B]~[D] detects the paper size.

Paper Size		Switch*1			
North America	Europe/Asia	[A]	[B]	[C]	[D]
DLT SEF*3	A3 SEF*3	On	Off	On	On
LG SEF*2	B4 SEF*2	On	On	On	On
A4 SEF	A4 SEF	On	On	Off	Off
LT SEF	LT SEF	On	Off	Off	Off
B5 SEF*5	B5 SEF*5	On	Off	Off	On
LT LEF*4	A4 LEF*4	On	On	On	Off
B5 LEF	B5 LEF	On	On	Off	On
—	A5 LEF	On	Off	On	Off
(No tray)		Off	Off	Off	Off

*1 On: Pushed Off: Not pushed

*2 Selected with SP1-902-1 [PaperSize - B4/LG], (LG SEF/B4 SEF)

*3 Selected with SP1-902-2 [PaperSize - A3/DLT], (DLT SEF/A3 SEF)

*4 Selected with SP1-902-3 [PaperSize - A4/LT], (LT LEF/A4 LEF)

*5 Selected with SP1-902-4 [PaperSize - B5/Executive], (B5 SEF/10.5" x 7.25" SEF)

NOTE: 1) For the input check table, see 5.2.2.

2) Other paper sizes are not detected. Use the Paper Input – Tray Paper Size user tool to set paper sizes.

6.7.5 BYPASS TRAY


Paper Feed Mechanism

The FRR (feed and reverse roller) feed mechanism (👉 **CT**) is used.

Bypass Tray Drive Power Path

Paper feed motor [A] → Gears → Feed clutch [B] → Rollers

- [A]: Paper feed motor
- [B]: By-pass paper feed clutch




G070D153.WMF

Pick-up Solenoid

The by-pass pick-up solenoid [A] is mechanically linked to the pick-up roller [B]. When the solenoid turns on, the pick-up roller touches the top sheet of the paper.

- [A]: By-pass pick-up solenoid
- [B]: Pick-up roller
- [C]: Feeler
- [D]: Paper end sensor



G070D954.WMF


Detailed Descriptions

Paper End Sensor

The feeler [C] is linked with the paper end sensor [D]. The paper end sensor functions not only as a paper end sensor but also as a paper set sensor.

6.8 PAPER TRANSFER AND SEPARATION

6.8.1 OVERVIEW



- | | |
|------------------------|--------------------------|
| 1. Image transfer belt | 4. Spring |
| 2. Discharge plate | 5. Paper transfer roller |
| 3. Separation lever | 6. Registration roller |

Jammed Paper Release

When you open the right cover, the units release the paper. This mechanism helps clear paper jams quickly.

Image Transfer and Paper Separation


 Photocopying Processes – Image Transfer and Paper Separation – Transfer Roller + Discharger – Example 2: Models A172/A199

The current is adjusted based on paper weight and environmental temperature and humidity.

A user tool (Paper Input – Paper Type) specifies the paper weights. If “Plain” is selected, then either SP 5-945 (MidThickPaper) or another user tool (Maintenance – Plain Paper Type) defines when the paper is “normal” or “> 90 g/m², 24lb”.

- “Plain” means normal or > 90 g/m², 24lb.
- “Thick” means paper heavier than 105 g/m² (28 lb).

6.8.2 MECHANISM



G070D453.WMF

G070D454.WMF

- [A]: Fusing unit motor
- [B]: Half-turn clutch
- [C]: Paper transfer solenoid
- [D]: Contact/separation lever
- [E]: Cam

Timing

When transferring toner to paper, the paper transfer roller unit contacts the image transfer belt. At other times during printing, the unit stays away from the image transfer belt. After printing, the unit contacts the belt and stays there.

NOTE: During standby mode, the unit stays away from the image transfer belt.

Mechanism

Fusing unit motor [A] → Gear → Paper transfer solenoid [C] → Cam [E] → Contact/separation lever [D] → Paper transfer roller unit movement

The fusing unit motor [A] drives the mechanism. (It also drives the paper transfer roller).

The cam [E] is controlled by the half-turn clutch [B] and the paper transfer solenoid [C].


When the solenoid is off, it catches a hook on the surface of the half-turn clutch [B]. As a result, the high point of the cam pushes the contact/separation lever [D], and the paper transfer roller unit is away from the belt.

When the solenoid is activated, the hook is released, so the half-turn clutch makes a half-turn—the unit moves to the right and contacts the image transfer belt.

6.8.3 POWER SUPPLY

Electric Power Path

High voltage supply [A] → Terminal [B] → Transfer roller axis [C]



- [A]: High voltage supply
- [B]: Terminal
- [C]: Transfer roller axis
- [D]: Temperature-humidity sensor (inside the rear-right cover)
- [E]: Discharge plate (negative charge)

G070D402.WMF

Transfer Roller Bias

Normally, a constant current is applied to the transfer roller shaft [C].

The conductive bearing allows the electrical connection between the bias terminal [B] and the transfer roller shaft.

The current varies with paper type, size, and thickness as well as humidity.

Discharge Plate

The discharge plate [E] discharges the remaining charge on the paper going past the transfer roller. This helps the paper separate from the transfer belt.

Temperature/Humidity Control

The temperature-humidity sensor [D] is inside the rear-right cover. The sensor is used to control the power for the transfer roller (☛ 5.2.2).

The temperature and humidity can be read with SP2-912 (Temp_HumDisp).

Roller Cleaning

The transfer roller is cleaned at the following times:

- After the user clears a paper jam
- After the user closes the front cover
- Just after the main power has been switched on
- While the doctor roller is reversing. This is done every 50 prints (SP 3-910, DoctorInterval), to remove toner blockages in the development unit; if the 50-print interval expires in the middle of a job, it is done at the end of the job.

After paper passes the transfer roller, the paper transfer solenoid releases the transfer roller from the image transfer belt.


Then, a certain time after the trailing edge of the paper passes the registration sensor, the following steps occur:

- 1) The paper transfer solenoid turns on again, and the transfer roller contacts the transfer belt.
- 2) A negative charge is applied to remove toner stuck to the transfer roller.
- 3) Positive and negative charge is applied alternately to remove any toner that is still stuck to the transfer roller.

Toner removed from the transfer roller goes back to the transfer belt, where it is removed by the transfer belt cleaning unit.

6.9 FUSING UNIT AND OIL SUPPLY UNIT

6.9.1 OVERVIEW




G070D501.WMF

- | | |
|------------------------------------|----------------------------|
| 1. Hot roller | 9. Heating roller |
| 2. Pressure roller separation pawl | 10. Fusing belt |
| 3. Pressure roller | 11. Oil supply unit |
| 4. Pressure roller fusing lamp | 12. Oiling roller |
| 5. Pressure roller thermistor | 13. Oil supply roller |
| 6. Heating roller thermistor | 14. Sponge cleaning roller |
| 7. Thermostat | 15. Metal cleaning roller |
| 8. Heating roller fusing lamp | |

NOTE: The fusing unit and the oil supply unit are user-replaceable. After 119 k prints, fusing unit near-end is indicated. After 120 k prints, fusing unit end is indicated, and printing stops until a new unit is added and the counter has been reset.

6.9.2 FUSING UNIT CONFIGURATION



Fusing Belt

This machine uses a fusing belt [A]. The paper goes between the fusing belt and the pressure roller [F].

Oil Supply

The oil supply unit contains a piece of felt. The felt absorbs the silicone oil in the unit and supplies it to the oil supply roller.

Heating Roller Lamp

The center of the heating roller [B] contains a lamp (770 W) [C]. The thermostat [D] and thermistor [E] control the temperature of the roller surface. The machine cuts power to the lamp when it detects 220°C. The thermostat cutoff point is 200°C.


Pressure Roller Lamp

The center of the pressure roller [F] contains a lamp (350 W) [G]. The thermistor [H] and thermofuse [I] control the temperature of the roller surface.

The temperature of the surface of the pressure roller reaches to 250 °C when the pressure roller temperature rises gradually or it reaches 300 °C when it rises rapidly. Normally, the machine cuts the lamp power when the thermistor detects 220 °C.

Pressure Roller Pawls

The pawls [J] above the pressure roller help prevent paper jams.



Fusing Bias

The high voltage supply [A] provides the fusing bias. The fusing bias is a negative bias. It quenches static electricity created on the belt [C] and rollers [D]~[F] by the paper. This prevents the belt and rollers from attracting dust and dirt.

Fusing Unit SCs

If a thermistor/thermostat problem occurs, a fusing unit SC may be displayed on the operation panel. Fusing unit SCs disable the machine (☛ 4.1.1). To reset fusing unit SCs, use SP5-810 [SC_Reset] (☛ 5.2.2).

6.9.3 TEMPERATURE CONTROL



The table lists default settings and variable ranges for temperature control.

External temperature (*1)		More than 15°C ~ less than 30°C		15°C or lower		30°C or higher		
Roller		Heating	Press.	Heat.	Press.	Heat.	Press.	
Fusing idling start (*2)		160	30	160	30	160	30	
Print ready (*3)		165	75	<i>Heat.: +5 Adjustable with SP1-105-27 (Fusing_Temp - H: OFFSET+)</i> <i>Press.: +0 Adjustable with SP1-105-28 (Fusing_Temp - P: OFFSET+)</i>		<i>Heat.: -5 Adjustable with SP1-105-29 (Fusing_Temp - H: OFFSET-)</i> <i>Press.: +0 Adjustable with SP1-105-30 (Fusing_Temp - P: OFFSET-)</i>		
Ready (standby mode)		175	120					
Energy saver		1	100					110
		2	Room temp.					Room temp.
Printing	Normal paper	Mono color	160					Lamp off
		Full color	170					Lamp off
	'>90 g/m2, 24 lb (*4)	Mono color	170					Lamp off
		Full color	180					Lamp off
	Thick	Mono color	165					Lamp off
		Full color	175					Lamp off
	OHP	Mono color	170	Lamp off				
		Full color	180	Lamp off				
Duplex (*5)	Mono color	155	Lamp off					
	Full color	165	Lamp off					
Variable range (*6)		100 ~ 190	30 ~ 200	0 ~ +20	0 ~ -20			

*1: External temperature is measured (temperature/humidity sensor) when the main switch is turned on and when a job start signal is received.

*2: The pressure and heating rollers start idling.

*3: Fusing idling stops when both roller temperatures reach the print ready condition. The printer can process jobs when the rollers reach this temperature during warm-up.


*4: A user tool (Paper Input – Paper Type) specifies the paper type in each tray (plain, thick, or OHP). If 'plain' is selected, then either SP 5-945 (MidThickPaper) or another user tool (Maintenance – Plain Paper Type) defines whether the paper in the tray is 'normal' or '>90 g/m2, 24 lb'. (☛ 5.2.2). '>90 g/m2, 24 lb' means 'greater than or equal to 90 g/m2, 24 lb'.

- 'Thick' means paper heavier than 105 g/m² (28 lb).

*5: Both sides of the paper are processed with the same roller temperatures.

*6: Use SP1-105 (Fusing_Temp) to adjust the fusing temperatures (☛ 5.2.2).

6.9.4 OIL SUPPLY AND CLEANING



G070D504.WMF

Oil Supply

☛  Photocopying Processes – Fusing – Oil Supply

Oil Path

The oil goes to the fusing belt as follows:

- | | |
|------------------------|---|
| Oil tank [B]: | Contains silicone oil |
| Felt [C]: | Absorbs oil for transfer to the oil supply roller |
| Oil supply roller [D]: | Supplies the oiling roller with a small amount of oil |
| Oiling roller [E]: | Supplies oil the fusing belt |

Oil Recycling

The sponge cleaning roller [F] removes excess oil and foreign substances from the belt. This oil returns to the oil supply roller [D] via the felt on the oil roller, and is recycled. The metal cleaning roller [G] also removes foreign substances from the belt.

Belt Cleaning

The roller carries a negative charge that removes foreign material from the belt.


Oil End Detection



The oil supply unit has an oil tank with a capacity of 70 grams. The sensor [A] under the tank passes a beam through part of the transparent tank bottom. When the oil volume becomes low or oil counter reaches 30 kp (whichever is first), the oil tank empty message appears on the operation panel. Then, the machine can output 1000 prints. After that, the machine stops and printing is disabled.

The oil end condition can be cleared by pressing and holding the reset key for more than 3 seconds.

- [A]: Oil end sensor
- [B]: Fusing unit switch




Fusing unit switch

If the fusing unit is out of position, the fusing unit switch [B] turns off. The message “reset fusing unit correctly” is displayed on the operation panel.

6.9.5 DRIVE

- [A]: Fusing unit motor
- [B]: Hot roller gear
- [C]: Fusing belt
- [D]: Heating roller
- [E]: Oiling roller
- [F]: Oil supply roller
- [G]: Pressure roller



Detailed
Descriptions

Drive Power Path (Fusing Unit and Oil Supply Roller)

Fusing unit motor [A] → Gears → Hot roller gear [B] → Fusing belt [C] → Heating roller [D] → Oiling roller [E] → Oil supply roller [F]

Drive Power Path (Pressure Roller)

Fusing unit motor [A] → Gears → Pressure roller [G]

6.9.6 ENERGY SAVER MODE

When the machine is not being used, the energy saver feature reduces power consumption by switching off the fusing lamp. This machine has two energy saver modes. To turn on energy saver modes, use the user tool. To adjust energy saver mode settings, use SP5-101 [Energy Saver] (☛ 5.2.2).

Level 1 Energy Saver Mode (default: off)

Level 1 energy saver mode starts a certain time after the machine has completed a print (timer: SP 5-101-3 [Energy Saver – Level 1], from 0 to 60 s in steps of 10 s). In this mode, the fusing lamps intermittently turn on and off to keep the heating roller and pressure roller at the appropriate temperature (☛ 6.9.3).

The machine returns to ready (standby) mode when one of the following happens.

- Print command received from the PC
- Any cover opened and closed
- Any operation panel keys pressed

Level 2 Energy Saver Mode

Level 2 energy saver mode starts after the machine has been idle for a certain time. This time is specified by a user tool or by SP 5-101-4 [Energy Saver – Level 2]. During level 2 energy saver mode, both lamps switch off.

- Off (energy saver mode never activates)
- 5 minutes
- 15 minutes
- 30 minutes (default)
- 45 minutes
- 60 minutes

When the machine is in this mode, the machine turns off +24V, +12V, and +5V lines. However, only +5VE lines, for the controller and circuit (voltage monitoring) on the BCU, are still active.

The machine returns to ready (standby) mode when one of the following happens.

- Print command received from the PC
- Any operation panel keys pressed


NOTE: The machine does not leave level 2 energy saver mode when covers are opened and closed, because the CPU on the BCU is not active.

Ready Mode

When an energy saver mode ends, the machine goes to the ready mode.

6.9.7 PAPER EXIT

- [A]: Fusing unit motor
- [B]: Paper exit sensor
- [C]: Fusing exit sensor



G070D601.WMF

Drive Power Path

Fusing unit motor [A] → Gears → Rollers

Paper Jam Detection


The paper exit sensor [B] and the fusing exit sensor [C] detect paper jams.

6.9.8 OVERFLOW DETECTION

When the paper lifts the feeler [A], the feeler turns on the sensor. If the sensor stays on for 10 seconds, the printer interrupts processing and a message is output to the PC screen.

Detailed Descriptions


- [A]: Feeler
- [B]: Paper overflow sensor



G070D602.WMF

6.10 PRINTED CIRCUIT BOARDS

6.10.1 PRINTER CONTROLLER



G070D998.WMF

Function

The printer controller manages the printing processes and computer interface functions.

Memory

A single, non-volatile random access memory (NVRAM) stores counter information and printer settings.

When the controller board is replaced, install the NVRAM from the old board on the new board.

Interfaces

Centronics (IEEE1284 Nibble, ECP)
 Ethernet (100Base-TX/10Base-T)
 USB 2.0

Slots

There are 4 slots. Two are for memory, one is for printer application software (PostScript) and the other is for GL emulation (GL – Japan only).

Options

IEEE1394 board

Hard disk drive (HDD)

User account enhancement module

DIP Switch

DIP SW No.	OFF	ON
1	Boot-up from machine	Boot-up from IC card
2 to 4	Factory Use Only: Keep these switches OFF.	

If a controller firmware download attempt failed, you must boot the machine from the IC card. To do this, set DIP SW 1 on the controller board to ON.

LED Indicators

	On	Off
Green	Linked	Not linked
Yellow	100 Mbps	10 Mbps

Detailed Descriptions

6.10.2 BASE ENGINE CONTROL UNIT (BCU)

Function

The BCU is at the rear-left corner of the main unit, on the left fence. The BCU controls:

- System I/O
- High-voltage supply
- AC supply
- Optional unit operations
- Engine sequence

Upgrading

To upgrade the BCU software, you must insert an IC card in the controller's IC card slot.

Nonvolatile Random Access Memory (NVRAM)

The NVRAM on the BCU stores the engine settings. These include the process control and the maintenance kit counter settings.

When the BCU board is replaced, install the NVRAM from the old board on the new board.

DIP Switch

DIP SW No.	OFF	ON
1	Boot-up from machine	Boot-up from IC card
2 to 4	Factory Use Only: Keep these switches OFF.	

If a BCU firmware download attempt failed, you must boot the machine from the IC card. To do this, set DIP SW 1 on the BCU board to ON.

6.10.3 INPUT/OUTPUT (I/O) BOARD

The board controls the following:

I/O

Motor and clutch operation

Sensors

Solenoids

6.10.4 POWER SUPPLY UNIT (PSU)

The PSU supplies power to each unit.

6.10.5 HIGH VOLTAGE SUPPLY

This supplies the following units with high voltage:

Charge corona unit

Image transfer unit


Image transfer belt cleaning unit

Development units

Paper transfer roller

6.11 CONTROLLER

6.11.1 OVERVIEW



G070D553.WMF

The controller uses GW (Ground Work) architecture.

1. **CPU:**
QED RM5261 (250 MHz)
2. **CELLO:**
GW architecture ASIC. It uses a 124 MHz bus (64 bit) for interfacing with CPU and memory. It controls the interface with the CPU and also controls the following functions: memory, local bus, interrupts, PCI bus, video data, HDD, network, operation panel, IEEE1284, and image processing.
3. **SDRAM DIMM (2 slots):** 64 MB SDRAM (resident), expandable up to 384 MB with a 64 MB, 128 MB, or 256 MB SDRAM.
4. **Flash ROM:**
8 MB flash ROM programmed for system and network applications.
5. **ROM DIMM (2 slots):**
The DIMM installed in the machine includes 4 MB flash ROM programmed for printer applications. This DIMM also includes 4 kB of Mask ROM for storing internal printer fonts. Currently the remaining DIMM slot is not being used.

- 6. NVRAM:**
8 kB NVRAM for storing the printer parameters and logged data
- 7. IEEE 1284 Interface:**
Supports compatible, nibble, and ECP modes
- 8. Network Interface:**
100BASE-TX/10BASE-T
- 9. USB Interface:**
See the USB Interface section.
- 10. NVRAM board (option):**
64 kB NVRAM used for storing a record of the number of pages printed under each "User Code".
- 11. IEEE 1394 Interface (option):**
See the IEEE 1394 Interface section.
- 12. IEEE 802.11b Interface (option):**
See the IEEE 802.1b Interface section.
- 13. HDD (option):**
A 3.5" HDD (20.5 GB) can be connected using the IDE interface. The hard disk is partitioned as shown below. The sizes cannot be adjusted.


Partition	Size	Function	Comment
File System 1	500 MB	Downloaded fonts, forms.	Remain stored even after cycling power off/on.
Image TMP	9800 MB	Collation, sample print, locked print.	Commonly used area for applications, erased after power off.
Job Log	10 MB	Job log.	Remains stored even after cycling power off/on.

The system and application software for the following boards can be downloaded from the Controller IC Card.

- Controller (Flash ROM and flash ROM DIMM)
- BCU
- NIB

For details about downloading software from an IC card, see Service Tables – Firmware Update Procedure.


6.11.2 BOARD LAYOUT




G070D722.WMF

6.11.3 PRINT DATA PROCESSING


RPCS Driver



PCL5c Driver



Detailed Descriptions

PS3 Driver

G070D564.WMF

CMS (Color Management System)

CMS optimizes the color print quality using a color profile that is based on the characteristics of the printer. With RPCS, the color profile is applied by the driver. With PS3 and PCL5c, the color profile is applied in the matching/CRD module on the controller except when using CMM/ICC/ICM profiles.

CMS is not used when the color profile setting in the printer driver is set to "Off."

Gray Correction

Gray correction processes gray with K or CMYK toner depending on the driver settings.

BG/UCR (Black Generation/Under Color Removal)

The RGB data is converted to CMYK data with BG/UCR. During CMYK conversion, some CMY data is replaced with K data by the BG/UCR algorithm.

Gamma Correction

The printer gamma can be adjusted with controller SP mode (Gamma Adj.). For CMYK, there are 15 points between 0 and 100%. The corrected gamma data is stored in NVRAM.

Toner Limitation

Toner limitation prevents toner from being scattered around text or printed lines.

Maximum values have been prepared independently for text and photo. They can be adjusted with controller SP mode (Toner Limit).

- Default: 190% for text, 260% for photo
- Adjustable range: 100% to 400%

Dither Processing and ROP/RIP

Dither patterns have been prepared for photo and text independently. Dithering converts the 8-bit data to 1-bit data. However, these dither patterns create the illusion of 256 gradations for high quality prints. The optimum dither pattern is selected depending on the selected resolution.

RIP: Raster Image Processing

ROP: Raster Operation

6.11.4 CONTROLLER FUNCTIONS

Sample Print

This feature was formerly known as “Proof Print”. It requires installing an optional HDD. This function gives users a chance to check the print results before starting a multiple-set print run.

- The size of the hard disk partition for the sample print feature is 5.8 GB. This partition is also used by the collation and locked print features.
- The partition can hold up to 30 files, including files stored using locked print.
- The partition can hold a log containing up to 20 errors, excluding jobs stored using locked print.
- The maximum number of pages is 2,000, including jobs using locked print and collation.

Locked Print

This feature requires installing an optional HDD. Using this feature, the print job is stored in the machine but will not be printed until the user inputs an ID at the machine’s operation panel. This ID must match the ID that was input with the printer driver.

- Stored data is automatically deleted after it is printed.
- Stored data can be manually deleted at the operation panel.
- The partition can hold up to 30 files, including files stored using sample print.
- The partition can hold a log containing up to 20 errors, excluding logs stored using locked print.
- The maximum number of pages is 2,000, including jobs using sample print and collation.
- Locked print uses the same hard disk partition as sample print and collation, which is 5.8 GB.

Paper Source Selection


Tray Priority (Auto Tray Select)

The “Tray Priority” setting determines the start of the tray search when the user selects “Auto Tray Select” with the driver. The machine searches for a paper tray with the specified paper size and type.

When no tray contains paper that matches the paper size and type specified by the driver, the controller stops printing until the user loads the correct paper.

The “Tray Priority” setting can be specified in the “Paper Input” menu. (Menu/ Paper Input/ Tray Priority)

NOTE: The by-pass feed table is not part of the tray search.



G070D555.WMF

Tray Lock

If “Tray Lock” is enabled for a tray, the controller skips the “locked” tray in the tray search process.

The “Tray Lock” setting can be specified in the “Paper Input” menu. (Menu/ Paper Input/ Tray Lock)

NOTE: The by-pass feed table cannot be unlocked (Tray Lock is always enabled).

Manual Tray Select

If the selected tray does not have the paper size and type specified by the driver, the controller stops printing until the user loads the correct paper.

Detailed Descriptions

Auto Continue

Overview

When this function is enabled, the machine waits for a specified period (0, 1, 5, 10, 15 minutes) for the correct paper size and type to be set in the tray. If the timer runs out, the machine starts printing, even if there is no paper tray which matches the paper size and paper type specified by the driver.


The machine searches for a paper tray in the following way.

- The interval can be set with the “System” menu in the User Tools.
(Menu/ System/ Auto Continue)

NOTE: The default setting for this feature is ‘disabled’.

Auto Tray Select

When there is no paper tray that matches the paper size and type specified by the driver, the machine searches for any tray that has paper, and prints from the first tray it finds. The start of the tray search is the tray selected as the “Priority Tray.”



Manual Tray Select

The machine prints from the selected tray even if the paper size and type do not match the setting specified from the driver.

If “Auto Continue” is disabled, the machine waits until the user loads the correct paper in the tray.

G070D555.WMF

Paper Output Tray

The output tray can be selected with the “Output Tray” setting in the “System” menu (Menu/ System/ Output Tray).

If a print job does not specify an output tray or if the driver specifies the default tray, the output tray selected with this user tool will be used.


Output Tray Selected

- If the machine cannot print to the selected output tray, it prints to the default paper output tray.
- If paper overflow is detected at the selected output tray, the controller stops printing until the overflow detector goes off.

Sequential Stacking

When the 4-bin mailbox is installed, “Auto Tray SW” is selected as the output tray in the “System” menu, and “Printer Default” is specified as the output tray in the driver, the machine automatically sends the output to the lowest tray. When that tray fills up, the machine sends the output to the next lowest tray. When that tray also fills up, the machine sends the output to the next lowest tray sequentially. This feature is called “Sequential Stacking”.

- If a tray becomes full and paper is detected in the next tray, the machine displays an error and stops printing. When paper in the next tray is removed, the machine automatically resumes printing to the next tray.
- If all trays become full (overflow detected in all trays), the machine displays an error and stops printing. This time, all paper in all trays must be removed.



Rear view

G070D556.WMF

Detailed Descriptions

Stapling

Stapling is available when the finisher is installed.

The finisher has only one stapling position.

- Depending on the paper orientation, the image may have to be rotated. The controller rotates the image. If the paper cannot be physically stapled as specified by the driver, it will not be stapled.
- There is a limit for the number of sheets which can be stapled. If a job has more than this number, it will not be stapled.

A3, B4, 11" x 17", LG: 20 sheets (80 g/m², 20 lb)

A4, B5 sideways, LT: 30 sheets (80 g/m², 20 lb)

6.12 IEEE1394 INTERFACE

6.12.1 SPECIFICATIONS

Hardware Specification

Interface: IEEE1394 (6 pins)
 (no power supply, cable power repeated, IEEE1394a-2000 compliant)
 Ports: 2 ports
 Data rates: 400Mbps/200Mbps/100Mbps

System Requirements


PC: Windows PC with IEEE1394 port
 OS: Microsoft Windows 2000 upgraded with service pack 1
 Cable length: 4.5m (15ft)

6.12.2 IEEE1394

IEEE1394, also known as FireWire (a name patented by Apple), is an easy-to-use peer-to-peer networking technology allowing speeds of up to 400 Mbps.

The current standard contains the following features, which are supported in most devices:

- Hot swapping (cables can be connected and disconnected while the computer and other devices are switched on)
- Peer-to-peer networking (no hub required)
- No terminator or device ID is required, unlike SCSI
- Automatic configuration of devices upon start-up, or “plug and play”.
- Real-time data transfer at 100, 200, and 400 Mbps
- Common connectors for different devices




G070D559.WMF

The cable length is limited to 4.5 m (15ft). However, up to 16 cables and 63 devices can be connected to an IEEE1394 network.

IEEE1394 cables can be either 4-pin (data only) or 6-pin (data and power). IEEE1394 allows either 6-pin or 4-pin connectors. However, this machine only uses the 6-pin connectors. The machine has two 6-pin ports.


6.12.3 BLOCK DIAGRAM



G070D560.WMF

- PHY: Physical layer control device
- Link: Link layer control device
- EEPROM: 256-byte ROM

6.12.4 PIN ASSIGNMENT



G070D561.WMF

Pin No.	Signal Description
1	Cable Power
2	GND
3	Receive strobe
4	Transmit data
5	Receive data
6	Transmit strobe

6.12.5 REMARKS ABOUT THIS INTERFACE KIT

Note the following points about this unit.

- The machine does not print reports specifically for IEEE1394. Just print the Configuration Page at installation to check that the machine recognizes the card.
- There is no spooler or print queue. If a computer tries to print over the IEEE1394 while the printer is busy, the IEEE1394 interface card inside the printer will return a busy signal.
- After starting a job using IEEE1394, do not switch the printer off until the job has been completed. Even though the printer may appear to be dead, it may be in the middle of an IEEE1394 protocol exchange with the computer.
- When using IEEE1394, it is not possible to check the printer status from the computer with a utility such as Printer Manager for Client.

6.12.6 TROUBLESHOOTING NOTES


If there are problems printing using the IEEE1394 interface, check the following.

- Is the computer using Windows 2000 with service pack 1?
- Has the interface card been replaced recently? Each card has an individual address, similar to the MAC address in an Ethernet card. If the card was changed, the driver cannot find the old card. The new card is another device and a new printer appears in Windows Control panel, and this must be configured in the same way as the printer that was replaced (the old printer icon in Windows Control Panel should be deleted) has to be reconfigured.
- Is there a loop somewhere in the network? An IEEE1394 network must be a chain or a branched chain. There can be no loops.
- Try to find out where in the chain the problem is occurring. Test the machine one-to-one with the computer to determine if the printer is defective (when the printer's interface cable is plugged in, the computer should see 'Printer Ready'; when the cable is disconnected, the computer should see 'Offline').

6.12.7 IP OVER IEEE 1394

This machine supports IEEE1394 printing by setting an IP address. This feature is called 'IP over 1394'.

The former IEEE1394 printing without IP address is known as 'SCSI printing'.



G070D902.WMF

- NOTE:** 1) IP over 1394 can only be used with Windows XP or Me. It only works with Windows Me if SmartNetMonitor for Client (version 5 or later) is installed.
- 2) Windows XP and 2000 supports IEEE1394 SCSI printing.

6.13 IEEE 802.11B (WIRELESS LAN)

6.13.1 SPECIFICATIONS


A wireless LAN is a flexible data communication system used to extend or replace a wired LAN. Wireless LAN employs radio frequency technology to transmit and receive data over the air and minimize the need for wired connections.

- With wireless LANs, users can access information on a network without looking for a place to plug into the network.
- Network managers can set up or expand networks without installing or moving wires.
- Most wireless LANs can be integrated into existing wired networks. Once installed, the network treats wireless nodes like any other physically wired network component.
- Flexibility and mobility make wireless LANs both effective extensions of and attractive alternatives to wired networks.

Standard applied: IEEE802.11b
 Data transfer rates: 11 Mbps/5.5 Mbps/2 Mbps/1 Mbps (auto sense)
 Network protocols: TCP/IP, Apple Talk, NetBEUI, IPX/SPX
 Bandwidth: 2.4GHz
 (divided over 14 channels, 2400 to 2497 MHz for each channel)

NOTE: The wireless LAN cannot be used together with the Ethernet. The “LAN Type” setting in the Host Interface menu determines the LAN interface to be used.

6.13.2 BLOCK DIAGRAM



Detailed Descriptions

G070D900.WMF

LED Indicators

LED	Description	On	Off
LED1 (Green)	Link status	Link success	Link failure
LED2 (Orange)	Power distribution	Power on	Power off

6.13.3 TRANSMISSION MODE


The following transmission modes are provided for wireless communication.

Ad hoc Mode

The ad hoc mode allows communication between each device (station) in a simple peer-to-peer network. In this mode, all devices must use the same channel to communicate.

In this machine, the default transmission mode is ad hoc mode and the default channel is 11. First, set up the machine in ad hoc mode and program the necessary settings, even if the machine will be used in the infrastructure mode.

To switch between ad hoc and infrastructure modes, use the following user tool: Host Interface Menu - IEEE802.11b - Comm Mode




G070D907.WMF

Infrastructure Mode

The infrastructure mode allows communication between each computer and the machine via an access point equipped with an antenna and wired into the network. This arrangement is used in more complex topologies.

- The wireless LAN client must use the same SSID (Service Set ID) as the access point in order to communicate.



G070D908.WMF

6.13.4 SECURITY FEATURES

SSID (Service Set ID)

The SSID is used by the access point to recognize the client and allow access to the network. Only clients that share the same SSID with the access point can access the network.

- NOTE:** 3) If the SSID is not set, clients connect to the nearest access point.
4) The SSID can be set using the web status monitor or telnet.

Using the SSID in Ad hoc mode

When the SSID is used in ad hoc mode and nothing is set, the machine automatically uses "ASSID" as the SSID. In such a case, "ASSID" must also be set at the client.

NOTE: SSID in ad hoc mode is sometimes called "Network Name."

WEP (Wired Equivalent Privacy)

WEP is a coding system designed to protect wireless data transmission. In order to unlock encoded data, the same WEP key is required on the receiving side. There is 128 bit WEP keys.

NOTE: The WEP key can be set using the web status monitor or telnet.

MAC Address

When the infrastructure mode is used, access to the network can also be limited at the access points using the MAC address. This setting may not be available with some types of access points.

6.13.5 TROUBLESHOOTING NOTES

Communication Status

Wireless LAN communication status can be checked with the UP mode “W.LAN Signal” in the Maintenance menu. This can also be checked using the Web Status Monitor or Telnet.

The status is described on a simple number scale.


Status Display	Communication Status
Good	76~100
Fair	41~75
Poor	21~40
Unavailable	0~20

NOTE: Communication status can be measured only when the infrastructure mode is being used.

Channel Settings

If a communication error occurs because of electrical noise, interference with other electrical devices, etc., you may have to change the channel settings.

To avoid interference with neighboring channels, it is recommended to change by 3 channels. For example, if there are problems using channel 11 (default), try using channel 8.



G070D901.WMF

Troubleshooting Steps

If there are problems using the wireless LAN, check the following.

- 1) Check the LED indicator on the wireless LAN card.
- 2) Check if "IEEE802.11b" is selected in the UP mode LAN Type in Network Setup in the Host Interface menu.
- 3) Check if the channel settings are correct.
- 4) Check if the SSID and WEP are correctly set.

If infrastructure mode is being used,

- 1) Check if the MAC address is properly set
- 2) Check the communication status

If the communication status is poor, bring the machine closer to the access point, or check for any obstructions between the machine and the access point.

If the problem cannot be solved, try changing the channel setting.

6.14 USB

6.14.1 SPECIFICATIONS

This model is equipped with standard USB.

Interface: USB 1.1, USB 2.0

Data rates: 480 Mbps (high speed), 12 Mbps (full speed), 1.5 Mbps (low speed);
High-speed mode is only supported by USB 2.0.

6.14.2 USB 1.1/2.0

USB (Universal Serial Bus) offers simple connectivity for computers, printers, keyboards, and other peripherals. In a USB environment, terminators, device IDs (like SCSI), and DIP switch settings are not necessary.

USB 1.1 contains the following features:


- Plug & Play
- Hot swapping (cables can be connected and disconnected while the computer and other devices are switched on)
- No terminator or device ID required
- Data rates of 12 Mbps (full speed), and 1.5 Mbps (low speed)
- Common connectors for different devices

USB 2.0 is a successor to the USB 1.1 specification. It uses the same cables, connectors, and software interfaces. It provides an easy-to-use connection to a wide range of products with a maximum data rate of 480 Mbps (high speed).

Up to 127 devices can be connected and six cascade connections are allowed. Power is supplied from the computer, and the maximum cable length is 5 m.


6.14.3 USB CONNECTORS

USB is a serial protocol and a physical link transmitting all data on a single pair of wires. Another pair provides power to downstream peripherals. The USB standard specifies two types of connectors, type “A” connectors for upstream connection to the host system, and type “B” connectors for downstream connection to the USB device.



G070D945.WMF

Type “A” connector





G070D952.WMF

Type “B” connector

6.14.4 PIN ASSIGNMENT

The controller has a type “B” receptacle (CN10).



G070D906.WMF

Detailed Descriptions

Pin No.	Signal Description	Wiring Assignment
1	Power	Red
2	Data –	White
3	Data +	Green
4	Power GND	White

6.14.5 REMARKS

- The machine does not print reports specifically for USB.
- Only one host computer is allowed for the USB connection.
- After starting a job using USB, do not switch the printer off until the job has been completed.
When a user cancels a print job and data transmitted to the printer has not been printed at the time of cancellation, the job will continue to print up to the page where the print job was cancelled
- When the controller board is replaced, the host computer will recognize the machine as a different device.

Related SP Mode

“USB Settings” in the printer engine service mode. Data rates can be adjusted to full speed fixed (12 Mbps). This switch may be used for troubleshooting if there is a data transfer error using the high-speed mode (480 Mbps).

SPECIFICATIONS

1. GENERAL SPECIFICATIONS

1.1 MAIN UNIT

Configuration:	Desktop
Print Process:	Laser beam scan & dry electrostatic transfer system
Resolution:	600 x 600 dpi
Warming-up Time:	99 seconds or less
1st Print (A4/LT LEF)*:	Color: 18.0 seconds or less Black & White: 7.5 seconds or less
	*From the start of polygon mirror rotation.

Auto Paper Tray Switch: Available

Paper Size: Regular sizes:

	Europe & Asia	N. America
Standard tray	A6 to A3	HLT to DLT
Bypass tray	A6 to A3	HLT to DLT

Standard tray: Paper size is automatically detected

Bypass tray: Manual input at the operation panel

Custom sizes (Europe, Asia, N. America):

	Min.	Max.
Standard tray	100 x 148 mm (3.9" x 5.8")	297 x 432 mm (11.7" x 17")
Bypass tray	90 x 148 mm (3.5" x 5.8")	305 x 457 mm (12" x 18")*

*Printable area is 297 x 432 mm (11.7 x 17").

Paper Weight:

Standard tray	60 to 105 g/m ² , 16 lb. Bond to 28 lb. Bond
Bypass tray	60 to 163 g/m ² , 16 lb. Bond to 43 lb. Bond

Printing Speed:

	Plain Paper	Thick	OHP
Color	10 ppm	4 ppm	2 ppm
Black & White	36 ppm	6.5 ppm	3.2 ppm

Paper Feed:

Standard tray	Friction pad
Optional paper tray unit	FRR
By-pass	FRR

Spec.

Paper Capacity:

Main	250 sheets x 1 tray
Optional paper tray unit	500 sheets x 1 or 2 trays
By-pass	100 sheets

Fusing: Heating rollers and fusing belt
 Paper Output: Face down
 Output Tray Full: Detected
 Capacity: 400 sheets (200 for A3/DLT)
 Photoconductor: OPC belt
 Charging: Corona wire with grid plate
 Laser Beam: Semiconductor laser
 Development: Mono component toner
 Transfer: Image transfer: Transfer belt with bias roller
 Paper transfer: Roller
 Separation: Discharge pin
 Cleaning: OPC belt: Blade
 Image transfer belt: Cleaning brush
 Quenching: Lamp
 Toner Supply: Cartridge
 Waste Toner Disposal: Toner bottle
 Total Counter: Electrical

Maintenance Counters:

Unit	Mechanical/ Electrical	Sheets/ Time	Reset
PCU	Electrical	120KD	Automatic
Development Unit (K)	Electrical	120KD	Automatic
Development Unit (Y,M,C)	Electrical	60KD	Automatic
O/B Waste Toner Bottle	Mechanical	50KD	Automatic
T/B Waste Toner Bottle	Mechanical	120KD	Automatic
Fusing Oil	Electrical	30KP	Manual
Fusing Unit	Electrical	120KP	Manual

Self-Diagnostics: Jam, Service Call
 Memory Standard: 64 MB
 Options: 64 MB, 128 MB, 256 MB
 Maximum allowable: 384 MB
 Test Printing: Available

Power Source:

	Voltage	Frequency	Amperage
NA	120 V	60 Hz	11 A
EU & Asia	220 to 240 V	50/60 Hz	7 A

Power Consumption: Regular mode: 1.2 KW (NA), 1.5 KW (EU & Asia)
 Energy star mode: 35 W or less
 Dimensions (W x D x H): 540 x 670 x 470 mm (by-pass tray not extended)
 Weight: 60 Kg or less
 Host Interfaces: Bi-directional (Centronics) IEEE1284 parallel x 1
 Ethernet (100 Base-TX/10 Base-T)
 USB 2.0
 IEEE1394 (IP over): Optional
 IEEE802.11b (Wireless LAN): Optional

- NOTE:** 1) USB 2.0 is on another board which occupies the optional interface slot.
 2) It is necessary to remove the USB board when an optional interface is installed.



2. SUPPORTED PAPER SIZES

2.1 MAIN TRAY, BYPASS TRAY, AND DUPLEX UNIT

Paper		Size	Main			By-pass			Duplex Common
			N.A.	EUR.	ASIA	N.A.	EUR.	ASIA	
A3	SEF	297 x 420 mm	Y [#]	Y	Y	Y [#]	Y [#]	Y [#]	Y
B4	SEF	257 x 364 mm	Y [#]	Y	Y	Y [#]	Y [#]	Y [#]	Y
A4	SEF	210 x 297 mm	Y	Y	Y	Y [#]	Y [#]	Y [#]	Y
A4	LEF	297 x 210 mm	Y [#]	Y	Y	Y [#]	Y [#]	Y [#]	Y
B5	SEF	182 x 257 mm	Y [#]	Y					
B5	LEF	257 x 182 mm	Y	Y	Y	Y [#]	Y [#]	Y [#]	Y
A5	SEF	148 x 210 mm	Y [#]	Y					
A5	LEF	210 x 148 mm	Y [#]	Y	Y	Y [#]	Y [#]	Y [#]	Y
B6	SEF	128 x 182 mm	Y [#]	N					
B6	LEF	182 x 128 mm	N	N	N	N	N	N	N
A6	SEF	105 x 148 mm	Y [#]	N					
A6	LEF	148 x 105 mm	N	N	N	N	N	N	N
DLT	SEF	11" x 17"	Y	Y [#]	Y				
LG	SEF	8 1/2" x 14"	Y	Y [#]	Y				
LT	SEF	8 1/2" x 11"	Y	Y	Y	Y [#]	Y [#]	Y [#]	Y
LT	LEF	11" x 8 1/2"	Y	Y [#]	Y				
HLT	SEF	5 1/2" x 8 1/2"	Y [#]	Y					
HLT	LEF	8 1/2" x 5 1/2"	Y [#]	Y [#]	Y [#]	N	N	N	N
Executive	SEF	7 1/4" x 10 1/2"	Y [#]	Y					
Executive	LEF	10 1/2" x 7 1/4"	Y [#]	N					
F	SEF	8" x 13"	Y [#]	Y					
Foolscap	SEF	8 1/2" x 13"	Y [#]	Y					
Folio	SEF	8 1/4" x 13"	Y [#]	Y					
8 K	SEF	267 x 390 mm	Y [#]	Y					
16 K	SEF	195 x 267 mm	Y [#]	Y					
16 K	LEF	267 x 195 mm	Y [#]	Y					
Customized	Width	100 to 297 mm	Y [#]	Y [#]	Y [#]	N	N	N	N
	Length	148 to 432 mm							
	Width	90 to 305 mm	N	N	N	Y [#]	Y [#]	Y [#]	N
	Length	148 to 457 mm							
Com10	SEF	4 1/8" x 9 1/2"	N	N	N	Y [#]	Y [#]	Y [#]	N
Monarch	SEF	3 7/8" x 7 1/2"	N	N	N	Y [#]	Y [#]	Y [#]	N
C6	SEF	114 x 162 mm	N	N	N	Y [#]	Y [#]	Y [#]	N
C5	SEF	162 x 229 mm	N	N	N	Y [#]	Y [#]	Y [#]	N
DL Env	SEF	110 x 220 mm	N	N	N	Y [#]	Y [#]	Y [#]	N

Symbols

- Y: Automatically detected
- Y[#]: Needs to be manually specified
- N: Not supported

2.2 FINISHER, MAIL BOX, AND PAPER TRAY UNIT

Paper		Size	Finisher			Mail Box	Paper Tray Unit		
			Clear	Shift	Staple		Common	N.A.	EUR.
			Common			Common			
A3	SEF	297 x 420	Y	Y	Y(30)	Y	Y	Y	Y
B4	SEF	257 x 364	Y	Y	Y(30)	Y	Y [#]	Y	Y
A4	SEF	210 x 297	Y	Y	Y(30)	Y	Y [#]	Y	Y
A4	LEF	297 x 210	Y	Y	Y(30)	Y	Y	Y	Y
B5	SEF	182 x 257	Y	N	N	Y	Y [#]	Y [#]	Y [#]
B5	LEF	257 x 182	Y	Y	Y(30)	Y	Y	Y	Y
A5	SEF	148 x 210	N	N	N	Y	Y [#]	Y [#]	Y [#]
A5	LEF	210 x 148	Y	N	N	Y	Y [#]	Y	Y
B6	SEF	128 x 182	N	N	N	N	N	N	N
B6	LEF	182 x 128	N	N	N	N	N	N	N
A6	SEF	105 x 148	N	N	N	N	N	N	N
A6	LEF	148 x 105	N	N	N	N	N	N	N
DLT	SEF	11" x 17"	Y	Y	Y(30)	Y	Y	Y	Y
LG	SEF	8 1/2" x 14"	Y	Y	Y(30)	Y	Y	Y [#]	Y [#]
LT	SEF	8 1/2" x 11"	Y	Y	Y(30)	Y	Y	Y [#]	Y [#]
LT	LEF	11" x 8 1/2"	Y	Y	Y(30)	Y	Y	Y	Y
HLT	SEF	5 1/2" x 8 1/2"	N	N	N	Y	N	N	N
HLT	LEF	11" x 8 1/2"	N	N	N	Y	Y	Y [#]	Y [#]
Executive	SEF	7 1/4" x 10 1/2"	Y	N	N	Y	Y [#]	Y [#]	Y [#]
Executive	LEF	10 1/2" x 7 1/4"	N	N	N	Y	N	N	N
F	SEF	8" x 13"	N	N	N	Y	Y [#]	Y [#]	Y [#]
Foolscap	SEF	8 1/2" x 13"	Y	Y	Y(30)	Y	Y [#]	Y [#]	Y [#]
Folio	SEF	8 1/4" x 13"	Y	N	N	Y	Y [#]	Y [#]	Y [#]
Folio	LEF	13" x 8 1/4"	N	N	N	N	N	N	N
A3 Long	SEF	12" x 18"	N	N	N	N	N	N	N
8 K	SEF	267 x 390	Y	Y	Y(30)	Y	Y [#]	Y [#]	Y [#]
16 K	SEF	195 x 267	N	N	N	Y	Y [#]	Y [#]	Y [#]
16 K	LEF	267 x 195	Y	Y	Y(30)	Y	Y [#]	Y [#]	Y [#]
Customized	Width	100 to 305	N	N	N	N	N	N	N
	Length	148 to 458	N	N	N	N	N	N	N

Symbols

- Y: Automatically detected
- Y[#]: Needs to be manually specified
- N: Not supported
- (30): Up to 30 sheets



3. SOFTWARE ACCESSORIES

The printer drivers and utility software are provided on one CD-ROM. An auto-run installer allows you to select which components to install.

3.1 PRINTER DRIVERS

Printer Language	Windows 95/98/ME	Windows NT4.0	Windows 2000	Windows XP	Macintosh
PCL 5c	Yes	Yes	Yes	Yes	No
PS3	Yes	Yes	Yes	Yes	Yes
RPCS	Yes	Yes	Yes	Yes	No

- NOTE:**
- 1) The printer drivers for Windows NT 4.0 are only for the Intel x86 platform. There is no Windows NT 4.0 printer driver for the PowerPC, Alpha, or MIPS platforms.
 - 2) The PS3 drivers are all genuine AdobePS drivers, except for Windows 2000, which uses Microsoft PS. A PPD file for each operating system is provided with the driver.
 - 3) The PS3 driver for Macintosh supports Mac OS 8.6, 9.x, 10.1.x, (10.0.x is not supported).
 - 4) The following Unix versions are supported:
 - Solaris 2.6, 7, 8
 - HP-UX 11.0
 - Red Hat Linux 6.2, 7.0, 7.1, 7.2


3.2 UTILITY SOFTWARE

Software	Description
Agfa Monotype Font Manager (Win 95/98/ME, NT4, W2000, XP)	A font management utility with screen fonts for the printer.
SmartNetMonitor for Admin (Win 95/98/ME, NT4, W2000, XP)	A printer management utility for network administrators. NIB setup utilities are also available.
SmartNetMonitor for Client (Win 95/98/ME, NT4, W2000, XP)	A printer management utility for client users.
Printer Utility for Mac	This software provides several convenient functions for printing from Macintosh clients.

4. MACHINE CONFIGURATION

4.1 SYSTEM COMPONENTS

Exterior




G070V001.WMF

No.	Unit	Code
—	Main unit	G071
1	500-sheet finisher	G314
2	4-bin mailbox	G312
3	Interchange unit	G305
4	Duplex unit	G303
5	Paper tray unit	G313

Spec.

Interior



G070V002.WMF

No.	Unit	Code
1	Printer hard disk	G315
2	64 MB DIMM	G330
	128 MB DIMM	G331
	256 MB DIMM	G332
3	IEEE 1394 board	G561
4	USB 2.0 board (Standard)	—
5	IEEE802.11b (Wireless LAN)	G628
6	User account enhancement unit	G311

Maintenance Kits

Unit	Code
O/B Waste toner bottle	G778-17
I/B Waste toner bottle	G778-18
Fusing unit oil	G779
PCU	G780
Bk development unit	G781
CMY development unit	G782
Fusing unit and paper feed roller/friction pad	G783

4.2 OPTIONAL EQUIPMENT

Paper Tray Unit

Paper Feed System:	FRR
Paper Height Detection:	4 steps (100%, 50%, Near End, and Empty)
Capacity:	500 sheets x 1 (up to 59 mm)
Paper Weight:	60 to 128 g/m ² (16 to 34 lb.)
Paper Size:	A3/11" x 17" to A5/5.5 x 8.5" (LEF)
Power Source:	DC24V, 5V (from the main frame)
Power Consumption:	Less than 50W
Dimensions (W x D x H):	540 x 600 x 120 mm
Weight:	15 kg (33 lb.)

Finisher

Paper Size:	A3, B4, A4, B5 LEF, 11" x 17", LG, LT
Paper Weight:	60 to 128 g/m ² (14 to 34 lb.)
Staple Capacity:	20 sheets (A3, B4, 11" x 17", LG : 80g/m ² , 20 lb) 30 sheets (A4, B5 sideways, LT : 80g/m ² , 20 lb)
Stack Capacity:	500 sheets (A4/LT or smaller: 80 g/m ² , 20 lb.) 250 sheets (A3, B4, 11" x 17" and LG. 80 g/m ² , 20 lb.)
Staple Position:	1
Staple Replenishment:	Cartridge (3,000 staples/cartridge)
Power Source:	24V DC, 5V DC (from the main frame)
Power Consumption:	48 W
Weight:	8.5 Kg (18.9 lbs)
Dimensions:	506 x 164 x 328 mm (19.9" x 6.5" x 12.9")

Mail Box

Trays:	4
Capacity:	125 sheets (A4:LEF 80 g/m ² , 20 lb)
Paper Weight:	60 to 128 g/m ² (16 to 34 lb.)
Power Source:	DC24V, 5V (from the main frame)
Power Consumption:	Less than 17 W.
Paper Size:	A3/11" x 17" to A5/LT
Dimensions (W x D x H):	440 x 520 x 370 mm (17.3" x 20.5" x 14.6")
Weight:	7 kg (15.5 lb)

Duplex Unit

Paper Size:	A3/11" x 17" to A5/5.5" x 8.5"
Paper Weight:	60 to 105 g/m ² (17 to 28 lb.)
Power Source:	DC 24V, 5V (from the main frame)
Power Consumption:	
Dimensions (W x D x H):	121 x 479 x 504 mm (4.8" x 18.9" x 19.8")
Weight:	6 kg (13 lbs.)

Interchange Unit

Paper Size:	A3/11" x 17" to A5/5.5" x 8.5"
Paper Weight:	60 to 128 g/m ²
Dimensions (W x D x H):	508 x 159 x 110 mm (20.0" x 6.3" x 4.3")
Weight:	3 kg (6.6 lbs.)