

## Notes for Users

---

This machine supports AirPrint.

AirPrint is installed on this machine by default.

Visit Apple's site at <http://www.apple.com/> for more information on AirPrint and how it works.

If no connection can be established by using the following procedure, contact your service representative.

### Note

- AirPrint can be used within a network.

If you cannot use AirPrint, check that IPP and Bonjour are enabled. IPP and Bonjour are enabled by default. Refer to Security Guide for login. The login procedure is as follows:

1. Log in to WebImageMonitor as a network administrator.
2. Click [Device Management] > [Configuration].
3. Click [IPv4] in [Network].
4. Check that [IPP] is set to [Active].  
Unless [Active] is selected, select it.
5. Click [OK] to proceed.
6. Click [Bonjour] in [Network].
7. Check that either of [IPv4] or [IPv6] in [Bonjour] is set to [Active].  
Unless [Active] is selected, select it.
8. Click [OK].

## For Users of Models Not Installed with the HDD

---

If the HDD is not installed and a print job is performed using AirPrint, black-and-white printouts may be delivered as color printouts.



AirPrint and the AirPrint logo are trademarks of Apple Inc.

© 2013

Printed in China

EN (GB) EN (US) EN (AU)

M124-8554



M1248554