

Notes for Users

This supplement provides corrections and notes for the manuals provided with this machine. Read this supplement in conjunction with the manuals.

Options

This machine does not support the following options:

- Trimmer Unit TR5020
- Ring Binder RB5000
- Perfect Binder GB5000
- Fuser Unit Air Separator Type C901
- Punch Unit PU5000 SC
- Punch Unit PU5020 SC
- Cooling Fan Unit Type 5000

请使用中性复印纸

复印机使用纸张进行复印，而纸张的特性将会直接影响到副本的质量。纸张一般可分为酸性和中性两类，为了保证复印机可长期稳定地使用和维持良好的复印质量，复印时使用中性纸较为妥当。

酸性纸中的硫酸铝成份与空气中的水分接触后会发生酸性变化，复印机内部的零件也会因此受到酸化腐蚀。加之，酸性纸本身亦容易酸化并引致变色和干化，所以，这种纸不适于复印及印刷之用。另外，纸粉多又是酸性纸的一大特征。纸粉多将会造成送纸不良，操作件感应失误，零件的使用寿命缩短和各部位故障率增加。而故障率的增加势必导致修理次数增多，从而使零件及修理费用的成本高涨。所以，我们郑重向您推荐请使用中性纸。

请向销售店直接查询有关中性纸的价格及其相关情况。

Laws and Regulations

警告

技术指标

工作频率范围: 13.553 - 13.567 MHz

磁场强度 (距设备 10 米处): $< 42\text{dB}\mu\text{A/m}$ (准峰值)

频率容限: $<100\text{ ppm}$

杂散辐射等其他技术指标请参照 2005/423 号文献

不得擅自更改发射频率, 加大发射功率 (包括额外加装射频功率放大器), 不得擅自外接天线或改用其它发射天线。

使用时不得对各种合法的无线电通信业务产生有害干扰; 一旦发现有干扰现象时, 应立即停止使用, 并采取措施消除干扰后方可继续使用。

使用微功率无线电设备, 必须忍受各种无线电业务的干扰或工业, 科学及医疗应用设备的辐射干扰。

不得在飞机和机场附近使用。

电子信息产品污染控制的表示

有毒有害物质或者元素的名称以及含有表示

RICOH Pro C901

本体	有毒有害物质或者元素					
部件名称	铅 (Pb)	水银 (Hg)	镉 (Cd)	六价铬 (Cr ⁶⁺)	多溴联 苯 (PBB)	多溴联 苯醚 (PBDE)
1 结构 / 驱动	×	○	○	○	○	○
2 外壳	×	○	○	○	○	○
3 操作面板	×	○	○	○	○	○
4 写入	×	○	○	○	○	○
5 显影	×	○	○	○	○	○
6 定影	×	○	○	○	○	○
7 送纸	×	○	○	○	○	○
8 电器	×	○	○	○	○	○
9 送稿器	—	—	—	—	—	—
10 附件	×	○	○	○	○	○
11 包装品	○	○	○	○	○	○

LCIT RT5030

纸处理选购件	有毒有害物质或者元素					
构成组件	铅 (Pb)	水银 (Hg)	镉 (Cd)	六价铬 (Cr ⁶⁺)	多溴联 苯 (PBB)	多溴联 苯醚 (PBDE)
1 结构 / 驱动 / 送稿器	×	○	○	○	○	○
2 外壳	×	○	○	○	○	○
3 电器	×	○	○	○	○	○
4 附件	×	○	○	○	○	○
5 包装品	○	○	○	○	○	○

Multi Bypass Tray BY5000

纸处理选购件	有毒有害物质或者元素					
构成组件	铅 (Pb)	水银 (Hg)	镉 (Cd)	六价铬 (Cr ⁶⁺)	多溴联 苯 (PBB)	多溴联 苯醚 (PBDE)
1 结构 / 驱动 / 送稿器	×	○	○	○	○	○
2 外壳	×	○	○	○	○	○
3 电器	×	○	○	○	○	○
4 附件	×	○	○	○	○	○
5 包装品	○	○	○	○	○	○

Cover Interposer Tray CI5010

纸处理选购件	有毒有害物质或者元素					
构成组件	铅 (Pb)	水银 (Hg)	镉 (Cd)	六价铬 (Cr ⁶⁺)	多溴联 苯 (PBB)	多溴联 苯醚 (PBDE)
1 结构 / 驱动 / 送稿器	×	○	○	○	○	○
2 外壳	×	○	○	○	○	○
3 电器	×	○	○	○	○	○
4 附件	×	○	○	○	○	○
5 包装品	○	○	○	○	○	○

High Capacity Stacker SK5010

纸处理选购件	有毒有害物质或者元素					
构成组件	铅 (Pb)	水银 (Hg)	镉 (Cd)	六价铬 (Cr ⁶⁺)	多溴联 苯 (PBB)	多溴联 苯醚 (PBDE)
1 结构 / 驱动 / 送稿器	×	○	○	○	○	○
2 外壳	○	○	○	○	○	○
3 电器	×	○	○	○	○	○
4 附件	×	○	○	○	○	○
5 包装品	○	○	○	○	○	○

Roll-Away Cart Type 5010

纸处理选购件	有毒有害物质或者元素					
构成组件	铅 (Pb)	水银 (Hg)	镉 (Cd)	六价铬 (Cr ⁶⁺)	多溴联 苯 (PBB)	多溴联 苯醚 (PBDE)
1 结构 / 驱动 / 送稿器	×	○	○	○	○	○
2 外壳	—	—	—	—	—	—
3 电器	—	—	—	—	—	—
4 附件	○	○	○	○	○	○
5 包装品	○	○	○	○	○	○

Finisher SR5000

纸处理选购件	有毒有害物质或者元素					
构成组件	铅 (Pb)	水银 (Hg)	镉 (Cd)	六价铬 (Cr ⁶⁺)	多溴联 苯 (PBB)	多溴联 苯醚 (PBDE)
1 结构 / 驱动 / 送稿器	×	○	○	○	○	○
2 外壳	○	○	○	○	○	○
3 电器	×	○	○	○	○	○
4 附件	○	○	○	○	○	○
5 包装品	○	○	○	○	○	○

Booklet Finisher SR5020

纸处理选购件	有毒有害物质或者元素					
构成组件	铅 (Pb)	水银 (Hg)	镉 (Cd)	六价铬 (Cr ⁶⁺)	多溴联 苯 (PBB)	多溴联 苯醚 (PBDE)
1 结构 / 驱动 / 送稿器	×	○	○	○	○	○
2 外壳	○	○	○	○	○	○
3 电器	×	○	○	○	○	○
4 附件	○	○	○	○	○	○
5 包装品	○	○	○	○	○	○

LCIT RT5050

纸处理选购件	有毒有害物质或者元素					
构成组件	铅 (Pb)	水银 (Hg)	镉 (Cd)	六价铬 (Cr ⁶⁺)	多溴联 苯 (PBB)	多溴联 苯醚 (PBDE)
1 结构 / 驱动 / 送稿器	×	○	○	○	○	○
2 外壳	×	○	○	○	○	○
3 电器	×	○	○	○	○	○
4 附件	×	○	○	○	○	○
5 包装品	○	○	○	○	○	○

Bridge Unit BU5000

纸处理选购件	有毒有害物质或者元素					
构成组件	铅 (Pb)	水银 (Hg)	镉 (Cd)	六价铬 (Cr ⁶⁺)	多溴联 苯 (PBB)	多溴联 苯醚 (PBDE)
1 结构 / 驱动 / 送稿器	×	○	○	○	○	○
2 外壳	×	○	○	○	○	○
3 电器	×	○	○	○	○	○
4 附件	×	○	○	○	○	○
5 包装品	○	○	○	○	○	○

Z-folding Unit ZF4000

纸处理选购件	有毒有害物质或者元素					
构成组件	铅 (Pb)	水银 (Hg)	镉 (Cd)	六价铬 (Cr ⁶⁺)	多溴联 苯 (PBB)	多溴联 苯醚 (PBDE)
1 电器	×	○	○	○	○	○
2 金属	○	○	○	○	○	○
3 树脂	×	○	○	○	○	○
4 附件	×	○	○	○	○	○
5 包装品	○	○	○	○	○	○

A3/11"×17" Tray Unit TK5000

纸处理选购件	有毒有害物质或者元素					
构成组件	铅 (Pb)	水银 (Hg)	镉 (Cd)	六价铬 (Cr ⁶⁺)	多溴联 苯 (PBB)	多溴联 苯醚 (PBDE)
1 结构 / 驱动 / 送稿器	×	○	○	○	○	○
2 外壳	○	○	○	○	○	○
3 电器	×	○	○	○	○	○
4 附件	○	○	○	○	○	○
5 包装品	○	○	○	○	○	○

Tab Sheet Holder Type3260

纸处理选购件	有毒有害物质或者元素					
构成组件	铅 (Pb)	水银 (Hg)	镉 (Cd)	六价铬 (Cr ⁶⁺)	多溴联 苯 (PBB)	多溴联 苯醚 (PBDE)
1 结构 / 驱动 / 送稿器	○	○	○	○	○	○
2 外壳	○	○	○	○	○	○
3 电器	○	○	○	○	○	○
4 附件	○	○	○	○	○	○
5 包装品	○	○	○	○	○	○

Punch Unit PU5000 EU

纸处理选购件	有毒有害物质或者元素					
构成组件	铅 (Pb)	水银 (Hg)	镉 (Cd)	六价铬 (Cr ⁶⁺)	多溴联 苯 (PBB)	多溴联 苯醚 (PBDE)
1 结构 / 驱动 / 送稿器	×	○	○	○	○	○
2 外壳	○	○	○	○	○	○
3 电器	×	○	○	○	○	○
4 附件	○	○	○	○	○	○
5 包装品	○	○	○	○	○	○

Punch Unit PU5020 EU

纸处理选购件	有毒有害物质或者元素					
构成组件	铅 (Pb)	水银 (Hg)	镉 (Cd)	六价铬 (Cr ⁶⁺)	多溴联 苯 (PBB)	多溴联 苯醚 (PBDE)
1 结构 / 驱动 / 送稿器	×	○	○	○	○	○
2 外壳	—	—	—	—	—	—
3 电器	×	○	○	○	○	○
4 附件	○	○	○	○	○	○
5 包装品	○	○	○	○	○	○

Waste Toner Bottle Type C900

其他选购件	有毒有害物质或者元素					
构成组件	铅 (Pb)	水银 (Hg)	镉 (Cd)	六价铬 (Cr ⁶⁺)	多溴联 苯 (PBB)	多溴联 苯醚 (PBDE)
1 电器	○	○	○	○	○	○
2 金属	×	○	○	○	○	○
3 树脂	○	○	○	○	○	○
4 附件	○	○	○	○	○	○
5 包装品	○	○	○	○	○	○

Buffer Pass Unit Type 5000

纸处理选购件	有毒有害物质或者元素					
构成组件	铅 (Pb)	水银 (Hg)	镉 (Cd)	六价铬 (Cr ⁶⁺)	多溴联 苯 (PBB)	多溴联 苯醚 (PBDE)
1 结构 / 驱动 / 送稿器	×	○	○	○	○	○
2 外壳	×	○	○	○	○	○
3 电器	×	○	○	○	○	○
4 附件	×	○	○	○	○	○
5 包装品	○	○	○	○	○	○

Pro Print Cartridge

耗材	有毒有害物质或者元素					
构成组件	铅 (Pb)	水银 (Hg)	镉 (Cd)	六价铬 (Cr ⁶⁺)	多溴联 苯 (PBB)	多溴联 苯醚 (PBDE)
1 碳粉	○	○	○	○	○	○
2 载体	○	○	○	○	○	○
3 电器	○	○	○	○	○	○
4 金属	○	○	○	○	○	○
5 树脂	○	○	○	○	○	○
6 附件	○	○	○	○	○	○
7 包装品	○	○	○	○	○	○

Color controller E-41

其他选购件	有毒有害物质或者元素					
构成组件	铅 (Pb)	水银 (Hg)	镉 (Cd)	六价铬 (Cr ⁶⁺)	多溴联 苯 (PBB)	多溴联 苯醚 (PBDE)
1 电器	×	○	○	○	○	○
2 金属	○	○	○	○	○	○
3 树脂	○	○	○	○	○	○
4 附件	○	○	○	○	○	○
5 包装品	○	○	○	○	○	○

Optional Counter Interface Unit Type A

其他选购件	有毒有害物质或者元素					
构成组件	铅 (Pb)	水银 (Hg)	镉 (Cd)	六价铬 (Cr ⁶⁺)	多溴联 苯 (PBB)	多溴联 苯醚 (PBDE)
1 电器	×	○	○	○	○	○
2 金属	○	○	○	○	○	○
3 树脂	○	○	○	○	○	○
4 附件	○	○	○	○	○	○
5 包装品	○	○	○	○	○	○

• 备注

- ○：表示相关部件所有均质材料中有害有毒物质的量低于 SJ/T11363-2006 标准规定的限量要求。
- ×：表示相关部件至少一种均质材料中有害有毒物质的量高于 SJ/T11363-2006 标准规定的限量要求。
- —：表示相关部件中不含有此有毒物质。

环保使用期限的说明



仅适用中国
环保使用期限

这个标志是在中国销售的电子信息产品适用的环保使用期限。

只要遵守有关该产品的安全和使用时的注意事项，从生产日期开始的年限内，不会出现环境污染，不会给人体和财产带来严重影响。这个期限是根据安全使用期限规律算出来的。

Environmental Conditions

对《环境标志产品技术要求 数字式多功能复印设备》要求的补充信息

- 理光根据保修单条款内容对产品承诺一年保修期或张数保修。当用户在保修期内属正常使用而引起机器故障，可与保修单上署名的经销商联系，享受免费修理。^{*1}
- 复印设备在停产 5 年之内，保证复印设备在正常使用范围内可能损坏的备件供应；在复印设备停产之后 5 年内保证消耗品的供应。
- 关于废旧产品、耗材（含光导鼓）、选购件回收的详细信息，参见理光（中国）网站：www.ricoh.com.cn 理光与环保。
- 本产品说明书优先选择不用氯化物漂白的纸张印刷。
- 复印设备能够使用由 100% 的回收纤维制成的回收纸进行复印。^{*2}
- 噪音大于 63 分贝的办公设备不适合放置在主要从事脑力劳动的人员的办公室内。考虑到噪音的排放，这样的设备应该放置在其他房间内。

^{*1} 相关内容以产品保修单中保修期及保证内容条款为准。

^{*2} 请使用理光推荐纸张，详情请向理光供应商查询。

Entering Text

How to Enter Characters

You can use the cursor to enter characters.

If there are characters above the cursor, new characters are inserted in front of those characters.

The following characters can be entered:

Available Characters

This section explains which characters are available.

You can enter the following characters:

- Chinese Character Set GB2312
- Symbols
- single- and double-byte alphanumerical characters
- qualified numbers
- Greek letters
- Cyrillic letters
- double-byte pinyin characters
- pinyin diacritical tone markings

About The Screen's Input Keys

This section explains the entry screen and the keys displayed on it.

You can switch between the following input methods:



- [Pinyin]
Enables pinyin character input mode.
- [Alphabet]
Enables alphanumerical character input mode.
- [Symbol Entry]
Mode for symbols, qualified numbers, Greek letters, Cyrillic letters, double-byte pinyin characters, and pinyin diacritical tone markings.
- [Text Code]
Enables character code input mode. Enter a character by its code if you do not know its reading.
- [←] [→]
Move the cursor left and right.

When inserting characters using the cursor, remember that characters are placed in front of the cursor.
- [Backspace]
Deletes the character that is directly in front of the cursor.
- [Delete All]
Deletes all entered characters.

- [Shift Lock]

Switches alphabetic characters between upper and lower case.

- [Space]

Inserts a blank space.

- [No Conversion]

Associates entered pinyin simply with pinyin.

- [Conversion]

Converts entered pinyin to the corresponding Chinese characters.

- [User Text]

Adds a User Text that has been registered in advance.

How to Enter Text

This section explains the various methods of character entry.

Pinyin

Enter the pinyin characters, and then press [Conversion].

The Chinese characters that correspond to the entered pinyin will appear on the screen. Select the character you require. If the character you require does not appear, scroll the screen upward or downward by pressing [Previous] or [Next] respectively.

If you do not know the reading of a character but you know its character code, you can enter the character by keying in its code.

Character Code

Press [Text Code], and then key in the code of the character that you want to enter.

Example: to enter "a", press [1] [6] [0] [1].

Alphanumeric Characters

To display alphanumeric characters, press [Alphabet].

If you press [Shift Lock], entered characters are switched between lower and upper case.

Symbols

To enter a symbol, press [Symbol Entry]. [Symbol Entry] is displayed, and the headings shown below appear under it. Pressing these headings switches the screen accordingly.

- Punctuation
- Characters
- Others

Character Entry Practice

Follow this procedure to learn how to enter characters.

Example: entering the name "caiwubuA1".

1. Press [PinYin].
2. Press [c][a][i].
3. Press [Conversion].
4. Press [cai].
5. Press [w][u].
6. Press [Conversion].
7. Press [wu].
8. Press [b][u].
9. Press [Conversion].
10. Press [bu].
11. Press [Shift Lock], and then switch to upper case mode.
12. Press [A].
13. Press [No Conversion].
14. Press [Shift Lock], and then switch to lower case mode.
15. Press [1].
16. Press [OK].

Note

- If you enter an incorrect character, press [Backspace] to enter the correct character in its place. To undo the conversion, press [Cancel Conversion].

Adding user text

You can select and use a User Text that is registered in [Program / Change / Delete User Text]. For the registration procedure under Program / Change / Delete User Text, see "System Settings", General Settings Guide.

1. **Press [User Text].**
2. **Select the User Text you want to use.**

Noise emission

- Sound power level:

	Main unit only	Complete system
Stand-by	Less than 68 dB (A)	Less than 69 dB (A)
Printing	Less than 76 dB (A)	Less than 80 dB (A)

- Sound pressure level:

	Main unit only	Complete system
Stand-by	Less than 66 dB (A)	—
Printing	Less than 72 dB (A)	Less than 72 dB (A)

The complete system consists of the main unit, Finisher SR5000, and the Wide Large Capacity Tray (Wide LCT).

Paper Library

The selectable paper types are as follows: Plain, Gloss coated, Matte coated, Envelope, and Pre-Punched. You cannot select Tab Stock.

© 2011

Printed in Japan

EN 

M077-2189



M0772189