

MODIFICATION BULLETIN NO. K100-179

ISSUED ON Dec.28, 1995

Model		Fax1000L, Fax1010 (USA only)				Date of Modification	
Modified Article		ADF				Execution Date	
Reason for Modification		<div><div><input checked="" type="checkbox"/> Parts catalog correction <input type="checkbox"/> Vender change</div><div><input type="checkbox"/> To meet standards () <input type="checkbox"/> Part standardization</div><div><input type="checkbox"/> To facilitate assembly <input type="checkbox"/> To improve reliability <input type="checkbox"/> Other</div></div>					
Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange-ability	Remarks	Parts Catalog	
						Index No.	Page
H0061205	H0067205	Sensor S2	1 → 1			42	1-5
<div>M. Iwasa Manager 2nd T.S.Sec. Int'l Marketing Group</div>							

MODIFICATION BULLETIN NO. K100-180ISSUED ON 29th, June, 1992

Model	FAX1000L/1010L, infotec 6755, SAVINFAX600		Date of Modification
Modified Article	ADF		Expected Date
Reason for Modification	<input type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input checked="" type="checkbox"/> To improve reliability <input type="checkbox"/> Other		Execution Date
	The pick-up friction spring may be broken due to using the machine for a long period of time. To increase reliability, the strength of it has been improved.		From 1st production of June, 1992.

Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
H0061276	H0061286	Pick-up Friction Spring	1 → 1	X / O		82	1-5

Reference No. for this MB

QECR	
ECN No.	92050058

H.Motojima

Assistant General Manager

FTS Sect. TS Dept.

MODIFICATION BULLETIN NO. K100-181

ISSUED ON Oct. 20, 1993

Model		K103					Date of Modification	
Modified Article		PCB-VPU2					Execution Date	
Reason for Modification		<div><div><input type="checkbox"/> Parts catalog correction <input type="checkbox"/> Vender change</div><div><input type="checkbox"/> To meet standards () <input type="checkbox"/> Part standardization</div><div><input type="checkbox"/> To facilitate assembly <input checked="" type="checkbox"/> To improve reliability <input type="checkbox"/> Other</div></div> <p>More than the permissible current flows to the LSI on the VPU2 continuously and the LSI might be damaged because the resistor value is too low to pull the signal down. To prevent this problem, the resistor has been changed from 820 Ω to 3.9 kΩ.</p>					Effective for the service parts.	
Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange-ability	Remarks	Parts Catalog		
						Index No.	Page	
H006 6077	H028 6006	PCB-VPU2	1 → 1	X / O		21	1-11	
<div>S.Hamano</div> <div>Assistant General Manager Second Technical Support Section International Marketing Group</div>								

RE-ISSUED ON Mar.15,1995ISSUED ON Feb.15, 1995MODIFICATION BULLETIN NO. Multi-001

Model	CSO, CFO, CS1, CRO, CGO, K200, AFO (Ricoh brand for North America)					Date of Modification	
Modified Article						Execution Date	
Reason for Modification	<input type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> Vender change <input checked="" type="checkbox"/> Part standardization <input type="checkbox"/> To improve reliability <input type="checkbox"/> Other					From the old part has become out of stock.	

Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
H0534808	H5134107	Handset Ass'y	1 → 1	O / O			
(H0534809)	(H5134157)	Handset Table - Upper	(1 → 1)	(O / O)			
(H0535214)	(H5135128)	Handset	(1 → 1)	(O / O)			
	(H1608600)	Installation Manual	(0 → 1)				

S.Hamano
 Assistant General Manager
 2nd T.S.Sec. Int'l Marketing Group

MODIFICATION BULLETIN NO. Multi-002ISSUED ON Oct. 15, 1995

Model	US: Fax2800L, 4000L, 7000L, 77, 80, 85, 86, 550 China: Fax3000L, 580					Date of Modification	
Modified Article	Handset					Execution Date	
Reason for Modification	<input type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> Vender change <input checked="" type="checkbox"/> Part standardization <input type="checkbox"/> To improve reliability <input type="checkbox"/> Other						
Handset and Handset Holder will not be available. Please order Handset Ass'y instead of these.							
Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
H5134157	H5134107	Handset Holder - US	1 → 0				
H5135128		Handset - US	1 → 0				
		Handset Ass'y - US					
H5134155	H5134105	Handset Holder - China	1 → 0				
H5135126		Handset - China	1 → 0				
		Handset Ass'y - China					
M. Iwasa Manager 2nd T.S.Sec. Int'l Marketing Group							

MODIFICATION BULLETIN NO. Multi - 007ISSUED ON Sep.15, 1996

Model	K100, K105, K200 (Ricoh and OEM)					Modification Schedule	
Modified Article	Main Switch					After the old part is out of stock.	
Reason for Modification	<div style="display: flex; justify-content: space-between;"> <div> <input type="checkbox"/> Parts catalog correction <input checked="" type="checkbox"/> Vender change </div> <div> <input type="checkbox"/> To meet standards () <input type="checkbox"/> Part standardization </div> <div> <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> To improve reliability <input type="checkbox"/> Other </div> </div>						

Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
H006 5223	H004 5209	Main Switch	1 - 1	O / O			

S.Fujii
General Manager
2nd Field Information Department
QA Division

Prepared by Y.Okunishi

RC	RE	ASIA	
----	----	------	--

Model: K100, K105, K200		Date: 31-Jul-97	No: Multi - 008
Modified Article: Main Switch		Prepared by: Y.Okunishi	
From: QAC 2nd Field Information Dept.			
Reason for Modification:	<input type="checkbox"/> Parts catalog correction <input checked="" type="checkbox"/> Vendor change <input type="checkbox"/> To meet standards <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> To improve reliability () <input type="checkbox"/> Part Standardization <input type="checkbox"/> Other		
Modification Schedule	After the old part is out of stock.		

Old part number	New part number	Description	Qty	Int	Page	Index	Note
H006 5223	H004 5209	Main Switch	1 - 1	O/O			

RC	RE	ASIA	