


MODIFICATION BULLETIN NO. IXO-001ISSUED ON July 23, 1993


Model	IXO					Date of Modification	
Modified Article						Execution Date	
Reason for Modification	<input checked="" type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input type="checkbox"/> To improve reliability <input type="checkbox"/> Other						
Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
H5042146	H5042148	Decal - Release Lever	1 → 1			63	1-5
H504 2154	H504 2157	Seal - Guide	1 → 1			62	1-5
	H504 2131	Reinforcement Feed Roller	0 → 1			77	1-5
	H504 2155	Small Seal - Guide	0 → 2			78	1-5
	H504 3127	Spacer - Speaker	0 → 1			20	1-3
H.Motojima Assistant General Manager FTS Sect. TS Dept.							

MODIFICATION BULLETIN NO. IXO-001

ISSUED ON July 23, 1993

DETAILS OF MODIFICATION

DETAILS OF MODIFICATION



MODIFICATION BULLETIN NO. IXO-002ISSUED ON July 23, 1993

Model	IXO(Telautograph)						Date of Modification	
Modified Article	Base						Execution Date	
Reason for Modification	<input checked="" type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input type="checkbox"/> To improve reliability <input type="checkbox"/> Other							
Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog		
						Index No.	Page	
H504 3101	H504 3151	Base: TEL				54	1 - 5	
<div style="text-align: right;"> H.Motojima Assistant General Manager FTS Sect. TS Dept. </div>								

MODIFICATION BULLETIN NO. IXO-003

ISSUED ON July 23, 1993

Model	IXO(NRG)						Date of Modification	
Modified Article	Base						Execution Date	
Reason for Modification	<input checked="" type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input type="checkbox"/> To improve reliability <input type="checkbox"/> Other							
Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog		
						Index No.	Page	
H504 3101	H504 3141	Base: NRG				54	1 - 5	
H.Motojima Assistant General Manager FTS Sect. TS Dept.								

MODIFICATION BULLETIN NO. IXO-004

ISSUED ON July 23, 1993

Model		IXO(SAVIN)				Date of Modification	
Modified Article		Base				Execution Date	
Reason for Modification		<div> <input checked="" type="checkbox"/> Parts catalog correction <input type="checkbox"/> Vender change <input type="checkbox"/> To meet standards () <input type="checkbox"/> Part standardization <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> To improve reliability <input type="checkbox"/> Other </div>					
Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
H504 3101	H504 3131	Base: SVN				54	1 - 5
<div style="text-align: right;"> H.Motojima Assistant General Manager FTS Sect. TS Dept. </div>							

MODIFICATION BULLETIN NO. IXO-005

ISSUED ON July 23, 1993

Model		IXO(infotec)				Date of Modification	
Modified Article		Base				Execution Date	
Reason for Modification		<div> <input checked="" type="checkbox"/> Parts catalog correction <input type="checkbox"/> Vender change <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> Part standardization <input type="checkbox"/> To improve reliability <input type="checkbox"/> Other </div>					
Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
H504 3101	H504 3131	Base: INF				54	1 - 5
<div style="text-align: right;"> H.Motojima Assistant General Manager FTS Sect. TS Dept. </div>							

MODIFICATION BULLETIN NO. IXO-006

REISSUED ON OCT. 21, 1993

ISSUED ON July 23, 1993

Model	IXO(U3 and Asia versions)						Date of Modification	
Modified Article	PCB-NCU						Execution Date	
Reason for Modification	<input checked="" type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input type="checkbox"/> To improve reliability <input type="checkbox"/> Other							
Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog		
						Index No.	Page	
H504 6003	H504 6016	PCB-NCU: UN				71	1 - 5	
	1633 0000	Jumper - 0Ω, ±1.00%, 1/10W	(4 → 2)					
<div style="text-align: right;"> <p>S.Hamano</p> <p>Assistant General Manager Second Technical Support Section International Marketing Group</p> </div>								

MODIFICATION BULLETIN NO. IXO-007

ISSUED ON oct. 20, 1993

Model	IXO(except US version)				Date of Modification	
Modified Article	Operators Manual				Execution Date	
Reason for Modification	<input type="checkbox"/> Parts catalog correction <input checked="" type="checkbox"/> To meet standards (German) <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input type="checkbox"/> To improve reliability <input type="checkbox"/> Other				Effetive after the old parts have become out of stock. Note:Concerning the German language kit, the new parts apply from the mass production.	

Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange-ability	Remarks	Parts Catalog	
						Index No.	Page
H504 4056	H504 4082	Cover - O/M : UN	1 → 1	O/O		*	1-3
H504 4057	H504 4083	Cover - O/M : UN : Ges	1 → 1	O/O		*	1-3
H504 4058	H504 4084	Cover - O/M : UN : Nas	1 → 1	O/O		*	1-3
H504 4059	H504 4085	Cover - O/M : UN : Rex	1 → 1	O/O		*	1-3
H504 4060	H504 4086	Cover - O/M : UN : INF	1 → 1	O/O		*	1-3

S.Hamano


Assistant General Manager
Second Technical Support Section
International Marketing Group

MODIFICATION BULLETIN NO. IXO-008

ISSUED ON OCT. 21, 1993

Model	IXO						Date of Modification	
Modified Article	Scanner						Execution Date	
Reason for Modification	<div> <input checked="" type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly </div> <div> <input type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input type="checkbox"/> To improve reliability </div> <div> <input type="checkbox"/> Other </div> <p>Please refer to the RTB IXO-010 when putting the spacers.</p>							
Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog		
						Index No.	Page	
	H504 1105	Right Scanner Spacer	O → 1			21	1-3	
	H504 1106	Left Scanner Spacer	O → 1			22	1-3	
<div>S.Hamano</div> <div>Assistant General Manager</div> <div>Second Technical Support Section</div> <div>International Marketing Group</div>								

DETAILS OF MODIFICATION



MODIFICATION BULLETIN NO. IXO-009ISSUED ON OCT. 20, 1993

Model	IXO					Date of Modification	
Modified Article	PCB - FDU					Execution Date	
Reason for Modification	<input type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly <input checked="" type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input type="checkbox"/> To improve reliability <input type="checkbox"/> Other					Effective after the old parts have become out of stock.	

Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
H504 6001M	H504 6001N	PCB - FDU	1 → 1	O/O		68	1-5
H504 6011L	H504 6011M	PCB - FDU : U2	1 → 1	O/O		68	1-5
1401 0991		Transistor - 2SD1368CC	(1 → O)				
	1401 1014	Transistor - 2SD1368CB,CC	(O → 1)				
	1402 0422	Diode - RK-14	(O → 1)				
1402 0478		Diode Array - 1SS226	(3 → O)				
	1402 1142	Diode Array - DAN217	(O → 3)				
1402 1170		Diode -2GWJ42	(1 → O)				

S.Hamano

 Assistant General Manager
 Second Technical Support Section
 International Marketing Group

MODIFICATION BULLETIN NO. IXO-009ISSUED ON OCT. 20, 1993

Old Parts No.	New Parts No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
1402 1171		Diode - 3GWJ42	(1 → O)				
	1402 1209	Diode - RK- 44	(O → 1)				
1407 0604		IC - C-MOS : TC4049BP	(1 → O)				
1407 2052		IC - LS-TTL : SN74LS74ANS	(1 → O)				
1407 2252		IC - LS-TTL : SN74LS257BNS	(3 → O)				
1407 3263		IC - C-MOS : TC7SO8F	(1 → O)				
	1407 3350	IC - LS-TTL : SN74LS74AM	(O → 1)				
	1407 4317	IC - C-MOS : SC7508F	(O → 1)				
	1407 4319	IC - LS-TTL : SN74LS257BM	(O → 3)				
	1408 0141	IC - C-MOS : MC14049uBCP	(O → 1)				
1604 2299		Capacitor - 35V, 2200μF, ±20%	(1 → O)				
1604 2645		Capacitor - 25V, 6800μF, ±20%	(1 → O)				
1604 2646		Capacitor - 25V, 4700μF, ±20%	(1 → O)				
	1604 4271	Capacitor - 25V, 6800μF, ±20%	(O → 1)				
	1604 4272	Capacitor - 25V, 4700μF, ±20%	(O → 1)				
	1604 4273	Capacitor - 35V, 2200μF, ±20%	(O → 1)				
1610 1221		Resistor - 1.91kΩ, ±0.50%, 1/10W	(1 → O)				
1610 1222		Resistor - 30.9kΩ, ±0.50%, 1/10W	(1 → O)				
1610 1223		Resistor - 1.2kΩ, ±0.50%, 1/10W	(3 → 1)				
	1610 1235	Resistor - 1.91kΩ, ±0.50%, 1/10W	(O → 1)				
	1610 1236	Resistor - 1.2KΩ, ±0.50%, 1/10W	(O → 3)				
	1610 1237	Resistor - 30.9KΩ, ±0.50%, 1/10W	(O → 1)				
	1630 3102	Resistor - 1KΩ, ±5.00%, 1/10W	(2 → 1)				
	1630 3821	Resistor - 820Ω, ±5%, 1/10W	(O → 1)				

MODIFICATION BULLETIN NO. IXO-010

ISSUED ON oct. 20, 1993

Model	IXO					Date of Modification	
Modified Article	PCB - IJC					Execution Date	
Reason for Modification	<input type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly <input checked="" type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input type="checkbox"/> To improve reliability <input type="checkbox"/> Other					Effective after the old parts have become out of stock.	

Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
H504 6002C	H504 6002D	PCB - IJC	1 → 1	O/O		69	1-5
1407 3156		IC - C-MOS:TC74HC133AF	(1 → O)				
	1407 4318	IC - C-MOS:MC74HC133F	(O → 1)				

S.Hamano

Assistant General Manager
Second Technical Support Section
International Marketing Group

MODIFICATION BULLETIN NO. IXO-011

ISSUED ON oct. 20, 1993

Model	IXO(except US version)					Date of Modification	
Modified Article	Insulating Sheet					Execution Date	
Reason for Modification	<input type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly <input checked="" type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input type="checkbox"/> To improve reliability <input type="checkbox"/> Other					Effective after the old parts have become out of stock.	

Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
H504 2121	H504 2128	Insulating Sheet	1 → 1	O/O		61	1-5

S.Hamano

Assistant General Manager
Second Technical Support Section
International Marketing Group

MODIFICATION BULLETIN NO. IXO-012

ISSUED ON Nov. 9th, 1993

Model	IXO (USA version)						Date of Modification	
Modified Article	PCB - FCEM						Execution Date	
Reason for Modification	<div> <input type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly </div> <div> <input type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input checked="" type="checkbox"/> To improve reliability </div> <div> <input type="checkbox"/> Other </div> <p>Refer to the RTB No. IXO-012 for a detailed explanation.</p>						From mass production	
Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog		
						Index No.	Page	
H504 6000	H504 6007	PCB - FCEM	1 → 1	X/O		67	1-5	
H504 7110	H504 7157	IC - ROM: IXO						
<div>S.Hamano</div> <div>Assistant General Manager</div> <div>Second Technical Support Section</div> <div>International Marketing Group</div>								

MODIFICATION BULLETIN NO.IXO-013ISSUED ON Nov. 9th, 1993

Model	IXO						Date of Modification	
Modified Article	Blank ROM - FCE						Execution Date	
Reason for Modification	<input type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input type="checkbox"/> To improve reliability <input checked="" type="checkbox"/> Other							
To supply a blank ROM for FCE as a service part, the following part number has been set up.								
Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog		
						Index No.	Page	
	H504 7156	IC - μPD27C2001GW - 15						
S.Hamano Assistant General Manager Second Technical Support Section International Marketing Group								

MODIFICATION BULLETIN NO. IXO-014

ISSUED ON Nov. 9th, 1993

Model	IXO					Date of Modification	
Modified Article	Operator's Manual					Execution Date	
Reason for Modification	<div> <input type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly </div> <div> <input type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input type="checkbox"/> To improve reliability </div> <div> <input type="checkbox"/> Other </div> <p>To meet BABT and N.Z. approval, the operator's manual has been changed.</p>					<p>U3 and Asia versions: From 1st production of October, 1993.</p> <p>The other versions: Effective after the old parts have become out of stock.</p>	
Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
U3 and Asia version							
H504 4041	H504 4048	Operator's Manual : English	1 → 1	X/O		*	1-3
The other versions							
H504 4041	H504 4048	Operator's Manual : English	1 → 1	O/O		*	1-3
<div>S.Hamano</div> <div>Assistant General Manager</div> <div>Second Technical Support Section</div> <div>International Marketing Group</div>							

MODIFICATION BULLETIN NO. IXO-015ISSUED ON Dec. 17, 1993

Model	IXO (except USA version)	Date of Modification
Modified Article	PCB - FCEM	Execution Date
Reason for Modification	<div> <input type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly </div> <div> <input type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input checked="" type="checkbox"/> To improve reliability </div> <div> <input type="checkbox"/> Other </div> <p>Refer to the RTB No.IXO-012 for a detailed explanation.</p>	Effective for the service parts.

Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
H504 6000	H504 6007	PCB - FCEM	1 → 1	X/O		67	1-5
H504 7110	H504 7157	IC - ROM : IXO	(1 → 1)				

S.Hamano
Assistant General Manager
2nd T.S.Sec. Int'l Marketing Group

MODIFICATION BULLETIN NO. IXO-016ISSUED ON Dec. 17, 1993

Model	IXO (USA version)						Date of Modification	
Modified Article	PCB - FCEM						Execution Date	
Reason for Modification	<input type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input checked="" type="checkbox"/> To improve reliability <input type="checkbox"/> Other						From 1st production of October, 1993.	
<p>1. The software has been changed:</p> <ul style="list-style-type: none"> - To change the default setting of the horizontal reduction ratio to 94% - To make the line type selection (DTMF/PD) available for users for Norway. - To introduce the Norwegian PTT requirement. <p>2. To ensure the supply of the DRAM, a 2nd vender has been set up.</p>								
Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog		
						Index No.	Page	
H504 6007	H504 6007A	PCB - FCEM	1 → 1	X/O		67	1-5	
H504 7107	H504 7107A	IC - RAM : HM514800JP-8	(1 → 1)					
H504 7157	H504 7157A	IC - ROM : IXO	(1 → 1)					
S.Hamano Assistant General Manager 2nd T.S.Sec. Int'l Marketing Group								

MODIFICATION BULLETIN NO.IXO-017ISSUED ON Dec. 17, 1993

Model	IXO (except USA version)	Date of Modification
Modified Article	PCB - FCEM	Execution Date
Reason for Modification	<div> <input type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly </div> <div> <input type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input checked="" type="checkbox"/> To improve reliability </div> <div> <input type="checkbox"/> Other </div> <p>1.The software has been changed: - To change the default setting of the horizontal reduction ratio to 94%. - To make the line type selection (DTMF/PD) available for users for Norway. - To introduce the Norwegian PTT requirement.</p> <p>2.To ensure the supply of the DRAM, a 2nd vender has been set up.</p> <p>3.The machine may disconnect the line even if it is a little noisy during reception.</p>	From 1st production of October, 1993.

Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
H504 6007	H504 6008	PCB - FCEM : E	1 → 1	X/O		67	1-5
H061 7102	H504 7154	IC - DSP : RF5C72	(1 → 1)				
H504 7107	H504 7107A	IC - RAM : HM514800JP-8	(1 → 1)				
H504 7157	H504 7157A	IC - ROM : IXO	(1 → 1)				

S.Hamano
Assistant General Manager
2nd T.S.Sec. Int'l Marketing Group

MODIFICATION BULLETIN NO.IXO-018ISSUED ON Dec. 17, 1993

Model	IXO (Universal 3 version)					Date of Modification	
Modified Article	PCB - NCU					Execution Date	
Reason for Modification	<input type="checkbox"/> Parts catalog correction <input checked="" type="checkbox"/> To meet standards (UK) <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input type="checkbox"/> To improve reliability <input type="checkbox"/> Other					From 1st production of October, 1993.	

Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
H504 6016	H504 6018	PCB - NCU	1 → 1	X/O		71	1-5
	1606 1762	Capacitor - 400V, 0.022μF, ± 10%	(1 → 2)				
1606 1970		Capacitor - 400V, 0.068μF, ± 10%	(1 → 0)				

S.Hamano
 Assistant General Manager
 2nd T.S.Sec. Int'l Marketing Group

MODIFICATION BULLETIN NO. IXO-019ISSUED ON Dec. 17, 1993

Model	IXO (USA version)					Date of Modification	
Modified Article	PCB - FCEM					Execution Date	
Reason for Modification	<div style="display: flex; justify-content: space-between;"> <div> <input type="checkbox"/> Parts catalog correction <input type="checkbox"/> Vender change </div> <div> <input type="checkbox"/> To meet standards () <input type="checkbox"/> Part standardization </div> <div> <input type="checkbox"/> To facilitate assembly <input checked="" type="checkbox"/> To improve reliability <input type="checkbox"/> Other </div> </div> <p>The machine cannot transmit by using the external handset and instead makes a copy because it cannot detect off-hook. To prevent this problem, a resistor has been removed. Also, the NCU has been modified as mentioned in MB No.IXO-021.</p>					From 1st production of October, 1993.	

Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
H504 6007A	H504 6007B	PCB - FCEM	1 → 1	X/O		67	1-5
	1630 4103	Resistor - 10kΩ, ± 5.00%, 1/16W	(4 → 3)				

S.Hamano
 Assistant General Manager
 2nd T.S.Sec. Int'l Marketing Group

MODIFICATION BULLETIN NO. IXO-020ISSUED ON Dec. 17, 1993

Model	IXO						Date of Modification	
Modified Article	PCBs						Execution Date	
Reason for Modification	<input type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly <input checked="" type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input type="checkbox"/> To improve reliability <input type="checkbox"/> Other						Effective after the old parts have become out of stock.	

Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
H504 6002D	H504 6002E	PCB - IJC	1 → 1	O/O		69	1-5
1604 2523		Capacitor - 6.3V, 47μF, ± 20%	(1 → 0)				
	1644 6470	Capacitor - 6.3V, 47μF, ± 20%	(0 → 1)				
H504 6004F	H504 6004G	PCB - SBU	1 → 1	O/O		70	1-5
1604 1673		Capacitor - 100μF, ± 20%, 16V	(2 → 0)				
	1642 1101	Capacitor - 100μF, ± 20%, 16V	(0 → 2)				
H504 6001P	H504 6001Q	PCB - FDU	1 → 1	O/O		68	1-5
1604 1728		Capacitor - 10V, 100μF, ± 20%	(1 → 0)				

S.Hamano
 Assistant General Manager
 2nd T.S.Sec. Int'l Marketing Group

MODIFICATION BULLETIN NO. IXO-020

ISSUED ON Dec. 17, 1993

[illegible]

MODIFICATION BULLETIN NO. IXO-021ISSUED ON Dec. 17, 1993

Model	IXO (USA and Taiwan versions)	Date of Modification
Modified Article	PCB - NCU	Execution Date
Reason for Modification	<div> <input type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly </div> <div> <input type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input checked="" type="checkbox"/> To improve reliability </div> <div> <input type="checkbox"/> Other </div> <p>To prevent the following problem, the diode has been changed to a schottky diode and the wire patterns of CN 3-2 and CN 3-5 have been cut.</p> <ol style="list-style-type: none"> 1. The machine cannot detect off- hook. 2. HANDSET may be displayed on the LCD even if the external telephone is not picked up. 	From 1st production of October, 1993.

Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange-ability	Remarks	Parts Catalog	
						Index No.	Page
H504 6012G	H504 6012H	PCB - NCU : US	1 → 1	X/O		71	1-5
1401 0826		Diode Array - ISS 187	(1 → 0)				
	1402 0982	Schottky Diode	(0 → 1)				

S.Hamano
Assistant General Manager
2nd T.S.Sec. Int'l Marketing Group

MODIFICATION BULLETIN NO. IXO-022ISSUED ON Jan. 14th, 1994

Model	IXO	Date of Modification
Modified Article	Paper Feed	Execution Date
Reason for Modification	<input type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input checked="" type="checkbox"/> To improve reliability <input type="checkbox"/> Other	From mass production.
To ensure positive mounting of the retaining ring, the ring has been changed.		

Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
H504 2122		Retaining Ring C - M4.6	1 → 0			44	1-5
	0727 0050E	Retaining Ring C - M5	0 → 1				

S.Hamano
 Assistant General Manager
 2nd T.S.Sec. Int'l Marketing Group

MODIFICATION BULLETIN NO. IXO-023ISSUED ON Jan. 14th, 1994

Model	IXO					Date of Modification	
Modified Article	PCB - FCE					Execution Date	
Reason for Modification	<input type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input checked="" type="checkbox"/> To improve reliability <input type="checkbox"/> Other					From 1st production of November, 1993.	
<p>To reflect the countermeasure for the problem that occurred in USA to the other versions, because the patterns of both NCUs are common, the following resistor has been removed.</p>							
Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
H504 6008	H504 6008A	PCB - FCE	1 → 1	X/O		67	1-5
	1630 4103	Resistor - 10KΩ, ± 5.00%, 1/16W	4 → 3				
<div style="text-align: right;"> <p>S.Hamano Assistant General Manager 2nd T.S.Sec. Int'l Marketing Group</p> </div>							

MODIFICATION BULLETIN NO. IXO - 024ISSUED ON April, 13th, 1994

Model	IXO	Date of Modification
Modified Article	Exterior	Execution Date
Reason for Modification	<div> <input type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input checked="" type="checkbox"/> To facilitate assembly </div> <div> <input type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input type="checkbox"/> To improve reliability </div> <div> <input type="checkbox"/> Other </div> <p>To facilitate assembly on the production line, the scanner spacers have been removed and the form of upper cover has been changed.</p>	Effective after the old parts have been out of stock.

Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
H504 3100	H504 3010	Upper Cover	1 → 1	O / O	(As a set with spacers)	7	1 - 3
H504 3140	H504 3012	Upper Cover: NRG	1 → 1	O / O	(As a set with spacers)	7	1 - 3
H504 3130	H504 3011	Upper Cover: INF/SVN	1 → 1	O / O	(As a set with spacers)	7	1 - 3
H504 3150	H504 3013	Upper Cover: TEL	1 → 1	O / O	(As a set with spacers)	7	1 - 3
H504 1105		Right Scanner Spacer	1 → 0			21	1 - 3
H504 1106		Left Scanner Spacer	1 → 0			22	1 - 3

S.Hamano
Assistant General Manager
2nd T.S.Sec. Int'l Marketing Group

MODIFICATION BULLETIN NO. IXO-025

ISSUED ON April, 13th, 1994

[illegible]

MODIFICATION BULLETIN NO. IXO-026ISSUED ON April, 13th, 1994

Model	IXO (Except USA version)					Date of Modification	
Modified Article	PCB - FCE					Execution Date	
Reason for Modification	<div style="display: flex; justify-content: space-between;"> <div> <input type="checkbox"/> Parts catalog correction <input type="checkbox"/> Vender change </div> <div> <input type="checkbox"/> To meet standards () <input type="checkbox"/> Part standardization </div> <div> <input type="checkbox"/> To facilitate assembly <input checked="" type="checkbox"/> To improve reliability <input type="checkbox"/> Other </div> </div> <p>"Check Display" may be blinking on the LED and "COMMUNICATION ERROR" may be displayed on the LCD in the follwoing condition in TAM mode.</p> <ol style="list-style-type: none"> 1. When the operator picks up the handset before the TAM takes the line. (The beeper starts to sound 40 seconds after picking up the handset.) 2. When the off time of the ringing signal cadence is more than 9 seconds. <p>To prevent this problem, the software has been changed.</p> <ol style="list-style-type: none"> 3. ROM (P/N: H504 7157A or B) is installed in the machine. 					H504-31: 4681132001~ H504-40: U2231100201~ H504-42: U2431100413~ H504-61: 6493110150~ The other versions: From 1st production of December, 1993	
Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
H504 6008A	H504 6008C	PCB - FCE	1 → 1	X / O		67	1 - 5
H504 7157A	H504 7157C	IC - ROM: IXO	(1 → 1)				
S.Hamano Assistant General Manager 2nd T.S.Sec. Int'l Marketing Group							

MODIFICATION BULLETIN NO. IXO - 027ISSUED ON April, 13th, 1994

Model	IXO(U1 version)						Date of Modification	
Modified Article	PCB - NCU						Execution Date	
Reason for Modification	<div style="display: flex; justify-content: space-between;"> <div> <input type="checkbox"/> Parts catalog correction <input type="checkbox"/> Vender change </div> <div> <input checked="" type="checkbox"/> To meet standards (Swiss) <input type="checkbox"/> Part standardization </div> <div> <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> To improve reliability <input type="checkbox"/> Other </div> </div> <p>To introduce the Swiss PTT requirement to the U1 versions, the following parts have been modified.</p>						From 1st production of December, 1993.	

Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
H504 6003G	H504 6019	PCB - NCU	1 → 1	X / O		71	1 - 5
	1606 2010	Capacitor - 0.033μF, 100V, ± 10%	(0 → 1)				
	1630 3120	Resistor - 12Ω, ± 5%, 1/10W	(0 → 1)				

S.Hamano
 Assistant General Manager
 2nd T.S.Sec. Int'l Marketing Group

MODIFICATION BULLETIN NO. IXO - 028ISSUED ON April, 13th, 1994

Model	IXO (U2 version)	Date of Modification
Modified Article	PCB - NCU	Execution Date
Reason for Modification	<div> <input type="checkbox"/> Parts catalog correction <input type="checkbox"/> Vender change <input checked="" type="checkbox"/> To meet standards (Norway) <input type="checkbox"/> Part standardization <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> To improve reliability <input type="checkbox"/> Other </div> <p>To introduce the Norwegian PTT requirement to the U2 versions, the following parts have been modified.</p>	From 1st production of January, 1994

Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
H504 6003G	H504 6003H	PCB - NCU	1 → 1	X / O		71	1 - 5
1610 1212		Resistor - 20Ω, ± 5%, 1/2W	(1 → 0)				
1633 1802		Resistor - 18kΩ, ± 1%, 1/10W	(1 → 0)				
1633 5602		Resistor - 56kΩ, ± 1%, 1/10W	(1 → 0)				
	1610 1200	Resistor - 33Ω, ± 5%	(0 → 1)				
	1633 1002	Resistor - 10kΩ, ± 1%, 1/10W	(0 → 1)				
	1633 2002	Resistor - 20kΩ, ± 1%, 1/10W	(0 → 1)				

S.Hamano
Assistant General Manager
2nd T.S.Sec. Int'l Marketing Group

MODIFICATION BULLETIN NO. IXO -029ISSUED ON April, 13th, 1994

Model	IXO					Date of Modification	
Modified Article	PCB - FDU					Execution Date	
Reason for Modification	<input type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input checked="" type="checkbox"/> To improve reliability <input type="checkbox"/> Other					H504-20: R7940100001~ H504-21: 6454010280~ H504-22: JT304012549~ H504-27: 044010001~ H504-40: U2240100001~ H504-42: U2440200018~ H504-60: 6464012925~ H504-62: 6474020111~ The other versions: From 1st production of February, 1994	
Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
H504 6001Q	H504 6001R	PCB - FDU	1 → 1	O / O		68	1 - 5
	16050435	Capacitor - 0.47μF	(0 → 1)				
	16061293	Capacitor - 0.22μF, -20 + 80%	(2 → 1)				
H504 6011P	H504 6011Q	PCB - FDU: U2	1 → 1	O / O		68	1 - 5
	16050435	Capacitor - 0.47μF	(0 → 1)				
	16061293	Capacitor - 0.22μF, -20 + 80%	(2 → 1)				
S.Hamano Assistant General Manager 2nd T.S.Sec. Int'l Marketing Group							

MODIFICATION BULLETIN NO. IXO-030

ISSUED ON May 24, 1994

Model		IXO				Date of Modification	
Modified Article		PCB-FCE				Execution Date	
Reason for Modification		<input type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input checked="" type="checkbox"/> To improve reliability <input type="checkbox"/> Other				H504-20: R7940200001~ H504-21: 6454020330~ H504-22: JT304023317~ H504-27: 044020041~ H504-40: U2240200014~ H504-41: U2340200001~ H504-42: U2440200001~ H504-50: A0340200001~ H504-52: A1140200001~ H504-60: 6464024216~ Other versions: From 1st production of March, 1994	
Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange-ability	Remarks	Parts Catalog	
						Index No.	Page
H5046007D	H5046007E	PCB-FCE	1 → 1	X / O		67	1-5
H5047157C	H5047157D	IC-ROM: IXO	(1 → 1)				
H5046008C	H5046008D	PCB-FCE	1 → 1	X / O		67	1-5
H5047157C	H5047157D	IC-ROM: IXO	(1 → 1)				
<div style="text-align: right;"> S.Hamano Assistant General Manager 2nd T.S.Sec. Int'l Marketing Group </div>							

MODIFICATION BULLETIN NO. IXO-31ISSUED ON May 24,1994

Model	IXO						Date of Modification	
Modified Article	Cassette						Execution Date	
Reason for Modification	<input type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input checked="" type="checkbox"/> To improve reliability <input type="checkbox"/> Other						From 1st production of March,1994	
<p>The machine may pick up the paper and print on the back whenever the paper is put on the cassette cover.</p> <p>To prevent this problem, a spacer has been attached to the cassette cover so that the paper does not reach the roller.</p>								
Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog		
						Index No.	Page	
H5044106	H5044067	Cassette Cover - A4	1 → 1	X / O		15	1-3	
H5044107	H5044068	Cassette Cover - Lt	1 → 1	X / O		15	1-3	
	H5044126	Spacer - Cassette Cover	(0 → 1)					
S.Hamano Assistant General Manager 2nd T.S.Sec. Int'l Marketing Group								

MODIFICATION BULLETIN NO. IXO-032ISSUED ON May 24, 1994

Model	IXO (USA version)						Date of Modification	
Modified Article	PCB-FCE						Execution Date	
Reason for Modification	<input type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> Vender change <input checked="" type="checkbox"/> Part standardization <input type="checkbox"/> To improve reliability <input type="checkbox"/> Other						Effective after the old parts have become out of stock.	
To standardize the FCE for the USA with the other versions, the following parts have been changed.								
Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog		
						Index No.	Page	
H5046007E	H5046008D	PCB-FCE	1 → 1	O / O		67	1-5	
H0617102	H5047154	IC-RF5C72: DSP	(1 → 1)					
S.Hamano Assistant General Manager 2nd T.S.Sec. Int'l Marketing Group								

MODIFICATION BULLETIN NO. IXO-033



ISSUED ON May 24, 1994

Model		IXO				Date of Modification	
Modified Article		PCB-FCE				Execution Date	
Reason for Modification		<div><div><input type="checkbox"/> Parts catalog correction</div><div><input type="checkbox"/> Vender change</div></div> <div><div><input type="checkbox"/> To meet standards (</div><div><input type="checkbox"/> Part standardization</div><div>)</div></div> <div><div><input type="checkbox"/> To facilitate assembly</div><div><input checked="" type="checkbox"/> To improve reliability</div><div><input type="checkbox"/> Other</div></div> <div>Please refer to the RTB No. IXO-026 for details.</div>				H504-20: R7940300541~ H504-21: 6454030380~ H504-30: 4680340001~ H504-31: 4680342001~ H504-40: U2240300701~ H504-42: U2440300301~ H504-60: 6464034556~ H504-62: 6474030126~ Other versions: From 1st production of April,1994	
Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
H5046008D	H5046009	PCB-FCE	1 → 1	X / O		67	1-5
H5047157D	H5047159	IC-ROM: IXO	(1 → 1)	X / O			
<div>S.Hamano Assistant General Manager 2nd T.S.Sec. Int'l Marketing Group</div>							

MODIFICATION BULLETIN NO. IXO-034ISSUED ON May 24, 1994

Model	IXO					Date of Modification	
Modified Article	TIJ Unit					Execution Date	
Reason for Modification	<input type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input type="checkbox"/> To improve reliability <input checked="" type="checkbox"/> Other						
<p>To supply the following parts included in the TIJ unit as service parts, the following part numbers have been set up.</p>							
Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
	H5042510	Paper Sensor - TIJ	(0 → 1)			1	
	H5042511	Carriage Drive Belt - TIJ	(0 → 1)			2	
	H5042512	Carriage Motor - TIJ	(0 → 1)			3	
	H5042513	Belt Tension Spring - TIJ	(0 → 1)			4	
	H5042514	Purge Unit - TIJ	(0 → 1)			5	
	H5042515	Carriage Shaft Stopper - TIJ	(0 → 1)			6	
	H5042516	Slider - TIJ	(0 → 1)			7	
	H5042517	Ribbon Cable Holder - TIJ	(0 → 1)			8	
	H5042518	Eject Roller - TIJ	(0 → 2)			9	
<p style="text-align: right;">S.Hamano Assistant General Manager 2nd T.S.Sec. Int'l Marketing Group</p>							

DETAILS OF MODIFICATION



MODIFICATION BULLETIN NO.IXO-035ISSUED ON May 24, 1994

Model	IXO (for Omnifax)					Date of Modification	
Modified Article	Op-port					Execution Date	
Reason for Modification	<div style="display: flex; justify-content: space-between;"> <div> <input type="checkbox"/> Parts catalog correction <input type="checkbox"/> Vender change </div> <div> <input type="checkbox"/> To meet standards () <input type="checkbox"/> Part standardization </div> <div> <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> To improve reliability <input checked="" type="checkbox"/> Other </div> </div> <p>The characters on the operation panel have been changed in accordance with Omnifax's request.</p>					Effective after the old parts have become out of stock.	

Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
H5043204C	H5043204D	Op-port Ass'y: TEL	1 → 1	O / O		11	1-3

S.Hamano
Assistant General Manager
2nd T.S.Sec. Int'l Marketing Group

MODIFICATION BULLETIN NO. IXO-035ISSUED ON May 24, 1994

Model	IXO (for Omnifax)					Date of Modification	
Modified Article	Op-port					Execution Date	
Reason for Modification	<div style="display: flex; justify-content: space-between;"> <div> <input type="checkbox"/> Parts catalog correction <input type="checkbox"/> Vender change </div> <div> <input type="checkbox"/> To meet standards () <input type="checkbox"/> Part standardization </div> <div> <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> To improve reliability <input type="checkbox"/> Other </div> </div> <p>The chatacters on the operation panel have been changed in accordance with Omnifax's request.</p>					Effective after the old parts have become out of stock.	

Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
H5043204C	H5043204D	Op-port Ass'y: TEL	1 → 1	O / O		11	1-3

S. Hamano
 Assistant General Manager
 2nd T.S.Sec. Int'l Marketing Group

MODIFICATION BULLETIN NO. IXO-036

ISSUED ON June 30, 1994

Model	IXO (for Omnifax)					Date of Modification	
Modified Article	Operator's Manual					Execution Date	
Reason for Modification	<input type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input type="checkbox"/> To improve reliability <input checked="" type="checkbox"/> Other					Effective after the old parts have become out of stock.	
The cover for the operator's manual has been changed in accordance with Omnifax's request.							

Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
H5044053	H5044053A	Cover - Operator's Manual: TEL	1 → 1	O / O		*	1-3

S. Hamano

Assistant General Manager

2nd T.S.Sec. Int'l Marketing Group

MODIFICATION BULLETIN NO. IXO-037ISSUED ON June 30, 1994

Model	IXO					Date of Modification	
Modified Article	PCB - FCE					Execution Date	
Reason for Modification	<div style="display: flex; justify-content: space-between;"> <div> <input type="checkbox"/> Parts catalog correction <input type="checkbox"/> Vender change </div> <div> <input type="checkbox"/> To meet standards () <input type="checkbox"/> Part standardization </div> <div> <input type="checkbox"/> To facilitate assembly <input checked="" type="checkbox"/> To improve reliability <input type="checkbox"/> Other </div> </div> <p>Please refer to the RTB No.IXO-026 for a detailed explanation. However, since H5047160 included a software bug concerning this modification, the software has been remodified and a suffix has been changed. Also, an additional notice to users has been added.</p>					H504-27: 044050001 ~ H504-40: U2240500801 ~ Other versions: From 1st production of June,1994	
Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange-ability	Remarks	Parts Catalog	
						Index No.	Page
H5046009	H5046009B	PCB-FCE	1 → 1	X / O		67	1-5
H5047159	H5047160A	IC - μPD27C5001GW - 15: PROM	(1 → 1)	X / O			
	H5048010	Sheet - Head Cleaning	(0 → 1)				
S. Hamano Assistant General Manager 2nd T.S.Sec. Int'l Marketing Group							

MODIFICATION BULLETIN NO. IXO-038ISSUED ON Sep. 14, 1994

Model	IXO French Version only (FAX800, I-3520, and NRG9645)	Date of Modification
Modified Article	PCB - FCEM	Execution Date
Reason for Modification	<input type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input checked="" type="checkbox"/> To improve reliability <input type="checkbox"/> Other See the attached page.	The old part has been become out of stock.

Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
H5046017A	H0546017C	PCB - FCEM FRA	1 → 1	O / O	"B" is not existing	67	1-5
H5047158	H5047161A	Programmed ROM - FRA	(1 → 1)	O / O			

S.Hamano
Assistant General Manager
2nd T.S.Sec. Int'l Marketing Group

DETAILS OF MODIFICATION

- 1) The black lines of the box around the reports have been changed to the lines of the asterisks (*).

————— → *****

- 2) On the current software, the machine cannot recognize inkend until the inkend mark is printed at the bottom of the page.

If the ink does not come out from the new Ink Cartridge and inkend mark is not printed on the first page after the head cleaning was done for the new cartridge, the machine displays NO INK and keeps the image data of the page in the page memory.

If the ink starts coming out from the cartridge in the middle of the page before printing the inkend mark and if the inkend mark is printed completely, the machine detects the ink at the inkend mark and clears the image data of the page in the memory because the machine considers all of the image data in the page is printed.

In this case, the image at the top of the page is not printed and it is lost from the memory.

On the new software, after the Ink Cartridge is changed and the Head Cleaning is done, the machine writes the inkend mark first and checks it before printing starts.

If no ink is detected, CREAMING ERROR is displayed and the machine does not start printing.

The image data of the page is not lost from the memory.

MODIFICATION BULLETIN NO. IXO-039ISSUED ON Sep. 14, 1994

Model	FAX800 Taiwan Version	Date of Modification
Modified Article	Operation Manual	Execution Date
Reason for Modification	<input type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input type="checkbox"/> To improve reliability <input type="checkbox"/> Other Chinese version O/M was made.	From July production in 1994.

Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
H5044048	Z H5044049	Operation Manual - English	1 → 0				
H5044082		Cover - O/M	1 → 0				
		Operation Manual - Chinese	0 → 1				

S.Hamano
Assistant General Manager
2nd T.S.Sec. Int'l Marketing Group

MODIFICATION BULLETIN NO. IXO-040ISSUED ON Sep. 14, 1994

Model	IXO						Date of Modification	
Modified Article	FDU						Execution Date	
Reason for Modification	<input type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input checked="" type="checkbox"/> To improve reliability <input type="checkbox"/> Other						From September production in 1994.	
For No Print Problem. See RTB No.IXO-028.								

Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
(FAX800 Universal 2 Europe, NRG9645 Universal 2 Europe)							
H5046011	H5046021	PCB - FDU - U2	1 → 1	X / O		68	1-5
	16430100	Capacitor - 10μF 10V	0 → 1				
(Other models)							
H5046001	H5046020		1 → 1	X / O		68	1-5
	16430100	Capacitor - 10μF 10V	0 → 1				

S.Hamano
 Assistant General Manager
 2nd T.S.Sec. Int'l Marketing Group

MODIFICATION BULLETIN NO. IXO-041ISSUED ON Apr. 30, 1995

Model	IXO					Date of Modification	
Modified Article	Lower Unit					Execution Date	
Reason for Modification	<input type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly <input checked="" type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input type="checkbox"/> To improve reliability <input type="checkbox"/> Other					After the old parts have become out of stock.	

Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog	
						Index No.	Page
AW020055	AW020086	Photointerruptor	1 → 1	O / O		32	1-4

M. Iwasa
 Manager
 2nd T.S.Sec. Int'l Marketing Group

MODIFICATION BULLETIN NO. IXO-042ISSUED ON Aug. 31, 1995

Model	IXO						Date of Modification	
Modified Article	TIJ Unit						Execution Date	
Reason for Modification	<input type="checkbox"/> Parts catalog correction <input type="checkbox"/> To meet standards () <input type="checkbox"/> To facilitate assembly <input type="checkbox"/> Vender change <input type="checkbox"/> Part standardization <input type="checkbox"/> To improve reliability <input checked="" type="checkbox"/> Other						Registered at the end of August in 1995.	
The following components of the TIJ Unit are registered in the spare parts computer system. Refer to RTB no. IXO-030 which will be issued in September.								
Old Part No.	New Part No.	Description	Q'ty Used Old → New	Interchange- ability	Remarks	Parts Catalog		
						Index No.	Page	
	H5042519	Idle Gear - TIJ	0 → 1					
	H5042521	Platen Plate - TIJ	0 → 1					
	H5042522	Feed Roller - TIJ	0 → 1					
	H5042523	Release Lever - TIJ	0 → 1					
	H5042524	Base - TIJ	0 → 1					
M. Iwasa Manager 2nd T.S.Sec. Int'l Marketing Group								