

Model: Adonis-C3		Date: 27-Jun-03	No.: RB082016
Subject: Service Manual Correction (Fax Option)		Prepared by: K. Takagi	
From: 1st Tech. Support Sec. Service Support Dept.			
Classification:	<input type="checkbox"/> Troubleshooting <input type="checkbox"/> Mechanical <input type="checkbox"/> Paper path <input type="checkbox"/> Other (       )	<input type="checkbox"/> Part information <input type="checkbox"/> Electrical <input type="checkbox"/> Transmit/receive	<input type="checkbox"/> Action required <input checked="" type="checkbox"/> Service manual revision <input type="checkbox"/> Retrofit information

Please make the following corrections to your Model A-C3 Fax Option Service Manuals (machine code: B547).

Revised items are underlined and items to be deleted are in *italics*.

## 1. Section 1 (Installation)

### 1.4.1 JBIG A892 (Page 1-14)

**REVISE** the following (underlined portions):

#### 1.4.1 FAX FUNCTION UPGRADE BOARD

## 2. Section 3 (Service Tables)

### 3.1 Service Program Mode – SP1-XXX (Bit Switches) (Page 3-2)

**DELETE** SP1-102 and SP1-110 from the table below.

**Note:** SP1-102 has been renamed as “SP3-201” – see next page.

### 3.2.2 FAX Switches Page (3-18 ~ 22)

REVISE titles in the SP tables from “1-102-XXX” to “3-201-XXX”, as this SP has been renamed.

Also, REVISE the underlined portions below, as there have been some revisions applied to the content.

<b>FAX Switch 08 – <u>Not used (do not change the settings)</u></b>	<b><u>SP No. 3-201-009</u></b>
---	--------------------------------

<b>FAX Switch 09 – <u>Not used (do not change the settings)</u></b>	<b><u>SP No. 3-201-010</u></b>
---	--------------------------------

FAX Switch 0A		SP No. 3-201-011
No	FUNCTION	COMMENTS
0-3	<u>Not used</u>	<u>Do not change the settings.</u>
4 to 7	MTF filter level (Colored background special original mode) The value can be between 0 (Off) and F. For a weaker threshold, input a lower value. <u>Default setting: 7</u> This setting is independent from the threshold specified by the copier SP modes.	

FAX Switch 0C		SP No. 3-201-013
No	FUNCTION	COMMENTS
0	Action when an original jam has occurred while scanning the original into memory for memory tx <b>0:</b> Continues scanning after recovery <b>1:</b> Stops scanning and erases all scanned pages for that job	This bit is only effective when parallel memory tx is disabled (user parameter 07 - bit 2). If parallel memory tx is enabled, the machine always erases the scanned pages when an original jam occurs. The machine then asks the user to retry from the first page, even if the parallel memory tx is not actually used. <b>0:</b> The machine displays a message asking the user to put the jammed page back into the original stack, and continues scanning. The message is displayed for the time period specified by scanner switch 0E, bit 2. <b>1:</b> The machine erases all the scanned pages and asks the user to retry from the first page.
1 to 2	Setting when an original size cannot be recognized <b>Bit 2 1 Setting</b> 0 0 No original 0 1 A5 <input type="checkbox"/> 1 0 A5 <input type="checkbox"/> 1 1 No original	
<u>3-7</u>	<u>Not used</u>	<u>Do not change the settings.</u>

Model: Adonis-C3

Date: 27-Jun-03

No.: RB082016

<b>FAX Switch 0E</b>		<b>SP No. 3-201-015</b>
<b>No</b>	<b>FUNCTION</b>	<b>COMMENTS</b>
<b>0</b>	<u>Not used</u>	<u>Do not change the settings.</u>
<b>1</b>	Scan resolution unit <b>0:</b> mm <b>1:</b> inches	This bit determines which resolution unit will be used for scanning a fax message. Default setting: mm
<b>2-7</b>	<u>Not used</u>	<u>Do not change the settings.</u>

**FAX Switch 10 ~ 1F** - Not used (do not change the settings)

### 3. SPECIFICATIONS

#### 2 Capabilities of Programmable Items (Page Spec-2)

**REVISE** the following (underlined portions).

**Note:** "With HDD" column has been deleted.

<b>Item</b>	<b>Standard</b>	<b>With Fax Function Upgrade Unit</b>
Quick Dial	<u>500</u>	1200 ( <u>2000*</u> )
Groups	64	64
Destination per Group	500	500
Boxes (Information/Personal/Transfer)	150	400
Destinations dialed from the ten-key pad overall	100	1000
Programs	100	200
Auto Document	6	18
Communication records for Journal stored in the memory	200	1000
Specific Senders	30	50

\* With the Printer/Scanner Option